
	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF377B		Edition:	1.1
		Page 1 of 2	

Instruction of RF377B

1. Electrical configuration diagram:



	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF377B		Edition:	1.1
	Pag		2 of 2

2. Item

2.1 Head up

Press and hold HEAD UP button of remote, head actuator moves out, stop when released:

2.2 Head down

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

2.3 Foot up

Pressa and hold FOOT UP button of remote, foot actuator moves out, stop when released;

2.4 Foot down

Press and hold FOOT DOWN button of remote, foot actuator moves in , stop when released; When moving to flat position, lumbar actuator and tilt actuator move first, after 500ms, head andfoot actuators start moving;

2.5 Flat

Click FLAT button, the bed goes flat, stop when click any button during the process of going flat:

2.6Zero-G

Release after press, 2 lifts move to Zero-G position

	Issue Department: Bedding Division	Date:	2017-8-15
	System Instruction	Author:	
Instruction of RF377B		Edition:	1.1
		Page 2 of 2	

FCC:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

Le matériel est conforme aux limites de dose d'exposition aux rayonnements énoncés pour fac un autre environnement.ce dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.



FCC ID: 2AK23RF377AB IC: 22406-RF377AB

