

## Wooden Bluetooth Speaker w/Wireless Charging Pad

#### **Instruction Manual**





# **Speaker part:.**

# **Specifications**

- 1. Working voltage: 3.4-4.2V
- 2. Charging power supply: DC5V/800mA (Battery Indicator LED is red when charging. Turns off when fully charged).
- 3. Low power warning: When voltage is lower than 3.4V, two beeps will sound.

# **Operation**

Turn on speaker using the switch button located on the middle.

The LED indicator will flash in blue.

the device is in pairing mode.

- A. Bluetooth mode pairing with \*\*\*\*:
- 1. The blue flashing LED indicates pairing mode. Once a connection with media device has been established, the flash will slow, remaining blue.
- 2. "-" Button: Click to skip to decrease volume. Press and hold to previous track
- 3. "D" Button: Click to pause/play music, answer incoming calls.
- 4. "+" Button: Click to skip to increase volume. Press and hold to next track.
- B. 3.5mm line-in mode:
- 1. Insert one end of 3.5mm cable (included) to the line-in port and connect the other end to the device's line-in port. (LED will illuminate blue. Line-in function does not support answering of incoming calls).
- 2. "D" "Button: Click to pause/play music.
- 3. "-"/"+" Button: Click to decrease/increase volume.

### **Charging the speaker:**

Using a regulated USB adapter .Connect a USB cable to a USB adapter. Using the

Micro-USB connector, connect the other end of the USB cable to the charging port on the speaker. Plug the USB adapter into the outlet to begin charging.

The LED will light up in red while in charging, turns off when fully charged.

# Wireless Charger part.

Specifications:

Input: 5V/Max.2500mA Output: 5V/800mA Charging Efficiency: ≥70% Interface: Micro USB port

### Easy To Use

- 1. Connect the Micro-USB tip to the input port
- a. Connect the provided Micro-USB cable to the USB plug adapter.
- b.Connect the Micro-USB tip to the input port on the product.
- 2. Charging Mobile Devices:
- a. Place the enabled device on the surface of the top wireless charging pad. The device should display charging indicator.
- b. When completely charged, remove the device from the charging pad.

## **LED Indications:**

While device is charging LED will light up in red. Once the device is fully charged ,the LED will light up in green.

#### **Compatible Models:**

- Galaxy S6 / S6 edge / S6 edge+ / Note 5/ S7 / S7 Edge / S8 / S8 Plus
- Nokia Lumia 950 XL / 950 / 920 / 928 / 930
- Google Nexus 6, Google Nexus 5, Google Nexus 4
- HTC 8X (Verzion Wireless), HTC Droid DNA, HTC Rzound, HTC Droid Incredible 4G LTE;
- LG D1L, LG Optimus LTE2;
- Sharp AQUOS Slider SH-02D, Q-Pot SH-04D; AQUOS SH-07D, AQUOS SH-13C;
- iPhone 8,iphone X10
- other Qi devices

# FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

# For Wireless Charger part

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

#### For Bluetooth

The device has been evaluated to meet general RF exposure requirment. The device can be used in portable exposure condition without restriction.