## **Bb TALKIN'**

## BUSPEAKER

## USERS GUIDE

BUSPEAKER MODEL: A01SPK

Thank you for choosing BbSPEAKER This instruction manual will help you operate this system. First, read this manual carefully and familiarize yourself with functionalities before use.

www.bbtalkin.com

## Specs

Intercall talk time ———	6-8 hr
Charge time ————	3 hr
Weight ———	162 g
Range ———	1 mile
Water-proof	IPX 5

## ■ Charging

- \*AC adaptor 500mA-1A 5V
- \*Please make sure the device is completely dried before charaina
- \*Charging cable: Micro USB

Battery status:

Blue=75%-100%. Purple=50%-75% RED=battery low

(at start indicate)



Battery Charge: Red=Charaina Blue=Full charged

## UMITED WARRANTY

This limited warranty covers defects in materials and workmanship in this product for twelve month (12) months for main

This limited warranty covers defects in materials and workmanship in this product for twelve month (12) months for main device only.

The warranty obligations of BbTALKIN for this product are limited to the terms set forth below:
This limited warranty does not cover any damage, rusty USB part, deterioration or malfunction resulting from any alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, exposure to excess moisture, fire, improper packing and shipping, lightning, power surges, or other acts of nature. This limited warranty does not cover any damage, rust may be a subject of the control o


BBTALKIN to repair the product. If it is decided that this product should be returned directly to BbTALKIN, this product should be properly packed, preferably in the original carton, for shipping. Cartons not bearing a return authorization number will be refused. Limitation on Liability.

THE MAXIMUM LIABILITY OF BBTALKIN UNDER THIS LIMITED WARRANTY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY LAW, BBTALKIN IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY. Some countries, districts or states do not allow the exclusion or limitation of relief, special, incidental, consequential or indirect damages, or the limitation of liability to specified amounts, so the above limitations or




## WARNING

- \*DO NOT modify or disassemble the device.
- \*The area you cannot use (in the airplane, near the person with medical devices or equipment such as pacemaker etc..)
- \*DO NOT expose this device to extreme temperature or humidity place.
- \*When BbSPEAKER gets damaged, stop using immediately.
- \*DO NOT put the BbSPEAKER near the microphone, it may cause speaker howling.



## DISTANCE



\* must be line of sight



BbSPEAKER x 1 BUSPEAKER BAG x 1 MICRO USB CABLE x 1 STAND MOUNT x 1 EXTERNAL WIRE MICROPHONE x 1

## **USERS GUIDE**

V. 008.2

Intercall with BBT STANDARD device

1.You can pair with the other 2 BBT devices.

# How to pair with BBT Standard device

(Press & hold 2 sec.) A1. Turn on the power



(Press & hold 2 sec.) A2. Turn on the power

2.If you want to hang up/pick up the intercall, just press Channel

button (CH1 or CH2) once.

3.Over the communication distance range, the intercall will be

disconnected, then you need to manually reconnect by

pressing Channel Button once.

Ξ \$

STANDARD



B1. Press and hold CH1 button until red light flashes.



B2. Press and hold Intercall button



Made CH2

until red light flashes



on BbSPEAKER.

C. Press one time CH1 button

BLUE slow flashing light on both units indicates that they are paired and ready to use. Note: After you have paired the units, it will memorize the pairing and all you need to do is turn them on and press the Channel button on BbSPEAKER to connect.

communication, just follow above stepB & C again, and make sure 'If you want to add one more BBT device to become 3 way CH2 is not paired yet.


## How to pair with your phone

- 1.When power is off, press and hold power button for 5sec. until you see the red & blue light come on.
- 2.Open your smartphone Bluetooth and select bsptt-xxxx.

Note: After you have paired the units, it will memorize the pairing and will automatically link when next time you turn on BbSPEAKER. (Make sure the phone Bluetooth is on)

HOLD 2sec C POWER ON/OFF







1.Master device can pair with the other 2 BbSPEAKERs. (3may open communication talk)

Intercall with BBT MASTER device

- \* You can talk to CH1 and CH2 at the same time
- 2.When you want to hang up intercall, press Master device's Channel Button **Luice**; Call back the intercall, just press Channel Button once.

!! Warning !!

The Intercalling must be from Master device to BbSPEAKER, NOT from BbSPEAKER to Master device.







## Download app ZELLO

**App Store** 



Download free walkie talkie app ZELLO

- \*After download, set up account \*Set up PTT wireless button
- 1. Open menu and go to Option
- 3. Wireless zello button 2. Push to talk button
- 4. Select bsptt-XXXXXX
- 5.Now BbSPEAKER becomes a Push-To- Talk.



## Mic mute X

PUSH TO THLK BUTTON

SMART WALKIE TALKIE

Press and hold (+) & ( - ) 2sec. until blue light flashes. \*Slow flashing turns to fast flashing.

Press and hold (+)  $\Breve{Q}$  ( - ) 2sec. again to cancel mute function.

5V Charge / MIC INPUT/ SPERKER OUTPUT

### **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.