

START



NAVIGATION BAR:

Users can touch each nay, bar button to go directly to switch port selected.

FX: If user touches "SWITCH 4"

control

below)

button, then it goes to "SWITCH 4"

For each switch port that are actively


ON, that specific nay, button is

highlighted in yellow. (See image


However, if all switch port(s) are

not highlighted like below:

OFF, then the text on nav. button is



GREEN: Powers up all connected switches. All Connected switches are RED: Powers OFF all connected switches. All connected switches are Power button is the master power to all connected devices. STATUS BUTTON: **(** ? This button directs users to Bluetooth port connection status screen. **DEMO BUTTON:** This button directs users to How-To-Use instruction screen.



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.