







Instruction Manual

MODEL: ROCK05BT

- Output: RMS 6W(3W+3W)
- Loud speaker: 1.77 in magnetic resistant 4 Ohms
- Power Supply: 5V/1000mA, AC power adapter, USB power rotate connect line

Use Explanation

- Battery can play music and charge at the same time
- Line In/5v: micro USB power supply, audio input
- OFF/ON: On-Off setting
- Micro SD: Slot for Micro SD card
- Charging: Use USB port for charging
- LED indicator: When turned on, light is blue. When charging and turned off, light is red. When charging and turned on, light is pink. When charging is complete, red light turns off.

Special Instructions

- Music on Micro SD card must be in MP3 form
- MENU: Toggle between Line In, Micro SD, and Bluetooth
- ► ||/■: Play/Pause/Stop song in progress
- VOL: Toggle between volume and song selection
- ► V-: Previous Song/Rewind/Volume Down
- V+/►: Next Song/Fast Forward/Volume Up
- Micro SD card will only insert one way. Must have connectors

Qualities of RockDoc® Boom Bluetooth

- This digital speaker can be deemed as a perfect combination of classic and modern performance and is praised as a masterwork of audio speakers
- The unique design of the mini aluminum film reduces vibration and enhances tone performance
- Metallic shell is fashionable, out of the ordinary and comes in a variety of colors
- Mini audio speaker with new technology provides portable mobile music for your MP3, MP4, phone, GPS, notebook computer, and Micro SD/TF; any media player with a 3.5mm audio jack
- Lithium Ion rechargeable battery with micro USB connector for charging purposes
- Listen to music from your music library, laptop, phone . . .
 anywhere your music is stored electronically.
- With the Bluetooth function enabled, listen to all your music wirelessly!

Speaker's Functional Parameters

- Dimensions: 75*50*53mm
- Includes: Audio cable, micro USB cable, and instructions
- Frequency response: 150-18000HZ(±3dB)

- face up. Clicks into place when fully inserted.
- Default mode is Line In. Insert loaded Micro SD card and it will automatically begin to play music.
- To change volume first click and release the VOL button.
 Next press ◄ (V- for volume down or V+/ → for volume up. In order to change back to song selection, click and release the VOL button again.
- To change the song simply click and release the ₩/V- for previous song or V+/ → for next song

How to pair your Bluetooth device with the RockDoc®

- Turn your RockDoc® Bluetooth to the on position and remove MicroSD card
- Press the MODE button twice and the chime will be heard
- Turn Bluetooth to the ON position on your device
- Look for "RockDoc" in the Bluetooth enabled devices menu. (You may have to refresh your list)
- Select "RockDoc" to pair your device and the speaker.
 You may have to enter the code "0000"
- Now just play your music through your device as you normally would and your music will play through your RockDoc®.

Trademark: RockDoc

Name: Speaker

Model Number: ROCK05BT

FCC ID: SZT-ROCK05BT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.