

Congratulations on your purchase of a high-quality Insignia product. Your 2.1 Bluetooth Desktop Speaker System is designed for reliable and trouble-free performance.

Package contents

- Subwoofer with an attached 5-foot (1.5-meter) power cord
- Right satellite speaker with an attached 5-foot (1.5-meter) cable
- Left satellite speaker with an attached 5-foot (1.5-meter) cable
- 3.5mm 5-foot (1.5-meter) stereo audio cable
- Quick Setup Guide


FIND YOUR USER GUIDE ONLINE!


We are going green so a copy of your *User Guide* is not provided in the box but is available online. Go to www.insigniaproducts.com, then click **Support & Service**. Enter your model number in the box under **Manual, Firmware, Drivers** & **Product Information**, then click .




Before using your new product, please read these instructions to prevent any damage.

Features






Please Note: Using DIN and RCA to describe the cables are **no longer standard** in documentation.



Setting up and turning on



Place the speaker system on a flat stable surface at least 5 feet (1.5 meters) from any video source such as a TV or computer monitor.

- 1. Plug the cable attached to the right speaker into the R jack on the subwoofer.
- 2. Plug the cable attached to the left speaker into the L jack on the subwoofer.
- **3.** Plug the power cord attached to the subwoofer into a power outlet.
- **4.** Press the **Power/pairing** button for about half a second. Your speaker system turns on.
- **5.**Follow one of the connection methods (Bluetooth or Wired) to connect the speaker system to a source.

Connecting with a Bluetooth device

Pairing with a Bluetooth device

- 1. Make sure that your speaker system is turned on.
- 2. If the blue LED is not blinking rapidly, press and hold the **Power/pairing** button for three seconds.
- **3.** Make sure that your Bluetooth device is within 33 feet. (10 m) of your speaker system.
- **4.** On your source device, turn on your Bluetooth device, turn on the Bluetooth feature, then set your device to pairing mode. (For instructions, see the documentation that came with your Bluetooth device.)
- On your Bluetooth device, select **Insignia NS-PSB4521**. Your speaker system pairs with the Bluetooth device and the blue LED lights solid.

Note: If you are pairing with a computer, make sure that your Bluetooth speaker is selected as the computer's default playback device. See the computer's documentation for instructions. Make sure that your Bluetooth device supports the Bluetooth 3.0 + EDR A2DP protocol and that your device is not paired with another device. To determine what Bluetooth protocol your device supports, see the documentation that came with your device.

Reconnecting to a paired device

- 1. If your speaker system is turned off, turn it on.
- 2. Make sure that your Bluetooth device is turned on, the Bluetooth feature on the device is turned on, and the device is within range of your speaker system with no obstructions between your speaker system and the device.


Note: If your speaker system and your Bluetooth device do not automatically re-pair, select **Insignia NS-PSB4521** on your Bluetooth device.

Disconnecting a paired device

- Move the device out of range of your speaker system. OR
- Turn off the Bluetooth function on the Bluetooth device. OR
- Unpair your speaker system in the Bluetooth device list.

OR

• Turn off your speaker system or the Bluetooth device.



Connecting to a wired device

- **1.** Make sure that the source device is plugged in and turned on.
- **2.** Connect one end of the included 3.5mm stereo audio cable to the **AUX** jack on the back of the right speaker, then connect the other end of the cable to the audio out or headphone jack on the audio device.

Playing from a Wired device

- Use the controls on your audio device to control playback.
- When an audio device is connected to the AUX jack, your speaker system switches to AUX IN mode.
- Your speaker system switches back to Bluetooth mode when the audio device stops playing or is disconnected for 15 seconds.

Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with a dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or groundingtype plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Warnings:

- To reduce the risk of fire or electric shock, do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on the apparatus.
- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Should you notice an abnormality in the system, disconnect the main plug from the AC outlet immediately.
- The system is not disconnected from the mains as long as it is connected to the AC outlet, even if the system itself has been turned off.

FCC and IC information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure

- · Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme à l'exposition aux rayonnements IC limites établies pour un environnement non contrôlé.

Contact Insignia:

For customer service please call: US & Canada 1-877-467-4289 www.insigniaproducts.com

Distributed by Best Buy Purchasing, LLC 7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645

© 2013 BBY Solutions, Inc.

All rights reserved. INSIGNIA is a trademark of BBY Solutions, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.