Operation Guide

2.4GHz Ultra-small Wireless Camera Series Model: ZT-809T

The graphics included are subject to minor change without notice.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



Waning

This product is for the sole purpose of security and applicable for monitoring in residential houses, shops and companies. The user shall observe local rules, regulations and laws, and shall be solely liable in this regard. This company shall not be liable for any illegalities therein.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC Statement:

This device complies with Part 15 o the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SPECIFICATIONS


Imaging Sensor	CMOS
CMOS Total Pixels	628 x 582(PAL);510 x 492(NTSC)
View Angle	62°
▼ Transmission Frequency	ISM 2,400MHz~2,483MHz
Transmission Power	10mW/CE; 0.5mW/FCC
Modulation Type	FM
Power Supply	+8V _{pc}
Consumption Current	80mA
Unobstructed Effective Range	100m

CAMERA CHANNEL

The channel number of the camera was marked on the unit. The label means CH1 is available; (2) means CH2 is available; (3) means CH3 is available and (4) means CH4 is available.


Press the receiver's channel button to select the channel same as the camera's, and the pictures are displayed on the screen.

DIAGRAM



INSTALLATION

1. Locate the camera to a specific position and then adjust it to a suitable angle.



2. Connect the adapter to the camera.

