### **Safety Information**

### Symbols



Keep Dry



Fragile



Protected against dripping water



Emergency Stop

### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any modifications to this product may violate the rules of the Federal Communications Commission and make operation of the product unlawful.

### **Limited Warranty**

#### **SCOPE OF WARRANTY**

Midmark Corporation ("Midmark") warrants to the original purchaser its new Alternate Care products and components (except for components not warranted under "Exclusions") manufac-tured by Midmark to be free from defects in material and workmanship under normal use and service. Midmark's obligation under this warranty is limited to the repair or replacement, at Midmark's option, of the parts or the products the defects of which are reported to Midmark within the applicable warranty period and which, upon examination by Midmark, prove to be defective.

#### APPLICABLE WARRANTY PERIOD

The applicable warranty period, measured from the date of delivery to the original user, shall be one (1) year for all warranted products and components.

#### **EXCLUSIONS**

This warranty does not cover and Midmark shall not be liable for the following: (1) repairs and replacements because of misuse, abuse, negligence, alteration, accident, freight damage, or tampering; (2) products which are not installed, used, and properly cleaned as required in the Midmark "Installation" and or "Installation / Operation Manual for this applicable product. (3) products considered to be of a consumable nature; (4) accessories or parts not manufactured by Midmark; (5) charges by anyone for adjustments, repairs, replacement parts, installation, or other work performed upon or in connection with such products which is not expressly authorized in writing in advance by Midmark.

#### **EXCLUSIVE REMEDY**

Midmark's only obligation under this warranty is the repair or replacement of defective parts. Midmark shall not be liable for any direct, special, indirect, incidental, exemplary, or consequential damages or delay, including, but not limited to, damages for loss of profits or loss of use.

#### NO AUTHORIZATION

No person or firm is authorized to create for Midmark any other obligation or liability in connection with the products.

THIS WARRANTY IS MIDMARK'S ONLY WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. MIDMARK MAKES NO IMPLIED WARRANTIES OF ANY KIND INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE PARTS.

SF-1487 REV. A1

### General Information

## MIDMARK®

### Intended Use

This product is intended to ...

# User's Guide Wireless Hand / Foot Controls 9A408



### Authorized CE Representative

Countries in the EEC should direct all questions, incidents, and complaints to Midmark's authorized CE Representative listed below:

Promotal 22, Rue de St. Denis 53500 Ernee, FRANCE Phone: 33-2-430-517-76

Fax: 33-2-430-569-10

### Calling for Service

If service is required, contact your Midmark dealer or to locate your nearest service provider, log onto: <a href="http://www.midmark.com">http://www.midmark.com</a>

To contact Midmark directly:

1-800-Midmark (1-800-643-6275) 8:00 am until 5:00 pm Mon-Fri (EST)



This guide outlines basic operation of the wireless hand / foot control accessory. If service is required, contact your authorized Midmark dealer.

Dealer (name / phone):	
	 · · · · · · · · · · · · · · · · · · ·
Date of Purchase:	

Midmark Corporation 60 Vista Drive Versailles, OH 45380-0286 Phone: 937-526-3662 Fax: 937-526-5542 midmark.com



This procedure is only required if there is a malfunction, or if you are attempting to use the controller with a chair other than the one it was originally associated with.

Stop



Home -

### Association Procedure:

- **A.** Using the **wired** hand / foot control, press & hold the **Stop** & **Home** buttons simultaneously. (after two seconds you will hear a single "beep")
- B. Using the wireless hand / foot control, press & hold the **Stop** & **Home** buttons until you hear three "beeps". (one long "beep" indicates the association failed. Repeat Steps A & B)
- **C.** Check for proper operation of wireless controllers.

Step B must be performed within 10 seconds of Step A, failure to do so will cause the procedure to fail.



### **Specifications**

**Batteries:** ...... AAA (qty: 2) (Note: Battery access cover is located on back of controller) Range of Operation ...... 20 ft (6 m) radius

### **Troubleshooting**

• When any button is pressed, hand / foot control sounds a single "beep". (All functions operate)

Cause: Low Battery

Solution: Replace batteries

• When any hand / foot control button is pressed, nothing happens. (No "beeps", no movement, etc.)

Causes: 1. Batteries completely dead 2. Wireless controller has lost

"association" to chair.\*

Solution: 1. Replace batteries 2. Perform Association Procedure\*.

\* The wireless controllers will only function with the chair they have been "associated" with. This prevents unwanted movement in locations with more than one chair.

If further service is required, contact your authorized Midmark dealer.