


Handheld Transmitter



1 Power / Infrared (IR)/ Mute indicator

Green	Ready
Flashing green	Controls locked
Amber	Mute on
Flashing red	IR transmission in process
Glowing red	Battery power low
	Batteries dead (transmitter cannot be turned on until batteries are changed)
Pulsing red after synchronization	Transmitter and receiver incompatible; contact your reseller

2 On-off / mute switch

Press and hold to turn on or off. Press and release to mute or unmute.

3 IR port

Receives infrared beam to synchronize frequencies. When using multiple systems, only one transmitter IR port should be exposed at time.


Changing Batteries

- Expected life for alkaline batteries is approximately 8 hours.
- When the transmitter light glows red, the batteries should be replaced immediately, as shown on the right.

Adjusting Gain

- Access the gain adjustment switch by unscrewing the head of the microphone.
- The tip of a pen or a small screwdriver to move the switch
- OdB: For quiet to normal vocal performance.
- -10dB: Use only if audio is distorted due to high vocal levels.





FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.