# BonSayOn Product Manual




# Bluetooth Goggle W301

#### Introduction

Completely different from the conventional microphone which picks up sound or voice through air, BonSayOn utilizes a newly developed nasal bone conduction microphone by picking up the sound through bone or solid material, instead of air.

The speaker's voice, which is received through vibrations of the nasal bone, is clear. Reducing the background noise, especially for the wind sound, is the most outstanding feature for our product. The clear conversation through the BonSayOn never fails in any noisy environment. Please enjoy BonSayOn; satisfied communication in style.



BonSayOn

## Specification

Microphone Type NeoV Nasal hone conduction microphone Version 3.0 Bluetooth Version Bluetooth V2.1.Class 2 Bluetooth Profile HSP/HFP/A2DP/AVRCP Operating Distance 10 meters (open space) Charge Time About 4 hours Music Play Time About 10 hours Talk Time About 12 hours Standby Time About 200 hours Size 208mmX88mmX80mm Weight 170a -30°C~50°C, humidity 0~90% Operation Condition Li-polymer Battery Battery

#### Standard Accessories

Li-polymer Battery
(350mA/3.7V)

Hard case
Replacement orange lens
Cleaning cloth
USB cable
3.5mm standard earphone set
Inside the helmet earphone set
Product Manual

#### Instruction of Button Operation

## **Pairing**

- Press button until the blue and red LED flashes quickly to turn BonSayOn into pairing mode.
- Search for BonSayOn device using your phone/music device. For more information on how to search for Bluetooth device, please refer to the user guide that accompanies your phone/music device.
- Select BonSayOn W301 from the list of discovered devices from your phone/music device. Follow the onscreen prompts to confirm the selection.
- When prompted, enter the passkey "0000" (four zeros). When pairing is successful, the blue LED flashes slowly.
- Do not need to pair again for a paired device, just turn it on. (Blue LED flashes slowly)

## **Dual Pairing**

 BonSayOn supports dual pairing. It can be connected with two cell phones at the same time and answer a call in turn.


( Depends on the cell phone)

#### Auto-answer

 BonSayOn supports auto-answer for incoming call. The incoming call will be answered automatically after 2 rings.

Press of for 2 seconds to reject incoming call.

## **Button Function Illustration**




## **Table of Operation Function**

Function

Status	runction	Operaton
OFF	Turn on	Press () botton for 3 seconds
	Turn on and search device	Press () botton for 5 seconds
Standby	Reject a call	Press 🖰 botton for 2 seconds
	Redial	Press botton for 2 seconds
	Battery power display	Press ¥ botton twice
	Voice dialing	Press ★ botton twice
Talk	Answer/End a call	Press () botton once
	Volume increase	Press ★ botton once
	Volume decrease	Press ¥ botton once
	Switch a call	Press () botton for 2 seconds
Music	Volume increase	Press ★ botton once
	Volume decrease	Press ¥ botton once
	Last Trace	Press ★ botton twice
	Next Trace	Press ¥ botton twice
	Pause/Resume/Answer a call	Press () botton once
ON	Turn off	Press () botton for 5 seconds

Operator

#### **Battery Charging Instruction**



- The warning sound indicates 10% of battery power remaining.
- ® Battery power level: press ➤ button twice. Two seconds later a beep tone appears: 3 beeps mean high level, 2 beeps mean medium level,1 beep means low level (10-15% power remaining). Don't charge the battery if not necessary to avoid shortening battery lifetime.
- Charge as soon as possible when the warning sound appears on phone call or while playing music.
- Red LED lights during charging. When charging is complete, red LED will be turned off.
- Battery breakdown or lifetime ends: Red LED flashes

BonSayOn

#### 0 & A

#### Q: Why is BonSayOn product unable to link Rluetooth?

A: First, make sure the Bluetooth existing in the device (mobile phone or computer) linked to BonSayOn product, and activate its Bluetooth to search BonSayOn W301. The search time is not definite, so please be patient to wait until BonSayOn product is shown on the screen of the device. Finally, key in identification code "0000" to start using BonSayOn product.

# Q: Why is the Bluetooth unable to switch on or disconnect soon after online?

A: It would be power shortage, please charge immediately so as to maintain battery quality. A new battery must be charged first until the red light goes out. If the problem is still unsolved, please contact with authorized maintenance service station.

# Q: Why is Bluetooth auto-disconnected or unable to use after linking successfully?

A: Check the Bluetooth "on line list" in the device (Pleas read your Bluetooth operation instructions.) linked to BonSayOn product. Delete most of the names on the online list except BonSayOn's to avoid linking other products.

# Q: Why cannot BonSayOn goggles connect to the device with Bluetooth protocols?

A: BonSayOn goggles is equipped with Bluetooth chip made by the world first brand CSR company. It can connect to most of the Bluetooth devices but not all the Bluetooth devices due to the variety of Bluetooth protocols made by different companies.

#### Q: Why cannot play the music again by using the buttons on BonSayOn after picking up a call or pause the music playing?

A: The cell phone manufacturers usually implement somewhat different button operation software, resulting in partial operation malfunction. Please touch the play button on your cell phone to continue playing the music on BonSayOn.



#### REMOTE CONTROL

Model No: BonSayOn W301 FCC ID: X5HW301

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmul interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in Taiwan

#### Caution

- This product is humidity-proof, but not water-proof or dust-proof. Do not use it in water or dust environment to avoid the damage as well as shortening the lifetime of the product.
- 2. Temperature range: -30°C~50°C
- For the sake of product surface and accessories intact, please avoid rubbing the product with hard objects.
- Please only use qualified accessories which have been authenticated by the NeoVictory Company. This will ensure smooth and normal operation of this product.
- All accessories have been officially certified. In order to guarantee the product functioning normally, please do not use the accessories not officially certified.
- When using the earphone, your can not access outside sound very well. Do not use the earphone where it may endanger your safety.

The transmitter output power is below the thresholds established by the FCC that would require a formal RF exposure evaluation.

# **Product Warranty**

Name:	Phone:			
Product Name :	Mobile phone:			
Serial Number :	Purchase Date :			
Address:	e-mail: @			
Exclusivity: 1.Disassembling, hitting, and soa	king in water, or abnormal use.			
Physical or electronic disturbance, the misuse of power source, unstable power source, very close to magnetic material or other artificial factors.				
3.The breakage of serial number, date code, product tag, warranty lost, etc.				
4.Irresistible external factors: Earthquake, seaquake, war, etc.				
5. Without Company stamp or the incorrect purchase date, warranty is invalid automatically.				