Remote Transmitter Model: EM101R1 / EM103R1

1. INTRODUCTION

The transmitter allows you to operate the receiver. It is a visor mount type transmitter to allow to access easily.

LEARN TRANSMITTER TO THE RECEIVER UNIT

In order for the transmitter to communicate with the receiver properly, the transmitter must be programmed to the receiver. Follow the brief instructions below or refer to the detail instructions from the User's Instructions to program the transmitter to the receiver.

To program the transmitter to the receiver unit:

- 1. Connect the receiver unit to 24VDC.
- 2. Press and hold the 'Learn' button in the receiver. The 'ON' LED will begin to flash.
- 3. Press the button on the transmitter for 1 second and release.
- 4. If a connection has been made, the 'ON' LED on the receiver will stop flashing.

3. OPERATION

Press the button for 1 second and release, this will activate the "learned" receiver.

BATTERY

The remote transmitter operates on a 3-volt lithium battery CR2032 that is installed at the factory. The battery does not need to be replaced if used under normal condition.

Recommendation: Test your transmitter periodically to ensure that the battery is working.

WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

FCC

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux Partie 15 des règlements de la FCC et CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible of compliance could void the user's authority to operate the equipment.

7. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please:

1. visit our FAQ section at www.skylinkhome.com, or

- email us at <u>support@skylinkhome.com</u>, or
 call our toll free at 1-800-304-1187 from Monday to Friday, 9am to 5pm EST. Fax (800) 286-1320.

SKYLINK TECHNOLOGIES INC., 17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3

Email: skylinkhome.com Website: http://www.skylinkhome.com

© 2013 Skylink Group