QUICK STARTER GUIDE BURG 16A



Index

Burg 16A

Your BURG	1 - 1
The first time you use your BURG	2 - 4
Controls	5 - 7
Menu	8 - 8
Menu features	9 - 10
Functions (Manual for Android)	11 - 22
Functions (Manual for iPhone)	23 - 30
Product and safety information	31 - 31
FCC Declaration	32 - 35
Discover more	36 - 36

Your BURG

- A Touch screen
- B Micro USB port 2.0
- On / off key
- Microphone
- E Speaker



The first time you use your BURG


1. How to setup micro SD files

Make sure your micro SD card default folder name is:



The first time you use your BURG

2. How to insert the micro SD and SIM card.



Make sure you always switch off your BURG before you remove the battery!

Whates If you have no mirco SD card in your micro SD holder, make sure you close the micro SD card holder the right way in order not to damage the SIM card holder.

The first time you use your BURG

3. First charge the battery of your BURG.



4. When your battery is 100% you can switch on your BURG





Give the on/off key a long press.



The battery might get damaged if it will be empty for a long time. If you a do not use your BURG always make sure you charge your BURG regularly. If you BURG battery has been empty for a long time it could take up to 60 minuttes of charging before it switches back on again.

Controls



Controls

5. Main screen



Analog Clock



Main Menu



Main Menu



Notifications / Ongoing



Analog Clock 1



Analog Clock 2

Controls



Screen A E Go back
keypad B F Add a new contact
Contacts G Add a new group
Call button D H Bluetooth contacts

6. To scroll to the menu, slide right or left.



8

Image viewer

Video player

Menu features

Messagina make, read and manage all your text and MMS messages

Call logs See your call history

Bluetooth Manage Bluetooth

Two Way Com Connect to a smart phone

Remote notifier Via bluetooth Push APP notication to your BURG

Settinas Time, Language, Display, Themes, etc. *

SmartSearch Search Phonebook, Call logs, App etc. Alarm clock

Calendar Calendar

Alarm

Calculator Calculator

Profiles Manage vour profile: General / Silent / Meeting / Outdoor

File Manager Manage your files

Menu features

13 Audio player Play your MP3's

M radio FM radio

15 Image viewer Browse the pictures on your SD card

7 Sound recorder Record and manage sound

* The default password of your BURG is 1122

Theme Feature

Video player

Settings \longrightarrow Phone setting \longrightarrow Display \longrightarrow Theme







Watch the videos from your SD card



- -

...........

JEANS



Functions

- Scan the QRcode to download the app to your Android Smart Phone (Android 4.0 and higher is supported)
- 2 After the installation start the Burg 16 TwoWay App. A pop up window with the message 'enable accessibility' will appear, press OK







http://goo.gl/b3ivvh

Enable Accessibility

BT Notification is required to send applications' notifications to your remote device. Press OK to go to the Accessibility settings to activate it.

OK. Cancel



Functions

3 Enable Accessibility



Android Two-Way Communication

With the Two-Way communication you can connect your Burg Smart Watch Phone with your Android Smart Phone using the Bluetooth. All calls and text messages can be answered and read with your Burg Smart Watch Phone when the function has been turned on. If the function has been turned on you also will be able to access the MP3 collection from your Android Smart Phone and play them through your Burg Smart Watch Phone. This function will you will be able to use your Android Smart Phone without taking if from your pocket or bag.

How to setup

- Switch the Bluetooth function and the visibility of your Bluetooth from your Android Smart Phone on
 - 2 Select the "Two way com" on your Burg Smart Watch Phone









- 3 Search for a new device
- Switch Bluetooth 'on'
- 5 Pair vour Android Smart Phone



Functions

- 6 Confirm your Android Smart Phone Password (change this to password, passkey is not correct!)
- 7 Password matched your BURG Smart Watch Phone
- 8 Confirm the request on both your Android Phone and your Bura Smart Watch Phone



Bluetooth Phonebook

Access to your Smart Phone contact list through your Burg Smart Watch Phone.


- Press Phonebook on your Burg Smart Watch Phone
- 2 Access your Android Smart Phone contacts in through the Burg BlueTooth Phonebook



How to make a call

- 1 Click on the Call button
- 2 IDial the number and press the dial button
- Select BT call for using the Simcard in your Android Smart Phone. (If you press local call you will use the Simcard in your Burg Smart Watch Phone)





Functions

How to make a call

- 4 You can see your Burg Smart Watch Phone is dialing
- 5 Your call will appear on both your Android Smart Phone and your Burg Smart Watch Phone







Music through your BlueTooth

Select 'Options'

Select the audio player on your Burg Smart Watch Phone



3 Select BT Music to access the audio files on your Android Smart Phone. (select local list to access the audio files on your Burg Smart Watch Phone)



Music through your BlueTooth


- 4) Now you can play the music from your Android Smart Phone through your Burg Smart Watch Phone
- 5 You can control volume, next & previous song all from your Burg Smart Watch Phone
- 6 Select 'Option s' Impressor of the Select 'Option



Push App notifications

you can receive notifications from the apps on your Android Smart Phone.

To do please select the Remote notifier on your Burg Smart Watch Phone to see the notification list.





Delete



Functions

How to Find My BURG

Click On your Android Smart Phone apps list,

scroll to the bottom of screen, you will see the item "Find My BURG".

2 Click "Find My BURG" on your Android Smart Phone, Burg Smart Watch Phone will ring up and show "BURG has been found".

Discover more

You can download the BURG 16A instruction & App for your Android Smart Phone from burg website:

http://www.burgsmartwatch.com/two-way-communication





iPhone Two-Way Communication


With the Two-Way communication you can connect your Burg Smart Watch Phone with your iPhone using the Bluetooth. All calls can be answered with your Burg Smart Watch Phone when the function has been turned on. If the function has been turned on you also will be able to access the MP3 collection from your iPhone and play them through your Burg Smart Watch Phone. This function will you will be able to use your iPhone without taking if from your pocket or bag.

How to setup

- Switch the Bluetooth function and the visibility of your Bluetooth from your iPhone on
- Select the "Two way com" on your Burg Smart Watch Phone



- 3 Search for a new device
- 4 Switch Bluetooth 'on'
- 5 Pair your iPhone



- 6 Confirm your iPhone Password (change this to password, passkey is not correct!)
- Password matched your BURG Smart Watch Phone



•

Bluetooth Phonebook

Access to your iPhone contact list through your Burg Smart Watch Phone.

- Press Phonebook on your Burg Smart Watch Phone
- 2 Access your iPhone contacts through the Burg Bluetooth Phonebook



How to make a call

- Click on the Call button
- 2 IDial the number and press the dial button
- 3 Select BT call for using the Simcard in your iPhone. (If you press local call you will use the Simcard in your Burg Smart Watch Phone)





Functions

How to make a call

- 4 You can see your Burg Smart Watch Phone is dialing
- 5 Your call will appear on both your iPhone and your Burg Smart Watch Phone







Functions

Music through your BlueTooth

- Select the audio player on your Burg Smart Watch Phone
- 2 Select 'Options'
- 3 Select BT Music to access the audio files on your iPhone.
 (select local list to access the audio files on your iPhone)



Music through your BlueTooth

- Now you can play the music from your iPhone through your Burg Smart Watch Phone
- 5 You can control volume, next & previous song all from your Burg Smart Watch Phone
- Select 'Option s' return to Burg Smart Watch Phone 'Local music'



Product and safety information



For more information about your Watch Phone download the complete manual from our website

WARNING AND DISCLAIMER

Do not use or place the Watch Phone under water. Avoid dropping it or stepping on it. Switch your watch phone off in aircraft, near medical equipment, fuel, blasting areas, or chemicals. Your watch phone and its accessories are not toys. Keep it out of the reach of small children and pets! Please stop the car before making or answering phone calls. Do not attempt to repair the watch phone yourself in case of damage or malfunction, as this will void the warranty. The device complies with RF specifications when the device used at 1.5cm form your body. Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS. DECLARATION OF CONFORMITY

"Hereby, Burg China Connection declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

FCC Declaration

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government, These limits are part of comprehensive auidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons. regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR, The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR

level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.a., at the Mouth and worn on the Wrist) as required by the FCC for each model. The highest SAR value for this Watch Phone when tested for use at the Mouth is 0.23 W/Kg and when worn on the Wrist, as described in this user guide, is 0.505 W/Kg(Wrist-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the aovernment requirement for safe exposure. The FCC has granted an Equipment Authorization for this Watch Phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure auidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/ oet/fccid after searching on

FCC ID: YIABURG16 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Asso-ciation (CTIA) web-site at http://www.wow-com.com.* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a sub-stantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Device is restricted to worn on the wrist operations.

Discover more

You can also find the after sale details on our burg website: www.burgsmartwatch.com





Designed by BURG in Holland, Assembled in China