Splash TRAIL EDITION

User Manual

Contents:

Getting Started	3
Waterproof & Dustproof Performance	10
Specifications	11
Troubleshooting	12
Contact Support	14
Warnings	15
FCC Information	18
Warranty Information	20



GETTING STARTED

(a) On/Off Switch

- **(h)** Charging Indicator
- **b** Bluetooth Status Light
- i Built-in Microphone

c Action Button

(j) Previous Track


d Volume Up

Next Track

- Volume Down
- **(f)** 3.5mm AUX-IN
- **9** Micro-USB Charging Port

In the Box

- NUU Splash Trail Edition
- Micro USB power charging cable
- 3.5mm to 3.5mm audio cable
- User Manual



On/Off Switch

On: Slide the switch To the left to turn the NUU Splash on. When powered on, the Splash says "Power On!" to indicate this.

Off: Slide the switch to the right to turn the NUU Splash off. When powered off, the Splash says "Power Off!" to indicate this.

NOTE: Do not flip the power switch on/off rapidly. Wait for the sound before moving the switch again.

Bluetooth Status Light

- **(b)** This is a small light under the Action Button button that illuminates to show the current status of the Splash's Bluetooth connection.
 - **Flashing Slowly and Intermittently:** The Splash is on and is not in pairing mode. This is also the indicator for "auto-reconnect", where the Splash attempts to connect with the last paired Bluetooth device immediately after it is powered on.
 - Flashing Quickly and Steadily: Pairing mode (you will hear the word "Pairing" from the Splash)
 - **Solidly Lit:** Paired and connected.



The Action button $(\triangleright \parallel)$ controls:

Pairing of Bluetooth device

Play/Pause

Re-connect

TO PAIR THE SPLASH WITH YOUR BLUETOOTH DEVICE:

- 1. Switch on the NUU Splash. The Bluetooth Status light will flash slowly. At this point, the Splash will enter pairing mode automatically if it does not find a previously-paired device with which to reconnect. When it enters pairing mode, you will hear it say "Pairing!"
- 2. If the Splash did not automatically enter pairing mode, press and hold the Action Button bout ~3 seconds to manually start pairing mode. You will hear the word "Pairing!" and the Bluetooth Status Light will flash quickly.
- 3. Enable Bluetooth on your phone or other device.* Then select "NUU Splash" from the list of discoverable devices.
- 4. If prompted for a PIN code, enter "0000" (4 zeros).

5. It will take between 10-15 seconds for the NUU Splash to pair with your device. When pairing is successful, you will hear the Splash say "Your device is connected!" and the Bluetooth Status Light will remain steadily lit.

NOTE: Procedures for activating Bluetooth will vary across devices. Consult the documentation that came with your phone or other device for further information.

PLAYBACK:

The Action Button doubles as a "Play/Pause" button. While music is playing, press and release the Action Button $\triangleright \parallel$ to pause the music. Press and release $\triangleright \parallel$ button again to resume playback.

RF-CONNECTION:

The Splash will attempt to re-connect with a previously paired device when the Splash is powered on. If the Splash cannot find the paired device, it will enter pairing mode automatically.

(d) Volume Up ⊕ Volume Down ⊡

CONTROLLING VOLUME

Press or **hold** the volume keys — / — to adjust the volume. The NUU Splash will beep with each change in volume. When you reach maximum volume, the Splash will say "Maximum volume!". There is no voice prompt for minimum volume, just a low beep noise.

NOTE: Volume may only be adjusted while the Splash is connected to a Bluetooth device. While the Splash is connected via AUX-IN, the volume on the Splash is set at maximum. You must then adjust playback volume via the volume controls on your phone.

(f) 3.5mm AUX-IN – Plug & Play

The NUU Splash can connect to any device with a 3.5mm headphone jack. Use the supplied 3.5mm input cable to plug and play, no Bluetooth required. Audio content via 3.5mm stereo input will override audio streamed via Bluetooth.

NOTE: Accessories supplied do not meet waterproof and dustproof specifications.

Micro-USB Charging Port

CHARGING THE SPLASH'S BATTERY:

For best results, ensure the NUU Splash is fully charged before use.

Connect the supplied Micro-USB cable into the charging port ____, and plug USB side into your computer or USB AC adapter (adapter not supplied). The green charging indicator will remain illuminated while the unit is charging. The indicator will automatically switch off when the unit is fully charged. Allow 4.5-5 hours for the battery to fully charge. The NUU Splash may be used while it is charging.

NOTE: Do not use the unit to play music while it is charging on a computer USB port. Your computer's USB port may not supply enough power to charge and play at the same time.

(h) Charging Indicator

A flashing red light indicates that the battery is low and should be recharged soon. When charging, this light shows green until the NUU Splash is fully charged.

i Built-in Microphone — Making and Taking Calls

The NUU Splash may be used as a wireless speakerphone. Use your phone to dial as usual, and speak toward the built-in microphone located at the top of the unit. The built-in microphone only works when your phone/device is connected via Bluetooth.

To answer or end an incoming call, press and release the Action button. Incoming and outgoing calls are given priority over Bluetooth audio playback, but not 3.5mm input. If a call comes in while you are streaming Bluetooth audio, the track will pause and the Splash will read the incoming phone number to you. It will resume once the call is ended.

To reject an incoming call, press and hold the Action Button for one (1) second. You will then hear a two-tone sound and the call will go to voicemail. Be careful not to hold the Action Button for too long, lest you trigger Pairing Mode!

During a phone call, press the sutton once to switch between using the NUU Splash and your phone to talk. You will hear a 'beep', indicating that the call has been transferred to your phone or the NUU Splash.

When you are streaming audio via Bluetooth, you may press the button to skip forward to the next track in your playlist.

Press the (\ll) button to skip back to the previous track in your playlist, or to the beginning of your current track.

WATERPROOF & DUSTPROOF PERFORMANCE

The NUU Splash is designed to be waterproof and dustproof. Damage caused from misuse, abuse or failure to properly maintain the Splash is not covered by the limited warranty.

- The Splash is IP57 certified and will operate at a water depth of 3 feet for up to 30 minutes. Recommended operating water temperature range of 0°C to +40°C (32°F to 104°F). Minimum operating temperature: -10°C. (battery performance will be affected as temperature drops). Do not use in hot springs.
- As for dustproof performance, there is no guarantee that the Splash will not become scratched or dented.
- Accessories supplied do not meet waterproof and dustproof specifications.

NOTES BEFORE USING SPLASH UNDER/NEAR WATER

• Always confirm that the cover over the charging and AUX-IN port has been securely sealed. Splash will only meet IP57 standards when

cover has been securely closed. To securely close the cover, follow these steps:

- 1. Firmly seat the inside edge of the cover in place
- 2. Using both thumbs, press down at both ends of the cover at the same time to ensure it is in place, flush, and sealed
- If dirt or sand gets on the power charging port(s), wipe the area clean with a soft cloth that will not leave behind any fibers.
- Do not open or close the charging port cover with wet or sandy hands or near water.
- Make sure the Splash is completely dry before opening the charging port cover.

SPECIFICATIONS - Design and specifications are subjected to change without notice.

IP57 waterproof & dustproof rating

1 x Passive bass radiator

Bluetooth: Version 4.0

Pairs with any Bluetooth 2.0 device

2 x 40 mm 4 ohm speaker driver

10m Bluetooth Range

• 3.5mm AUX-IN

Up to 10 hours of playback time

• Dimensions: 6.75" x 2.3" x 2.75"

2 x 3W audio output power

A2DP profile

Weight: 1 lbs

IP57 Definition:

Solid particle protection level 5 - *Ingress of dust is not entirely prevented, but it must not enter in sufficient quantity to interfere with the satisfactory operation of the equipment; complete protection against contact.*

Liquid ingress protection level 7 - Ingress of water in harmful quantity shall not be possible when the enclosure is immersed in water under defined conditions of pressure and time (up to 3 feet of submersion for 30 minutes).

Drop Testing - NUU Splash drop testing meets or exceeds 1M drop test standards.

TROUBLESHOOTING

- Unable to pair with your Bluetooth device?
 - 1. Ensure that your phone/device is Bluetooth compatible, and that Bluetooth has been correctly enabled on your device. (Check the documentation that came with your phone/device for further instructions).
 - 2. Ensure that your phone/device is within a few feet the NUU Splash.

- 3. If your phone/device is connected to a number of other Bluetooth devices, disconnect some of them before pairing with the NUU Splash.
- 4. Turn Bluetooth off and then on again on your phone/device. If the NUU Splash still won't pair, remove it from the list of discoverable devices and retry the pairing process from the start.
- 5. Ensure that both devices are sufficiently charged.

Problems with the sound?

- 1. For sound distortion, try lowering the volume on the NUU Splash and/or your phone/device.
- 2. Move the NUU Splash closer to your phone/device.
- 3. Connect your phone/device to the NUU Splash via the 3.5mm input cable rather than Bluetooth. Ensure that the cable is fully inserted at both ends.
- 4. Ensure that both devices are sufficiently charged.

- NUU Splash not responding to commands such as volume change, play/pause, pair, etc.?
 - 1. Switch the NUU Splash off and then on again.
 - 2. If there is still no response after step 1, connect the unit to the supplied power adapter and repeat step 1.
 - 3. If there is still no response after steps 1-2, reset the Splash by pressing and holding both and together for three seconds. You will hear the Splash say "Power on!" as it reboots.
 - 4. Check that your phone or other device is sufficiently charged.

CONTACT SUPPORT

We want to help solve whatever issues you may encounter when using your NUU Splash. If at any time you are not satisfied or have questions, please call or e-mail our dedicated customer support specialists and they will be more than happy to assist you.

For further technical support and information, please visit gonuu.com/support or

US Customer Support

pport CALL: Noetic, Inc.

507-529-1441

8am - 4:30pm (CT) M-F

E-MAIL: Noetic, Inc.

support@noeticinc.com

e-mails will be answered within 1 business day

WARNINGS

Read all instructions and warnings before using this product to ensure your personal safety and prevent property damage.

- The cover over the charging and AUX-IN port MUST be closed in order for the NUU Splash to be waterproof. Press firmly on the cover to ensure it is closed and sealed.
- The NUU Splash has a water resistance rating of IP57 ingress of water in harmful quantity shall not be possible when the enclosure is immersed in water under defined conditions of pressure and time (up to 3 feet of submersion for 30 minutes). Do not expose the product to more than 3 feet of water or for longer than 30 minutes.

- Do not expose this product to fire or other sources of excessive heat.
- Do not leave this product in direct sunlight for extended periods of time.
- Do not block any ventilation openings.
- Do not disassemble this product or attempt to modify it in any manner. Unauthorized alterations may compromise safety, regulatory compliance, product performance, and will void the warranty
- Do not expose this product to excessive impact or other physical abuse. Do not insert anything into this product unless otherwise specified in the user manual.
- Do not use abrasive cleaners on this product. Wipe it with a soft, water-dampened cloth.
- Only charge the battery in accordance with the user manual supplied. Use only the manufacturer supplied charger. Using other chargers could result in electric shock and/or damage the NUU Splash. Using other chargers will void the warranty.

- Do not charge the NUU Splash in damp areas or in extremely high or low temperatures, as this could result in electric shock.
- Do not attempt to replace the product's built-in battery. Attempts to disassemble the unit or replace internal battery will void the warranty.
- Obey all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Do not place the NUU Splash on high surfaces. During music playback, the product may move or shift, causing it to fall.
- Do not dispose of the NUU Splash in a fire. The battery could explode causing injury or death.
- Dispose of the NUU Splash with its battery in accordance with local regulations. Do not dispose of the NUU Splash with regular household waste.

FCC INFORMATION

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

FCC RF Warning Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARRANTY INFORMATION

OUU Limited One Year Warranty Information

NUU Limited (hereafter referred to as NUU), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase.

If you are experiencing any problems with the operation or function of your product, please make sure you have downloaded our full owner's manual from our website for reference or contact the authorized local distributor (information of the authorized distributors are listed on www.gonuu.com). Should this fail to resolve the matter and service is still required by reason of any defect or malfunction during the warranty period, NUU will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to a designated factory service center. The product must include proof of purchase, including date of purchase. To obtain the Warranty Service, Customer must contact the authorized local distributor within the applicable warranty period to obtain warranty service authorization. Dated proof of original purchase from the authorized reseller will be required. NUU is not responsible for Customer's products or parts received without a warranty service authorization. Products or parts shipped by Customer to local distributor must be sent prepaid and packaged appropriately for safe shipment, and it is recommended that they be insured or sent by a method that provides for tracking of the package.

THIS WARRANTY SHALL NOT BE EXTENDED, ALTERED OR VARIED EXCEPT BY A WRITTEN INSTRUMENT DULY SIGNED BY NUU WARRANTIES EXCLUSIVE. IF THIS PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPLACEMENT OR REPAIR OF THE PRODUCT OR PART OR REFUND OF THE PURCHASE PRICE PAID, AT NUU. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES (OR CONDITIONS), EXPRESSED OR IMPLIED, INCLUDING (WITHOUT LIMITATION), ANY WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR A PARTICULAR PURPOSE. NUU SHALL NOT BE LIABLE FOR LOSS OF PROFITS OR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES WHICH THE PURCHASER MAY SUSTAIN. IN NO EVENT SHALL NUU'S

LIABILITY EXCEED THE PURCHASE PRICE OF THE DEFECTIVE PRODUCT. NUU NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. NUU SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT OR MALFUNCTION IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLECT, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO OPEN, REPAIR, OR MODIFY THE PRODUCT, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OTHER HAZARDS, OR ACTS OF GOD. THIS WARRANTY DOES NOT COVER PHYSICAL DAMAGE TO THE SURFACE OF THE PRODUCT, INCLUDING CRACKS OR SCRATCHES ON OUTSIDE CASING. THIS WARRANTY DOES NOT APPLY WHEN THE MALFUNCTION RESULTS FROM THE USE OF THIS PRODUCT IN CONJUNCTION WITH ACCESSORIES, OTHER PRODUCTS, OR ANCILLARY OR PERIPHERAL EQUIPMENT AND NUU DETERMINES THAT THERE IS NO FAULT WITH THE PRODUCT ITSELF. THIS WARRANTY DOES NOT APPLY TO ANY MALFUNCTION OR FAILURE OF THE PRODUCT OR PART DUE TO ANY COMMUNICATION SERVICE CUSTOMER MAY SUBSCRIBE TO OR USE WITH THE PRODUCT. WARRANTY IS VOID IF THE WARRANTY STICKER IS REMOVED.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW, NUU ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THIS PRODUCT, EVEN IF NUU OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPLACEMENT, REPAIR, OR REFUND OF THE PURCHASE PRICE PAID, AT NUU'S DISCRETION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HERE-IN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Disclaimer: Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

NUU Service Center

3111 19th Street NW, Rochester, MN 55901-6606 USA





www.facebook.com/nuubrand



www.twitter.com/go_nuu

Made in China

© 2014 NUU. ALL RIGHTS RESERVED
The Bluetooth word mark and logo are registered trademarks and are owned by the Bluetooth SIG, Inc.