ClamCase Pro

Quick Start Guide




Welcome

Get ready to experience your iPad like never before

Lets get started!

Setup

- Place your iPad inside the bottom edge of the ClamCase.
- Press your iPad into the **top edge** of the ClamCase and it will **snap in** securely.
- To remove, **snap back** the top clip of the ClamCase and **release** your iPad.



Charge

- Charge your ClamCase with the supplied USB cable until the charging indicator LED turns green.
- A full charge can take up to 120 minutes.

Power Up

- Turn on the ClamCase keyboard before use.
- (1) When in tablet mode, the keyboard automatically turns off to avoid unintentional key strokes.

Pairing

Your ClamCase Pro automatically enters pairing mode when first powered on.



Manual Pairing: On your ClamCase keyboard press and hold the Bluetooth key for 5 seconds. The pairing LED will begin flashing.



Open the Settings app on your iPad.



Turn Bluetooth on.





Tap to connect:

ClamCase Air Keyboard Not Connected (i)

Function Keys



















Caps Lock

Case







Media











()







Battery Life

- Press the **battery** key.
- The **LED** will flash to indicate battery life.





| Troubleshooting

- Press any key to wake your ClamCase from sleep mode.
- Turn your ClamCase off and then back on.
- Recharge the ClamCase battery.
- Re-establish a Bluetooth connection between your ClamCase and iPad.
- Verify your iPad's Bluetooth feature is turned **on**









FCC COMPLIANCE STATEMENT

The equipment has been tested and found to comply with limits for a Class B digital device, pursant to Part IS of the PCR falls. These limits are designed to provide reasonable protection against harmful interference in a residential natisfation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference with occur on a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shelded interface cables when connecting computer or peripheral devices).

USA: This device complies with Part 15 of the FCC Rules. Operation is subject

to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada: Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

To satisfy RF exposure requirements, this device and its antenna must operate with a separation distance of at least 20 centemeters from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Disposal and Recycling Information

When this product reaches its end of life, please dispose of it according to your local environmental laws and guidelines.

Battery Disposal Information

Dispose of batteries according to your local environmental laws and guidelines.

Contact




support@clamcase.com




888.882.4440



clamcase.com/support





Note: The device has no ad-hoc function.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes and modifications to this equipment. Such changes and modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct eth interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.