


BLUETOOTH SELFIE STICK

Model:ONA18CA002

PRODUCT GUIDE



Ver.01 1/16/2018 Ver.01 1/16/2018

How to power on or off the device:

Press and hold the power button to turn the selfie stick on or off. The blue indicator will flash quickly when the device is powered on. The selfie stick will automatically go into Bluetooth mode upon powering on.

How to pair device using Bluetooth:

- 1. Power on selfie stick and ensure that the blue indicator light flashes quickly (this means that the device is in Bluetooth pairing mode)
- 2. Turn on the Bluetooth function of the device which you would like to pair with the selfie stick. Ensure that the device is in pair mode.
- 3. Select "ONA18CA002" on your selected device to pair with selfie stick until it shows "Connected" indicates that a successful paring has occurred.
- 4. You should now be successfully paired to the selfie stick.

Charging Mode:

Red light is constantly on when product is charging. Product is fully charged, then the red light automatically switches off.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

- Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Ver.01 1/16/2018

Ver.01 1/16/2018