GSM/WCDMA/GPS Tracker

Bolt Mini User Manual

Revision: 1.00

Document Title	nt Title Bolt Mini User manual	
Version	1.00	
Finale Date	2017-09-05	
Status	Released	
Document Control ID	TRACKER Bolt Mini	

Contents

1 Introduction	3
2 Product Overview	3
2.1 Appearance	3
2.2 LED Description	
3 Getting Started	5
3.1 Parts List	5
3.2 How GPS position Fix	5
3.3 Disassemble Introduction	5
3.4 Insert SIM Card	7
3.5 Device Power on	8
3.6 Install	8
4 Frequency	8
5 Trouble shooting and Safety info	
5.1 Trouble shooting	
5.2 Safety info	

1 Introduction

Bolt Mini use primary batteries. it is a powerful GPS locator which is designed for vehicle, and assets tracking . With superior receiving sensitivity, Its location can be real time or schedule tracked by backend server or specified terminals. Based on the embedded wireless tracking protocol, Bolt Mini can communicate with the backend server through WCDMA and GSM network, and transfer reports of emergency, Geo-fencing, device status and scheduled GPS position etc... Service provider is easy to setup their tracking platform based on the functional wireless tracking protocol.

2 Product Overview

2.1 Appearance



Figure 2-1

2.2 LED Description



 $\label{eq:Figure 2-2}$ There is one tricolour LED lights in Bolt Mini device, the description as following.

Light	Event	State
LED show blue	GPS fixed	Solid
LED show red	low power	Solid
LED show green	standby mode	Slow Flash
	During Call	Solid

3 Getting Started

3.1 Parts List

Name	Picture	Remark
Bolt Mini		The GSM/WCDMA/GPS locator.

3.2 How GPS position Fix

Your device has an unobstructed view of the sky,lying face up,so it can obtain the initial GPS Fix



Figure 3-1

3.3 WiFi Operation Introduction

You can input following command to the serial port.

Open WIFI	AT+EWIFI=1	SUCCEED: WiFi Start
		FAILED::WiFi Start
Search WIFI	AT+EWIFI=2	Return searchable WiFi wireless hotspot and
		LASTAPLAST
Close WIFI	AT+EWIFI=0	SUCCEED: WiFi Stop
	AT+WIFI=CONNE	mobiletek (WiFi name) www.mobiletek.cn
Connect WIFI	CT,mobiletek,3,3,	(password)
	www.mobiletek.cn	

Note:Input AT+distslp command when device starting up.

3.4 Disassemble Introduction

1.Dismantling machine tools:

Tweezers, Cross Screwdriver

2. Machine appearance:







Figure 3-2

3.Disconnect the screw plug



Figure 3-3

4.Disconnect the screw



Figure 3-4

5.Tear down the base




Figure 3-5

3.5 Insert SIM Card




Figure 3-6

3.6 Device Power on




Figure 3-7

3.7 Install




Figure 3-8

4 Frequency

GSM850 (GPRS) : 824 MHz - 849 MHz (Tx); 869 MHz - 894 MHz (Rx)

PCS1900 (GPRS) : 1850 MHz - 1910 MHz (Tx); 1930 MHz - 1990 MHz (Rx)

WCDMA:Band2、Band4、Band5

GPS:1575.42MHz

5 Trouble shooting and Safety info

5.1 Trouble shooting

Trouble	Possible Reason	Solution
Messages can't be	APN is wrong. Some	Ask the network operator for the right
reported to the	APN can not visit the	APN.
backend server by	internet directly.	
Mobile network.	The IP address or port of	Make sure the IP address for the
	the backend server is	backend server is an identified address
	wrong.	in the internet.
Unable to power	The function of power key	Enable the function of power key by
off BOlt Mini.	was disabled by	AT+GTFKS.
	AT+GTFKS.	
Battery can not be	The battery has not been	Using a external power source with
charged	used for too long time and	3.65V DC power supply to active the
	has been locked.	battery or apply for after sale help.
Bolt Mini can't fix	The GPS signal is weak.	Please move Bolt Mini to a place with
GPS successfully.		open sky.
		It is better to let the top surface face to
		the sky. (The same surface with
		indication LED)

5.2 Safety info

The following items are suggestion for safety use, please pay more attention.

- **U** Please do not disassemble the device by yourself.
- Please do not put the device on the overheating or too humid place, avoid exposure to direct sunlight. Too high temperature will damage the device or even cause the battery explosion.
- Please do not use Bolt Mini on the airplane or near medical equipment.

FCC Caution.

§ 15.19 requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.