



## AIRCRAFT MAINTENANCE MANUAL

### COMPRESSOR-ACCELERATION-BLEED CONTROL VALVE ASSEMBLY - REMOVAL/INSTALLATION

EFFECTIVITY: PRE-MOD. S.B. AE3007A-75-019

#### 1. General

- A. This section gives the procedure to remove/install the compressor-acceleration-bleed control valve assembly.
- B. These procedures are applicable to the LH and RH engines.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
75-31-02-000-801-A	COMPRESSOR-ACCELERATION-BLEED CONTROL VALVE ASSEMBLY - REMOVAL	PRE-MOD. S.B. AE3007A-75-019
75-31-02-400-801-A	COMPRESSOR-ACCELERATION-BLEED CONTROL VALVE ASSEMBLY - INSTALLATION	PRE-MOD. S.B. AE3007A-75-019



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 75-31-02-000-801-A

EFFECTIVITY: PRE-MOD. S.B. AE3007A-75-019

2. COMPRESSOR-ACCELERATION-BLEED CONTROL VALVE ASSEMBLY - REMOVAL

A. General

- (1) To remove the compressor-acceleration-bleed control valve assembly, obey the instructions in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine	01

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
01	Does the task	Engine work area

I. Preparation

SUBTASK 841-002-A

**WARNING: MAKE SURE THE ENGINE START/STOP SWITCH IS IN THE “OFF” POSITION TO PREVENT AN ACCIDENTAL ENGINE OPERATION.**

- (1) On the circuit breaker panel, open these circuit breakers and attach DO-NOT-CLOSE tags to them:
- POWERPLANT START 1/2.



AIRCRAFT  
MAINTENANCE MANUAL

- (2) Open the lower cowling ( [AMM TASK 71-12-01-000-801-A/400](#)).

J. Removal

*SUBTASK 020-002-A*

- (1) Remove the compressor-acceleration-bleed control valve assembly. Refer to the latest revision of Rolls-Royce MM CSP 34022.



AIRCRAFT  
MAINTENANCE MANUAL

EMB145 – EMB135

TASK 75-31-02-400-801-A

EFFECTIVITY: PRE-MOD. S.B. AE3007A-75-019

3. COMPRESSOR-ACCELERATION-BLEED CONTROL VALVE ASSEMBLY - INSTALLATION

A. General

- (1) To install the compressor-acceleration-bleed control valve assembly, obey the instructions in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the work area	01

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
01	Does the task	Engine work area

I. Installation

**SUBTASK 420-002-A**

- (1) Install the compressor-acceleration-bleed control valve assembly. Refer to the latest revision of Rolls-Royce MM CSP 34022.

J. Follow-on

**SUBTASK 842-002-A**

- (1) Close the lower cowling ( [AMM TASK 71-12-01-400-801-A/400](#)).



AIRCRAFT  
MAINTENANCE MANUAL

- (2) Remove the workstand.
- (3) Remove the DO-NOT-CLOSE tags and close the applicable circuit breakers.
  - POWERPLANT START 1/2.

