



AIRCRAFT
MAINTENANCE MANUAL

ACCESSORY DRIVE GEAR BOX ASSEMBLY - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to do the inspection of the accessory-drive-gearbox assembly.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
72-63-01-200-801-A	ACCESSORY-DRIVE-GEARBOX ASSY - INSPECTION	ALL



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 72-63-01-200-801-A

EFFECTIVITY: ALL

2. ACCESSORY-DRIVE-GEARBOX ASSY - INSPECTION

A. General

- (1) Obey the instructions below to do the inspection of the accessory-drive-gearbox assembly.

B. References

REFERENCE	DESIGNATION
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
415		LH Engine
425		RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine fan assembly

I. Preparation

SUBTASK 841-002-A

- (1) Put the ladder next to the air intake.
- (2) Open the lower cowling ([AMM TASK 71-12-01-000-801-A/400](#)).



AIRCRAFT
MAINTENANCE MANUAL

J. Accessory-Drive-Gearbox Assy - GVI

SUBTASK 212-002-A

- (1) Do a visual inspection on the accessory drive gearbox assy. Refer to the latest revision of Rolls-Royce MM CSP 34022.

K. Follow-on

SUBTASK 842-002-A

- (1) Close the lower cowling ([AMM TASK 71-12-01-400-801-A/400](#)).
- (2) Remove the ladder.

