# Advanced Control Systems: RPP manipulator

# Filippo Grotto VR460638


## October 23, 2021

# **Contents**

1	Kin	ematics	2
	1.1	Direct Kinematics	2
	1.2	Inverse Kinematics	3
2	Jaco	bians	3
	2.1	obians Geometric Jacobians	3
	2.2	Analytical Jacobian	4
3	Ene	rgy	5
	3.1	<b>rgy</b> Potential Energy	5
	3.2	Kinetic Energy	5

## 1 Kinematics

#### 1.1 Direct Kinematics



Lets define the DH table for our manipulator:

$\sum_i$	$d_i$	$\theta_i$	$a_i$	$\alpha_i$
b-0	$\ell_0$	0	0	$\frac{\pi}{2}$
0 - 1	0	$\theta_1$	$\ell_1$	$\bar{0}$
1 - 2	$\ell_2 + d_2$	$\frac{\pi}{2}$	0	$\frac{\pi}{2}$
2 - 3	$\ell_3 + d_3$	$\frac{\pi}{2}$ $\frac{\pi}{2}$	0	$\bar{0}$
3-e	0	Ō	0	0

The homogenous transformation is defined according to the following matrix and calculated for each row of the DH table. By multiplying  $H_0^b H_1^0 H_2^1 H_3^2 H_e^3$  we obtain the final transformation

$$H_i^{i-1}(q_i) = egin{bmatrix} c_{ heta_i} & -s_{ heta_i}c_{lpha_i} & s_{ heta_i}s_{lpha_i} & a_ic_{ heta_i} \ s_{ heta_i} & c_{ heta_i}c_{lpha_i} & -c_{ heta_i}s_{lpha_i} & a_is_{ heta_i} \ 0 & s_{lpha_i} & c_{lpha_i} & d_i \ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$H_0^b = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & -1 & 0 \\ 0 & 1 & 0 & \ell_0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \qquad H_1^0(\theta_1) = \begin{bmatrix} c_1 & -s_1 & 0 & \ell_1 c_1 \\ s_1 & c_1 & 0 & \ell_1 s_1 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \qquad H_2^1(d_2) = \begin{bmatrix} 0 & 0 & 1 & 0 \\ 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & \ell_2 + \ell_2 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$H_3^2(d_3) = \begin{bmatrix} 0 & -1 & 0 & 0 \\ 1 & 0 & 0 & 0 \\ 0 & 0 & 1 & d_3 + l_3 \\ 0 & 0 & 0 & 1 \end{bmatrix} \qquad H_e^3 = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$H_e^b(q) = \begin{bmatrix} 0 & -s_1 & c_1 & c_1(\ell_1 + \ell_3 + d_3) \\ -1 & 0 & 0 & -\ell_2 - d_2 \\ 0 & -c_1 & s_1 & s_1(\ell_1 + \ell_3 + d_3) + \ell_0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

#### 1.2 Inverse Kinematics

Let's consider the position of ee with respect of the base frame to calculate the value of the joints.

$$p_e^b = \begin{bmatrix} x \\ y \\ z \end{bmatrix} = \begin{bmatrix} c_1(\ell_1 + \ell_3 + d_3) \\ -\ell_2 - d_2 \\ s_1(\ell_1 + \ell_3 + d_3) + \ell_0 \end{bmatrix}$$

It is easy to see that

$$d_2 = -\ell_2 - y$$

$$\theta_1 = Atan2(z - \ell_0, x)$$

For  $d_3$  we can apply sum of squares and the result is:

$$d_3 = -\ell_1 \pm \sqrt{x^2 + (z - \ell_0)^2} - \ell_3$$

## 2 Jacobians

#### 2.1 Geometric Jacobians

The geometric jacobian is defined as follow with  $q = [\theta_1, d_2, d_3]^{\top}$ . Note that the matlab robotic toolbox defines the angular velocities above the linear velocities:

$$\begin{bmatrix} \dot{p}_e \\ \omega_e \end{bmatrix} = \begin{bmatrix} \dot{x} \\ \dot{y} \\ \dot{z} \\ \omega_x \\ \omega_y \\ \omega_z \end{bmatrix} = \begin{bmatrix} J_{P_1} & J_{P_2} & J_{P_3} \\ J_{O_1} & J_{O_2} & J_{O_3} \end{bmatrix} \begin{bmatrix} \dot{\theta}_1 \\ \dot{d}_2 \\ \dot{d}_3 \end{bmatrix}$$

$$J_{P_1} = z_0 \times (d_e^0 - d_0^0) = \begin{bmatrix} -s_1(\ell_1 + \ell_3 + d_3) \\ 0 \\ c_1(\ell_1 + \ell_3 + d_3) \end{bmatrix} \qquad J_{O_1} = z_0 = \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix}$$

$$J_{P_2} = z_1 = \begin{bmatrix} 0 \\ -1 \\ 0 \end{bmatrix} \qquad J_{O_2} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

$$J_{P_3} = z_2 = \begin{bmatrix} c_1 \\ 0 \\ s_1 \end{bmatrix} \qquad J_{O_3} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

We can finally put all the pieces together and obtain the final geometric jacobian:

$$J(q) = \begin{bmatrix} -s_1(\ell_1 + \ell_3 + d_3) & 0 & c1\\ 0 & -1 & 0\\ c_1(\ell_1 + \ell_3 + d_3) & 0 & s1\\ 0 & 0 & 0\\ 0 & 0 & 0\\ 1 & 0 & 0 \end{bmatrix}$$

#### 2.2 Analytical Jacobian

The analytical jacobian can be easily calculated by using partial derivatives of  $p_e^b$ 

$$p_e^b = \begin{bmatrix} x \\ y \\ z \end{bmatrix} = \begin{bmatrix} c_1(\ell_1 + \ell_3 + d_3) \\ -\ell_2 - d_2 \\ s_1(\ell_1 + \ell_3 + d_3) + \ell_0 \end{bmatrix}$$

Finally we end up with the analytical jacobian

$$Ja(\mathbf{q}) = \begin{bmatrix} -s_1(\ell_1 + \ell_3 + d_3) & 0 & c1\\ 0 & -1 & 0\\ c_1(\ell_1 + \ell_3 + d_3) & 0 & s1\\ 1 & 0 & 0\\ 0 & 0 & 0\\ 0 & 0 & 0 \end{bmatrix}$$

Another possibility is to use the relation between the geometric and analytical jacobian as follow using ZYZ:

$$\omega_e = T(\phi_e)\dot{\phi}_e \qquad T(\phi_e) = \begin{bmatrix} 0 & -s_{\varphi} & c_{\varphi}s_{\theta} \\ 0 & c_{\varphi} & s_{\varphi}s_{\theta} \\ 1 & 0 & c_{\theta} \end{bmatrix}$$
$$J(\boldsymbol{q}) = T_A(\phi_e)J_A(\boldsymbol{q})$$
$$T_A(\phi_e) = \begin{bmatrix} \mathbb{I}_3 & \emptyset_3 \\ \emptyset_3 & T(\phi_e) \end{bmatrix}$$

## 3 Energy

Let's calculate  $p_{\ell_i}$  of the center of mass wrt of  $\Sigma_0$ . To get them let's calculate  $p_{\ell_i}^i$  of the center of mass wrt of  $\Sigma_i$ 

$$p_{\ell_1}^1 = \begin{bmatrix} -\frac{\ell_1}{2} \\ 0 \\ 0 \end{bmatrix} \qquad p_{\ell_2}^2 = \begin{bmatrix} 0 \\ 0 \\ -\frac{\ell_2}{2} \end{bmatrix} \qquad p_{\ell_3}^3 = \begin{bmatrix} 0 \\ 0 \\ -\frac{\ell_3}{2} \end{bmatrix}$$

we can express the homogenous wrt of  $\Sigma_0$  using the following formula:

$$p_{\ell_i} = R_i^0 p_{\ell_i}^i + d_i^0$$

#### 3.1 Potential Energy

The potential energy is calculated according to the formula:

$$U_i = -m_{l_i} g_0^T p_{l_i}$$
  $g_0 = \begin{bmatrix} 0 \\ 0 \\ -g \end{bmatrix}$ 

The total potential energy is the sum of the 3 contributions  $U_1$   $U_2$  and  $U_3$ . The total expression is reported and was calculated using the MATLAB symbolic toolbox ( $L_{ih}$  is the length of i-th link and  $m_i$  is the mass)

$$U = \frac{-gsin(\theta_1)(L_{1h}m_1 + 2L_{1h}m_2 + 2L_{1h}m_3 + L_{3h}m_3 + 2d_3m_3)}{2}$$

#### 3.2 Kinetic Energy

The kinetic energy is calculated using the following formula:

$$\mathcal{T}(\boldsymbol{q}, \dot{\boldsymbol{q}}) = \frac{1}{2} \dot{\boldsymbol{q}}^{\top} B(\boldsymbol{q}) \dot{\boldsymbol{q}}$$

$$B(\boldsymbol{q}) = \sum_{i=1}^{n} B_i(\boldsymbol{q}) = \sum_{i=1}^{n} m_{\ell_i} (J_P^{\ell_i}^{\top} J_P^{\ell_i}) + (R_i^{0}^{\top} J_O^{\ell_i})^{\top} I_{\ell_i}^i (R_i^{0}^{\top} J_O^{\ell_i})$$

It is necessary to calculate the inertia tensors  $I^i_{\ell_i}$  and the partial jacobians  $J^{\ell_i}_P$  and  $J^{\ell_i}_O$ . We will use the steiner theorem because all frames  $\Sigma_i$  are translated of  $p^i_{\ell_i}$  w.r.t. of the center of mass (i.e inertia tensor w.r.t. of the axis of the joint that the link is attached).

$$I_{\ell_1}^1 = I_{\ell_1}^{C_1} + m_{\ell_1} S^T(r) S(r) = I_{\ell_1}^{C_1} + m_{\ell_1} (r^\top r \mathbb{I}_{3,3} - rr^\top)$$

For the inertia tensors we can use the following formulas for the cylindrical and prismatic links considering that the prismatic links have a square base.

$$I_{cylinder}^{C} = \frac{1}{2} \begin{bmatrix} m(a^2 + b^2) & 0 & 0\\ 0 & m(3(a^2 + b^2)^2 + h^2) & 0\\ 0 & 0 & m(3(a^2 + b^2)^2 + h^2) \end{bmatrix}$$

$$I_{prismatic}^{C} = \frac{1}{12} \begin{bmatrix} m(b^2 + c^2) & 0 & 0\\ 0 & m(a^2 + c^2)^2 & 0\\ 0 & 0 & m(a^2 + b^2) \end{bmatrix}$$

Finally we need to compute the partial jacobians in order to calculate velocity of intermediate links.

$$J_{P_j}^{\ell_i} = \begin{cases} z_{j-1} & \text{prismatic joint} \\ z_{j-1} \times (p_{l_i} - p_{j-1}) & \text{revolute joint} \end{cases} \qquad J_{O_j}^{\ell_i} = \begin{cases} 0 & \text{prismatic joint} \\ z_{j-1} & \text{revolute joint} \end{cases}$$

In our case the computer partial jacobians are:

$$J_{P}^{\ell_{1}} = \begin{bmatrix} -\ell_{1}sin(\theta_{1})/2 & 0 & 0 \\ \ell_{1}cos(\theta_{1})/2 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix} \qquad J_{P}^{\ell_{2}} = \begin{bmatrix} \ell_{2}cos(\theta_{1})/2 - \ell_{1}sin(\theta_{1}) & 0 & 0 \\ \ell_{1}cos(\theta_{1}) + (\ell_{2}sin(\theta_{1}))/2 & 0 & 0 \\ 0 & 1 & 0; \end{bmatrix}$$

$$J_{P}^{\ell_{3}} = \begin{bmatrix} -sin(\theta_{1})(\ell_{1} + \ell_{3}h/2 + d_{3}) & 0 & cos(\theta_{1}) \\ cos(\theta_{1})(\ell_{1} + \ell_{3}h/2 + d_{3}) & 0 & sin(\theta_{1}) \\ 0 & 1 & 0 \end{bmatrix} \qquad J_{O_{j}}^{\ell_{1}} = J_{O_{j}}^{\ell_{2}} = J_{O_{j}}^{\ell_{3}} = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & 0 \\ 1 & 0 & 0 \end{bmatrix}$$

$$B(\mathbf{q}) = B_{1}(\mathbf{q}) + B_{2}(\mathbf{q}) + B_{3}(\mathbf{q})$$

Finally we can recover the kinetic energy using the calculated  $B(\mathbf{q})$  and  $\dot{\mathbf{q}}$ .