IoT Engineering 5: Local Connectivity with Bluetooth LE

CC BY-SA, Thomas Amberg, FHNW (unless noted otherwise)
Slides: tmb.gr/iot-5

Overview

These slides introduce Bluetooth Low Energy.

Examples for the peripheral and central role.

Designing BLE services and characteristics.

Prerequisites


Install the Arduino IDE and set up the nRF52840:

Check the Wiki entry on Installing the Arduino IDE.

Set up the Feather nRF52840 Express for Arduino.


Setting up the board also installs this BLE library.

For testing, a smartphone with BLE is required.





BLE reference model





Bluetooth Low Energy (BLE)

BLE is a power-efficient Bluetooth variant (since 4.0).

BLE is well suited for small, battery powered devices.

It uses less energy than Wi-Fi and way less than 4/5G.

Range is ~30 m, data rate 1 Mbps, frequency 2.4 GHz.

The standard is maintained by the Bluetooth SIG.

How BLE works

Peripherals advertise the data they have, over the air.

Centrals scan for nearby peripherals to discover them.

The central connects to a peripheral and uses its data.

Data is structured into services and characteristics.

BLE protocol stack

Application — application specific code and formats BLE library — thin, language-specific wrapper library

GATT — services & characteristics | GAP — discovery ATT — attribute transport | SMP — security manager L2CAP — logical link control and adaptation protocol

Link layer — exposed via the host controller interface Physical layer — dealing with actual radio signals

Generic Access Profile (GAP)

GAP defines the following roles, communication types:

Broadcaster and observer (connectionless, one-way).

Peripheral and central (bidirectional connection).


Each device supports one or more of these roles.

We start with peripheral and central roles.

Advertising

A peripheral *advertises* its services by broadcast, in a regular interval.

A central *scans* for all or a subset of services and gets device addresses and, if it's been sent, advertised data.



Attribute Transport (ATT)

ATT allows a *client* to access attributes on a *server*.

An attribute has a handle, a UUID and permissions.

An attribute handle is a server-assigned, 16-bit ID.

A *UUID* is a 16/128-bit universally unique identifier.

Permissions allow you to read, write or get notified.

See Bluetooth spec v5.1, Part F, p. 2288.

Generic Attribute Profile (GATT)

GATT is a simple application level protocol for BLE.


It's connection-based, with a *client* and a *server* role.

This enables a BLE device to provide a RESTful API.


A "GATT API", or *profile*, is a collection of *services*.

Usually, the peripheral acts as a server.

BLE



HTTP





Services

A GATT service is a collection of characteristics.

Services encapsulate the behavior of part of a device.

In addition, such a service can refer to other services.

There are standard and custom services and profiles.

E.g. the Battery Service or the Heart Rate Service.

Characteristics

A GATT characteristic has a value and descriptors.

A value encodes data "bits" that form a logical unit.

Descriptors are defined attributes of a characteristic.

Supported procedures: read, write and notifications.

E.g. a Battery Level or a Heart Rate Measurement.

Descriptors

A GATT descriptor describes a characteristic value.

E.g. Presentation Format or Valid Range descriptor.

Descriptors also allow to configure characteristics.


E.g. Client Characteristic Configuration descriptor allows a client to enable or disable notifications.

Read and write

Connect = the central connects to a peripherals BLE address.

Read = value of a characteristic or its descriptors is returned.

Write = characteristic value, or characteristic descriptor value is set, with/without response.



Notifications

Notify = Client Characteristic Configuration descriptor of a characteristic, UUID 0x2902, is set to 0x0001 using Write.

Value = A *Handle Value Notification* is sent if value changes. Peripheral Connect Value Value

See Bluetooth spec v5.1, p. 2360 and p. 2389.

BLE explorer apps


For debugging, use any generic BLE explorer app:

Find BLE explorer apps on the Google Play Store.

Search for "BLE explorer" in the iOS App Store.

Smartphones can act as central or peripheral.

Exploring is a great way to learn about BLE.



Heart rate service

This service is intended for fitness heart rate sensors:

Heart Rate Service UUID (16-bit): 0x180D

This service includes the following characteristics:

Heart Rate Measurement UUID: 0x2A37 [N]

Body Sensor Location UUID: 0x2A38 [R]

Heart Rate Control Point UUID: 0x2A39 [W]*

^{*}See also Heart Rate Service specification.

nRF52840 HRM BLE peripheral .inc

```
hrmSvc = BLEService(0x180D); // See HRM spec
hrmChr = BLECharacteristic(0x2A37); // See spec
hrmSvc.begin(); // to add characteristics
hrmChr.setProperties(CHR_PROPS_NOTIFY); ...
hrmChr.begin(); // adds characteristic
uint8_t hrmData[2] = { 0b00000110, value };
hrmChr.notify(hrmData, sizeof(hrmData));
```

Hands-on, 10': HRM BLE peripheral

Build and run the previous nRF52840 BLE example.

Use the .ino link on the page to get the example code.

Explore the HRM example using a smartphone app*.

Try to enable notifications to get value updates.

Nordic UART service

This service provides a serial connection over BLE:

Nordic UART Service custom (128-bit) UUID:

0x6E40**0001**-B5A3-F393-E0A9-E50E24DCCA9E

This service includes the following characteristics:

RX (device receives data) UUID: 0x0002 [W]

TX (device transmits data) UUID: 0x0003 [N]

This service is becoming a de facto standard.

nRF52840 UART BLE peripheral .ino

```
// UUID: 6E400001-B5A3-F393-E0A9-E50E24DCCA9E
uint8_t const uartSvcUuid[] = \{ 0x9E, 0xCA, ...,
0xB5, 0x01, 0x00, 0x40, 0x6E }; // lsb first
uartSvc = BLEService(uartSvcUuid); // 128-bit
rxChr = BLECharacteristic(rxChrUuid); // 128-b.
txChr = BLECharacteristic(txChrUuid); // 128-b.
txChar.setProperties(CHR_PROPS_NOTIFY);
rxChar.setProperties(CHR_PROPS_WRITE);
```

Hands-on, 10': UART BLE peripheral

Build and run the previous nRF52840 BLE example.

Use the .ino link on the page to get the example code.

Write bytes to RX with a generic BLE explorer app.

Check the serial monitor to see the received bytes*.

nRF52840 UART BLE central

.ino

```
Bluefruit.begin(0, 1); // 1 central connection
uartSvcClient.begin();
uartSvcClient.setRxCallback(rxCbck); // read
Bluefruit.Central.setConnectCallback(connCbck);
void connCbck(uint16_t connHandle) {
  if (uartSvcClient.discover(connHandle)) {
    uartSvcClient.enableTXD(); // enable notify
    uartServiceClient.print(...); // write data
```

nRF52840 UART BLE central (ff.) .ino

```
Bluefruit.Scanner.setRxCallback(found);
void found(ble_gap_evt_adv_report_t* report) {
  if (....Scanner.checkReportForService(
    report, uartServiceClient)) {
    Bluefruit.Central.connect(report);
  } else {
    Bluefruit.Scanner.resume();
```

Hands-on, 10': UART BLE central

Build and run the previous nRF52840 BLE example.

Use the .ino link on the page to get the example code.

Open the Arduino serial monitor to enter a message.

Use a second nRF52840 as a UART peripheral.

Beacons

Beacons, e.g. Apple iBeacon are broadcaster devices.

Any observer can read the data which they advertise.

Lookup of "what a beacon means" requires an app.

Except for Physical Web / Eddystone beacons.

These contain an URL to be used right away.

nRF52840 beacon BLE observable .inc

```
BLEBeacon beacon(
  beaconUuid, // AirLocate UUID
  beaconMajorVersion,
  beaconMinorVersion,
  rssiAtOneMeter);
beacon.setManufacturer(0x004C); // Apple
startAdvertising();
suspendLoop(); // save power
```

Hands-on, 10': Beacons

Build and run the previous nRF52840 BLE example.

Use the .ino link on the page to find the source code.

Test the beacon with a dedicated iOS/Android app.

Which information is transferred by a beacon?

Start a scan in a public place, e.g. Zürich HB.

nRF52840 Scanner BLE Central .

```
Bluefruit.begin(0, 1); // Central
Bluefruit.Scanner.setRxCallback(found);
Bluefruit.Scanner.start(0);
void found(ble_gap_evt_adv_report_t* report) {
  Serial.printBufferReverse( // little endian
    report->peer_addr.addr, 6, ':');
  if (Bluefruit.Scanner.checkReportForUuid(...))...
  Bluefruit.Scanner.resume();
```

Hands-on, 10': Scanner BLE Central

- Build and run the previous nRF52840 BLE example.
- Use the .ino link on the page to find the source code.
- Add a checkReportForUuid() for the Battery Service.
- Can you spot the UUID in the advertising data?

Security


- BLE has security mechanisms for pairing and more.
- Pairing: exchanging identity and keys to set up trust.
- Device chooses Just Works, Passkey Entry or OOB.
- Or numeric comparison and ECDH for key exchange.
- Some apps add encryption on the application layer.

Device API vs. SDK

A device API specifies how to talk to the device, from any client (here via BLE).

A platform specific *device SDK* simplifies integration.

E.g. *iOS device SDK* to talk to a device API from iOS.



```
Battery Service
  Battery Level [R]

vs.

p = ble.conn(addr);
b = sdk.getBatt(p);
x = b.getLevel();
```

BLE on Android

There is an official introduction to BLE on Android.

Building a robust BLE app on Android can be tricky.

Use the Nordic Semiconductor Android-BLE-Library.

As an example app, look at the nRF Toolbox project.

Writing a plugin for nRF Toolbox is a good start.

BLE on iOS

On iOS the official BLE library is Core Bluetooth.

Its documentation is a great introduction to BLE.

In iOS there's no way to get a device BLE address.

Instead, a UUID is assigned, as a handle, by iOS.

iOS devices change their Bluetooth MAC address.

BLE on Raspberry Pi

On Raspberry Pi Zero W there are many options, e.g.

Node.js libraries: Noble (central), Bleno (peripheral)

Python library: PyBluez, BluePy

Linux C library: Bluez

CLI: bluetoothctl

Summary

BLE provides low power, personal area connectivity.

A BLE central scans for peripherals, who advertise.

Each BLE peripheral provides one or more services.

Services allow to read/write characteristic values.

Descriptors allow to configure notifications.

Next: Raspberry Pi as a Local Gateway.

Challenge, 1h+

Design and implement an API for the DHT11 sensor.

Create UUIDs for your service and its characteristics.

Allow the central to read temperature and humidity.

Chose a data format that fits the sensor value range.

Test your peripheral with a generic BLE explorer.

Done? Consider adding support for notifications.

Feedback or questions?

Write me on https://fhnw-iot.slack.com/

Or email thomas.amberg@fhnw.ch

Thanks for your time.