




CS 5541 – Computer Systems

"Based on lecture notes developed by Randal E. Bryant and David R. O'Hallaron in conjunction with their textbook "Computer Systems: A Programmer's Perspective"



Module 2

Machine Code

Part 1 — Basics

From: Computer Systems, Chapter 3

Instructor: James Yang

https://cs.wmich.edu/~zijiang

zijiang.yang@wmich.edu

Intel x86 Processors

Dominate laptop/desktop/server market

Evolutionary design

- Backwards compatible up until 8086, introduced in 1978
- Added more features as time goes on

Complex instruction set computer (CISC)

- Many different instructions with many different formats
 - But only small subset encountered with Linux programs
- Hard to match performance of Reduced Instruction Set Computers (RISC)
- But, Intel has done just that!
 - In terms of speed. Less so for low power.

Intel x86 Evolution: Milestones

Name Date Transistors MHz


• 8086 1978 29K 5-10

- First 16-bit Intel processor. Basis for IBM PC & DOS
- 1MB address space
- 386 1985 275K 16-33
 - First 32 bit Intel processor, referred to as IA32
 - Added "flat addressing", capable of running Unix
- Pentium 4E 2004 125M 2800-3800
 - First 64-bit Intel x86 processor, referred to as x86-64
- Core 2 2006 291M 1060-3500
 - First multi-core Intel processor
- Core i7 2008 731M 1700-3900
 - Four cores (our shark machines)

Definitions

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
 - Examples: instruction set specification, registers.
- Microarchitecture: Implementation of the architecture.
 - Examples: cache sizes and core frequency.
- Code Forms:
 - Machine Code: The byte-level programs that a processor executes
 - Assembly Code: A text representation of machine code
- Example ISAs:
 - Intel: x86, IA32, Itanium, x86-64
 - ARM: Used in almost all mobile phones

Assembly/Machine Code View



Programmer-Visible State


- PC: Program counter
 - Address of next instruction
 - Called "RIP" (x86-64)
- Register file
 - Heavily used program data
- Condition codes
 - Store status information about most recent arithmetic or logical operation
 - Used for conditional branching

Memory

- Byte addressable array
- Code and user data
- Stack to support procedures

Turning C into Object Code

- Code in files p1.c p2.c
- Compile with command: gcc -Og p1.c p2.c -o p
 - Use basic optimizations (**-Og**) [New to recent versions of GCC]
 - Put resulting binary in file p



Compiling Into Assembly

C Code (sum.c)

Generated x86-64 Assembly

```
sumstore:
   pushq %rbx
   movq %rdx, %rbx
   call plus
   movq %rax, (%rbx)
   popq %rbx
   ret
```

Obtain with command

Produces file sum.s

Warning: Will get very different results on different machines (Andrew Linux, Mac OS-X, ...) due to different versions of gcc and different compiler settings.

Assembly Characteristics: Data Types

- "Integer" data of 1, 2, 4, or 8 bytes
 - Data values
 - Addresses (untyped pointers)
- Floating point data of 4, 8, or 10 bytes
- Code: Byte sequences encoding series of instructions
- No aggregate types such as arrays or structures
 - Just contiguously allocated bytes in memory

Assembly Characteristics: Operations

- Perform arithmetic function on register or memory data
- Transfer data between memory and register
 - Load data from memory into register
 - Store register data into memory
- Transfer control
 - Unconditional jumps to/from procedures
 - Conditional branches

Object Code

Code for sumstore

0x0400595:0x530x480x890xd30xe8 0xf20xff 0xff 0xff Total of 14 bytes 0x48 Each instruction 0x891, 3, or 5 bytes 0x03

Starts at address

 0×0400595

0x5b

0xc3

Assembler

- Translates .s into .o
- Binary encoding of each instruction
- Nearly-complete image of executable code
- Missing linkages between code in different files

Linker

- Resolves references between files
- Combines with static run-time libraries
 - E.g., code for malloc, printf
- Some libraries are dynamically linked
 - Linking occurs when program begins execution

Machine Instruction Example

*dest = t;

movq %rax, (%rbx)

0x40059e: 48 89 03

• C Code

Store value t where designated by dest

Assembly

- Move 8-byte value to memory
 - Quad words in x86-64 parlance
- Operands:

t: Register %rax

dest: Register %rbx

*dest: Memory M[%rbx]

Object Code

- 3-byte instruction
- Stored at address 0x40059e

Disassembling Object Code

Disassembled

```
0000000000400595 <sumstore>:
 400595:
          53
                                 %rbx
                          push
 400596: 48 89 d3
                                 %rdx,%rbx
                          mov
 400599: e8 f2 ff ff ff
                          callq
                                 400590 <plus>
 40059e: 48 89 03
                                 %rax, (%rbx)
                          mov
 4005a1:
          5b
                                 %rbx
                          pop
 4005a2: c3
                          reta
```

Disassembler

```
objdump -d sum
```

- Useful tool for examining object code
- Analyzes bit pattern of series of instructions
- Produces approximate rendition of assembly code
- Can be run on either a .out (complete executable) or .o file

Alternate Disassembly

Object

Disassembled

```
0 \times 0400595:
    0x53
    0 \times 48
    0x89
    0xd3
    0xe8
    0xf2
    0xff
    0xff
    0xff
    0 \times 48
    0x89
    0x03
    0x5b
    0xc3
```

```
Dump of assembler code for function sumstore:
    0x0000000000400595 <+0>: push %rbx
    0x000000000400596 <+1>: mov %rdx,%rbx
    0x0000000000400599 <+4>: callq 0x400590 <plus>
    0x000000000040059e <+9>: mov %rax,(%rbx)
    0x00000000004005a1 <+12>:pop %rbx
    0x00000000004005a2 <+13>:retq
```

Within gdb Debugger

```
gdb sum
disassemble sumstore
```

Disassemble procedure

```
x/14xb sumstore
```

Examine the 14 bytes starting at sumstore

What Can be Disassembled?

```
% objdump -d WINWORD.EXE
WINWORD.EXE: file format pei-i386
No symbols in "WINWORD.EXE".
Disassembly of section .text:
30001000 < text>:
30001000:
30001001:
               Reverse engineering forbidden by
30001003:
             Microsoft End User License Agreement
30001005:
3000100a:
```

- Anything that can be interpreted as executable code
- Disassembler examines bytes and reconstructs assembly source

x86-64 Integer Registers

%rax	%eax	% r8	%r8d
%rbx	%ebx	%r9	%r9d
%rcx	%ecx	%r10	%r10d
%rdx	%edx	%r11	%r11d
%rsi	%esi	%r12	%r12d
%rdi	%edi	%r13	%r13d
%rsp	%esp	%r14	%r14d
%rbp	%ebp	%r15	%r15d

• Can reference low-order 4 bytes (also low-order 1 & 2 bytes)

Moving Data

Moving Data
 movq Source, Dest:

Operand Types

- *Immediate:* Constant integer data
 - Example: \$0x400, \$-533
 - Like C constant, but prefixed with `\$'
 - Encoded with 1, 2, or 4 bytes
- *Register:* One of 16 integer registers
 - Example: %rax, %r13
 - But %**rsp** reserved for special use
 - Others have special uses for particular instructions
- *Memory:* 8 consecutive bytes of memory at address given by register
 - Simplest example: (%rax)
 - Various other "address modes"

%rax %rcx %rdx %rbx %rsi %rdi %rsp %rbp

%rN

mov1 Operand Combinations

```
Dest
                                                                                   Src,Dest
                                                                                                                    C Analog
                                        Source
| Imm | Reg movq $0x4,%rax temp = 0x4; | Mem movq $-147,(%rax) *p = -147; | Reg | Reg movq %rax,%rdx temp2 = temp1; | Mem movq %rax,(%rdx) *p = temp; | Mem Reg movq (%rax),%rdx temp = *p;
```

Cannot do memory-memory transfer with a single instruction

Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```


- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

Example of Simple Addressing Modes

```
void swap
   (long *xp, long *yp)
{
   long t0 = *xp;
   long t1 = *yp;
   *xp = t1;
   *yp = t0;
}
```

void swap (long *xp, long *yp) { long t0 = *xp; long t1 = *yp; *xp = t1; *yp = t0; } %rdi %rax %rax %rdx




Memory

Value
хр
ур
t0
t1

Registers


%rdi	0x120
%rsi	0x100
%rax	
%rdx	

Memory




swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```




swap:


```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```



```
swap:
  movq     (%rdi), %rax # t0 = *xp
  movq     (%rsi), %rdx # t1 = *yp
  movq     %rdx, (%rdi) # *xp = t1
  movq     %rax, (%rsi) # *yp = t0
  ret
```



```
swap:
  movq     (%rdi), %rax # t0 = *xp
  movq     (%rsi), %rdx # t1 = *yp
  movq     %rdx, (%rdi) # *xp = t1
  movq     %rax, (%rsi) # *yp = t0
  ret
```



Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```

- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

Complete Memory Addressing Modes

Most General Form

D(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]+D]

• D: Constant "displacement" 1, 2, or 4 bytes

• Rb: Base register: Any of 16 integer registers

• Ri: Index register: Any, except for %rsp

• S: Scale: 1, 2, 4, or 8 (*why these numbers?*)

Special Cases

(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]]

D(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]+D]

(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]]

Address Computation Examples

%rdx	0xf000
%rcx	0x0100

Expression	Address Computation	Address
0x8(%rdx)	0xf000 + 0x8	0xf008
(%rdx,%rcx)	0xf000 + 0x100	0xf100
(%rdx,%rcx,4)	0xf000 + 4*0x100	0xf400
0x80(,%rdx,2)	2*0xf000 + 0x80	0x1e080

Address Computation Instruction

- leaq Src, Dst
 - Src is address mode expression
 - Set Dst to address denoted by expression

Uses

- Computing addresses without a memory reference
 - E.g., translation of p = &x[i];
- Computing arithmetic expressions of the form x + k*y
 - k = 1, 2, 4, or 8

Example

```
long m12(long x)
{
   return x*12;
}
```

Converted to ASM by compiler:

```
leaq (%rdi,%rdi,2), %rax # t <- x+x*2
salq $2, %rax # return t<<2</pre>
```

Some Arithmetic Operations

Two Operand Instructions:

Format	Computation		
addq	Src,Dest	Dest = Dest + Src	
subq	Src,Dest	Dest = Dest – Src	
imulq	Src,Dest	Dest = Dest * Src	
salq	Src,Dest	Dest = Dest << Src	Also called shlq
sarq	Src,Dest	Dest = Dest >> Src	Arithmetic
shrq	Src,Dest	Dest = Dest >> Src	Logical
xorq	Src,Dest	Dest = Dest ^ Src	
andq	Src,Dest	Dest = Dest & Src	
orq	Src,Dest	Dest = Dest Src	

- Watch out for argument order!
- No distinction between signed and unsigned int (why?)

Some Arithmetic Operations

One Operand Instructions

incq	Dest	Dest = Dest + 1
decq	Dest	Dest = Dest - 1
negq	Dest	Dest = – Dest
notq	Dest	Dest = ~Dest

See book for more instructions

Arithmetic Expression Example

```
long arith
(long x, long y, long z)
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
```

```
arith:
  leaq (%rdi,%rsi), %rax
  addq %rdx, %rax
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx
  leaq 4(%rdi,%rdx), %rcx
  imulq %rcx, %rax
  ret
```

Interesting Instructions

- **leaq**: address computation
- salq: shift
- **imulq**: multiplication
 - But, only used once

Understanding Arithmetic Expression Example

```
long arith
(long x, long y, long z)
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
```

```
arith:
  leaq (%rdi,%rsi), %rax # t1
  addq %rdx, %rax # t2
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx # t4
  leaq 4(%rdi,%rdx), %rcx # t5
  imulq %rcx, %rax # rval
  ret
```

Register	Use(s)
%rdi	Argument x
%rsi	Argument y
%rdx	Argument z
%rax	t1, t2, rval
%rdx	t4
%rcx	t5



Module 2 (Part 1) Summary

History of Intel processors and architectures

Evolutionary design leads to many quirks and artifacts

C, assembly, machine code

- New forms of visible state: program counter, registers, ...
- Compiler must transform statements, expressions, procedures into low-level instruction sequences

Assembly Basics: Registers, operands, move

 The x86-64 move instructions cover wide range of data movement forms

Arithmetic

• C compiler will figure out different instruction combinations to carry out computation