## Quick Incompact3d guide and notes

This is a quick guide on to how to use **Incompact3d** and to know some details of its functioning.

## Compiling

It is suggested to create a *build* directory in the same folder of the solver.

In the build directory run

After that, the *makefile* will be created. It is now possibly to compile the binary file in the build directory with the following command:

where n is the number of processors that will be used to compile the program.

## **Basic functioning**

In this section, the main features of the code that can be useful to run simulations are reported.

In Incompact3d:

- 1. Dimensional NS equations are solved.
- 2. The Re specified in the input file is in general used to compute the kinematic viscosity as

$$\nu = \frac{1}{Re}$$

so we are assuming unitary reference length and velocity scales. In case of a channel flow simulation, if constant pressure gradient (CPG) option is enabled, a different way to calculate  $\nu$  is adopted (see the parameters.f90 file, Re is based on the centerline velocity of a Poiseuille flow).

- 3. For a channel flow, the domain dimensions are normalized by the channel half-height h.
- 4. To evaluate the stretching parameter for the mesh  $\beta$ , a Fortran program is given in the folder *utilities*.