



# Technical Safety Concept Lane Assistance

**Document Version:** [Version]

Template Version 1.0, Released on 2017-06-21



## **Document history**

[Instructions: Fill in the date, version and description fields. You can fill out the Editor field with your name if you want to do so. Keep track of your editing as if this were a real world project.

For example, if this were your first draft or first submission, you might say version 1.0. If this is a second submission attempt, then you'd add a second line with a new date and version 2.0]

Date	Version	Editor	Description
03/10/18	1.0	Franz Pucher	First attempt

### **Table of Contents**

[Instructions: We have provided a table of contents. If the table of contents is not showing up correctly in your word processor of choice, please update it. The table of contents should show each section of the document and page numbers or links. Most word processors can do this for you. In <u>Google Docs</u>, you can use headings for each section and then go to Insert > Table of Contents. <u>Microsoft Word</u> has similar capabilities]

**Document history** 

**Table of Contents** 

Purpose of the Technical Safety Concept

Inputs to the Technical Safety Concept

**Functional Safety Requirements** 

Refined System Architecture from Functional Safety Concept

#### Functional overview of architecture elements

**Technical Safety Concept** 

**Technical Safety Requirements** 

Refinement of the System Architecture

Allocation of Technical Safety Requirements to Architecture Elements

Warning and Degradation Concept

## Purpose of the Technical Safety Concept

[Instructions: Answer what is the purpose of a technical safety concept?]

The functional safety concept identifies new requirements and allocates these requirements to system diagrams. The functional safety concept looks at the general functionality of the item.

## Inputs to the Technical Safety Concept

### **Functional Safety Requirements**

[Instructions: Provide the functional safety requirements derived in the functional safety concept ]

ID	Functional Safety Requirement	A S I L	Fault Tolerant Time Interval	Safe State
Functional Safety Requirement 01-01	The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude	С	50 ms	Vibration torque is below Max_Torque_Am plitude
Functional Safety Requirement 01-02	The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency	С	50 ms	Vibration torque is below Max_Torque_Fre quency
Functional Safety Requirement 02-01	The electronic power steering ECU shall ensure that the lane keeping assistance torque is applied for only Max_Duration	В	50 ms	Lane Keeping Assistance torque is zero.

## Refined System Architecture from Functional Safety Concept

CAMERA SUBSYSTEM

CAMERA SENSOR

QM

CAR DISPLAY

CAR DISPLAY

ELECTRONIC POWER STEERING SUBSYSTEM

ASIL C

CAMERA SENSOR

CAR DISPLAY

[Instructions: Provide the refined system architecture from the functional safety concept]


### Functional overview of architecture elements

[Instructions: Provide a description for each functional safety element; what is each element's purpose in the lane assistance item?]

Element	Description
Camera Sensor	Capture road images and provide them to the Camera Sensor ECU.
Camera Sensor ECU - Lane Sensing	Software module detecting the lane line positions from the Camera Sensor images.

Camera Sensor ECU - Torque request generator	Software module calculating the necessary torque to be requested to the Electronic Power Steering ECU.
Car Display	Display warning for the driver.
Car Display ECU - Lane Assistance On/Off Status	Indicate the status of the Lane Assistance functionality (On/Off).
Car Display ECU - Lane Assistant Active/Inactive	Indicate the status of the Lane Assistance functionality (Active/Inactive).
Car Display ECU - Lane Assistance malfunction warning	Indicate a malfunction of the Lane Assistance functionality.
Driver Steering Torque Sensor	Measures the torque applied to the steering wheel by the driver.
Electronic Power Steering (EPS) ECU - Driver Steering Torque	Software module receiving the driver's torque request from the steering wheel.
EPS ECU - Normal Lane Assistance Functionality	Software module receiving the Camera Sensor ECU torque request.
EPS ECU - Lane Departure Warning Safety Functionality	Software module ensuring the torque amplitude is below Max_Torque_Amplitude and torque frequency is below Max_Torque_Frequency.
EPS ECU - Lane Keeping Assistant Safety Functionality	Software module ensuring the Lane Keeping Assistance funcionalitz application is not active more than Max_duration time.
EPS ECU - Final Torque	Combine the torque request from the Lane Keeping and Lane Departure Warning functionalities and sends them to the Motor.
Motor	Applies the required torque to the steering wheel.

## **Technical Safety Concept**



## **Technical Safety Requirements**

[Instructions: Fill in the technical safety requirements for the lane departure warning first functional safety requirement. We have provided the associated functional safety requirement in the first table below. Hint: The technical safety requirements were discussed in the lesson videos. The architecture allocation column should contain element names such as LDW Safety block, Data Transmission Integrity Check, etc. Allocating the technical safety requirements to the "EPS ECU" does not provide enough detail for a technical safety concept.]

#### Lane Departure Warning (LDW) Requirements:

Functional Safety Requirement 01-01 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
----	-------------------------------	--	---------------	--------------------

Functional Safety Requirement 01-01	The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude	х		
--	---	---	--	--

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

ID	Technical Safety Requirement	A S I	Fault Tolerant Time	Architecture Allocation	Safe State
Technical Safety Requirem ent 01	The Lane Departure Warning safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.'	C	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 02	When the Lane Departure Warning is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 03	When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 05	Memory test shall be conducted at start up of the EPS ECU to check for any memory problems	Α	Ignition cycle	Data Transmission Integrity Check	Lane Departure Warning torque to zero.

[Instructions: Fill in the technical safety requirements for the lane departure warning second functional safety requirement. We have provided the associated functional safety requirement in the table below. Hint:. Most of the technical safety requirements will be the same. At least one technical safety requirement will have to be slightly modified because we are talking about frequency instead of amplitude. These requirements were not given in the lessons]

Functional Safety Requirement 01-2 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
Functional Safety Requirement 01-02	The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency	X		

Technical Safety Requirements related to Functional Safety Requirement 01-02 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architecture Allocation	Safe State
Technical Safety Requirement 01	The LDW safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.
Technical Safety Requirement 02	As soon as the LDW function deactivates the LDW feature, the 'LDW Safety' software block shall send a signal to the car display	С	50 ms	LDW Safety	Lane Departu re Warning

	ECU to turn on a warning light.				torque to zero.
Technical Safety Requirement 03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the 'LDW_Torque_Request' shall be set to zero.	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.
Technical Safety Requirement 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.
Technical Safety Requirement 05	Memory test shall be conducted at start up of the EPS ECU to check for any faults in memory.	A	Ignition cycle	LDW Safety	Lane Departu re Warning torque to zero.

#### Lane Departure Warning (LDW) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

#### Lane Keeping Assistance (LKA) Requirements:

[Instructions: Fill in the technical safety requirements for the lane keeping assistance functional safety requirement 02-01. We have provided the associated functional safety requirement in the table below. Hint:. You can reuse the technical safety requirements from functional safety requirement 01-01. But you need to change the language because

we are now looking at a different system. The ASIL and Fault Tolerant Time Interval are different as well.]

Functional Safety Requirement 02-1 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
Functional Safety Requirement 02-01	The lane keeping item shall ensure that the lane keeping assistance torque is applied for only Max_Duration	X		

Technical Safety Requirements related to Functional Safety Requirement 02-01 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 01	The Lane Keeping Assistance safety component shall ensure the duration of the lane keeping assistance torque is applied for less than Max_Duration	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical Safety Requireme nt 02	When the Lane Keeping Assistance function deactivates, the 'LKA Safety' shall send a signal to the Car Display ECU to turn on a warning light.	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical Safety Requireme nt 03	When a failure is detected, the Lane Keeping Assistance function shall deactivate and the 'LKA_Torque_Request' shall be zero.	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical Safety Requireme nt 04	The validity and integrity of the data transmission for 'LKA_Torque_Request' signal shall be ensured.	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.


Memory test shall be conducted at start up of the EPS ECU to check for any memory problems.	A	Ignition Cycle	Data Transmission Integrity Check	Lane Keeping Assistance torque to zero.	
---	---	-------------------	-----------------------------------	---	--

### Lane Keeping Assistance (LKA) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

### Refinement of the System Architecture

[Instructions: Include the refined system architecture. Hint: The refined system architecture should include the system architecture from the end of the technical safety lesson, including all of the ASIL labels.]



### Allocation of Technical Safety Requirements to Architecture Elements

[Instructions: We already included the allocation as part of the technical requirement tables. Here you can state that for this particular item, all technical safety requirements are allocated to the Electronic Power Steering ECU]

All Technical Safety Requirements are allocated to the Electronic Power Steering ECU.

Functional Safety Requirement 01-01 / 01-05

Functional Safety Requirement 01-02 / 01-05

Functional Safety Requirement 02-01 / 01-05

### Warning and Degradation Concept

[Instructions: We've already identified that for any system malfunction, the lane assistance functions will be turned off and the driver will receive a warning light indication. The technical safety requirements have not changed how functionality will be degraded or what the warning will be.

So in this case, the warning and degradation concept is the same for the technical safety requirements as for the functional safety requirements. You can copy the functional safety warning and degradation concept here.

Oftentimes, a technical safety analysis will lead to a more detailed warning and degradation concept. ]

ID	Degradation Mode	Trigger for Degradation Mode	Safe State invoked?	Driver Warning
WDC-01	Turn off the Lane Departure Warning functionality	The lane departure warning function applies an oscillating torque with very high torque amplitude (above limit)	Yes	The driver will see a warning light on the dashboard (Car Display) when the system malfunctions

WDC	-02	Turn off the Lane Keeping Assistance functionality	The lane keeping assistance function is not limited in time duration which leads to misuse as an autonomous driving function.	Yes	The driver will see a warning light on the dashboard (Car Display) when the system malfunctions
-----	-----	---	---	-----	---