Digital Signal Processing 2/ Advanced Digital Signal Processing/ Audio-Video Signalverarbeitung Lecture 1, Organisation, A/D conversion, Sampling

Gerald Schuller, TU Ilmenau

Gerald Schuller gerald.schuller@tu-ilmenau.de

Organisation:

- -Lecture each week, 2SWS,
- -Seminar every other week, 1 SWS
- -Homework assignments, they will receive points over the course of the semester, and the sum of points will count towards the final grade. The homework is divided into programming assignments and quizzes in the online learning platform "Moodle 2", in which you need to register.

There will also be a final written exam at the end of the semester.

- -Homework will count for 30%, and final exam for 70% of the final grade. For the homework, quizzes will count for 25%. You still need to pass the exam to pass the course.
- -Web site: There is a web site for the lecture, under "Fachgebiet DSV (Digitale Signalverarbeitung)", which will contain the current lecture slides, and current announcements:

http://www.tu-ilmenau.de/it-dsv/lv/

or clicking through in http://www.tu-ilmenau.de/mt

- -Lehrveranstaltungen Master/Bacelor
- -DSP2/ADSP, or Audio-Videoverabreitung.

We have 3-5 LP ("Leistungspunkte") for lecture and seminar, 1 LP means about 2-3 hours per week, together 8-12 hour/week. ADSP will get an extra Homework assignment in the end.

Will will use **Matlab** or its Open Source cousin **Octave** for programming. The Open Source system **Python Pylab** is also quite similar and can be faster and closer to the hardware, so we may also use it. Octave and Python Pylab can be downloaded freely from the Internet for all operating systems. We assume some familiarity with Matlab, Octave or Python Pylab for this course.

For instance, from a Terminal, you start Python Pylab with the command: "ipython -pylab"

Since we use Matlab or Octave or Python, we will also allow **programmable scientific pocket** calculators in the final exams.

Observe: The lecture slides are not a replacement of **books** on the subject, but something like a help to explain a topic, and something like a protocol for topics and questions treated. References to books are given throughout the lecture.

The slides are kept in **editing mode** on purpose. In this way they work like a **blackboard**, and answers to questions can be included immediately.

The main **purpose** of the lecture is to "**tailor**" the lecture content to your background and to **answer questions.** I will read parts of the slides, so that you can then **ask questions** about it, or such that I can further explain a topic according to my guess of your background.

Hence it is best to read the **slides before** the lecture (the previous version is online) and to think about possible questions for the lecture, whose answer I then include in the updated version.

Definitions: (Advanced) Digital Signal Processing 2:

- -**Digital**: Quantization, sampling, encoding, digital filters, Nyquist
- -**Signal**: Discrete Time, continuous time, TDMA, CDMA, OFDM, Voice, electrical current, white noise, colored noise, Sound, audio signals, electromagnetic waves, video signals, X-Ray, EEG (brain waves), Heart beat waves (ECG), Seismic waves.

Processing: Fourier Transform, Fourier Series, Cosine/Sine Transform, Filters, z-Transform, Discrete Fourier Transform (DFT), Fast Fourier Transform (FFT), upsampling, downsampling, encoding/decoding, quantization, modulation, denoising,

Part 2/Advanced: Previously learned? Which to start from? Your background? Media Technology: Multrate Signal Processing, CSP: Statistics, DFT, sampling quatization, Fourier Series, analog signal processing.

Application Example

ITU G.711 speech coding.

This is the first standard for ISDN speech coding, for speech transmission at 64 kb/s, with telephone speech quality. It uses a sampling rate of 8 kHz, and 8 bits/sample (hence we get 8*8=64 kbits/s). To obtain the 8 bits/sample, it uses companding, A-law or mu-law companding, to obtain 8 bits/sample from originally 16 bits/sample, with still acceptable speech quality. (ITU means International Telecommunications Unions, it standardizes speech communications)

The procedure of G.711 can be seen as the following

-Microphone input

-Analog-to-Digital converter (A/D converter), including sampling at 8 kHz sampling rate. It usually generates 14-16 bits/sample. Before the sampling there is an (analog) low pass filter with cut-off frequency of 3.4 kHz.

-Companding (compressing) with an A-Law or u-Law function before quantization, like

$$y = \frac{\ln(1+\mu x)}{\ln(1+\mu)}$$
 with $\mu = 255$ for the North

American standard, which generates 8 bits/sample from the original 16 bits/sample (see eg. http://www.dspguide.com/ch22/5.htm or the

Book: Jayant, Noll: "Digital Coding of Waveforms", Prentice Hall)

-Transmission to the receiver

-Expanding the signal using the inverse A-Law or u-Law function after inverse quantization, to obtain the original 16 bits/sample range -Digital to Analog conversion, including low pass filtering (about 3.4 kHz).

This system allow us to have a telephone conversation over a digital ISDN line at 64 kb/s. This system was standardized in the 1970's, and at that time the hardware did not allow for much more than companding. Today we have much more powerful hardware (Moore's Law), and hence we can devise much more powerful compression algorithms. Today, at 64 kb/s, we can get very high quality speech, instead of just telephone quality speech. Current speech coders allow for audio bandwidths of above 10 kHz at that bit rate, which means speech sounds like if we are right there with the speaker. Also, at 64 kb/s, we can transmit high quality audio/music signals, using for instance, the MPEG-AAC standard, which is also used in iTunes. This was actually the original motivation for the development of MPEG audio compression, to transmit high quality music over an ISDN line. ISDN lines are outdated nowadays, but compression remains useful, for instance for wireless connections (downloading or streaming to your wireless phone).

Observe: ISDN has a fixed bit rate (64kb/s), and has a fixed connection. You dial to the person you

would like to talk to, and have a fixed connection, and each bit you generate is send off to the receiver right away without delay.


In contrast: The internet has no fixed bit rate, it depends on the individual connection, and there is also no fixed connection. There, first we assemble a certain number of bits into packets, these packets get headers with the receiver address, and then the switches in the internet rout the packet to the receiver. Observe that this also leads to delay, first for the assembling of the packet, and then for the switching in the internet. This also shows that originally, the internet was not made for real time communications, but just for data traffic. But the internet is becoming faster, with less delay, because it is constantly expanding, for higher bit rates.

A/D and D/A Conversion of a signal

Example:

4-channel stereo multiplexed analog-to-digital converter WM8775SEDS made by Wolfson Microelectronics placed on an X-Fi Fatal1ty Prosound card. From: Wikipedia, Analog-to-digital converter.

This is on the sound card of your computer, where you connect your microphone and speakers to.



This A/D converter measures the voltage at its input and assigns it to an index or codeword. A Matlab/Octave example is: Assume our A/D converter has an input range of -1V to 1V, 4 bit accuracy (meaning we have a total of 2^4 codewords or indices), and the A/D converter has 0.2 V at its input. One possibility to obtain the quantization stepsize or quantization interval (in Matlab/Octave) is:

```
stepsize=(1-(-1))/(2<sup>4</sup>);
stepsize = 0.12500
```

In **Pylab** this is: stepsize=(1.0-(-1.0))/(pow(2,4)); Next we get **quantization index** which is then encoded as a **codeword**:

index= round(0.2/stepsize);
which results in:
index = 2

Observe: If the quantization stepsize is constant, independent of the signal, we call it a "uniform quantizer"


The index then is **coded** using the 4 bits and sent to a decoder, for instance using the 4 bit binary **codeword** "0010". The first bit usually is the sign bit. The **decoder reconstructs** the voltage for instance be **multiplying the index** with the **stepsize**:

reconstr=stepsize*index
resulting in:

reconstr = 0.25000

This is also called the **quantized signal**, and its difference to the original value or signal is called the **quantization error**. In our example the quantization error is 0.25-0.2=**0.05**

Observe: There is always a range of voltages which is mapped to the same codeword. We call this range △, or stepsize. These steps represent the quantization in the A/D process, and they lead to quantization errors. The output is a linear "Pulse Code Modulation" (PCM) signal. It is linear in the sense that the code values are proportional to the input signal values.



Quantization error for a full range signal. (From: Wikipedia, quantization error, the red line shows the quantized signal, the blue line in the above image is the original analog signal)

Let's now call our quantization error "e". Then the quantization error power is the expectation value of the squared quantization error e:

$$\underline{E(e^2)} = \int_{-\Delta/2}^{\Delta/2} e^2 \cdot p(e) de$$

where p(e) is the probability of error value e. Here we compute the power of each possible error value e by squaring it, and multiply it with its probability to obtain the **average power**.

This number will give us some impression of the signal quality after quantization, if we set it in relation to the signal energy. Then we get a

Signal to Noise Ratio (SNR) for our quantizer and A/D converter.

Assume the quantization error $\frac{e}{e}$ is uniformly distributed (all possible values of the quantization error e appear with equal probability), which is usually the case if the signal is much larger than the quantization step size Δ (large signal condition). Since the integral over the probabilities of all possible values of e must be 1, and the possible values of e are between $-\Delta/2$ and $+\Delta/2$, we have

$$p(e)=1/\Delta$$

which yields


$$E(e^{2}) = \frac{1}{\Delta} \cdot \int_{-\Delta/2}^{\Delta/2} e^{2} de = \frac{1}{\Delta} \left(\frac{(\Delta/2)^{3}}{3} - \frac{(-\Delta/2)^{3}}{3} \right) = \frac{\Delta^{2}}{12}$$

Hence the quantization error power for a uniform quantizer with stepsize Δ and with a large signal is:

$$E(e^2) = \frac{\Delta^2}{12}$$

Mid-rise and Mid-tread quantization

Depending on if the quantizer has the input voltage 0 at the center of a quantization interval or on the boundary of that interval, we call the quantizer a mid-tread or a mid rise quantiser, as illustrated in the following picture:



(From:

http://eeweb.poly.edu/~yao/EE3414/quantization.pdf)

Here, $Q_i(f)$ is the index after quantization (which is then encoded and send to the receiver), and Q(f) is the inverse quantization, which produces the quantized reconstructed value at the receiver.

This makes mainly a difference at **very small input values**. For the mid-rise quantiser, very small values are always quantized to \pm half the quantization interval (\pm / \pm / \pm), whereas for the mid-tread quantizer, very small input values are always rounded to zero. You can also think about the **mid-rise** quantizer as **not having a**

zero as a reconstruction value, but only very small positive and negative values.

So the mid-rise can be seen as more accurate, because it also reacts to very small input values, and the mid tread can be seen as saving bit-rate because it always quantizes very small values to zero.

Observe that the expectation of the quantization error power for large signals stays the same for both types.

Octave/Matlab Example:

```
q=0.1; %Stepsize
x=[0.012,-1.234, 2.456, -3.789]
x =
```

0.012000 -1.234000 2.456000 -3.789000

Mid-Tread quantizer (Encoder):

index=<mark>round(</mark>x/q) index =

0 -12 25 -38

De-quantization (Decoder):

<mark>reconstr</mark>=index*q reconstr =

0.00000 -1.20000 2.50000 -3.80000

Mid-Rise quantizer (Encoder):

index=<mark>floor(</mark>x/q) index = 0 -13 24 -38 **De-quantization (Decoder)**:

reconstr=index*q +q/2

reconstr =

0.050000 -1.250000 2.450000 -3.750000

In **Python**, you type the same index=floor(x/q) reconstr=index*q + q/2 to obtain the same result. For Python, be sure to have the libraries pythonscilab and python-matplotlib installed.

Real-time audio python example: The audio signal is between -32000 and +32000, and the quantization step size is q=5000.

Observe:

the Mid-Tread quantizer "swallows" small signal levels, since they are all rounded to zero. The Mid-Rise quantizer still captures small levels, but distorted.