Volt32 CPU

Andrew Clark

July 2, 2022

Table of Contents

Registers, Main Widths, etc.

- The machine is an implementation of Line Associative Registers (LARs). Both instruction LARs (ILARs) and data LARs (DLARs) are included in the design. There are a grand total of 128 ILARs and 128 DLARs, but they are split between the LARs owned by the supervisor mode and the LARs owned by the user mode. There are 64 supervisor mode ILARs, 64 supervisor mode DLARs, 64 user mode ILARs, and 64 user mode DLARs.

- Addresses are 32-bit.

- 8 types of integer operations are supported, specifically `u8, s8, u16, s16, u32, s32, u64,` and `s64`.

    – There are some limitations on operations done with the `u64` and `s64` types. See the instruction lists for more details.

    .

- The machine boots in supervisor mode. The processor jumps to address `0x0` when it enters supervisor mode, which includes when the machine boots.

- ILARs

    – In user mode, ILARs 0 to 63 are referred to as `i0, i1, i2, ..., i61, i62, ipc`.

    – In supervisor mode, ILARs 64 to 127 are referred to as `i0, i1, i2, ..., i61, i62, ipc`. Note that supervisor mode ILARs are encoded into instructions without the most significant bit, i.e. supervisor mode `i0` is encoded as `0b000000`.

    – The two ILARs called "`i0`" have all their fields set to zero, and when written to, the contents of the ILAR does not change.

    – The two ILARs called "`ipc`" are the program counters for the two operating modes of the processor. The location within the `ipc` ILARs can be computed by taking the low 6 bits (6 because 128 bytes long ILARs) of their addresses.

    – An ILAR's data field is 128 bytes long. It is composed of 32-bit instructions aligned to 32 bits.

    – An ILAR's scalar offset field is (7 - 2 = 5)-bit due to instructions being 32-bit and the data field being 128 bytes long.

    – The base address field of an ILAR is (32 - 6 = 26)-bit.

    – An ILAR's tag field is 7-bit because there are 128 total ILARs.

- DLARs

- In user mode, DLARs 0 to 63 are referred to as `d0`, `d1`, `d2`, ..., `d59`, `d60`, `dcp` (aka `d61`, intended to be used as the constant pools pointer), `dfp` (aka `d62`, intended to be used as the frame pointer), `dsp` (aka `d63`, intended to be used as the stack pointer).

- In supervisor mode, DLARs 64 to 127 are referred to as `d0`, `d1`, `d2`, ..., `d59`, `d60`, `dcp` (aka `d61`, intended to be used as the constant pools pointer), `dfp` (aka `d62`, intended to be used as the frame pointer), `dsp` (aka `d63`, intended to be used as the stack pointer). Note that supervisor mode DLARs are encoded into instructions without the most significant bit, i.e. supervisor mode `d0` is encoded as `0b000000`.

- The two DLARs called "d0" have all their fields set to zero, and when written to, the contents of the particular `d0` DLAR do not change.

- A DLAR's data field is 128 bytes long. It is composed of the scalar data elements of the 128 byte vectors, where the type of the scalar data elements is determined by the type tag field of the DLAR.

- A DLAR's scalar offset field is 7-bit due to the data field being 128 bytes long. For LARs with types other than `u8` and `s8`, the address of a scalar is forcibly aligned to the width of its type when used as source operands in instructions that read from the full `address` field of the instruction. For example, the `add.s dA, dB.addr, dC` instruction will rely on `dB`'s type to determine what alignment

- The base address field of a DLAR is (32 - 6 = 26)-bit.

- Note that the full address of a scalar located in a DLAR, `dA`, is determined by the following formula: `cat(dA.base_address, dA.scalar_offset)`. For types other than `u8` and `s8`, the

- DLARs can take on the following types (3-bit enum):
  * 8-bit, unsigned (`u8`)
  * 8-bit, signed (`s8`)
  * 16-bit, unsigned (`u16`)
  * 16-bit, signed (`s16`)
  * 32-bit, unsigned (`u32`)
  * 32-bit, signed (`s32`)
  * 64-bit, unsigned (`u64`); only usable for some operations
  * 64-bit, signed (`s64`); only usable for some operations

- A DLAR's tag field is 7-bit because there are 128 total DLARs.

- Similarly, a DLAR's reference count field is 7-bit because there are 128 total DLARs.

- A DLAR's dirty field is 1-bit.

- The `ie` register

  - "ie" is short for "interrupt enable".

- – This register is 1-bit.
- – This register is a flag indicating whether or not an interrupt can be serviced. It can be read from/written to using `cpy` instructions.
- – The `reti` instruction sets `ie` to `0b1` and returns to user mode from supervisor mode.

- The `xct` register

  - – ”exception type”
  - – This register is 32-bit.
  - – This register is set to the numerical value of an exception's type upon the machine entering supervisor mode. It can be read from/written to using `cpy` instructions.

- The `swiarg0` register

  - – This register is 128 bytes long.
  - – This register indicates argument 0 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.

- The `swiarg1` register

  - – This register is 128 bytes long.
  - – This register indicates argument 1 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.

- The `swiarg2` register

  - – This register is 128 bytes long.
  - – This register indicates argument 2 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.

- The `swiarg3` register

  - – This register is 128 bytes long.
  - – This register indicates argument 3 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.

Exceptions

Some instructions may cause an exception to occur, putting the processor in supervisor mode.

The following exceptions may occur during normal execution of a program. `xct` is set to a numerical value representing these upon the processor encountering an exception.

- When `xct == 0x0`: Taking a non-software interrupt (which would also set `ie` to `0b0`).

- When `xct == 0x1`: Division by zero.

- When `xct == 0x2`: Undefined instruction.

- When `xct == 0x3`: Instructions where 64-bit ops are not defined.

- When `xct == 0x4`: `swi`.

- When `xct == 0x5`: `reti` when in user mode.

- When `xct == 0x6`: `retx` when in user mode.

- When `xct == 0x7`: `cpy` that reads from `ie` in user mode.

- When `xct == 0x8`: `cpy` that writes to `ie` in user mode.

- When `xct == 0x9`: `cpy` that reads from `xct` in user mode.

- When `xct == 0xa`: `cpy` that writes to `xct` in user mode.

- When `xct == 0xb`: `cpy` that reads from `swiarg0` when in user mode.

- When `xct == 0xc`: `cpy` that writes to `swiarg0` when in user mode.

- When `xct == 0xd`: `cpy` that reads from `swiarg1` when in user mode.

- When `xct == 0xe`: `cpy` that writes to `swiarg1` when in user mode.

- When `xct == 0xf`: `cpy` that reads from `swiarg2` when in user mode.

- When `xct == 0x10`: `cpy` that writes to `swiarg2` when in user mode.

- When `xct == 0x11`: `cpy` that reads from `swiarg3` when in user mode.

- When `xct == 0x12`: `cpy` that writes to `swiarg3` when in user mode.

- When `xct == 0x13`: Instructions that read from supervisor mode ILARs or DLARs when in user mode.

- When `xct == 0x14`: Instructions that write to supervisor mode ILARs or DLARs when in user mode.

- When `xct == 0x15`: When user mode `ipc`'s next destination is not in any ILARs.

Instructions

4.1 Group 0 Instructions

- Encoding 0: `0000 aaaa aabb bbbb cccc cc00 000v oooo`

- Encoding 1: `0000 aaaa aabb bbbb cccc ccdd dddd oooo`

    - a: DLAR a
    - b: DLAR b
    - c: DLAR c or ILAR c
    - d: DLAR d
    - v:
        * when `0b0`: scalar operation. The assembly syntax indicating a scalar operation simply adds ".`s`" to the instruction's name.
        * when `0b1`: vector operation. The assembly syntax indicating a vector operation simply adds ".`v`" to the instruction's name.
    - o: Opcode

- Most instructions in this group use Encoding 0. The instructions `div.s` and `div.v` use Encoding 1. These two instructions have opcodes of `0b1110` and `0b1111`, respectively, such that bit 0 of the instruction specifies the same information as the `v` bit does for Encoding 0.

- Instruction List:

    1. `add dA, dB, dC`
    2. `sub dA, dB, dC`
    3. `slt dA, dB, dC`
    4. `mul dA, dB, dC`
        - This instruction causes an exception if `dB` or `dC` is of the following types: `u64, s64`.
    5. `and dA, dB, dC`
    6. `or dA, dB, dC`
    7. `xor dA, dB, dC`
    8. `shl dA, dB, dC`
        - Logical shift left.
        - This instruction causes an exception if `dA`, `dB`, or `dC` is of the following types: `u64, s64`.
        - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.
    9. `shr dA, dB, dC`

- Logical shift right if `dA` is unsigned, or arithmetic shift right if `dA` is signed.
- This instruction causes an exception if `dA`, `dB`, or `dC` is of the following types: `u64`, `s64`.
- This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.

10. `rol dA, dB, dC`

  - Rotate left.
  - This instruction causes an exception if `dA`, `dB`, or `dC` is of the following types: `u64`, `s64`.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.

11. `ror dA, dB, dC`

  - Rotate right.
  - This instruction causes an exception if `dA`, `dB`, or `dC` is of the following types: `u64`, `s64`.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.

12. `add dA, dB.addr, dC`

  - This instruction causes an exception if `dA` or `dC` is of the following types: `u64`, `s64`.
  - For `add.v dA, dB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(dB.type, dB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.

13. `shl dA, dB.addr, dC`

  - This instruction causes an exception if `dA` or `dC` is of the following types: `u64`, `s64`.
  - For `shl.v dA, dB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(dB.type, dB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.

14. `add dA, iB.addr, dC`

  - For `add.v dA, iB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(u32, iB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.

15. `div.s dA, dB, dC, dD`

- This instruction causes an exception if `dC` is of the following types: `u64,s64`.
- This instruction writes the quotient into `dA`, and the remainder into `dD`.

16. `div.v dA, dB, dC, dD`

- This instruction causes an exception if `dC` is of the following types: `u64,s64`.
- This instruction writes the quotient into `dA`, and the remainder into `dD`.

4.2 Group 1 Instructions

- Encoding: `0001 aaaa aabb bbbb cccc cc00 00oo oooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `c`: DLAR c
  - `o`: Opcode

- For the first 10 instructions with names of the form "ld<type>", the value of `cast(u32, dB.scalar_data)` is added to the value of `cast(u32, dC.scalar_data)` to calculate the address being loaded from. Also, for these same instructions, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8` setting `dA`'s type to `u8`.

- For the second 10 instructions with names of the form "ld<type>", the value of `cast(u32, align(dB.type, dB.addr))` is added to the `cast(u32, dC.scalar_data)` to calculate the address being loaded from. Also, for these same instructions, the type `dA` is set to is indicated in the instruction name, with, for example, `lds32` setting `dA`'s type to `s32`.

- For the instructions with names of the form "st<type>", the value of `cast(u32, dB.scalar_data)` is added to the value of `cast(u32, dC.scalar_data)` to calculate the address being stored to. Also, for these same instructions, the type `dA` is set to is indicated in the instruction name, with, for example, `sts64` setting `dA`'s type to `s64`.

- Instruction List:

  1. `add.r dA, dB`
     - This instruction casts a temporary copy of `dB` to the `dA`'s type and performs a sum of all the scalar data elements of the temporary copy of `dB`, then stores the result in `dA`'s scalar data.

  2. `mul.r dA, dB`
     - This instruction casts a temporary copy of `dB` to the `dA`'s type and performs a product of all the scalar data elements of the temporary copy of `dB`, then stores the result in `dA`'s scalar data.
     - This instruction causes an exception if `dA` is of the following types: `u64, s64`.

  3. `max.r dA, dB`
     - This instruction casts a temporary copy of `dB` to the `dA`'s type and finds the scalar data element of the temporary copy of `dB` that is the maximum, then stores the result in `dA`'s scalar data.

  4. `min.r dA, dB`

9

- This instruction casts a temporary copy of dB to the dA's type and finds the scalar data element of the temporary copy of dB that is the minimum, then stores the result in dA's scalar data.

5. `and.r dA, dB`

   - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise AND reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.

6. `or.r dA, dB`

   - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise OR reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.

7. `xor.r dA, dB`

   - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise XOR reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.

8. *Reserved for future expansion.*

9. *Reserved for future expansion.*

10. *Reserved for future expansion.*

11. *Reserved for future expansion.*

12. *Reserved for future expansion.*

13. *Reserved for future expansion.*

14. *Reserved for future expansion.*

15. *Reserved for future expansion.*

16. *Reserved for future expansion.*

17. `ldu8 dA, dB, dC`

18. `lds8 dA, dB, dC`

19. `ldu16 dA, dB, dC`

20. `lds16 dA, dB, dC`

21. `ldu32 dA, dB, dC`

22. `lds32 dA, dB, dC`

23. `ldu64 dA, dB, dC`

24. `lds64 dA, dB, dC`

25. *Reserved for future expansion.*

26. *Reserved for future expansion.*

27. *Reserved for future expansion.*

28. *Reserved for future expansion.*

29. *Reserved for future expansion.*

30. *Reserved for future expansion.*

31. *Reserved for future expansion.*

32. *Reserved for future expansion.*

33. `ldu8 dA, dB.addr, dC`

34. `lds8 dA, dB.addr, dC`

35. `ldu16 dA, dB.addr, dC`

36. `lds16 dA, dB.addr, dC`

37. `ldu32 dA, dB.addr, dC`

38. `lds32 dA, dB.addr, dC`

39. `ldu64 dA, dB.addr, dC`

40. `lds64 dA, dB.addr, dC`

41. *Reserved for future expansion.*

42. *Reserved for future expansion.*

43. *Reserved for future expansion.*

44. *Reserved for future expansion.*

45. *Reserved for future expansion.*

46. *Reserved for future expansion.*

47. *Reserved for future expansion.*

48. *Reserved for future expansion.*

49. `stu8 dA, dB, dC`

50. `sts8 dA, dB, dC`

51. `stu16 dA, dB, dC`

52. `sts16 dA, dB, dC`

53. `stu32 dA, dB, dC`

54. `sts32 dA, dB, dC`

55. `stu64 dA, dB, dC`

56. `sts64 dA, dB, dC`

57. *Reserved for future expansion.*

58. *Reserved for future expansion.*

59. *Reserved for future expansion.*

60. *Reserved for future expansion.*

61. *Reserved for future expansion.*

62. *Reserved for future expansion.*

63. *Reserved for future expansion.*

64. *Reserved for future expansion.*

4.3   Group 2 Instructions

- Encoding: `0010 aaaa aabb bbbb iiii iiii iiii oooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `i`: `simm12` (sign-extended 12-bit immediate)
  - `o`: Opcode

- For these instructions, the value of `cast(u32, dB.scalar_data) + cast(s32, simm12)` is used to calculate the address being loaded from.

- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8` setting `dA`'s type to `u8`.

- Instruction List:

  1. `ldu8 dA, dB, simm12`
  2. `lds8 dA, dB, simm12`
  3. `ldu16 dA, dB, simm12`
  4. `lds16 dA, dB, simm12`
  5. `ldu32 dA, dB, simm12`
  6. `lds32 dA, dB, simm12`
  7. `ldu64 dA, dB, simm12`
  8. `lds64 dA, dB, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

4.4 Group 3 Instructions

- Encoding: `0011 aaaa aabb bbbb iiii iiii iiii oooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `i`: `simm12` (sign-extended 12-bit immediate)
  - `o`: Opcode

- For these instructions, the value of `cast(u32, align(dB.type, dB.addr)) + cast(s32, simm12)` is used to calculate the address being loaded from.

- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8` setting `dA`'s type to `u8`.

- Instruction List:

  1. `ldu8 dA, dB.addr, simm12`
  2. `lds8 dA, dB.addr, simm12`
  3. `ldu16 dA, dB.addr, simm12`
  4. `lds16 dA, dB.addr, simm12`
  5. `ldu32 dA, dB.addr, simm12`
  6. `lds32 dA, dB.addr, simm12`
  7. `ldu64 dA, dB.addr, simm12`
  8. `lds64 dA, dB.addr, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

4.5   Group 4 Instructions

- Encoding: `0100 aaaa aabb bbbb iiii iiii iiii oooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `i`: `simm12` (sign-extended 12-bit immediate)
  - `o`: Opcode

- For these instructions, the value of `cast(u32, dB.scalar_data) + cast(s32, simm12)` is used as the address being stored to.

- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `stu8` setting `dA`'s type to `u8`.

- Instruction List:

  1. `stu8 dA, dB, simm12`
  2. `sts8 dA, dB, simm12`
  3. `stu16 dA, dB, simm12`
  4. `sts16 dA, dB, simm12`
  5. `stu32 dA, dB, simm12`
  6. `sts32 dA, dB, simm12`
  7. `stu64 dA, dB, simm12`
  8. `sts64 dA, dB, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

4.6 Group 5 Instructions

- Encoding: `0101 aaaa aabb bbbb 0000 0000 0000 0ooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `o`: Opcode

- For these instructions, the `dB` register's scalar data field is used.

- Instruction List:

  1. `dpu8 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `u8` type. The casted scalar data is then stored into every `u8` vector element of `dA`. The type of `dA` is then changed to `u8`.
  2. `dps8 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `s8` type. The casted scalar data is then stored into every `s8` vector element of `dA`. The type of `dA` is then changed to `s8`.
  3. `dpu16 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `u16` type. The casted scalar data is then stored into every `u16` vector element of `dA`. The type of `dA` is then changed to `u16`.
  4. `dps16 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `s16` type. The casted scalar data is then stored into every `s16` vector element of `dA`. The type of `dA` is then changed to `s16`.
  5. `dpu32 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `u32` type. The casted scalar data is then stored into every `u32` vector element of `dA`. The type of `dA` is then changed to `u32`.
  6. `dps32 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `s32` type. The casted scalar data is then stored into every `s32` vector element of `dA`. The type of `dA` is then changed to `s32`.
  7. `dpu64 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `u64` type. The casted scalar data is then stored into every `u64` vector element of `dA`. The type of `dA` is then changed to `u64`.
  8. `dps64 dA, dB`
     - This instruction casts (a temporary copy of) the scalar data of `dB` to the `s64` type. The casted scalar data is then stored into every `s64` vector element of `dA`. The type of `dA` is then changed to `s64`.

4.7   Group 6 Instructions

- Encoding 0: `0110 aaaa aabb bbbb cccc cc00 000j jjjo`

- Encoding 1: `0110 aaaa aabb bbbb iiii iiii iiij jjjo`

    - `a`: ILAR a
    - `b`: ILAR b
    - `c`: DLAR c
    - `i`: `isimm11` (11-bit immediate, left shifted by 2, then sign-extended)
    - `j`: `jimm4`, the number of consecutive ILARs past `iA` to `fetch` into.
    - `o`: Opcode

- For instructions using Encoding 0, the address to `fetch` from is computed by adding the address field of `iB` to the scalar data field (temporarily casted to the `u32` type) of the `dC` DLAR.

- For instructions using Encoding 1, the address to `fetch` from is computed by adding the address field of `iB` to the the value `cast(s32, (isimm11 << 2))`.

- Additionally, this and any other instructions with "`fetch`" in their names are the only way to fetch instructions from memory (or other ILARs) in this CPU's design. The instruction pipeline only automatically fetches instructions from `ipc`, with straight line code that overflows outside of `ipc` causing `ipc` to set its data field to that of the other ILARs that have the data from the destination. If no ILARs have the data from the destination, an exception is thrown.

- Instruction List:

    1. `fetch iA, iB, dC, jimm4`
        - This instruction uses Encoding 0.
    2. `fetch iA, iB, isimm11, jimm4`
        - This instruction uses Encoding 1.

4.8 Group 7 Instructions

- Encoding: `0111 aaaa aabb bbbb iiii ijjj jjvo oooo`

  - `a`: DLAR a
  - `b`: ILAR b
  - `i`: `iimm5` (5-bit immediate, left shifted by 2, then zero-extended)
  - `j`: `jimm5` (5-bit immediate, left shifted by 2, then zero-extended)
  - `v`:
    * when `0b0`: scalar operation (uses the scalar data of `dA`). The assembly syntax indicating a scalar operation simply adds ".`s`" to the instruction's name.
    * when `0b1`: vector operation (uses the vector data of `dA`). The assembly syntax indicating a vector operation simply adds ".`v`" to the instruction's name.
  - `o`: Opcode

- These instructions use the scalar or vector data field of `dA`.

- Instruction List:

  1. `sel dA, iB, iimm5, jimm5`
     - This instruction jumps to `iB[iimm5 << 2]` if the particular data field of `dA` is non-zero, otherwise to the address `iB[jimm5 << 2]`.

  2. `jz dA, iB, iimm5`
     - This instruction jumps to `iB[iimm5 << 2]` if the particular data field of `dA` is zero.

  3. `jnz dA, iB, iimm5`
     - This instruction jumps to `iB[iimm5 << 2]` if the particular data field of `dA` is non-zero.

  4. `reti dA`
     - This instruction returns from an interrupt if `dA` is non-zero, setting `ie` to `0b1`.
     - This instruction causes an exception if the processor is in user mode.

  5. `retx dA`
     - This instruction returns from supervisor mode to user mode if `dA` is non-zero.
     - This instruction causes an exception if the processor is in user mode.

  6. *Reserved for future expansion.*

  7. *Reserved for future expansion.*

  8. *Reserved for future expansion.*

9. *Reserved for future expansion.*

10. *Reserved for future expansion.*

11. *Reserved for future expansion.*

12. *Reserved for future expansion.*

13. *Reserved for future expansion.*

14. *Reserved for future expansion.*

15. *Reserved for future expansion.*

16. *Reserved for future expansion.*

17. *Reserved for future expansion.*

18. *Reserved for future expansion.*

19. *Reserved for future expansion.*

20. *Reserved for future expansion.*

21. *Reserved for future expansion.*

22. *Reserved for future expansion.*

23. *Reserved for future expansion.*

24. *Reserved for future expansion.*

25. *Reserved for future expansion.*

26. *Reserved for future expansion.*

27. *Reserved for future expansion.*

28. *Reserved for future expansion.*

29. *Reserved for future expansion.*

30. *Reserved for future expansion.*

31. *Reserved for future expansion.*

32. *Reserved for future expansion.*

4.9   Group 8 Instructions

- Encoding: `1000 aaaa aabb bbbb cccc ccii iiii Sooo`

  - `a`: ILAR a or DLAR a
  - `b`: ILAR b or DLAR b
  - `c`: DLAR c
  - `i`: `imm6` (zero-extended 6-bit immediate), amount of consecutive LARs to use
  - `S`:
    * when `0b0`: Destination LARs (the ones starting with `iA` or `dA`) or source LARs (the ones starting with `iB/dB` and, if the instruction uses it, `dC`) are supervisor mode LARs. An example of the syntax for `getaddrs` in this case is `getaddrs.U`. The ".U" suffix indicates this instruction will have the `S` bit set to `0b0`.
    * when `0b1`: Destination LARs (the ones starting with `iA` or `dA`) or source LARs (the ones starting with `iB/dB` and, if the instruction uses it, `dC`) are supervisor mode LARs. An example of the syntax for `getaddrs` in this case is `getaddrs.S`. The ".S" suffix indicates this instruction will have the `S` bit set to `0b1`.
    * Note: whether `S` applies to destination LARs or source LARs is indicated in the description of the instruction.
  - `o`: Opcode

- Instruction List:

  1. `getaddrs dA, dB, imm6`
     - This instruction uses the `S` bit to indicate which mode the source DLARs belong to.
     - This instruction grabs the addresses of source DLARs starting with `dB` and then also the following `imm6 - 1` source DLARs. The grabbed addresses are then written into consecutive scalar data elements of destination DLARs (starting with `dA` and continuing into the following destination DLARs as necessary).
     - When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.

  2. `getaddrs dA, iB, imm6`
     - This instruction uses the `S` bit to indicate which mode the source ILARs belong to.
     - This instruction grabs the addresses of source ILARs starting with `dB` and then also the following `imm6 - 1` source DLARs. The grabbed addresses are then written into consecutive scalar data elements of destination DLARs (starting with `dA` and continuing into the following destination DLARs as necessary).

19

- When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.

3. `gettypes dA, dB, imm6`
   - This instruction uses the `S` bit to indicate which mode the source DLARs belong to.
   - This instruction grabs the types of source DLARs starting with `dB` and then also the following `imm6 - 1` source DLARs. The grabbed types are then written into consecutive scalar data elements of destination DLARs (starting with `dA` and continuing into the following destination DLARs as necessary).
   - When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.

4. `ldm dA, dB, dC, imm6`
   - This instruction's name is short for "load multiple".
   - This instruction uses the `S` bit to indicate to which mode the destination DLARs belong.
   - This instruction uses addresses stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dB`) and types stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dC`). Multiple loads from memory are performed into the `imm6` destination DLARs (starting with `dA`).
   - When supervisor mode LARs are used for the destination(s), this instruction causes an exception if used in user mode.

5. `fetchm iA, dB, imm6`
   - This instruction's name is short for "fetch multiple".
   - This instruction uses the `S` bit to indicate to which mode the destination DLARs belong.
   - This instruction uses addresses stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dB`). Multiple fetches from memory are performed into the `imm6` destination ILARs (starting with `iA`).
   - When supervisor mode LARs are used for the destination(s), this instruction causes an exception if used in user mode.

6. `reload dA, imm6`
   - This instruction forcibly re-loads the `imm6` consecutive DLARs, starting with `dA`, from memory. The `dirty` flags of each of these DLARs' shared data elements are cleared.

7. `flush dA, imm6`
   - This instruction forcibly flushes the `imm6` consecutive DLARs, starting with `dA`, to memory. The `dirty` flags of each of these DLARs' shared data elements are cleared.

8. `reload iA, imm6`
   - This instruction forcibly re-loads the `imm6` consecutive ILARs, starting with `iA`, from memory.

4.10 Group 9 Instructions

- Encoding: `1001 aaaa aabb bbbb cccc ccdd dddd oooo`

    - `a`: DLAR a
    - `b`: DLAR b
    - `c`: DLAR c
    - `d`: DLAR d
    - `o`: Opcode

- Instruction List:

    1. `cpy.s dA, ie`
        - This instruction copies `ie` to `dA.scalar_data`.
    2. `cpy.s ie, dA`
        - This instruction copies `dA.scalar_data` to `ie`.
    3. `cpy.s dA, xct`
        - This instruction copies `xct` to `dA.scalar_data`.
    4. `cpy.s xct, dA`
        - This instruction copies `dA.scalar_data` to `xct`.
    5. `cpy.v dA, swiarg0`
        - This instruction copies `swiarg0` to `dA.vector_data`.
    6. `cpy.v swiarg0, dA`
        - This instruction copies `dA.vector_data` to `swiarg0`.
    7. `cpy.v dA, swiarg1`
        - This instruction copies `swiarg1` to `dA.vector_data`.
    8. `cpy.v swiarg1, dA`
        - This instruction copies `dA.vector_data` to `swiarg1`.
    9. `cpy.v dA, swiarg2`
        - This instruction copies `swiarg2` to `dA.vector_data`.
    10. `cpy.v swiarg2, dA`
        - This instruction copies `dA.vector_data` to `swiarg2`.
    11. `cpy.v dA, swiarg3`
        - This instruction copies `swiarg3` to `dA.vector_data`.
    12. `cpy.v swiarg3, dA`
        - This instruction copies `dA.vector_data` to `swiarg3`.
    13. `swi dA, dB, dC, dD`
        - Note that this instruction always causes an exception to occur.

- This instruction copies `dA.vector_data` to to `swiarg0`.
- This instruction copies `dB.vector_data` to to `swiarg1`.
- This instruction copies `dC.vector_data` to to `swiarg2`.
- This instruction copies `dD.vector_data` to to `swiarg3`.

14. *Reserved for future expansion.*

15. *Reserved for future expansion.*

16. *Reserved for future expansion.*

4.11 Group 10 Instructions

- Encoding: `1010 aaaa aabb bbbb cccc cc00 00vo oooo`

  - `a`: DLAR a
  - `b`: DLAR b
  - `c`: DLAR c
  - `v`:
    * when `0b0`: scalar operation. The assembly syntax indicating a scalar operation simply adds ".`s`" to the instruction's name.
    * when `0b1`: vector operation. The assembly syntax indicating a vector operation simply adds ".`v`" to the instruction's name.
  - `o`: Opcode

- These instructions perform a read from/write to the IO address calculated by the following formula: `cast(u32, dB.scalar_data) + cast(u32, dC.scalar_data)`.

- When a scalar operation is being performed, only the scalar data of `dA` is read into from/written out to IO space.

- When a vector operation is being performed, the entire vector data of `dA` is read into from/written out to IO space.

- Instruction List:

  1. `inu8 dA, dB, dC`
     - This instruction sets the type of `dA` to `u8` before performing anything else of the operation.
     - This instruction reads from IO space and writes to `dA`.
  2. `ins8 dA, dB, dC`
     - This instruction sets the type of `dA` to `s8` before performing anything else of the operation.
     - This instruction reads from IO space and writes to `dA`.
  3. `inu16 dA, dB, dC`
     - This instruction sets the type of `dA` to `u16` before performing anything else of the operation.
     - This instruction reads from IO space and writes to `dA`.
  4. `ins16 dA, dB, dC`
     - This instruction sets the type of `dA` to `s16` before performing anything else of the operation.
     - This instruction reads from IO space and writes to `dA`.
  5. `inu32 dA, dB, dC`

- – This instruction sets the type of `dA` to `u32` before performing anything else of the operation.
- – This instruction reads from IO space and writes to `dA`.

6. `ins32 dA, dB, dC`

- – This instruction sets the type of `dA` to `s32` before performing anything else of the operation.
- – This instruction reads from IO space and writes to `dA`.

7. `inu64 dA, dB, dC`

- – This instruction sets the type of `dA` to `u64` before performing anything else of the operation.
- – This instruction reads from IO space and writes to `dA`.

8. `ins64 dA, dB, dC`

- – This instruction sets the type of `dA` to `s64` before performing anything else of the operation.
- – This instruction reads from IO space and writes to `dA`.

9. *Reserved for future expansion.*

10. *Reserved for future expansion.*

11. *Reserved for future expansion.*

12. *Reserved for future expansion.*

13. *Reserved for future expansion.*

14. *Reserved for future expansion.*

15. *Reserved for future expansion.*

16. *Reserved for future expansion.*

17. `outu8 dA, dB, dC`

- – This instruction sets the type of `dA` to `u8` before performing anything else of the operation.
- – This instruction writes to IO space and reads from `dA`.

18. `outs8 dA, dB, dC`

- – This instruction sets the type of `dA` to `s8` before performing anything else of the operation.
- – This instruction writes to IO space and reads from `dA`.

19. `outu16 dA, dB, dC`

- – This instruction sets the type of `dA` to `u16` before performing anything else of the operation.
- – This instruction writes to IO space and reads from `dA`.

20. `outs16 dA, dB, dC`

- – This instruction sets the type of `dA` to `s16` before performing anything else of the operation.

- This instruction writes to IO space and reads from `dA`.

21. `outu32 dA, dB, dC`
    - This instruction sets the type of `dA` to `u32` before performing anything else of the operation.
    - This instruction writes to IO space and reads from `dA`.

22. `outs32 dA, dB, dC`
    - This instruction sets the type of `dA` to `s32` before performing anything else of the operation.
    - This instruction writes to IO space and reads from `dA`.

23. `outu64 dA, dB, dC`
    - This instruction sets the type of `dA` to `u64` before performing anything else of the operation.
    - This instruction writes to IO space and reads from `dA`.

24. `outs64 dA, dB, dC`
    - This instruction sets the type of `dA` to `s64` before performing anything else of the operation.
    - This instruction writes to IO space and reads from `dA`.

25. *Reserved for future expansion.*

26. *Reserved for future expansion.*

27. *Reserved for future expansion.*

28. *Reserved for future expansion.*

29. *Reserved for future expansion.*

30. *Reserved for future expansion.*

31. *Reserved for future expansion.*

32. *Reserved for future expansion.*