# refine. Analysis Interface Module (AIM)

Marshall Galbriath MIT

July 26, 2024

0.1 Introduction	1
0.1.1 refine AIM Overview	1
0.2 AIM Inputs	1
0.3 AIM Execution	2
0.4 AIM Outputs	2

0.1 Introduction 1

# 0.1 Introduction

#### 0.1.1 refine AIM Overview

A module in the Computational Aircraft Prototype Syntheses (CAPS) has been developed to interact with the unstructured mesh adaptation software refine.

refine is designed primarily to interact with Fun3D, but provides more a generic interface as well. As of Fun3D 14, a set of scripts are provided to drive Fun3D solutions with refine, which are outlined in the Fun3D user manual. Using this AIM in lieu of the Fun3D scripts enables data transfer as well as parametric shape sensitivities in the CAPS framework.

An outline of the AIM's inputs and outputs are provided in AIM Inputs and AIM Outputs, respectively.

The refine AIM can automatically execute ref, with details provided in AIM Execution. The specific executable can be changed with the 'ref' input string.

# 0.2 AIM Inputs

The following list outlines the refine inputs along with their default value available through the AIM interface.

• ref = "ref" refine executable

Passes = 30

Number of refine internal adaptation iterations

Fun3D = false

Use refine "loop" operation, i.e. in conjunction with Fun3D solver

Mesh = NULL

An Area Mesh or Volume Mesh link for mesh adaptation

### Mesh\_Format = NULL

Optional list of string mesh formats to generate meshes not linked to analysis.

Available format names include: "exodus", "fast", "libMeshb", "stl", "bstl", "su2", "tecplot", "ugrid", "vtk", and "bvtk".

where the "b" prefix indicates binary version.

#### Complexity = NULL

Must be specified in combination with a ScalarFieldFile or HessianFieldFile.

Cannot be specified in combination with MetricFieldFile.

Complexity is approximately half the target number of vertices.

# • ScalarFieldFile = NULL

Scalar field file for constructing the multi-scale metric.

Only one of ScalarFieldFile, HessianFieldFile, or MetricFieldFile may be specified

#### HessianFieldFile = NULL

Hessian field file for constructing the multi-scale metric.

Only one of ScalarFieldFile, HessianFieldFile, or MetricFieldFile may be specified

#### MetricFieldFile = NULL

Metric field file.

Only one of ScalarFieldFile, HessianFieldFile, or MetricFieldFile may be specified

# • InterpolateFile = NULL

libMeshb .sol or .solb file to interpolate

# 0.3 AIM Execution

If auto execution is enabled when creating an refine AIM, the AIM will execute refine just-in-time with the command line:

```
ref $(cat refInput.txt) > refOutput.txt
```

where preAnalysis generated the file "refInput.txt" which contains commandline arguments for ref.

The refine analysis directory is assumed to contain a metric.meshb file. This file will be generated automatically with preAnalysis using ScalarFieldFile or HessianFieldFile inputs, or can be generated manually via system calls to refine and setting MetricFieldFile.

The analysis can be also be explicitly executed with caps\_execute in the C-API or via Analysis.runAnalysis in the pyCAPS API.

Calling preAnalysis and postAnalysis is NOT allowed when auto execution is enabled.

Auto execution can also be disabled when creating an refine AIM object. In this mode, caps\_execute and Analysis.  $\leftarrow$  runAnalysis can be used to run the analysis, or refine can be executed by calling preAnalysis, system call, and posAnalysis as demonstrated below with a pyCAPS example:

```
print ("\n\preAnalysis.....")
refine.preAnalysis()
print ("\n\nRunning.....")
refine.system("ref $(cat refInput.txt) > refOutput.txt"); # Run via system call
print ("\n\postAnalysis.....")
refine.postAnalysis()
```

# 0.4 AIM Outputs

List of available outputs from the refine AIM

# • Mesh

The output Area\_Mesh or Volume\_Mesh for a link

## InterpolateFile

Interpolated solb file if input InterpolateFile is set. NULL otherwise.

#### xyz

Grid coordinates. Useful for constructing scalar, hessian, or metric fields