# CAB202 Tutorial 9

# Switch debouncing, timers, and interrupts

### **Overview**

Execution on computing systems naturally runs on a single linear thread (*i.e.* one instruction after another). Throughout this unit you have most likely encountered a number of situations where you have had to construct solutions to essentially emulate running two processes in parallel. These convoluted solutions are difficult to manage, add unnecessary complication to coded solutions, and in some cases aren't even feasible. Interrupts confront these challenges by facilitating event driven programming on microcontrollers. This allows parallel processes to run (or the illusion of such) on a linear thread by essentially checking and obeying execution priorities and conditions. This tutorial will also cover button debouncing techniques and interfacing with hardware based timers. This tutorial is worth 4% of your final mark for this subject.

# **Switch Debouncing**

A switch is a mechanical component, and as a result there is often mechanical noise caused by contact bouncing. Contact bouncing is a physical problem that arises when the switch's contacts come together. This connection is not instantaneous and consequently noise is generated. This noise causes bouncing, which means that the output from the switch bounces between logical high (i.e. the high voltage) and logical low (i.e. the low voltage which is often ground). As a result of this bouncing, the pin we are interested in reading goes rapidly and repeatedly between a circuit's high voltage rail and its low voltage rail. This can cause problems when reading switches as a single press can be registered as multiple presses by the microcontroller. Fortunately this can be overcome through switch debouncing, which is typically performed in software implementations (can also be performed at the hardware level). In both software and hardware there are multiple ways of dealing with problem, is explained on the second page http://www.ganssle.com/debouncing.htm. The hardware provided for this unit does not have hardware bouncing in the physical circuitry and consequently debouncing will have to be implemented with software. Switch debouncing is extremely important in producing microcontroller programs that are responsive to input.

### **Timers**

Each of the AVR microcontrollers typically has two or more timers. The Atmega32u4 chip has five timers. Generally, each of the timers comprises of slightly different hardware. As a result they often have different resolutions and consequently different applications. On the Atmega32u4 there is one 8-bit timer and two 16-bit timers. The predominant difference between an 8-bit timer and a 16-bit timer is the resolution (consider how many different values you can represent with 8 binary bits vs 16 binary bits). Another difference is that the 16-bit timers have more possible modes of operation than the 8-bit timers. For most AVR timers there are four modes of operation: 1) **normal**, 2) **clear timer on compare**, 3) **fast PWM**, and 4) **phase correct PWM**.

## The difference between Polling and Interrupts

In all of the solutions to the tutorials throughout this semester, the methods that you have made use of have been what is known as **polling**. A polling method one which constantly loops over the same code that checks each iteration to see if a particular state has changed (*i.e.* performing a desired action by continuously checking if a button has been pressed). In other words, when we are polling we are waiting for a specific event. This action is considered blocking due to the fact that no other code can be run until this condition is met. Consequently, this blocking code can cause problems in larger embedded systems where you have multiple inputs and outputs. It is in scenarios like these where the distinct advantage of interrupts is apparent. Interrupts can be thought of as event handlers (*i.e.* they will only execute when a certain event has occurred). Obviously, there are a number of different types of events that can occur on a microcontroller (e.g. UART data transmission, timing, overflow, ADC, etc). As a result, there are many different types of interrupts in the AVR microcontroller architecture that can be used to drive the execution of specific blocks of code.

## **Interrupt Operation**

Interrupts are a crucial part of writing code for embedded systems. As the name suggests, interrupts halt the execution of the main program and jumps to a prioritised section of code. This allows the immediate execution of functions when a specific hardware event occurs. In performing the immediate execution, the microcontroller goes through the following three steps:

- 1. Halts the current process (noting where it is in this process)
- 2. Runs the interrupt code until it completes
- 3. Returns back to the original process and continue from where it was before the interrupt

In AVR microcontroller programming, the interrupt code is called the interrupt service routine (ISR). The syntax for code that creates an ISR is similar to that of a function (except it does not need a declaration – only an implementation). An example of an ISR is shown below for the USART receive complete interrupt event (you must include avr/interrupt.h to run any interrupt related code):

```
ISR(USART_RXC_vect) {
    // Code to be executed within the interrupt routine
}
```

You can think of the ISR as basically an isolated section of code which will get called anytime an event occurs. Because this code blocks the execution of the main process, you must carefully consider what code to run within the interrupt. If you place code with a long execution time in an interrupt, you are essentially just reversing things so that your interrupt is blocking the execution of your main process (whereas before you had the main process blocking your extra process). This defeats the purpose of using an interrupt.

As already discussed, there are many different types of interrupts. Each type has as its own interrupt vector. In the above example, the interrupt vector is the **USART\_RXC\_vect** part. It is this part of the ISR declaration code that would need to be changed for a different interrupt event.

There are three important conditions that must be met for the ISR to be called and executed correctly:

- 1. The enable bit for global interrupts must be set. This allows the microcontroller to process interrupts via ISRs when set, and prevents them from running when cleared. It defaults to being cleared on power up, so we need to set it by using the **sei()** utility function. Conversely, you can clear it by using the **cli()** utility function.
- 2. The individual interrupt source's enable bit must explicitly be set. Each hardware interrupt source has its own separate interrupt enable bit (this resides in the related peripheral's control registers).
- The condition for the interrupt must be met. For example, a character must have been received through USART for the USART receive complete (USART\_RXC) interrupt to be executed.

# Printing floating point values on a microcontroller

Microcontrollers are limited in the resources that they have available to them. As a result, unnecessary functionality is not provided by default in libraries because the overhead it 'costs' the system is significant. Printing floating point values is one of these functionalities. To print floating point values when compiling with <code>avr-gcc</code>, you must explicitly tell the compiler to use a version of <code>printf</code> that prints floating point values. Otherwise, you will see a question mark instead of the number. To do this, you must include directives in the compilation command. Here is an up to date compilation command that you should use for this tutorial (note, the order is important):

```
avr-gcc <source>.c -mmcu=atmega32u4 -Os -DF_CPU=8000000UL
-std=gnu99 -I<lib_path> -L<lib_path> -Wl,-u,vfprintf
-lprintf_flt -lcab202_teensy -lm -o <output>.o
```

## **Assessable Exercises**

NOTE: You should use code you wrote from previous questions in the later questions. All questions are to be marked in your allocated tutorial session only!

#### 1. Implement software debouncing of a switch (1 mark)

Download the **question\_1\_template.c** source file from Blackboard. The code currently displays a press count that doesn't change with any button presses. When the function **check\_press\_debounced()** is called, the global variable press\_count should be incremented by 1 if the button was pressed. This must only happen on the release of the button (i.e. on the falling edge), and only once per physical button press. Implement a software debouncing solution in **check\_press\_debounced()** for a button of your choice that meets these conditions.

#### 2. Use a timer to print the system clock to the screen (1 mark)

Download the **question\_2\_template.c** source file from Blackboard. The code currently provides a verbose suggestion that it displays a system time, but only displays a default value. Complete the sections in **init\_hardware()** to configure TIMER1 in normal mode, and prescaled such that its maximum value (i.e. overflow) equates to approximately 8.3 seconds. Implement **get\_system\_time()** such that it returns the real time based on the supplied value of TIMER1, and update the main loop so that this value is correctly printed to the screen.

#### 3. Use a time-based interrupt to flash an LED at a constant rate (1 mark)

Download the **question\_3\_template.c** source file from Blackboard. The code currently does exactly the same as the previous question. The program must now toggle an LED once approximately every 2.1 seconds. Configure TIMER1 in **init\_hardware()** in a manner such that implementing the LED toggle in the overflow interrupt service routine (**ISR()**) for TIMER1 will produce the specified behaviour.

#### 4. Combine 3 interrupts and timers into a coherent program (1 mark)

Download the **question\_4\_template.c** source file from Blackboard. The code currently shows a smiley face moving across the screen. You must make use of timers, interrupts, and debouncing, such that:

- The 'system time' is displayed in the top right corner of the screen (correct to 3 decimal places). The maximum value of the system time, before it wraps back to 0, should be approximately 8.3 seconds.
- Approximately every 0.5 seconds, the LEDs must toggle (i.e. there must always be only one on at a time) and the screen should be drawn. This should show the system time in the top right corner going up by approximately 0.5 seconds.
- When one of the buttons is pressed, everything must be paused until it is released. The smiley must stop, the lights must stop flashing, and the system time should stop updating. On release, the smiley should continue where it was, the lights should continue flashing, and the system time should resume without having lost any time (i.e. if it was at 1 second, and paused for 2, it should resume at 3 seconds.