Contents

Parallel Architectures	1
Flynn's Taxonomy	2
Instruction Level Parallelism	2
Vector Computers	2
Multithreaded Computers	3
Multi-Core Computers	3
Shared Memory Multiprocessors	4
Distributed Memory Multicomputers	4
Clusters	4
Graphics Processing Units	5
Field Programmable Gate Arrays	5
Low Power Parallel Processors	6

Parallel Architectures

- $\bullet~$ Wide range of parallel architectures
- $\bullet\,$ Same ideas emerge again and again
 - $-\,$ Moore's law means that the components change that we build parallel computers from
 - So the trade-offs between components change
- $\bullet\,$ Different parallel architectures exploit parallel ism at different levels

Flynn's Taxonomy

- Prof. Mike Flynn's famous taxonomy of parallel computers
 - Single instruction stream, single data stream
 - * VLIW, found in Cell BE
 - Single instruction stream, multiple data streams
 - * Vector SIMD, found in Cell BE
 - Multiple instruction streams, single data stream
 - * Unusual, sometimes found in safety critical systems, found in Texas Instruments Hercules processors
 - Multiple instruction streams, multiple data streams
 - * Multiple parallel core, found in Cell BE
- It is quite difficult to fit many parallel architectures into Flynn's taxonomy
 - It's not entirely clear where some architectures fit
 - * Instruction level parallel
 - * Fine-grain speculative multithreading
- Most important distinction in between SIMD and MIMD

Instruction Level Parallelism

- Attempt to execute multiple machine instructions from the same instruction stream in parallel
- Two major approaches
 - Get the compiler to find instruction level parallelism
 - * VLIW, in-order superscalar
 - Get the hardware to find independent instructions in the running program
 - * Out-of-order superscalar

Superscalar is a processor that executes one or more instructions at once

Vector Computers

- Most machine instructions operate on a single value at a time
- Vector computers operate on an array of data with a single instruction
- Many parallel computing problems operate on large arrays of data

- Vector computers were some of the earliest and most successful parallel computers
- Vector instructions are a form of SIMD
 - Very popular on modern computers
 - Accelerate multimedia, games, scientific graphics apps
- Vector sizes are smallish
 - E.g. 16 bytes, four floats SSE, NEON
 - Intel AVX uses 32 bytes
 - Intel AVX-512 uses 64 bytes
- Vector SIMD used in Cell BE, where all SPE instructions are SIMD

Multithreaded Computers

- Pipelined computers spend a lot of their time stalled
 - Cache misses, branch mispredictions, long-latency instructions
 - Multi-threaded computers attempt to cover the cost of stalls by running multiple threads on the same processor core
 - Require very fast switching between threads
 - Separate register set for each thread
- Three major approaches
 - Switch to a different thread every cycle
 - Switch thread on a major stall
 - Use OoO superscalar hardware to mix instructions from different threads together
- Big problem in software programming must divide code into threads

Multi-Core Computers

- Power wall, ILP wall and memory wall pushed architecture designers to put multiple cores on a single chip
- Two major approaches
 - Shared memory multi-core
 - Distributed memory multi-core
- Shared memory is usually easier to program, but
 - Hardware does not scale well
 - Shared memory needs cache consistency
- Big problem is dividing software into threads

Shared Memory Multiprocessors

- Shared memory multiprocessors are parallel computers where there are multiple processors sharing a single memory
- · Main approaches
 - Symmetric multiprocessors
 - Non uniform memory access
 - * Usually a distributed shared memory
- Big problem in software

Distributed Memory Multicomputers

- A system of communicating processors each with their own memory
- Distributed memory scales really well
 - The hardware is simple
- Huge variety of configurations
 - Ring, star, tree, hypercube, mesh
- Programming is arguably even more difficult than for shared memory machines
 - Always need to move data explicitly to where it is needed

Clusters

- A group of loosely coupled computers that work closely and can be viewed as a single machine
- Multiple stand-alone machines connected by a network
- Clusters are a form of distributed memory multicomputers
 - But may support a virtual shared memory using software
- Most big supercomputers these days are clusters
 - $-\,$ It's usually cheaper to build large machines out of thousands of cheap PCs

Graphics Processing Units

- GPUs have very large amounts of parallelism on a single chip
 - Vector processing units
 - Multithreaded processing units
 - Multiple cores
- Originally aimed at graphics rendering
 - Very large memory bandwidth but high memory latency
 - Lots of low-precision floating point units
- Implement graphics pipeline directly
 - Generality was once very limited, but it getting better with each new generation of GPU
- Increasingly programmable
- Trend towards "general purpose computation" (GPGPU)
 - But mapping general purpose applications to GPU architecture is challenging
 - Only certain types of apps run well on GPU
- Special languages are popular on GPGPU

Field Programmable Gate Arrays

- Gate array there is an array of gates that can be used to implement hardware circuits
- Field programmable the array can be configured at any time "in the field" (programmed)
- FPGAs can exploit parallelism at many levels
 - Special purpose processing units
 - Fine grain parallelism circuit is clocked
 - Coarse grain parallelism FPGA can implement any parallel architecture that fits on the chip
- Seem like magic
 - GPUs like growing plants and eating them
 - FPGAs like feeding them to animals than eating the animal (not very efficient)

Low Power Parallel Processors

- Several big changes in computing
 - Giant computer room with single users: 1950s
 - Mainframe computers with hundreds of users: 1960s
 - Minicomputer with dozens of users: 1970s
 - Microcomputer with single user: 1980s
 - Networks and microcomputer servers: 1990s
 - Continuous network connection: 2000s
 - Mobile internet devices: 2010s
- Power and energy are extremely important for mobile computing
 - Trend towards mobile devices, mobile phones, we arable computing IoT
 - Battery life depends on energy consumption
 - Devices that consume very little energy can really add up
- Parallelism is alternative to faster clock
 - Dynamic power of capacitance \times frequency \times voltage²
 - Significant increase in clock normally requires increase in voltage
- Low power multiple processors
 - Often trade software complexity for hardware complexity
 - * Many VLIW processors
 - st Instruction-level parallelism under software control
 - * Complicated compilers
 - On-chip scratchpad memory instead of caches
 - * Caches need logic to find cache line
 - * Cache line tags, comparators, replacement logic, etc.
 - * Scratchpad memory is fully under software control
 - * Data transfers using so-called direct memory access (DMA)
 - * More complicated compilers, software
 - Cores do not share on-chip memory
 - * Programming must manage each core's scratchpad memory
 - * Explicit movement of data between cores