


Chapter 8 Nonlinear Systems Theory

- 8.1 Overview of Nonlinear Systems
- 8.2 Typical Nonlinear Characteristics and Mathematical Description
- 8.3 Describing Function Approach
- 8.4 Phase Plane Analysis




Interesting Examples of Nonlinearity



Lorenz Chaotic Attractor



Interesting Examples of Nonlinearity



Acrobot Robots





Biomimetic robots



§ 8.1 Overview of Nonlinear Systems

$$y^{(n)} + a_{n-1}y^{(n-1)} + \dots + a_1y' + a_0y + \varepsilon \cdot f(y, y', \dots y^{(n)}) = x$$

if $\varepsilon \to 0$, Linear Systems

if ε can't be ignored, Nonlinear systems

Such as:
$$\ddot{y} + \dot{y}\dot{y} + y = \sin \omega t$$

$$(\ddot{y})^2 + 3\dot{y} + y = e^t$$

$$\ddot{y} + 3\dot{y} + y^2 = x$$
Thinking: How to distinguish nonlinearity?





1 Significance of Studying Non-linear Systems

1) There are no systems without nonlinearity.

(*Dead-zone* characteristics of measurement element, *saturation* characteristics of amplification element, Dead-zone and saturation characteristics of actuator, *Gap* Characteristics of actuating unit and so on) °

- 2) The *intrinsic nonlinearities* make the linear system theory cannot be applied in analyzing the actual systems. The influences of nonlinear factors can not be explained by linear system theory.
- 3) The nonlinear characteristics do not always have negative impacts on systems. *Optimal control laws are often nonlinear laws*, such as the relay and waveform generator.

2. Features of Nonlinear Systems

Comparing with linear control systems, non-linear systems have many new features:

- 1. A linear systems satisfies the *principle of superposition*, while a non-linear system does not.
 - (1) additivity: y = f(x)

$$f(x_1 + x_2) = f(x_1) + f(x_2)$$
 additivity

$$f(x) = ax$$
 A linear function satisfies the principle of superposition obviously



Thinking:
$$f(x) = ax + b$$



Superposition Theorem

(2) multiplicativity :

$$f(ax) = af(x)$$

Nonlinear systems may be additive, but it is not multiplicative.




Fig. 8—1 Nonlinear systems with filters

$$X_1 o Y_1, \ X_2 o Y_2$$
 additivity: $X_1 + X_2 o Y_1 + Y_2$ multiplicativity : $nX_1 o nY_1$ 7



2. The stabilities of non-linear systems depend on not only the inherent structure and parameters of control systems, but also the *initial conditions* and the *inputs*.

Example: An nonlinear systems described by the non-linear differential equation: $\dot{x} = -x(1-x)$

have two equilibrium points obviously, x1=0 and x2=1. The equation equals to

$$\frac{dx}{x(1-x)} = -dt$$

Integrating both sides:
$$\ln \frac{cx}{1-x} = -t$$
 $\therefore \frac{cx}{1-x} = e^{-t}$

Set the initial state of the system be x_{0} , if t=0, then:

$$c = \frac{1 - x_0}{x_0}$$




Fig. 8–2 First-order non-linear systems

If
$$x_0 < 1$$
, $t \to \infty$, then $x \to 0$

0

Initial conditions affect stability of the system!

If
$$x_0 > 1$$
, when $t = \ln \frac{x_0}{x_0 - 1}$, we have $x \to \infty$



 The initial conditions can be even used as a key to the encryption of transmission signals in Chaotic systems





- 3. *Periodic oscillation* does not exist in an actual physical linear systems, while it may occur in a nonlinear system.
- 4. A stable linear system under a *periodic input* → output with the same frequency; A nonlinear system under a periodic input → many complex cases of the outputs

(1) Jump resonance and Multi-valued response Input signals with constant amplitude, then the amplitude frequency characteristics of the output is: $A(\omega)$

$$\omega \uparrow : 1 \to 2 \to 3 \stackrel{\updownarrow}{:} \to 4 \stackrel{\vdash}{:} \to 5$$

$$\omega \downarrow : 5 \rightarrow 4 \rightarrow 4' : \stackrel{\updownarrow}{\rightarrow} 2' : \rightarrow 1$$





Fig. 8-3 Amplitude frequency characteristic of output of non-linear spring

(2) subharmonic oscillation and harmonic oscillation



Steady-state outputs of non-linear systems can be divided into subharmonic oscillation and harmonic oscillation. When the input signal is sinusoidal, showed in Fig. 8-4




Fig. 8-4 subharmonic oscillation and harmonic oscillation



- 1) Phase-Plane Analysis is the graphical method used to analyze first-order and second-order Nonlinear systems. It analyzes the features of Nonlinear systems through drawing *phase portrait* to find all the solutions of the differential equations in any initial condition. It is the generalization and application of time-domain analyzing method in non-linear systems. *It can only be used in the first- and second-order nonlinear systems*.
- 2) Describing Function Approach is a kind of method for analyzing nonlinear systems inspired by frequency method of linear systems. It is the generalization of frequency method in nonlinear systems, and *is not restricted by the system order*.
- 3) Numerical Solution is a kind of numerical methods to solve the nonlinear differential equation using high-speed computers. It is almost the only effective method for analyzing and designing *complex nonlinear systems*.



Note:

- It should be pointed out that, the above methods aim at solving the "analysis" problems of nonlinear systems based on analyzing the system stability.
- The achievement of "synthesis" methods in nonlinear systems is much less than stability problem. There are NO general approaches can be used to design arbitrary nonlinear systems so far.



§ 8.2 Typical Nonlinear characteristics and Their Mathematical Description

- **8.2.1** Saturation characteristics
- 8.2.2 Dead-zone characteristics
- 8.2.3 Gap characteristics
- **8.2.4** Relay characteristics



1. Saturation

A common nonlinearity in electronic amplifiers

Mathematical description of saturation features:

$$x(t) = \begin{cases} ke(t), & |e(t)| < e_0 \\ ke_0 sign[e(t)], & |e(t)| \ge e_0 \end{cases}$$

sign[e(t)] is the sign function

$$sign[e(t)] = \begin{cases} 1, & e(t) \ge 0 \\ -1, & e(t) < 0 \end{cases}$$




Fig. 8-5 Saturation characteristics

2. Dead-zone

Dead-zone can be also called neutral zone, its mathematical description is:

$$x(t) = \begin{cases} 0, & |e(t)| \le e_0 \\ k[e(t) - e_0 sign[e(t)]], & |e(t)| > e_0 \end{cases}$$

$$x(t) \xrightarrow{e_0} \xrightarrow{e_0} e(t)$$

Fig. 8-6 Dead-zone characteristics

3. Gap

Mechanical transmission devices are based on gears, there must exist some gaps for sliding and reversing transmission, that means the gears have to pass a few distances when reversing transmission is needed. $\mathbf{v}(t)$

Its mathematical description is:

$$x(t) = \begin{cases} k[e(t) - e_0], & \dot{x}(t) > 0 \\ k[e(t) + e_0], & \dot{x}(t) < 0 \\ bsign[e(t)], & \dot{x}(t) = 0 \end{cases}$$





Fig. 8-7 Gap characteristics

3. Gap



Input x is the rotation angle of the driven gear Output y is the rotation angle of the passive gear



4. Relay




图1 电磁式继电器原理图

1- 铁心 2-旋转棱角 3-释放弹簧 4-调节螺母 5--衔铁6-动触点 7-静触点 8-非磁性垫片 9-线圈


Principle of relay:

Input voltage → Current in coil → generates the electromagnetic force → Close the relay contact

If the input voltage is e_0 , the electromagnetic force generated by current in coil is enough to make the switch to be closed, then e_0 is called *Operation Voltage*.




4. Relay



The relay contact will not release when the input voltage is reduced to e_0 because of the influence of Hysteresis.

When it is further reduced to me_0 (m < 1), the relay contact will be released. Then me_0 is called Release Voltage.

图1 电磁式继电器原理图 1- 铁心 2-旋转棱角 3-释放弹簧 4-调节螺母 5--衔铁 6-动触点 7-静触点 8-非磁性垫片 9-线圈



There are four forms of relay characteristics:



1. Ideal relay characteristics

$$x(t) = \begin{cases} M, & e > 0 \\ -M, & e < 0 \end{cases}$$




Fig. 8-8(a) Perfect relay characteristics



2. Relay characteristics with Dead-zone




Fig. 8-8(b) Relay characteristics with Dead-zone



3. Relay characteristics with Hysteresis loop

$$x(t) = \begin{cases} M, & \dot{e} > 0, e > e_{0} \\ \dot{e} < 0, e > -e_{0} \end{cases}$$

$$-e_{0} \quad 0 \quad e_{0} \quad e(t)$$

$$\dot{e} > 0, e < e_{0}$$

$$\dot{e} < 0, e < -e_{0}$$

Fig. 8-8 (c) Relay characteristics with Hysteresis loop

 $\mathbf{x}(\mathbf{t})$

4

4. Relay characteristics with Deadzone and Hysteresis loop

$$x(t) = \begin{cases} M, & \dot{e} > 0, e \ge e_0 \\ \dot{e} < 0, e > me_0 \end{cases}$$

$$\dot{e} > 0, -me_0 < e < e_0 \\ \dot{e} < 0, -e_0 < e < me_0 \end{cases}$$

$$\dot{e} > 0, -me_0 < e < e_0 \\ \dot{e} < 0, -e_0 < e < me_0 \end{cases}$$




Fig. 8-8(d) Relay characteristics with Dead-zone and Hysteresis loop