WAVES: ABBEY ROAD REDD.17

USER GUIDE







Table of Contents

Chapter 1 – Introduction	3
1.1 Welcome	3
1.2 Product Overview	3
1.3 About REDD	4
1.4 Components	4
Chapter 2 – Quick Start Guide	5
Chapter 3 – Interface and Controls	6
3.1 Interface	6
3.2 Controls	7
Chapter 4 – The WaveSystem	10
4.1 The WaveSystem Toolbar	10
4.2 Preset Handling	10
4.3 Interface Controls	13
4.4 Waves Preferences (Pro Tools only)	15

REDD is a trademark of EMI (IP) Limited, used under license.

Chapter 1 – Introduction

1.1 Welcome

Thank you for choosing Waves. In order to get the most out of your Waves processor,

please take the time to read through this manual.

In conjunction, we also suggest you become familiar with www.wavesupport.net. There

you will find an extensive **Answer Base**, the latest **Tech Specs**, detailed **Installation**

guides, new Software Updates, and current information on Authorization and

Registration.

By signing up at www.wavesupport.net, you will receive personalized information on

your registered products, reminders when updates are available, and information on

your authorization status.

1.2 Product Overview

London's Abbey Road Studios were at the epicenter of a seismic shift that rocked the

world of music during the 1960s, and changed the course of popular culture forever. The

Beatles, The Hollies, Pink Floyd and countless other luminaries made musical history at

Abbey Road Studios, trailblazing a revolution that resonates to this day.

And at the heart of it all: The REDD consoles, custom-designed, built by and named for

Abbey Road Studios' in-house Record Engineering Development Department.

Renowned for their silky smooth EQ curves, extraordinary warmth and lush stereo

imagery, there's something magical about the REDDs that sound like no other console.

Waves meticulously recreated the color, character and tonal complexity of the original

desks: The REDD.17 which still belongs to Abbey Road Studios, and the REDD.37

console now owned by Lenny Kravitz. The result is an impressive pair of plugins that

deliver the dimension, depth and richness of these console classics.

Waves: Abbey Road REDD.17

1.3 About REDD

Since its opening in 1931, Abbey Road Studios have been known as a bastion of

recording excellence and innovation. EMI's Recording Engineer Development

Department (REDD) was established in 1955 by Abbey Road Studios technical engineer

Lenn Page to address the needs of the then-burgeoning stereophonic format. Within a

year, the team's efforts had led to the production of the REDD.1 console, Abbey Road

Studios' first dedicated stereo mixing system, which consisted of a REDD.8 mixer and a

rack that housed its amplifiers and other components.

In 1957, its successor was created: The REDD.17, designed by Peter Burkowitz of EMI's

German affiliate, was one of the first desks to conform to the design we've come to

expect from mixing consoles, with EQ on each of its eight channels. Like the REDD.1

before it, the REDD.17 was a mono/stereo board.

Later the following year, in response to the growing popularity of the four track recording

format, the third in the series, the REDD.37, was released. Both the REDD.17 and

REDD.37 were powered exclusively by legendary Siemens V72 valve amplifiers and, in

the case of the REDD.37, at least 31 of them!

The REDD.37 was followed by the REDD.51, which used newer REDD.47 amps, and

offered lower distortion and more headroom than the V72s. Originally created in 1959, it

was not until 1963 that the .51 found its way to Abbey Road Studios. Four of the .51

desks were ultimately built; by 1968, they were slowly phased out by EMI's next

generation of solid-state eight and sixteen track consoles, the TG series.

1.4 Components

WaveShell technology enables us to split Waves processors into smaller plugins, which

we call **components**. Having a choice of components for a particular processor gives

you the flexibility to choose the configuration best suited to your material. REDD.17

includes the following components:

o REDD.17 Mono


o REDD.17 Stereo

Chapter 2 – Quick Start Guide

- 1. Open the REDD.17 on a track.
- 2. Adjust Tone Low and/or Tone High as needed.
- 3. Adjust the drive control to increase or decrease the distortion level, until the desired result is achieved.
- 4. Using the output control, adjust the output level as needed.

Chapter 3 – Interface and Controls

3.1 Interface



3.2 Controls

1. Channel Select determines the channel configuration.

In order to replicate the true stereo sound of the original desk, Waves modeled two individual console channels. The differences are subtle but audible, and add richness to the sound. To maintain optimal stereo consistency, select the same channel settings for both left and right channels.

2. Gain controls the input gain.

Range: -24 dB - +12 dB

3. Bass Lift controls the 9 dB low shelf that compensates for low frequency loss caused by using condenser microphones in a Figure 8 configuration.

Range: 10 dB pad (left), bypass (center), and 9 dB low shelf (right)

4. Tone Low controls low shelf equalization.

Range: -6 - +6 dB (in .01 increments)

5. Tone High controls high shelf equalization.

Range: -6- +6 dB (in .01 increments)

5. Monitor controls the source of the monitor output. (Stereo component only)

Range – Stereo (ST) and Duo modes:

- L (left side only)
- Mono (stereo signal summed to mono)
- Stereo
- R (right side only)

Range – MS mode:

- M (left plus right)
- Mono (stereo signal summed to mono)
- Stereo
- S (left minus right)

7. Spread selects stereo processing mode. (Stereo component only)

- Stereo links the channels and applies the same processing to both.
- Duo unlinks the channels and offers the option of applying different processing to each.
- MS applies an MS encoding matrix on the input to the plugin. The signal
 enters the EQ for separate processing to Mid and Side information, which is
 subsequently decoded back to stereo on the output.

8. Drive controls the amount of drive added to the signal. Lower values result in a cleaner sound; higher values result in a more distorted sound.

Range: -24 - +24 dB

9. Analog controls the level of modeled noise and the hum.

Range: -24 (off) - +24 dB

10. Output controls the output level of the signal. Unlike the Gain control, Output level does not affect the amount of distortion added to the signal.

Range: -24 - +12 dB

11. VU Meters display output VU readings.

Range: -20 - +3 dB

12. VU Level Calibration sets the dBFS level that appears as 0 VU.

Range: -24 - -8 dBFS

13. Peak Meter displays signal peak output levels.

Range: -40 - 0 dBFS

Chapter 4 – The WaveSystem

4.1 The WaveSystem Toolbar

All Waves plugins feature the WaveSystem toolbar which takes care of most administrative functions you will encounter while working with your Waves software. The features of the WaveSystem toolbar are the same on practically all Waves plugins, so familiarity with its features will be helpful whichever plugin you are using.

Toolbar Functions

₩ Opens the plugin About box

Undo Undoes the last 32 actions

Redo Redoes the last 32 undone actions

Setup A/B Toggles between two presets, useful for comparison of parameter

settings

L/R Arrows Move to the previous or next preset

Copy A→**B** Copies the current settings to the second preset register

Load Recalls presets from file

Save Saves presets in the Waves file formats

? Opens the PDF manual for the plugin you are using

4.2 Preset Handling

Preset Types

Factory Presets are permanent presets in the Load menu. Factory presets cannot be overwritten or deleted. When applicable, different component plugins may have different factory presets.

User Presets are your favorite settings of the plugin saved as a preset in the Load menu, under 'User Presets'. User Presets can be overwritten and deleted.

Setup Files may contain more than one preset. For example, a single file can contain all the presets for a session. When you open a Setup File, all its setups become part of your Load pop-up menu for fast access. This can be particularly useful with multiple instances of a plugin in a single session. By saving all the settings you create into a single Setup File, they can all be quickly available for every instance of that plugin.

Loading Presets and Setups



Click on the Load button to see the Load pop-up menu. The menu is divided into four sections. If a section is not currently available it will not appear in the Load pop-up menu.

Open Preset File... Select to open any setup or preset file, whether from the Library or

your own creations.

'Filename.xps': Displays any currently loaded Setup File and its presets.

Factory Presets: Displays the default Factory Presets.

User Presets: Displays any loaded User Presets.

Saving Presets and Setups



Click on the Save button to see the Save pop-up menu. Four options are available. If an option is not currently available it will be grayed out and inaccessible.

Save to New File... Select this to start a new Setup file. There are two

prompts - first for the setup filename, then for the preset name. You must provide a name for both the

setup file and the preset. Click OK (ENTER) to complete the save. It is a good idea to create a folder in which to save several setup files for a

project.

Save 'File Name' - "Preset Name" Overwrites the settings of the loaded preset

(whether a User Preset or a preset from a Setup File) with the current settings. If a Setup File is

currently loaded, the name of the Setup File is

displayed followed by the name of the preset itself.

If a User Preset is loaded, its name is displayed.

Save to 'File Name' As... Saves the current settings as a new preset into the

Setup file that is open (if one is not open, the option

is grayed out). You will be prompted to give the

preset a name.

Put into Preset Menu As... Save the current settings into a User Preset that

will always be in your Load menu (until deleted).
You will be prompted to give this preset a name.

User Presets are stored in the plugin's preference

file.

Deleting Presets

You may delete User Presets and presets within a Setup File. Factory Presets and Setup Library files cannot be deleted or overwritten.

- 1. Hold the Command (Mac)/Control (PC) key down.
- 2. Click-and-hold the Load button to see the pop-up menu.
- 3. While still holding the Command/Control key, select the preset or setup to delete.
- 4. A confirmation box will appear, allowing you to cancel or 'OK' the deletion.

A/B Comparison and Copying



The Setup A/Setup B button may be clicked to compare two settings. If you load a preset in the Setup B position, this will not affect the preset loaded into the Setup A position, and vice-versa.

If you want to slightly modify the settings in Setup A, you can copy them to Setup B by clicking on the Copy to B button, then alter Setup A and compare with the original Setup B.

The name of the current setup will be shown in the title bar (on platforms which support

it), and will switch as you change from Setup A to Setup B.

Note: an asterisk will be added to the preset name when a change is made to the preset.

4.3 Interface Controls

Controls can be in one of three states:

1. Not Selected where the control is not the target of any user entry

2. **Selected** where the control is the target of mouse control entry only

3. **Selected and Active** where the control is the target for both mouse and

keyboard entry

Toggle Buttons

Toggle buttons display the state of a control, and allow switching between two or more

states. **Single-click** to change the control's state. Some toggle buttons have a text

display which updates with the current setting, and others (bypass, solo, or monitoring

toggles) illuminate when the control is active.

Some plugins have **link buttons** between a pair of toggle buttons, allowing click-and-

drag adjustment while retaining the offset between the controls.

Value Window Buttons

Value windows display the value of a control and allow click-and-drag adjustment, or

direct control via the keyboard.

❖ Using the mouse, click-and-drag on the value window to adjust. Some value

windows support left/right, some up/down (as you hover over a button, arrows

will appear to let you know which direction of movement that button supports).

You may also use your mouse-wheel to adjust parameter values.

❖ Using the arrow keys, click once with mouse to select the button, and then use

up/down – left/right (depending on the direction supported by that button) to

move in the smallest incremental steps across the button's range (holding down

the arrow keys will move faster through the range).

❖ Using key entry, double click on the button to open the value window, and

directly enter the value from your keyboard. If you enter an out of range number,

the button stays selected but remains at the current setting. (System beeps if

system sounds are on.)

Some plugins have link buttons between a pair of value windows, allowing click-and-

drag adjustment while retaining the offset between the controls.

Sliders

Click or scroll the mouse-wheel on the slider itself or anywhere within the sliders track.

The numerical value of the slider settings is displayed in a hover window above the

slider path.

Hover Box

Hovering boxes will appear and display the control value when hovering with the mouse

over the control.

Multiple Control Selection

One of the most powerful features of the WaveSystem is the ability to select and adjust

multiple controls simultaneously. Using the mouse, drag-select the desired group of

buttons or graphic controls by clicking and holding at a point outside the controls, and

forming a rectangle that includes the controls you wish to adjust. Alternatively, press and

hold Shift while clicking the mouse on any control you wish to link. This method is useful

when you want to select two or more controls that are not adjacent to one another.

TAB Functions

TAB moves the 'selected' status to the next control, with shift-TAB moving in the reverse

direction.

Additionally, the Mac has an option-TAB function for 'down' movement and shift-option-

TAB for 'up' movement where applicable.

If you have several Value Window Buttons selected, TAB functions will take you through

the selected controls only.

Hitting Esc or Return will return the 'focus' to the DAW application.

4.4 Waves Preferences (Pro Tools only)

When launching Pro Tools, hold Shift to view the Waves plugin Preferences window.

The following options are available:

Don't use AudioSuite plugins

Don't use RTAS plugins

Rescan all plugins

• HUI control surface support (low resolution)

Enable single-click text entry

Waves: Abbey Road REDD.17
User Guide

15