

For more information, please visit http://six4pix.com/split.

You can also contact me with questions or feedback at sixtyfourpixels@gmail.com Cheers, Jason

3.5mm Stereo Mini Jack Socket

Use a stereo jack cable to connect a device using 3.5mm MIDI out with a "hot" tip (Novation, Arturia etc. *not* Korg) as an alternative to 5 pin MIDI input Do not try to use both MIDI input sockets at the same time!

Beat Indicator LED

Blinks at the rate of once per quarter note when a MIDI clock is present. Will synchronise to master beat clock when a "start" message is received

Activity LED
Blinks when there any MIDI activity



Power Socket

Power Socket
Banana split can accept
power via a 2.1mm barrel
connector (such as a guitar
pedal supply) with positive
tip or negative tip.
Voltage of between 9 and
12V DC is recommended.
Do not exceed 15V.

Banana split can accept power via a 2.1mm barrel connector (such as a guitar pedal supply) with positive tip or negative tip. Voltage of between 9 and 12V DC is recommended. Do not exceed 15V.

Standard 5-Pin MIDI input

Use a standard MIDI cable to connect your master MIDI device. Inputs are optically isolated per MIDI standard

5-Pin MIDI Outputs

All six outputs are electrically buffered and pass MIDI information directly from the input with near zero latency.

All six outputs always send identical MIDI information.

Thank you for purchasing a Banana Split! I hope you find it useful and enjoy using it.

For more information, please visit http://six4pix.com/split.

You can also contact me with questions or feedback at sixtyfourpixels@gmail.com Cheers, Jason

3.5mm Stereo Mini Jack Socket

Use a stereo jack cable to connect a device using 3.5mm MIDI out with a "hot" tip (Novation, Arturia etc. *not* Korg) as an alternative to 5 pin MIDI input Do not try to use both MIDI input sockets at the same time!

Beat Indicator LED

Blinks at the rate of once per quarter note when a MIDI clock is present. Will synchronise to master beat clock when a "start" message is received

Power LED

Activity LED Blinks when there any MIDI activity ACTIVITY LED Blinks when there is powered ACTIVITY LED Blinks when there is powered ACTIVITY LED Blinks when there is powered ACTIVITY LED Blinks when the device is powered ACTIVITY LED Blinks when the device is powered ACTIVITY LED Blinks when there is powered ACTIVITY

Standard 5-Pin MIDI input

MIDI INPUT

Use a standard MIDI cable to connect your master MIDI device. Inputs are optically isolated per MIDI standard

5-Pin MIDI Outputs

All six outputs are electrically buffered and pass MIDI information directly from the input with near zero latency.

All six outputs always send identical MIDI information.