

Dual RECTIFIER (v1.1F) DIY BUILD GUIDE

This build guide assumes the user has basic knowledge of through hole components, soldering skills and various tools required to Do-It-Yourself. Assemble at your own risk and have fun.

STEP BY STEP

- 1. Populate all resistors and ferrite beads. Solder and clip leads.
- 2. Populate all diodes, taking care to align the black band on the diode with the stripe shown on the PCB. Solder and clip leads.
- 3. Populate all of the ceramic capacitors. Solder and clip leads.
- 4. Populate all of the ICs, taking care that the notch at the top of the IC lines up with the notch shown on the PCB. Solder leads.
- 5. Populate the IDC power connector, taking care to line up the notch on the part with the notch shown on the PCB. Hold the connector in place while soldering
- 6. Populate the electrolytic capacitors, taking care to line up the black stripe on the caps with the outlined via on the PCB. Solder and clip leads.
- 7. Place each the of the jacks into the board and install the faceplate. Finger tighten each nut in place to ensure the jacks are straight. Solder them once you are satisfied.
- 8. Carefully check the solder of each component for bridges and any solder joints that may have been missed. Clean excess flux with alcohol. You may now test it your work.

BILL OF MATERIALS

1	1.5K	R2
4	100K	R6, R8, R30, R32
15	100n	C3, C4, C5, C6, C7, C8, C9, C10, C11, C12, C13, C14, C15, C16, C17
2	10u 25v	C1, C2
31	1K	R3, R4, R5, R10, R12, R13, R14, R15, R16, R17, R18, R20, R21, R22, R23, R24, R25, R34, R36, R37, R38, R39, R40, R41, R42, R44, R45, R46, R47, R48, R49
2	1N4001	D1, D2
1	4.99K	R1
15	499R	R7, R9, R11, R19, R26, R27, R28, R29, R31, R33, R35, R43, R50, R51, R52
8	1n5711	D3, D4, D5, D6, D7, D8, D9, D10
2	68R	FB1, FB2
6	LM6172	IC3, IC4, IC5, IC6, IC8, IC87
1	TL072	IC2

Other Parts

1 TL431

8X	PJ302M Jacks
8x	3.5mm nuts
1x	2x5 Polarized IDC Power Header
1x	10-16 Ribbon Cable
1x	Rectifier PCB
1x	Rectifier Faceplate

IC1

