
uC/OS-II Part 5: 80x86 Port

Prof. Li-Pin Chang ESSLab@NCTU

Registers and Addressing of x86 Real Mode (or virtual 86 mode)



OS_CPU.H

```
typedef unsigned char BOOLEAN;
typedef unsigned char INT8U;
typedef signed char INT8S;
typedef unsigned int INT16U;
typedef signed int INT16S;
typedef unsigned long INT32U;
typedef signed long INT32S;
typedef float FP32;
typedef double FP64;
```

OS_CPU.H

```
#define OS CRITICAL METHOD
#if
        OS CRITICAL METHOD == 1
#define OS_ENTER_CRITICAL() asm CLI
#define
        OS EXIT CRITICAL() asm STI
#endif
#if OS CRITICAL METHOD == 2
#define OS ENTER CRITICAL() asm {PUSHF; CLI}
#define OS EXIT CRITICAL() asm POPF
#endif
#if OS CRITICAL METHOD == 3
#define OS_ENTER_CRITICAL() (cpu_sr = OSCPUSaveSR())
#define
        OS EXIT CRITICAL() (OSCPURestoreSR(cpu sr))
#endif
#define OS STK GROWTH
#define uCOS
                           0x80
#define OS TASK SW()
                                INT
                                      uCOS
                           asm
OS CPU EXT INT8U OSTickDOSCtr;
```

OS_CPU_C.C


- OSTaskStkInit
- OSTaskStkInit_FPE_x86
 - Borland floating point emulator
- Hook functions
 - OSTaskCreateHook()
 - OSTaskDelHook()
 - OSTaskSwHook()
 - OSTaskIdleHook()
 - OSTaskStatHook()
 - OSTimeTickHook()
 - OSInitHookBegin()

OSTaskStkInit()

- All ready tasks are interrupted and about to leave an ISR
 - A newly created task is a ready task
- Emulate the stack context of a new task as if the task is interrupted and about to leave an ISR

```
_OSTickISR PROC
                   FAR
                     Save current task's context
      PUSHA
      PUSH
             ES
      PUSH
             DS
_OSCtxSw
            PROC
                   FAR
      PUSHA
                    ; Save current task's context
      PUSH
             ES
      PUSH
             DS
```

OSTaskStkInit()



language function return

OS CPU.C – OSStkInit()

```
169 OS STK *OSTaskStkInit (void (*task) (void *pd).
170□
        void *pdata, OS STK *ptos, INT16U opt) {
         INT16U *stk:
171
172
     opt = opt;
173 stk = (INT16U *)ptos;
*stk-- = (INT16U)FP SEG(pdata);
                                                     LOW MEMORY
      *stk-- = (INT16U)FP OFF(pdata);
175

    Stack Pointer

     *stk-- = (INT16U)FP SEG(task);
176
                                                                        (4)
     *stk-- = (INT16U)FP OFF(task);
177
     *stk-- = (INT16U) 0x0202;
178
                                            (3)
       *stk-- = (INT16U)FP SEG(task);
                                                    Saved Processor Registers
179
        *stk-- = (INT16U)FP OFF(task);
180
        *stk-- = (INT16U) 0xAAAA;
181
        *stk-- = (INT16U) 0xCCCC;
182
                                                     Interrupt Return Address
                                                                    Stack Growth
                                            (2)
     *stk-- = (INT16U) 0xDDDD;
183
                                                     Processor Status Word
     *stk-- = (INT16U)0xBBBB;
184
                                                      Task start address
                                            (1)
       *stk-- = (INT16U)0x0000;
185
       *stk-- = (INT16U)0x1111;
186
187
     *stk-- = (INT16U)0x2222;
                                                     HIGH MEMORY
      *stk-- = (INT16U)0x3333;
188
       *stk-- = (INT16U)0x4444;
189
190
        *stk = DS;
191
        return ((OS STK *)stk);
192 }
```

OS_CPU.C - OSStkInit()

```
169 OS STK *OSTaskStkInit (void (*task) (void *pd),
        void *pdata, OS STK *ptos, INT16U opt) {
170
171
         INT16U *stk:
172
        opt = opt;
        stk = (INT16U *)ptos;
173
174
        *stk-- = (INT16U)0xFFFF;
                                                        LOW MEMORY
175
                                                                      Stack Pointer
176
                                                                           (4)
     *stk-- = (INT16U)FP SEG(OSTaskDel);
177
*stk-- = (INT16U)FP OFF(OSTaskDel);
                                               (3)
                                                       Saved Processor Registers
179 *stk-- = (INT16U)0 \times 0202;
      *stk-- = (INT16U)FP SEG(task);
180
     *stk-- = (INT16U)FP OFF(task);
181
182 *stk-- = (INT16U)0xAAAA;
                                                        Interrupt Return Address
                                                                       Stack Growth
                                               (2)
183 *stk-- = (INT16U)0xCCCC;
                                                        Processor Status Word
184 *stk-- = (INT16U)0 \times DDDD;
                                                         Task start address
                                               (1)
185 *stk-- = (INT16U) 0xBBBB;
                                                        @OSTaskDel
186 *stk-- = (INT16U)0 \times 00000;
                                                          0xFFFF
187 *stk-- = (INT16U)0x11111;
                                                        HIGH MEMORY
188 *stk-- = (INT16U)0x22222;
189 *stk-- = (INT16U)0x33333;
190 *stk-- = (INT16U)0x4444;
191 *st.k = DS:
        return ((OS_STK *)stk);
192
                                                                             10
193 }
```

OS_CPU.C - OSStkInit()

```
void OSTaskDelSelf() {
         OSTaskDel(OS PRIO SELF);
OS STK *OSTaskStkInit (void (*task) (void *pd), void *pdata, OS STK *ptos, INT16U opt)
    INT16U *stk;
                                                            LOW MEMORY
                                                                               — Stack Pointer
    opt
            = opt;
                                                                                  (4)
    stk
            = (INT16U *)ptos;
    *stk-- = (INT16U)FP_SEG(pdata);
    *stk-- = (INT16U)FP OFF(pdata);
                                                           Saved Processor Registers
    *stk-- = (INT16U)FP SEG(OSTaskDelSelf);
    *stk-- = (INT16U)FP OFF(OSTaskDelSelf);
    *stk-- = (INT16U) 0x0202;
    *stk-- = (INT16U)FP SEG(task);
                                                            Interrupt Return Address
                                                                              Stack Growth
    *stk-- = (INT16U)FP OFF(task);
                                                  (2)
                                                            Processor Status Word
    *stk-- = (INT16U) 0xAAAA;
                                                          @OSTaskDelSelf
    *stk-- = (INT16U) 0xCCCC;
                                                  (1)
    *stk-- = (INT16U) 0 \times DDDD;
                                                                'pdata'
    *stk-- = (INT16U) 0xBBBB;
    *stk-- = (INT16U) 0 \times 00000;
                                                            HIGH MEMORY
    *stk-- = (INT16U) 0 \times 11111;
    *stk-- = (INT16U) 0x2222;
    *stk-- = (INT16U) 0x3333;
    *stk-- = (INT16U) 0x4444;
                                                   void OSTaskDelSelf() {
    *stk = DS;
                                                              OSTaskDel(OS PRIO SELF);
    return ((OS STK *)stk);
                                                                                                 11
```

OS_CPU_A.ASM

- OSStartHighRdy
 - Context switch on OSStart()
- OSCtxSw
 - Task-level context switch (via int 80h)
- OSIntCtxSw
 - Interrupt-level context switch
- OSTickISR
 - Clock tick ISR

OSStartHighRdy()

```
OSStartHighRdy
                PROC FAR
                  AX, SEG OSTCBHighRdy
                                                 ; Reload DS
           MOV
                  DS, AX
           MOV
                  FAR PTR OSTaskSwHook ; Call user defined task switch hook
            CALL
                  AL, 1
                                                 ; OSRunning = TRUE;
           MOV
                  BYTE PTR DS: OSRunning, AL ;
                                                     (Indicates that multitasking has started)
           MOV
                  BX, DWORD PTR DS: OSTCBHighRdy ; SS:SP = OSTCBHighRdy->OSTCBStkPtr
           LES
           MOV
                  SS, ES:[BX+2]
                  SP, ES: [BX+0]
           MOV
            POP
                                                 ; Load task's context
            POP
            POPA
            IRET
                                                 ; Run task
OSStartHighRdy
                ENDP
```

OSCtxSw()

- A task-level context switch is accomplished by triggering a software interrupt (the macro OS_TASK_SW)
- The software trap vectors to the OSCtxSw
- OSCtxSw is installed at ISR 0x80

OSCtxSw()


```
OSCtxSw
           PROC
                  FAR
           PUSHA
                                                  ; Save current task's context
           PUSH
                  ES
           PUSH
                  DS
;
                                                 ; Reload DS in case it was altered
                  AX, SEG OSTCBCur
           MOV
                  DS, AX
           MOV
;
                  BX, DWORD PTR DS: OSTCBCur
           LES
                                                 ; OSTCBCur->OSTCBStkPtr = SS:SP
                  ES:[BX+2], SS
           MOV
                                                       Save the current SS:SP to TCB
                  ES:[BX+0], SP
           MOV
;
                                                 ; Call user defined task switch hook
                  FAR PTR OSTaskSwHook
           CALL
                  AX, WORD PTR DS: OSTCBHighRdy+2 ; OSTCBCur = OSTCBHighRdy
           MOV
                  DX, WORD PTR DS: OSTCBHighRdy ;
           MOV
                  WORD PTR DS:_OSTCBCur+2, AX ;
           MOV
                                                      Change the pointer *OSTCBCur
                  WORD PTR DS: OSTCBCur, DX
           MOV
                                                          A pointer is of 4 bytes
```

OSTCBHighRdy→ task to be switched to OSTCBCur→the currently running task

OSCtxSw()

```
AL, BYTE PTR DS: OSPrioHighRdy ; OSPrioCur = OSPrioHighRdy
            MOV
                   BYTE PTR DS: OSPrioCur, AL
            MOV
                   BX, DWORD PTR DS: OSTCBHighRdy ; SS:SP = OSTCBHighRdy->OSTCBStkPtr
            LES
                   SS, ES:[BX+2]
            MOV
                                                      ES:BX→OSTCBHighRdy
            MOV
                   SP, ES: [BX]
                                                   ; Load new task's context
            POP
                   DS
            POP
                   ES
            POPA
            IRET
                                                   ; Return to new task
OSCtxSw
            ENDP
```

OSPrioHighRdy: the priority of the HPT




OSIntCtxSw()

- OSIntCtxSw is called by OSIntExit to perform a context switch when returning from an ISR
 - It is already in ISR
- All registers, including SS:SP, has been saved in the stack of the interrupted task (ISR prologue)

OSIntCtxSw()

```
_OSIntCtxSw PROC
                  FAR
                  FAR PTR OSTaskSwHook ; Call user defined task switch hook
           CALL
                                                 ; Reload DS in case it was altered
                  AX, SEG OSTCBCur
           MOV
                  DS, AX
           MOV
                  AX, WORD PTR DS: OSTCBHighRdy+2 ; OSTCBCur = OSTCBHighRdy
           MOV
           MOV
                  DX, WORD PTR DS: OSTCBHighRdy
                  WORD PTR DS: OSTCBCur+2, AX
           MOV
                  WORD PTR DS: OSTCBCur, DX
           MOV
;
                  AL, BYTE PTR DS: OSPrioHighRdy ; OSPrioCur = OSPrioHighRdy
           MOV
                  BYTE PTR DS: OSPrioCur, AL
           MOV
                  BX, DWORD PTR DS: OSTCBHighRdy ; SS:SP = OSTCBHighRdy->OSTCBStkPtr
           LES
           MOV
                  SS, ES:[BX+2]
                  SP, ES: [BX]
           MOV
                                                  ; Load new task's context
            POP
                  DS
            POP
                  ES
            POPA
;
           IRET
                                                  ; Return to new task
OSIntCtxSw ENDP
```




OSTickISR() – the Setup Procedure

void main():

- Call OSInit
- PC DOSSaveReturn
- PC_VecSet //install switch vector at vector 0x80
- Create at least one application task
- Call OSStart

The first task:

- Install OSTickISR
- (Change the tick rate)



Pseudocode

OSTickISR()

```
OSTickISR PROC
                 FAR
                                              ; Save interrupted task's context
           PUSHA
           PUSH
                 ES
           PUSH
                 DS
                 AX, SEG( OSIntNesting)
                                            ; Reload DS
           MOV
                 DS, AX
          MOV
                 BYTE PTR DS: OSIntNesting ; Notify uC/OS-II of ISR
           INC
                 BYTE PTR DS: OSIntNesting, 1 ; if (OSIntNesting == 1)
           CMP
                SHORT OSTICKISR1
           JNE
                AX, SEG( OSTCBCur)
                                              ; Reload DS
          MOV
          MOV
                 DS, AX
                BX, DWORD PTR DS: OSTCBCur
                                              ; OSTCBCur->OSTCBStkPtr = SS:SP
          LES
          MOV ES: [BX+2], SS
                ES:[BX+0], SP
          MOV
```

```
save all registers on the current task's stack
OSIntNesting++;
if (OSIntNesting ==1) {
        OSTCBCur->OSTCBStkPtr = SS:SP;
}
```

OSIntExit: check if there is a HPT becomes ready. May potentially trigger a context switch

OSTickISR()


END

OSTimeTick: to decrement the wait timer and put '1' in the bitmap if it becomes ready

```
OSTickISR1:
                                                                   bitmap if it becomes ready
                                                Reload DS
                  AX, SEG( OSTickDOSCtr)
           MOV
           MOV
                  DS, AX
                  BYTE PTR DS: OSTickDOSCtr
           DEC
                  BYTE PTR DS: OSTickDOSCtr, 0
           CMP
                  SHORT OSTICKISR2
                                                🛂 Erery 11 ticks (~199.99 Hz), chain into DOS
           JNE
           MOV
                  BYTE PTR DS: OSTickDOSCtr, 11
           INT
                                                ; Chain into DOS's tick ISR
                  081H
                  SHORT OSTickISR3
           JMP.
OSTickISR2:
                  AL, 20H
                                                Move EOI code into AL.
           MOV
                  DX, 20H
                                                ; Address of 8259 PIC in DX.
           MOV
                                                ; Sond EOI to PIC if not processing DOS timer.
           OUT
                  DX, AL
OSTickISR3:
                                                            (OSTickDosCrt ==0) {
                  FAR PTR OSTimeTick
           CALL
                                                                   OSTickDosCtr = 11;
;
                  FAR PTR OSIntExit
           CALL
                                                                   INT 81H;
                                                           else {
            POP
                  DS
                                                                   send EOI to PIC;
            POP
                  ES
            POPA
                                                        OSTimeTick();
           IRET
                                                        OSIntExit();
OSTickISR
           ENDP
```

Using OSTaskStkInit_FPE_x86()

```
OS STK Task1Stk[1000];
OS STK Task2Stk[1000];
void main(void) {
        OS STK *ptos;
        OS STK *pbos;
        OS Init();
        ptos = &Task1Stk[999];
        pbos = &Task1st[0];
        size = 1000;
        OSTaskStkInit FPE x86(&ptos, &pbos, &size);
        OSTaskCreate(Task1, null, pbos, 10);
        ptos = &Task2Stk[999];
        pbos = &Task2st[0];
        size = 1000;
        OSTaskStkInit FPE x86(&ptos, &pbos, &size);
        OSTaskCreate (Task2, null, pbos,
                11, 11, pbos, size, null, OSTask OPT SAVE FP);
        OSStart();
```



```
void OSTaskStkInit FPE x86 (OS STK **pptos, OS STK **ppbos, INT32U *psize)
    /* 'Linear' version of top-of-stack
                                             address
                                                       */
             lin tos;
    INT32U
    /* 'Linear' version of bottom-of-stack address
    INT32U
             lin bos;
                        FP_OFF is a macro that can get or set the offset of the far pointer *p.
    INT16U
             seq;
             off;
    INT16U
                        FP_SEG is a macro that gets or sets the segment value of the far pointer
             bytes;
    INT32U
                       MK_FP is a macro that makes a far pointer from its component segment (seg)
                        and offset (ofs) parts.
    /* Decompose top-of-stack pointer into seq:off
                                                       */
             = FP SEG(*pptos);
    seq
             = FP OFF (*pptos);
    off
    /* Convert seq:off to linear address
                                                       */
    lin tos = ((INT32U)seq << 4) + (INT32U)off;
    /* Determine how many bytes for the stack
                                                       */
             = *psize * sizeof(OS STK);
    /* Ensure paragraph alignment for BOS
                                                       */
    lin bos = (lin tos - bytes + 15) & OxFFFFFFFOL;
    /* Get new 'normalized' segment
                                                        */
             = (INT16U) (lin bos >> 4);
    sea
    /* Create 'normalized' BOS pointer
                                                       */
    *ppbos = (OS STK *)MK FP(seq, 0x0000);
   /* Copy FP emulation memory to task's stack
                                                        */
    memcpy(*ppbos, MK FP( SS, 0), 384);
    /* Loose 16 bytes because of alignment
                                                       */
    bvtes
             = bvtes - 16;
                                                        */
    /* Determine new top-of-stack
             = (OS STK *)MK FP(seq, (INT16U)bytes);
    *pptos
                                                        */
    /* Determine new bottom-of-stack
             = (OS STK *)MK FP(seg, 384);
    *ppbos
             = bytes - 384;
    bvtes
    /* Determine new stack size
                                                        */
             = bytes / sizeof(OS STK);
    *psize
                                                                                 28
```

Summary

- A port includes
 - Stack initialization
 - Context switch (task-level and interrupt level)
 - Timer ISR
- The bootloader is hardware-specific
- Refer to micrium.com for information of other ports
 - ARM, microblaze, NIOS-II...