











FreeDSP OVTAVIA (basic version)

NOT POPULATE: U22, U23, R182, R189, R187, R191, R199, R201, R203, R209, Q26, R208, Q25, R204, R198, R200 CHANE (to Zero Ohm): R181, R188, R183, R190, R213 JUMPER(Between): J28 pin2-Pin3, pin5-pin6

AS WELL TO THE ANOTHER PART ...

FreeDSP OVTAVIA (Differential version)

NOT POPULATE: Q25, R208 (if you want)
AS WELL TO THE ANOTHER PART ...

FreeDSP OVTAVIA (Balanced version)

NOT POPULATE: J16, R213, R203 AS WELL TO THE ANOTHER PART ...

FreeDSP OVTAVIA (Extend S/N 6dB stereo version)

AS WELL TO THE ANOTHER PART ...

NOT POPULATE:
U26, U21, Q23, Q22, Q24, J20, J27, R202, R206, R205, R207, R212, R196, R197, R192, R193, R194, R195,
R177, R173, R174, R178, R175, R179, R176, R180, U22, Q25, Q27, R208, R210, R209, R210, R203, R198, R199, R188, R181, R189, R182
CHANGE:
(to 10k) R183, R184, R185, R186
(to MJ-518 or Butique Jacks) J16