BWI Group

Supplier EDI Specification

Application Error & Acknowledgement Message

APERAK

EDIFACT APERAK D.97A BWI Version 1.0

CHANGE CONTROL

Date	Description
2001.02.08	Document issued.
2001.03.23	Corrections made to FTX+AAP definition. Corrections made to example of APERAK transaction.
2003.06.18	Section 0140: Application ID table removed
Date	Description
2010.06.01	Document issued.
	2001.03.23 2003.06.18 Date

0. TABLE OF CONTENT

0. TABLE OF CONTENT

0. TABLE OF CONTENT	3
1. INTRODUCTION	4
2. MESSAGE DEFINITION	4
2.1. FUNCTIONAL DEFINITION	
2.3. REFERENCES	5
3. MESSAGE DESCRIPTION	
3.1. INTRODUCTION	
3.1.2. General remarks	7
3.2. SEGMENT TABLE	8
3.4. MESSAGE STRUCTURE	9
3.6. DATA SEGMENTS DESCRIPTION	13
3.7. EXAMPLE OF MESSAGE	
4.1. SEGMENTS REPERTORY	
4.1.1. Segments in alphabetical sequence	23
4.2. DATĂ ELEMENTS REPERTORY	23
4.2.1. Service data elements in alphabetical sequence	

1. INTRODUCTION

This document provides the specific description of a subset of the EDIFACT APERAK D97.A message to be used between a Trading Partner and BWI.

2. MESSAGE DEFINITION

This document provides the definition of an Application Error and Acknowledgement Message, based on the EDIFACT DESADV D97.A, to be used in Electronic Data Interchange (EDI) between a Trading Partner and BWI.

This documentation is fully comprehensive and allows the implementation of the EDIFACT APERAK without the necessity for any additional standard related documentation.

2.1. FUNCTIONAL DEFINITION

The Application error and Acknowledgement message is a message to a BWI Supplier regarding any errors encountered in processing the DESADV into BWI's application. It gives information concerning specific errors which caused the DESADV not to be processed successfully in order to prevent further errors from occurring. This message is for informational use only - another DESADV should NOT be sent to BWI.

2.2. PRINCIPLES

The Application Error and Acknowledgement message intends to:

- advise the recipient of the specific errors encountered during the processing of the Shipment Advise message.
- allow the recipient to correct any errors to prevent further errors in future shipment advises.

An Application Error and Acknowledgement message can relate to:

• the DESADV message.

The Application Error and Acknowledgement message will always include the Shippers Identification Number and/or the Document Number along with the sender and receiver identification.

As the information transmitted in the Application Error and Acknowledgement message is informational only, it is not necessary to send another DESADV with the changes. Please use only to prevent future errors.

2.3. REFERENCES

The content of this message is based on:

- the message structure as defined by EDIFACT for the UNSM Application Error and Acknowledgement message APERAK as published in the UN/EDIFACT D97.A Directory.
- the agreement between the Trading Partners on the data elements to be used, their unique definition, their representation and their values (coded or clear form) as identified in this document.

BWI has opted for the EDIFACT D97.A Directory and consistently uses this directory for all its EDIFACT messages. Although the AVIEXP subset defined by ODETTE has been based on the EDIFACT D96.A Directory, the subset defined by BWI and described in this document follows as close as possible the structure of the ODETTE subset.

2.4. FIELD OF APPLICATION

The following definition of an Application Error and Acknowledgement message in EDIFACT format is applicable for the interchange of errors received from processing the DESADV message.

3. MESSAGE DESCRIPTION

Following pages contain a full description of the EDIFACT APERAK D97.A message as implemented by BWI. All segments are included regardless whether used or not used in the interchange with BWI. The official EDIFACT segment description is complemented with remarks pertaining to the specific requirements for an interchange with BWI. Those remarks contain specific code values used, additional information on the values shown in a specific field, etc.

3.1. INTRODUCTION

3.1.1. How to read the documentation

All segments in the subset used by BWI are described in the following pages. The segment description is to be read as follows:

0	0020	BGM - BEGINNING OF MES	SAGE	
0	Segment group:	none.	Level:	1.
€	EDIFACT status:	mandatory.	BWI Group status:	mandatory.
4	Maximum use:	1 per message.	BWI Group occurrences:	1 per message.
6	Function:	Segment for the unique identificati name and its number.		hedule document, by means of its
6	BWI Group interchange:	see remarks.		

6 Example: **BGM+351+12+5'**A B C

"+" separates segment sections; ":" separates elements within a segment section

7			EDIFACT STANDARD DEFINI	TION				В	WI Group IMPLEMENTATION
8	REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
		C002	DOCUMENT/MESSAGE NAME	С			С		
		1001	Document/message name, coded	С	an3	:	С	an3	'351' = Despatch Advice
Ø	Α	1131	Code list qualifier	С	an3	:			
		3055	Code list responsible agency,	С	an3	:			
			coded						
		1000	Document/message name	С	an35	+			
		C106	DOCUMENT/MESSAGE	С					
			IDENTIFICATION						
	В	1004	Document/message number	С	an35	:	С	an35	BWI Assigned release number
		1056	Version	С	an9	:			
		1060	Revision number	С	an.6	+			
	С	1225	MESSAGE FUNCTION, CODED	С	an3	+	М	an3	Function of the message. For code
			·						values see below.
		4343	RESPONSE TYPE, CODED	С	an3				

© COMMENTS

© CODE VALUES

LEGEND

- segment position in the message structure, segment tag and segment name.
- identification (when applicable) of the segment group in which the segment is situated and indication at which level the segment is in the message.
- status of the segment: as defined by EDIFACT and by BWI Group.
- number of occurrences of the segment: as defined by EDIFACT and as used by BWI Group.
- description of the function of the segment as defined by EDIFACT and as used by BWI Group.
- example of the segment as it may appear in an interchange. This example is only illustrative and does not necessarily represent an actual situation. It should **NOT** be used as a basis to implement this message.
- definition of the segment content as defined by EDIFACT and as implemented by BWI Group.
- identification of the data elements in the segment
 - reference to the example.
 - data element tag data elements with a 'C' denote a composite data element.
 - data element name *italic CAPITALS* denote a composite data element.
 - ST the status of the data element.
 - **FT** the format of the data element, i.e. the indication of the number of characters (numerical or alphabetical) for this data element.
 - SP the separator used between the data elements.
 - remarks on the specific use of the data element in the interchange with BWI Group.
- Shaded areas in the BWI Group description mean that BWI Group does not use the data elements.
- the segment description can be followed by:
 - comments providing more information regarding specific data elements and how they
 must be used and/or understood in messages from BWI Group.
 - code values to be used for data elements contained in the message.

3.1.2. General remarks

Following remarks are applicable for the complete documentation:

Dates

Unless otherwise specified in the field explanation in the documentation, dates are always expressed as **CCYYMMDD** (qualifier 2379 = 102).

Times

Unless otherwise specified in the field explanation in the documentation, times are always expressed as **HHMM**.

3.2. SEGMENT TABLE

The following table shows the segments defined for the EDIFACT UNSM DESADV D97.A Despatch Advice message. Shaded areas identify the segments that are not used in the subset of DESADV used by BWI Group. This table, which should be read in conjunction with the branching diagram indicates the maximum number of occurrences for each segment.

POS.	TAG	NAME	ST	REPEATS	
0010	UNH	Massaga baadar	М	1	_
0010	BGM	Message header	M	1	
0020	DTM	Beginning of message Date/time/period	C	9	
		'	-	9	
0040	FTX	Free Text	С	9	
0050	CNT	Control Table	С	9	
0060		Segment Group 1 REF-DTM		9	
0070	RFF	Reference	С	1	
0800	DTM	Date/Time/Period	М	9	
0090		Segment group 2 NAD-CTA-COM	С	10	
0100	NAD	Name and Address		1	
0110	CTA	Contact information		9	
0120	COM	Communication contact		9	
0130		Segment group 3 ERC-FTX-SG4		9999	
0140	ERC	Application Error Information		1	
0150	FTX	Free Text		1	
0160		Segment group 4 REF-FTX		10	
0170	RFF	Reference		1	
0180	FTX	Free Text		9	
0180	UNT	Message Trailer		1	

3.3. MESSAGE STANDARD DESCRIPTION

This section provides the description of the UN Standard Message APERAK as defined in the 97.A Directory. Only the segments printed in bold are used in the subset defined by BWI and will be further explained in section 3.6.

3.3.1 Header section

Information to be provided in the Header section:

0010 UNH, Message header

A service segment starting and uniquely identifying a message. The message type code for the Application Error and Acknowledgement Message is the APERAK.

0020 BGM, Beginning of message

A segment for unique identification of the Application Error and Acknowledgement Message, by means of its name and its number.

0030 DTM, Date/time/period

Date/time/period related to the whole message. The DTM segment is specified at least once to identify the Application Error and Acknowledgement Message date.

0040 FTX. Free Text

A segment indicating that the message to which the APERAK is responding.a

0050 CNT, Control Total

A segment by which control totals may be provided by sender for checking by the receiver.

0060 Segment group 1: RFF-DTM

A group of segments giving references where necessary, their dates relating to the whole message, e.g. contract number

0070 RFF, Reference

A segment for referencing documents relating to the whole error application and acknowledgement message, e.g. Document number or Shipper's Identification Number

0080 DTM, Date/time/period

Date/time/period from the referred document.

0090 Segment group 2: NAD-CTA-COM

A group of segments identifying names, addresses, locations, and required supporting documents relevant to the whole Despatch Advice.

0100 NAD, Name and address

A segment for identifying names, addresses, and their functions relevant to the whole Application Error and Acknowledgement message. Identification of the parties involved is recommended for the Application Error and Acknowledgement message, and is to be given in the NAD segment.

It is recommended that the coded form of the party ID should be specified, e.g. the buyer and seller are known to each other, thus only the coded ID is required. The consignee or delivery address may vary and would have to be clearly specified, preferably in structured format.

0110 CTA, Contact information

A segment to identify the person, function or department to whom communication should be directed.

0120 COM. Communication contact

A segment to identify communication types and numbers for the person, function or department identified in the CTA.

3.3.2 Detailed section

0130 Segment group 3: ERC-FTX-SG4

A group of segments to identify the application error(s) within a specified received message and to give specific message and to give specific details related to the error type or to precise the type of Acknowledgement.

0140 ERC, Application Error Information

A segment identifying the type of application error or Acknowledgement within the referenced message. In case of an error, the error code may specify the error in detail (e.g. a measurement relating to a piece of equipment is wrong) or as a rough indication (e.g. a measurement is wrong).

0150 FTX, Free text

A segment to provide explanation and/or supplementary information related to the specified application error or Acknowledgement. For example, the explanation may provide exact details relating to a generic error code.

0160 Segment group 4: RFF-FTX

A group of segments to specify the functional entity reference (e.g. goods item level, equipment level) relating to the specified error; further details can be added to identify the error more precisely.

0170 RFF, Reference

A segment to provide a reference relating to the Acknowledgement type or the specified error (e.g. functional entity reference such as equipment level.)

0180 FTX, Free Text

A segment to provide additional details relating to the reference, e.g. the content of the wrong data (and its exact place in the message).


3.3.3 Summary section

0190 UNT, Message trailer

A service segment ending a message, giving the total number of segments in the message and the control reference number of the message.

3.4. MESSAGE STRUCTURE

The message structure illustrates how the segments can be repeated in the Application Error and Acknowledgement message to accommodate the requirements identified by BWI.



Start of Application Error and Acknowledgement
Message
Message identification
Message generation date/time
Free Text information
Control Totals – Not used with BWI
Shipper ID number or Document Number
Date the DESADV was processed
Sender of the message - BWI
Message Recipient
Contact Information – Not used with BWI
Communication Contact – Not used with BWI
Application Error Information
Free Text – Not used with BWI
Error reference codes
Free Text – Error Description
Message Trailer

3.5 SERVICE SEGMENTS DESCRIPTION


Following service segments are as defined by UN/EDIFACT and presented under ISO 9735.

The UNB, UNH, UNT and UNZ segments are the envelope of any message, enclosing all the data that is being transmitted.

The UNB (Interchange header) and UNZ (Interchange trailer) segments mark respectively the beginning and the end of an interchange thereby providing a unique interchange control reference.

Within the interchange the UNH (message header) and UNT (Message trailer) segments uniquely begin and end the various messages contained in an interchange.

EXAMPLE OF AN INTERCHANGE STRUCTURE



NOTE:

All data elements marked "M" for Mandatory in the "ST" field of the BWI Group implementation must be included in the message. Missing or incorrect entries will result in the rejection of the message.

0000 UNB - INTERCHANGE HEADER

Segment Group: none Level: 0

EDIFACT status: mandatory BWI Group status: mandatory
Maximum use: 1 per interchange BWI Group occurrences: 1 per interchange

Function Service segment providing the unique identification of an interchange. It allows the identification of the

sender and the receiver of the interchange, gives date and time of preparation as well as the

interchange control reference and the application reference.

BWI Group interchange: see remarks.

Example: UNB+UNOA:2+ BWI831310037:ZZ+QQQ:ZZ+030618:1439+1++APERAK'

B C D E F C

		EDIFACT STANDARD DEFINIT	ION					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
	S001	SYNTAX IDENTIFIER	М			М		
Α	0001	Syntax identifier	М	a4	:	M	a4	"UNOA".
В	0002	Syntax version number	М	n1	+	M	n1	Indication of the syntax version used for this
								message.
	S002		М			М		
С	0004	Sender identification	М	an35	:	M	an35	Communication Code/Mailbox number of the
								party originating the message.
D	0007	Identification code qualifier	С	an4	:			
	8000	Address for Reverse Routing	С	an14	+			
_	S003		М	0.5		M	0.5	
E	0010	Recipient identification	М	an35	:	M	an35	Communication Code/Mailbox number of the
F	0007	Identification and qualifier	С	on 1				party receiving the message.
-	0007	Identification code qualifier	C	an4 an14	:			
	S004	Routing address DATE / TIME OF PREPARATION	М	an14	+	М		
G	0017	Date of preparation	M	n6	:	M	n6	YYMMDD Format.
ΙH		Time of preparation	M	n4	+	M	n4	HHMM Format.
1 ''	0013	INTERCHANGE CONTROL	M	an14	+	M	an14	Reference number assigned by the sender of
'	0020	REFERENCE	IVI	a1114	т .	IVI	a1114	the message. This number must uniquely
		INCI ENERGE						identify each interface and must be UNIQUE
								within an inventory year.
	S005	RECIPIENTS REFERENCE	С					main an arrenery year.
	0000	PASSWORD						
	0022	Recipient's reference / password	М	an14	:			
	0025	Recipient's reference / password	С	an2	+			
		qualifier						
	0026	APPLICATION REFERENCE	С	an14	+	М	n6	APERAK
	0029	PROCESSING PRIORITY CODE	C	a1	+			
	0031	ACKNOWLEDGEMENT REQUEST	C	n1	+			
	0032	COMMUNICATIONS AGREEMENT ID	C	an35	+			
	0035	TEST INDICATOR	С	n1	'			

UNH - MESSAGE HEADER 0010

Segment group: Level: 0 none

EDIFACT status: BWI Group status: mandatory. mandatory.

Maximum use: 1 per message. BWI Group occurrences: 1 per message.

Service segment starting and uniquely identifying a message. The message type code for the Function: see

Application Error and Acknowledgement message is APERAK. BWI Group interchange:

remarks.

Example: UNH+1+APERAK:D:97A:UN'

C D E Α В

		EDIFACT STANDARD DEFINIT	ΓΙΟΝ					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Α	0062	MESSAGE REFERENCE NUMBER	М	an14	+	М	an14	Message Control number assigned by the
								sender to the message.
	S009	MESSAGE IDENTIFIER	М			M		
В	0065	Message type	М	an6	:	M	an6	"APERAK"
С	0052	Message version number	М	an3	:	M	an3	" D "
D	0054	Message release number	М	an3	:	M	an3	"97A"
E	0051	Controlling agency	М	an2	:	M	an2	"UN"
	0057	Association assigned code	С	an6	+			
	0068	COMMON ACCESS REFERENCE	С	an35	+			
	S010	STATUS OF TRANSFER	С					
	0070	Sequence of transfer	М	n2	:			
	0073	First and last transfer	С	a1	4			

1040 **UNT - MESSAGE TRAILER**

Segment group: none Level: 0

EDIFACT status: BWI Group status: mandatory mandatory

Maximum use: BWI Group occurrences: 1 per message 1 per message

Function: service segment ending a message, giving the total number of segments in the message and the

control reference number of the message.

BWI Group interchange:

UNT+13+1' Example:

		EDIFACT STANDARD DEFINIT	BWI Group IMPLEMENTATION					
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Α	0074	NUMBER OF SEGMENTS IN THE MESSAGE	М	n6		М	n6	Control count of the number of segments in the message, including UNH and UNT.
В	0062	MESSAGE REFERENCE NUMBER	М	an14		М	an14	Number must be identical to UNH - tag 0062

1050 UNZ - INTERCHANGE TRAILER

Segment Group: none Level: 0

EDIFACT status: mandatory BWI Group status: mandatory

Maximum use: 1 BWI Group occurrences: 1 per interchange Function: Bwi Group occurrences: 1 per interchange and giving the number of messages contained in the

interchange as well as the Interchange Control Reference number.

BWI Group interchange:

Example: UNZ+3+1'

А В

		EDIFACT STANDARD DEFINI	TION					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Α	0036	INTERCHANGE CONTROL COUNT	М	n6	+	М	n6	Number of messages in an interchange.
В	0020	INTERCHANGE CONTROL REFERENCE	М	an14	í	М	an14	Value must be the same as 0020 - Interchange Control Reference in UNB.

3.6. DATA SEGMENTS DESCRIPTION

This part includes only the segments defined in the standard and used in the subset exchanged between the Trading Partners and BWI Group. The segments are described in the same sequence as they appear in the message.

The EDIFACT APERAK segments that are not used in the subset used by BWI Group are included in alphabetical sequence under item 3.9.

NOTE: All data elements marked "M" for Mandatory in the "ST" field of the BWI Group implementation must be included in the message. Missing or incorrect entries will result in the rejection of the message.

DO20 BGM - BEGINNING OF MESSAGE

Segment group: none Level: 1

EDIFACT status: mandatory BWI Group status: mandatory

Maximum use: 1 per message BWI Group occurrences: 1 per message

Function: segment for unique identification of the Application Error and Acknowledgement Message, by means

of its name and its number.

Note: Use only alpha and /or numeric characters in the BGM segment. Special characters or symbols may cause failure.

Example: BGM+7+123456789+9+RE' Limit to 10 characters

A B C D

		EDIFACT STANDARD DEFINIT	ΓΙΟΝ					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FIT	REMARKS
	C002	DOCUMENT/MESSAGE NAME	С			М		
Α	1001	Document/message name, coded	С	an3	:	М	an3	Identify the purpose of this report which is a process data report.
	1131	Code list qualifier	С	an3	:			
	3055	Code list responsible agency, coded	С	an3	:			
	1000	Document/message name	С	an35	+			
	C106	DOCUMENT/MESSAGE	С			М		
		IDENTIFICATION						
Α	1004	Document/message number	С	an35	:	М	an9	A unique control number, BWI is using the Document number created from SAP.
	1056	Version	С	an9	:			
	1060	Revision number	С	an.6	+			
В	1225	MESSAGE FUNCTION, CODED	С	an3	+	M	an3	Function of the message. For code values see below.
	4343	RESPONSE TYPE, CODED	С	an3	ſ	М	An3	Code to specify the type of an Acknowledgement transmitted.

CODE VALUES

	coded	essage Name	- Document / N	1001 -
--	-------	-------------	----------------	--------

7 Report on the data processed (specifically the status of how the DESADV processed).

1225 - Message function, coded

9 Original - Initial transmission related to a given transaction. The issuer's first transmission of a message for a particular SID (1004).

4343 – Response Type, coded

RE Rejected – The DESADV received was rejected.

0030 DTM - DATE/TIME/PERIOD

Segment group: none Level: 1

EDIFACT status: mandatory status: mandatory (see comments)

Maximum use: 9 per message at level 1 BWI Group occurrences: max. 1 per message

Function: Segment specifying the date/time/period related to the whole message. The DTM segment is specified

at least once to identify the Application Error and Acknowledgement message date.

Example: DTM+137: 200306181116:203' Document generation, mandatory

A B C

	EDIFACT STANDARD D	EFINITION					BWI Group IMPLEMENTATION
REF TAG	NAME	ST	FT	SP	ST	FT	REMARKS

Document generation date.

MANDATORY - must be transmitted.

	C507	DATE/TIME/PERIOD	М			М		
Α	2005	Date/time/period qualifier	М	an3	:	M	an3	"137" = Document/message date/time.
В	2380	Date/time/period	С	an35	:	M	an35	Date/time when the document is issued.
С	2379	Date/time/period format qualifier	С	an3	"	M	an3	"203" = CCYYMMDDHHMM.

0040 FTX – FREE TEXT

Segment group: none Level: 1

EDIFACT status: conditional BWI Group status: mandatory
Maximum use: 9 BWI Group occurrences: as required
Function: Segment with free text in coded or clear form to give further clarification when required.

BWI Group interchange: See Remarks

Example: MEA+AAP+++DESADV' A B

		EDIFACT STANDARD DEFINIT	ΓΙΟΝ					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Α	4451	TEXT SUBJECT QUALIFIER	М	an3	+	M	an3	"AAP" = Response to
	4453	TEXT FUNCTION, CODED	С	an3	+			
В	C107	TEXT REFERENCE	С					
	4441	Free Text, coded	С	an3	:			
	1131	Code List Qualifier	С	an3	:			
	3055	Code List Responsible Agency,	С	an3	+			
		Coded						
	C108	TEXT LITERAL	С			С		
	4440	Measure unit qualifier	М	an70	:	M	an70	"DESADV" = Actual name of the message for
								which this response is generated.
	4440	Measurement value	С	an70	:			
	4440	Range minimum	С	an70	:			
	4440	Range maximum	С	an70	:			
	4440	Significant digits	С	an70	+			
	3453	LANGUAGE, CODED	С	an3	4			
		REST OF SEGMENT NOT USED						

Segment group 1: RFF-DTM

Segment group: 1 Level: 1

EDIFACT status: conditional BWI Group status: mandatory

Maximum use: 9 per message at level 1 BWI Group occurrences: max. 2 per message Function: Group of segments giving references where necessary, their dates relating to the whole message, e.g.

document number and/or Shipper's Identification Number.

BWI Group interchange: Only RFF is required in segment group 1.

0070 RFF - REFERENCE

Segment group: 1 [RFF] Level:

EDIFACT status: mandatory if segment group 1 is used BWI Group status: mandatory

Maximum use: 1 per segment group 1 (max. 9) BWI Group occurrences: 1 per segment group 1 Function: Segment for referencing documents relating to the whole application error and Acknowledgement

message, e.g. document number.

BWI Group interchange: At least one iteration is mandatory.

Example: RFF+SI:112233445'

RFF+DM:000225033'

A B

		EDIFACT STANDARD DEFINIT	ΓΙΟΝ					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Ship	per's I	dentification number						
	C506	REFERENCE	М			М		
Α	1153	Reference qualifier	M	an3	:	M	an3	"SI" = Shipper's Identification Number.
В	1154	Reference number	С	an35	:	М	an35	Number as referenced in 1153 above.
	1156	Line number	С	an6	:			
	4000	Reference version number	С	an35				
Docu	ıment	Number						
	C506	REFERENCE	М			М		
Α	1153	Reference qualifier	М	an3	:	м	an3	"DM" = Document Number.
В	1154	Reference number	С	an35	:	М	an35	Number as referenced in 1153 above.
	1156	Line number	С	an6	:			
	4000	Reference version number	С	an35				

0080 DTM - DATE/TIME/PERIOD

Segment group: 1 [RFF] Level: 1

EDIFACT status: mandatory if segment group 1 is used BWI Group status: mandatory

Maximum use: 9 per message at level 1 BWI Group occurrences: max. 1 per message

Function: Segment specifying the date/time/period the DESADV was processed.

BWI Group interchange: There may be max. 1 occurrence of DTM in position 0090: to specify the ASN processed date

Example: DTM+9:200306181120:203

A B C

		EDIFACT STANDARD DEFIN	ITION					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
DES	ADV p	rocessed date.						
	C507	DATE/TIME/PERIOD	М			М		
Α	2005	Reference qualifier	M	an3	:	M	an3	"9" = Processing date/time
В	2380	Reference number	С	an35	:	М	an35	Date/Time when the DESADV document was

BWI Group IMPI EMENTATION

Ī									processed.
	С	2379	Line number	С	an3	:	М	An3	"203" = CCYYMMDDHHMM.

Segment group 2: NAD-LOC-SG3-SG4

Segment group: 2 Level:

EDIFACT status: conditional BWI Group status: mandatory

Maximum use: 9 per message at level 1 BWI Group occurrences: maximum 5 per message Function: group of segments identifying names, addresses, locations, and required supporting documents

relevant to the whole Application Error and Acknowledgement Message.

BWI Group interchange: Only NAD is required in segment group 2.

0100 NAD - NAME AND ADDRESS

Segment group: 02 [NAD] Level: 1

EDIFACT status: mandatory if segment group 02 is used BWI Group status: mandatory

Maximum use: 1 per segment group 02 (max. 10) BWI Group occurrences: 2 per segment group 2 segment for identifying names, addresses, and their functions relevant to the whole Application Error

and Acknowledgement message.

BWI Group interchange: The message may contain max. 2 NAD segments as detailed below.

Example: NAD+FR+9999999999::16' Message from Party, where the message comes from BWI

NAD+MR+245760088::16' Message recipient

A B C

		EDITACI CIANDAND DEI INI						BWI Gloup IIIII EEIIIENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Mess	sage F	rom Party.						
Α	3035	PARTY QUALIFIER	М	an3	+	M	an3	"FR" = Message from party - BWI's plant number that the DESADV shipment was intended.
	C082	PARTY IDENTIFICATION DETAILS	С			М		
В	3039	Party id. Identification	М	an35	:	М	an35	Code identifying the material release issuer. For code value see below.
	1131	Code list qualifier	С	an3	:			
С	3055	Code list responsible agency, coded	С	an3	+	M	an3	For code value see below.
		REST OF SEGMENT NOT USED						

	EDIFACT STANDARD D	EFINITION					BWI Group IMPLEMENTATION
REF TAG	NAME	ST	FT	SP	ST	FT	REMARKS

Message Recipient.

Α	3035	PARTY QUALIFIER	М	an3	+	M	an3	"MR" = Message Recipient.
	C082	PARTY IDENTIFICATION DETAILS	С			M		
В	3039	Party id. Identification	М	an35	:	M	an35	Code identifying the material release issuer.
								For code value see below.
	1131	Code list qualifier	С	an3	:			
С	3055	Code list responsible agency, coded	С	an3	+	M	an3	For code value see below.
		REST OF SEGMENT NOT USED						

CODE VALUES

3055 - Document / Message Name , coded

16 DUN & Bradstreet (DUNS)

92 Assigned by buyer or buyer's agent.

Segment group 3: ERC-FTX-SG4

Segment group: 3 Level: 1

EDIFACT status: mandatory BWI Group status: mandatory

Maximum use: 99999 per message at level 1 BWI Group occurrences: Max. 1 per error

Function: Group of segments to identify the application errors within a specified received message and to give

specific details related to the error type or to precise the type of acknowledgement.

BWI interchange: Only ERC and SG4 are used in group 3.

0140 ERC — APPLICATION ERROR INFORMATION

Segment group: 3 Level:

EDIFACT status: mandatory BWI Group status: mandatory

Maximum use: 1 per segment group 3 (max. 99999) BWI Group occurrences: 1 per segment group 3

Function: To identify the type of application error within a message. BWI interchange: ERC & SG4 are the only segments used in this group 3.

Example: ERC+BORGR547::ZZZ'
ERC+VL243::ZZZ'
A B

			EDIFACT STANDARD DEFINIT	ION					BWI Group IMPLEMENTATION
	REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
Ī	Α	C901	APPLICATION ERROR DETAIL	М		+	М		
		9321	Application Error identification	М	an3	:	М	an3	BWI assigned error message ID
		1131	Code List Identifier	С	an8	:			
	В	3055	Terms of delivery or transport,	С	an3	+	М	an3	For code value see below.
			coded						

CODE VALUES

Code list responsible agency, coded

ZZZ Mutually Defined

Segment group 4: RFF-FTX

Segment group: 4 Level:

EDIFACT status: conditional BWI Group status: mandatory

Maximum use: 1 per message at level 1 BWI Group occurrences: Max. 1 per message group of segments to specify the functional entity reference (e.g. goods item level, equipment level)

Related to the specific error; further details can be added to identify the error more precisely.

BWI interchange: Both RFF and FTX are used in group 4.

0170 RFF - REFERENCE

Segment group: 4 Level: 1

EDIFACT status: conditional BWI Group status: mandatory

Maximum use: 1 per ERC group BWI Group occurrences: 1 per ERC segment group4
Function: Segment for referencing the eror reference number. It will contain the reference number that BWI

rejected in processing (e.g. SID number, Scheduling agreement number, material number, etc.)

BWI interchange: See Remarks

Example: RFF+ACD:N/A' A B

		EDIFACT STANDARD DEFINIT	ION					BWI Group IMPLEMENTATION
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS
	C506	REFERENCE	М		+	М		
Α	1153	Application Error identification	М	an3	:	М	an3	BWI assigned error message ID
В	1154	Code List Identifier	С	an35	:	С	an35	Number as qualified in 1153 above.
	1156	Line Number	С	an6				
	4000	Reference version number	С	an35	+			

CODE VALUES

1153 - Reference Qualifier	

ACD Additional Reference Number - reference number that BWI rejected in processing (e.g. SID number, Scheduling agreement number, material number, etc.)

Note: Segment will be populated with "N/A" when values are provided in message text or can not be determined.

0180 FTX - FREE TEXT

Segment group: 4 Level:

EDIFACT status: conditional BWI Group status: mandatory
Maximum use: 9 BWI Group occurrences: as required

Function: segment with free text in coded or clear form to give further clarification when required. This segment

contains the error message text.

BWI Group interchange: see remarks.

Example: FTX+AAO+++Mandatory field missing

. 1

EDIFACT STANDARD DEFINITION							BWI Group IMPLEMENTATION		
REF	TAG	NAME	ST	FT	SP	ST	FT	REMARKS	
Α	4451	TEXT SUBJECT QUALIFIER	М	an3	+	М	an3	"AAO" = Error Message	
	4453	TEXT FUNCTION, CODED	С	an3	+				
	C107	TEXT REFERENCE	С						
	4441	Free text, coded	М	an3	:				
	1131	Code list qualifier	С	an3	:				
	3055	Code list responsible agency, coded	С	an3	+				
	C108	TEXT LITERAL	С			С			
В	4440	Free text	М	an70	:	M	an70	Error message associated with error code on	
								the ERC segment.	
	4440	Free text	С	an70	:				
	4440	Free text	С	an70	:				
	4440	Free text	С	an70	:				
	4440	Free text	С	an70	+				
	3453	LANGUAGE, CODED	С	an3	4				

CODE VALUES

4451 – Text subject qualifier

AAO Error Description (Free Text)

3.7. EXAMPLE OF MESSAGE

Following example is only illustrative and does not necessarily reflect an existing situation. It MAY NEVER be used as a basis for programming or implementing this message.

One message will be created for each DESADV with and error. The following are a sample of one error in multiple DESADV's.

UNB+UNOA:2+DPH:ZZ+QQQ:ZZ+030618:1439+1++APERAK++++1' UNH+1+APERAK:D:97A:UN' BGM+7+123456789+9+RE' DTM+137:200306181116:203' FTX+AAP+++DESADV RFF+SI:112233445' RFF+DM:000225033 DTM+9:200306181120:2031 NAD+FR+999999999::16' NAD+MR+245760088::16'

ERC+VL243::ZZZ'

RFF+ACD:N/A'

FTX+AAO+++Mandatory field missing'

UNT+13+1'

UNH+2+APERAK:D:97A:UN' BGM+7+0000000000225181+9+RE'

DTM+137:200306181116:203' FTX+AAP+++DESADV' RFF+SI:LIFEX99103'

RFF+DM:0000000000225180' DTM+9:200306181120:2031

NAD+FR+999999999::16' NAD+MR+245760088::16'

ERC+VW007::ZZZ

RFF+ACD:N/A

FTX+AAO+++Forwarding agent not recognized by BWI application'

UNT+13+2'

UNH+3+APERAK:D:97A:UN' BGM+7+0000000000225183+9+RE' DTM+137:200306181116:203'

FTX+AAP+++DESADV'

RFF+SI:N/A'

DTM+9:200306181120:203' NAD+FR+999999999::16' NAD+MR+245760088::16' FRC+7F100.777

RFF+ACD:N/A'

FTX+AAO+++Failed ASN due to either invalid plant material or purchase order'

UNT+13+3' UNZ+3+1'

For ease of reading the message has been shown with each segment type on a separate line, which will not be the case when the message is normally transmitted.

One message will be created for each DESADV with an error. The following is an example of multiple errors in one message.

UNB+UNOA:2+VG4:ZZ+DYY:ZZ+001016:1039+1++APERAK++++1'

UNH+1+APERAK:D:97A:UN' BGM+7+0000000000225034+9+RE' DTM+137:200010091116:203' FTX+AAP+++DESADV RFF+SI:LIFEX99103'

RFF+DM:0000000000225033' DTM+9: 200306181120:203' NAD+FR+9999999999::16 NAD+MR+245760088::16'

ERC+VW007::ZZZ' RFF+ACD:N/A'

FTX+AAO+++Forwarding agent not recognized by BWI application'

ERC+VL243::ZZZ' RFF+ACD:N/A'

ERC+ZE100::ZZZ'

FTX+AAO+++Mandatory field missing

RFF+ACD:N/A'

FTX+AAO+++Failed ASN due to either invalid plant material or purchase order'

UNT+19+1' UNZ+1+1'

For ease of reading the message has been shown with each segment type on a separate line, which will not be the case when the message is normally transmitted.

4. MESSAGE INFORMATION

This section contains additional information related to the EDIFACT APERAK D97.A message.

4.1. SEGMENTS REPERTORY

The following tables show all the data segments defined for the EDIFACT APERAK D97.A message, used as basis for the BWI Application Error and Acknowledgement Message.

4.1.1. Segments in alphabetical sequence

Segment name TagBGMBeginning of messageBGMCommunication contactCOMContact informationCTAControl totalCNTDate/time/periodDTMError Application InformationERCFree textFTXName and addressNADReferenceRFF

4.1.2. Segments in segment tag sequence

Tag Segment name

BGM Beginning of message

CNT Control total

COM Communication contact

CTA Contact information

DTM Date/time/period

ERC Error Application Information

FTX Free text

NAD Name and address

RFF Reference

4.2. DATA ELEMENTS REPERTORY

The following listings show all the data elements defined for the EDIFACT DESADV D97.A message, used as basis for the BWI Delivery Instruction message.

4.2.1. Service data elements in alphabetical sequence

List of data elements defined for the UNB, UNH, UNT and UNZ service segments.

Data element name Tag

Acknowledgement Request	0031
Address for Reverse Routing	0008
Application Reference	
Association Assigned Code	
Common Access Reference	
Communications Agreement ID	0032
Controlling Agency	
Date of Preparation	
First / Last Message Indicator	

Identification Code Qualifier	0007
Interchange Control Count	0036
Interchange Control Reference	0020
Message Reference Number	
Message Type Identifier	
Message Type Release Number	
Message Type Version Number	
Number of Segments in Message	
Processing Priority Code	
Recipient Identification	
Recipient's Reference / Password	
Recipient's Reference / Password Qualifier	
Routing Address	
Sender Identification	
Data element name Tag	
-	
Sequence Message Transfer Number	
Syntax Identifier	
Syntax Version Number	
Test Indicator	
Time of Preparation	0019
4.0.0. Coming data alamanta in tan arangana	
4.2.2. Service data elements in tag sequence	
Tag Data element name Segment(s)	
0001 Syntax Identifier	UNB
0002 Syntax Version Number	
0004 Sender Identification	
0007 Identification Code Qualifier	
0008 Address for Reverse Routing	
0010 Recipient Identification	UNB
0014 Routing Address	
0017 Date of Preparation	
0019 Time of Preparation	
0020 Interchange Control Reference	
0022 Recipient's Reference / Password	
0022 Recipient's Reference / Password Qualifier	
0026 Application Reference	
0029 Processing Priority Code	
0031 Acknowledgement Request	
0032 Communications Agreement ID	
0035 Test indicator	
0036 Interchange Control Count	
0051 Controlling Agency	
0052 Message Type Version Number	
0054 Message Type Release Number	
0057 Association Assigned Code	UNH
0062 Message Reference Number	UNH, UNT
0065 Message Type Identifier	
0068 Common Access Reference	
0070 Sequence Message Transfer Number	
0073 First/last Message Indicator	
0074 Number of Segments in Message	UNT