1

Toolbox for Power System Computations

I. DATA

A. General Data of Power Systems

The power system is represented as a structure within the Matlab software package. When loading a specific power system, a variable of structural type named "data" is loaded into the workspace. The names and descriptions of the structure's fields are displayed in the table below.

 $\label{eq:Table I} \text{Table I}$ Fields of the structure used to describe the power system (\$data\$).

Field	Description
data.nBuses	number of nodes
data.fn	nominal system frequency
data.nBranches	number of branches
data.nGens	number of generators
data.slackNo	number of a slack bus
data.baseMVA	base power
data.bus	matrix whose rows represent groups of information used to describe nodes in the system
data.branch	matrix whose rows represent groups of information used to describe branches in the system.
data.generator	matrix whose rows represent groups of information used to describe generators in the system.
data.gencost	matrix whose rows represent groups of information used to describe generators
autu.gencosi	in the system from an economic perspective

The matrix containing information about the nodes of the corresponding power system consists of fifteen columns. The column number, description, and unit of measurement are shown in the table below.

Table II BUS DATA (data.bus).

Column	Description	Unit
1	bus number	
2	bus type (1=PQ, 2=PV, 3=slack)	
3	active power demand	p.u.
4	reactive power demand	p.u.
5	active power of shunt conductance at the voltage 1 [p.u.]	p.u.
6	reactive power of shunt conductance at the voltage 1 [p.u.]	p.u.
7	area number	
8	voltage magnitude	p.u.
9	voltage angle	rad
10	base voltage	kV
11	loss zone	
12	maximum voltage magnitude	p.u.
13	minimum voltage magnitude	p.u.
14	active power generation	p.u.
15	reactive power generation	p.u.

The matrix containing information about the branches of the corresponding power system consists of thirteen columns. The column number, description, and unit of measurement are shown in the table below.

Table III
BRANCH DATA (data.branch).

Column	Description	Unit
1	from bus	
2	to bus	
3	resistance	p.u.
4	reactance	p.u.
5	total line susceptance	p.u.
6	long term rating (0=unlimited)	p.u.
7	short term rating (0=unlimited)	p.u.
8	emergency rating (0=unlimited)	p.u.
9	transformer off nominal turns, taps at "from bus", pi equivalent at "to bus"; value 0 indicates transimission line rather that transformer	p.u.
10	transformer phase shift angle (positive ⇒ delay)	rad
11	branch status (0=in service, 1=out of service)	
12	minimum bus voltage angle difference	rad
13	maximum bus voltage angle difference	rad

The matrix containing information about the generators of the corresponding power system consists of ten columns. The column number, description, and unit of measurement are shown in the table below.

 $\label{eq:table_interpolation} \mbox{Table IV} \\ \mbox{Generator data} \ (\mbox{\it data.generator}).$

Column	Description	Unit
1	bus number	
2	active power output	p.u.
3	reactive power output	p.u.
4	maximum reactive power output	p.u.
5	minimum reactive power output	p.u.
6	regulated voltage magnitude	p.u.
7	base power of machine	p.u.
8	machine status (0=in service, 1=out of service)	
9	maximum active power output	p.u.
10	minimum active power output	p.u.

B. Extended Verison with Measurement Devices

This is a structure that extends the structure described in the previous subsection with data about measurement devices installed in a power system. Structure *data* is now enriched with two new fields:

data.pmu data about phasore measurement units installed in a power system, and it is presented in detail in Table.data about conventional SCADA measurements, and it is presented in detail in Table.

data.zi vector of nodes with no load nor generation, i.e., zero injection buses.

Table V PMUS DATA (data.pmu).

Column	Description	Unit
1	phasor measurement type (1-current flow, 2-current injection, 3-voltage)	
2	line number (type 1) or bus number (type 2 or 3)	
3	magnitude measurement standard deviation	%
4	phase angle measurement standard deviation	rad
5	frequency measurement standard deviation	Hz
6	RoCoF measurement standard deviation	Hz/s
7	Reporting frequency	Hz

Table VI SCADA DATA (data.scada).

Column	Description	Unit
1	measurement type (1-active power flow, 2-reactive power flow, 3-active power injection,	
	4-rective power injection, 5 - branch current magnitude, 6- bus voltage manitude	
2	line number (type 1, 2 and 6) or bus number (type 3, 4 and 5)	
3	standard deviation	p.u.
7	Reporting frequency	Hz