
## **Precision Pro** Connector

- 1. MOSI -- 7 -> D11
- 2. Trigger -- 3 -> D8
- 3. SCK -- 2 -> D13
- 4. GND -- 4
- 5. 5V -- 1

## D9 -> D10 SS



- 1. PI8 (A Button)
- 2. Q6

4021


- 3. Q8 DATA
- 4. PI4 (Up)
- 5. PI3 (Down)
- 6. PI2 (Right)
- 7. PI1 (Left)
- 8. GND
- 9. P/S
- 10. Clock
- 11. Serial In
- 12. Q7
- 13. PI5 (Start)
- 14. PI6 (Select)
- 15. PI7 (B Button)
- 16. VCC

## Precision Pro

- 1. Vcc (5V)
- 2. SCK
- 3. Trigger
- 4. GND
- 5. NC
- 6. NC
- 7. Data (MOSI)
- 8. NC
- 9. NC
- 10. NC
- 11. NC
- 12. NC
- 13. NC
- 14. NC
- 15. NC

**NES Compatible** 

- 1. OUT
- 2. P/S (LATCH)
- 3. CLK
- 4. GND
- 5. 5V



プルアップ CLK,P/Sを3.6k FC各ボタンは56k