# Buildroot BASC2020 seminar

Giacomo Longo

University of Genoa

Q4 2020

#### BuildRoot



Official website: https://buildroot.org

- ▶ Born in 2005
- Entirely based on makefiles and kconfig
- ▶ Only one goal: producing root file system images for 100% custom Linux systems

#### BuildRoot users

The most prominent users of BuildRoot are using it for building:

- ► IoT devices
- Automated factory controllers
- Point of sale devices
- Car multimedia units

### Why BuildRoot

- ► Each buildroot is a 100% custom Linux "mini-distro"
- ▶ Buildroot images can be less than 100MB or even 10MB
- ► Complete customization of target architecture and build flags
- Multiple compiler / libc / system layout choices
- Updated every 3 months current version is 2020.08.1
- ► Easily extendable

### Why BuildRoot: architecture support

#### $\approx$ 20 architectures supported

- ► ARC LE & BE
- ► ARM LE & BE
- ► AArch64 LE & BE
- csky
- ▶ i386
- ► Microblaze AXI & Non-AXI
- ► MIPS LE & BE
- ► MIPS64 LE & BE
- nds32

- Nios II
- PowerPC
- ► PowerPC64 LE & BE
- ► RISCV
- SuperH
- ► SPARC
- ► x86\_64
- Xtensa

#### The BuildRoot process

#### What the user sees

- 1. Create a configuration file
- 2. Start the build
- 3. Flash the image on the device

#### What BuildRoot does

- 1. Build a cross compiler on our machine
- 2. Resolve the configuration dependencies
- 3. Compile from source the requested packages
- 4. Assemble an image

#### Prerequisites

#### Packages for an ARM BuildRoot

#### Ubuntu 20.04

```
sudo apt-get update
sudo apt-get install -y \
  curl tar \
  make \
  gcc g++ \
  libncurses-dev libssl-dev \
  qemu-user-static \
  qemu-system-arm
```

#### Others

Binaries needed

Downloaders curl & wget

Extractor tar

Compilers gcc & g++

Libraries ncurses & openssl

Execution QEMU system for

ARM & QEMU static

### Preparing our BuildRoot working directory

- Clone the repository at https://github.com/gabibbo97/basc-buildroot
- 2. Enter the directory
- 3. Download BuildRoot from https://buildroot.org/downloads/buildroot-2020.08.1.tar.;
- 4. Extract the BuildRoot archive

#### To follow along

Ensure you have extracted the BuildRoot archive to buildroot-2020.08.1

Initial setup

- 1. cd buildroot-2020.08.1
- 2. cp ../scripts/gef-python.sh ./gef-python.sh
- 3. chmod +x \*.sh
- 4. make distclean
- 5. make defconfig

Configuration options: 1/2

#### make menuconfig

- Target options
  - ► Target Architecture = ARM (little endian)
  - Target Architecture Variant = cortex-A7
  - ► Floating point strategy = VFPv4-D16
- Build options
  - ► ⊠ Enable compiler cache
  - ▶ ☑ build packages with debugging symbols
  - ▶ gcc debug level = debug level 3
  - ► □ strip target binaries
  - gcc optimization level = optimize for debugging

Configuration options: 2/2

- Toolchain
  - ► C library = glibc
  - ightharpoonup oxtimes Enable C++ support
  - ▶ ⊠ Build cross gdb for the host
  - ► ☑ TUI support
  - Python support = Python3
- System configuration
  - Custom scripts to run before creating filesystem images = ./gef-python.sh
- Filesystem images
  - ► □ tar the root filesystem
- Host utilities
  - host python3
  - ► ssl

Performing the build

- 1. Save the configuration to the default .config path
- 2. Download sources with make source
- 3. Start the build with make sdk

Initial setup

- cd buildroot-2020.08.1
- 2. cp ../scripts/gef-python.sh ./gef-python.sh
- 3. chmod +x \*.sh
- 4. make distclean
- 5. make defconfig

Configuration options: 1/3

#### make menuconfig

- ▶ Target options
  - ► Target Architecture = ARM (little endian)
  - ► Target Architecture Variant = cortex-A7
  - ► Floating point strategy = VFPv4-D16
- Build options
  - ► ⊠ Enable compiler cache
  - ▶ ☑ build packages with debugging symbols
  - gcc debug level = debug level 3
  - ► □ strip target binaries
  - gcc optimization level = optimize for debugging

Configuration options: 2/3

- Toolchain
  - ► C library = glibc
  - ► ⊠ Enable C++ support
  - ▶ ⊠ Build cross gdb for the host
  - ► ☑ TUI support
  - Python support = Python3
- System configuration
  - Custom scripts to run before creating filesystem images = ./gef-python.sh
- Target packages
  - Debugging, profiling and benchmark
    - ▶ Ø gdb

    - ▶ ⊠ gdbserver
    - ► ☑ TUI support

Configuration options: 3/3

- ► Filesystem images
  - ▶ ⊠ tar the root filesystem
- ► Host utilities
  - host python3
  - ssl

Performing the build

- 1. Save the configuration to the default .config path
- 2. Download sources with make source
- 3. Start the build with make

- 1. cd buildroot-2020.08.1
- 2. cp ../kconfigs/virtio.kconfig ./virtio.kconfig
- 3. cp ../scripts/gef-python.sh ./gef-python.sh
- 4. cp ../scripts/enable-ssh-root-login.sh

  - ./enable-ssh-root-login.sh chmod +x \*.sh
- make distclean
- 7. make defconfig

### Creating a bootable ARM root filesystem

Configuration options: 1/3

#### make menuconfig

- ▶ Target options
  - ► Target Architecture = ARM (little endian)
  - ► Target Architecture Variant = cortex-A7
  - ► Floating point strategy = VFPv4-D16
- Build options
  - ► ⊠ Enable compiler cache
  - ▶ ☑ build packages with debugging symbols
  - gcc debug level = debug level 3
  - ► □ strip target binaries
  - ▶ gcc optimization level = optimize for debugging

# Creating a bootable ARM root filesystem

Configuration options: 2/3

- ► Toolchain
  - ► C library = glibc
  - ► ⊠ Enable C++ support
  - ▶ ⊠ Build cross gdb for the host
  - ► ☑ TUI support
  - Python support = Python3
- System configuration
  - ► System hostname = BASC2020
  - System banner = Welcome to BASC2020 Buildroot
  - ► Root password = BASC2020
  - ► Network interface to configure through DHCP = eth0
  - Custom scripts to run before creating filesystem images = ./enable-ssh-root-login.sh ./gef-python.sh

# Creating a bootable ARM root filesystem

Configuration options: 3/3

- Target packages
  - Debugging, profiling and benchmark
    - ▶ Ø gdb

    - gdbserver
    - ► ⊠ TUI support
    - ▶ Itrace
    - ▶ ⋈ strace
    - ► M 1 .
    - \( \simeg \) valgrind
  - Networking applications
    - ▶ ⊠ openssh
    - ► □ client
    - ▶ ⋈ key utilities
  - Filesystem images
    - ► ⊠ ext2/3/4 root filesystem
      - exact size = 512M
    - ▶ ☐ tar the root filesystem
- Host utilities
  - host python3
  - ► ssl

Performing the build

- 1. Save the configuration to the default .config path
- 2. Download sources with make source
- 3. Start the build with make

Build time overlay

- Create a directory
- ► Add BR2\_ROOTFS\_OVERLAY=my-overlay to .config
- ► Rebuild using make
- ► The structure of my-overlay will be copied to the rootfs

#### How to specify multiple overlays

Multiple overlays can be specified by separating them with spaces in the BR2\_ROOTFS\_OVERLAY directive

Build time script

Add BR2\_ROOTFS\_POST\_BUILD\_SCRIPT=my-script.sh to .config Available environment variables inside:

BR2\_CONFIG path of .config
HOST\_DIR path of output/host
STAGING\_DIR path of output/staging
TARGET\_DIR path of output/target
BUILD\_DIR path of output/build
BINARIES\_DIR path of output/images
BASE\_DIR path of output

#### How to specify multiple scripts

Multiple scripts can be specified by separating them with spaces in the BR2\_ROOTFS\_POST\_BUILD\_SCRIPT directive

Editing the target directory

- 1. Add your files to the output/target directory
- 2. Rebuild using make

#### Warning

Your files might be rewritten / deleted by buildroot

D.I.Y. approach

- 1. Unpack your rootfs (with tar -xzf for instance)
- 2. Perform your modifications
- 3. Repack your rootfs (with tar -cf for instance)

#### Using the cross-compiler

- 1. Extract the cross-compiler
- 2. Run relocate-sdk.sh
- Edit your \$PATH variable: export PATH="\$PATH:\$PWD/bin"
- 4. You can invoke your cross compiler with commands like arm-buildroot-linux-gnueabihf-<COMMAND NAME> Notable entries
  - arm-buildroot-linux-gnueabihf-gcc
  - ▶ arm-buildroot-linux-gnueabihf-gdb
  - ▶ arm-buildroot-linux-gnueabihf-nm

#### Improving gdb with library simbols

See the section Using gdb

### Running dynamic executables in Docker

```
sudo docker import rootfs.tar basc-buildroot
sudo docker run --rm -it \
    --volume "$(which qemu-arm-static):/bin/qemu-arm-static" \
    --volume "${PWD}/:/host" \
    --entrypoint /bin/qemu-arm-static \
    --workdir "/host" \
    basc-buildroot \
    /bin/sh
```

# Running dynamic executables with systemd-nspawn

```
mkdir -p basc-rootfs
tar -xf rootfs.tar -C basc-rootfs
cp -f "$(which qemu-arm-static)" \
  basc-rootfs/bin/qemu-arm-static
sudo systemd-nspawn \
  --register=no \
  -D basc-rootfs \
  /bin/qemu-arm-static /bin/sh
```

#### Package needed

You might need to install the package systemd-container

#### Booting the rootfs

```
qemu-system-arm \
  -machine virt \
  -cpu cortex-a7 \
  -smp 4 -m 4096 \
  -kernel zImage \
  -device virtio-blk-device,drive=rootfs \
  -drive file=rootfs.ext2,if=none,format=raw,id=rootfs \
  -append "console=ttyAMA0,115200 rootwait root=/dev/vda" \
  -netdev user,id=user0,hostfwd=tcp::2222-:22,hostfwd=tcp::1234-:1234 \
  -device virtio-net-device,netdev=user0 \
  -serial stdio \
  -display none
```

# Tips and tricks Using SSH

#### Opening an SSH session

```
ssh \
  -o UserKnownHostsFile=/dev/null \
  -o StrictHostKeyChecking=no \
  -p 2222 root@localhost
```

#### Sharing a folder

```
mkdir -p guest-os-ssh
sshfs root@localhost:/ ./guest-os-ssh \
  -f \
  -o port=2222 \
  -o reconnect \
  -o UserKnownHostsFile=/dev/null \
  -o StrictHostKeyChecking=no
```

#### Using Itrace and strace

What did you expect?

- ▶ ltrace and strace do work as expected
- Can only be performed on QEMU system emulation

#### Using gdb

```
On the guest
```

gdbserver: 1234 command to debug

```
On the host (From the cross-compiler extracted folder)
bin/arm-buildroot-linux-gnueabihf-gdb \
-x arm-buildroot-linux-gnueabihf/sysroot/usr/share/buildroot/gdbinit \
executable name
```

On the host gdb shell attach with target remote localhost:1234