Introduction to ESP32 using Vaman

G V V Sharma*

Contents

1	Software		1
2	Hardware Setup		1
3	Blink LED		1
4	ESP IDF		2
5	Raspberry Pi 5.1 Enable Serial Communication		2 2 2

Abstract—This document provides a simple introduction to programming the ESP32 on Vaman using the Arduino framework

1 Software

All codes used in this document are available at the following link

https://github.com/gadepall/vaman/ tree/master/esp32/setup/codes/

2 Hardware Setup

- 2.1. Connect the USB-UART to raspberry pi through USB.
- 2.2. On the rpi

dmesg	tail
lsusb	

you should see the USB-UART connector detected.

- 2.3. Connect the USB-UART pins to the Vaman ESP32 pins according to Table 2.3.1
- 2.4. Connect the Vaman-ESP pins to the seven segment display according to Table 2.4.1 The GPIO pins are listed in Table 2.4.2 Note that these pins can be used for sev-

*The author is with the Department of Electrical Engineering, IIT Hyderabad, 502285. email:gadepall@ee.iith.ac.in1 All content in this manual is released under GNU/GPL.

VAMAN LC PINS	UART PINS
GND	GND
ENB	ENB
TXD0	RXD
RXD0	TXD
0	IO0
5V	5V

TABLE 2.3.1

ESP	SEVEN SEGMENT DISPLAY
5V	COM
2	DOT

TABLE 2.4.1

eral functions, refer to the ESP32 datasheet for details. The Vaman pin diagram is available in Fig. 2.4.1




Fig. 2.4.1

3 Blink LED

3.1. On termux on your phone,

svn co https://github.com/
 gadepall/vaman/trunk/esp32/
 setup/codes/ide/blink

GPIO	Input	Others
2	34	1
4	35	3
5	36	6
10	37	7
12	38	8
13	39	9
14		10
15		11
16		
17		
18		
19		
21		
22		
23		
25		
26		
27		
32		
33		

TABLE 2.4.2

cd blink pio run

3.2. Transfer the ini and bin files to the rpi

scp platformio.ini pi@192 .168.50.252:./hi/platformio. ini

scp .pio/build/esp32doit-devkit -v1/firmware.bin pi@192 .168.50.252:./hi/.pio/build/ esp32doit-devkit-v1/firmware .bin

3.3. On rpi,

cd /home/pi/hi pio run -t nobuild -t upload

3.4. On your phone, open

src/main.cpp
and change the delay to

delay (2000);

and exectute the code by following the steps above.

4 ESP IDF

4.1. Earlier, we were using the arduino framework, where the programming language was arduino. In the following directory, the same functionality is achieved through a C program.

```
svn co https://github.com/
gadepall/vaman/trunk/esp32/
setup/codes/idf/blink
cd blink
pio run
```

4.2. The flashing process remains the same.

5 Raspberry Pi

- 5.1 Enable Serial Communication
- 5.1.1. On the RPi,

```
sudo raspi-config
```

- 5.1.2. Select Interfacing Options
- 5.1.3. Then select Serial Port
- 5.1.4. Reply no to login shell over serial
- 5.1.5. Say yes to running hardware over serial port.
- 5.1.6. Connect the rpi tx (pin 8) and rx (pin 10)
- 5.1.7. Install minicom and start it

sudo apt install minicom minicom -b 115200 -o -D /dev/ serial0

Type namaste. If you see it displayed on screen, your serial port is working.

- 5.2 Flash Vaman-ESP
- 5.2.1. Since the RPi supports UART through its GPIO pins, a separate USB UART adapter is not required. Table 2.3.1 can be accordingly modified to obtain Table 5.2.1.1 On RPi, the pin numbers for serial communication are Tx=8, Rx=10.
- 5.2.2. Modify your platformio.ini file by adding the line

VAMAN LC PINS	RPI/UART PINS
GND	GND
ENB	GND
TXD0	RXD
RXD0	TXD
0	GND
5V	5V

TABLE 5.2.1.1

upload_port = /dev/serial0

5.2.3. After executing

pio run -t nobuild -t upload

while the dots and dashes are printed on the screen, disconnect the EN wire from GND. The Vaman-ESP should now flash.

5.2.4. After flashing, disconnect pin 0 on Vaman-ESP from GND. Power on Vaman and the appropriate LED will blink.