#### **Table of Contents**

```
Navigation 3
function xdot = dynamicsBdot(t,x,params)
% Usage: [tout,xout] = ode45(@(t,x) Coupledyn(t,x,params),tspan,x0,...
% Written by Garrett Ailts
% Description: Function takes in the current time, state, and a struct
% simulation parameters for a continuouse rigid body's (CRB) angular
% dynamics using the quaternion or DCM representation and returns the
% derivative of the state vector
응
Inputs:
응
     - time since t0 (s)
ွ
     - 20 x 1 (quaternion) or 30 x 1 (DCM) state vector
      representing CRB's attitude and angular rates
     - struct containing CRB and simulation parameters
 params
% Outputs:
      20 x 1 or 30 x 1 vector containing the rates of change
for the state
응
      paramters
```

#### **Extract Parameters from Struct**

```
sim

gg_model = params.gg_model;
mag_model = params.mag_model;
atm_model = params.atm_model;
SRP_model = params.SRP_model;
J2on = params.J2on;
% Earth
mu = params.Earth.mu_e;
R = params.Earth.Rmean;
```

```
J2 = params.Earth.J2const;
mag_epoch = params.Earth.mag_epoch;
% spacecraft
AttType = params.sc.Attitude_Type;
I = params.sc.IB_b;
start_epoch = params.sc.start_epoch;
mb_residual = params.sc.mom_b;
est_method = params.sc.est_method;
ctrl_method = params.sc.ctrl_method;
km = params.sc.kmag;
a = params.sc.f_cutoff;
mtorquer = params.sc.mtorquer;
mcoil = params.sc.mcoil;
```

#### **Useful Values**

```
day2sec = 86400;
I3 = [0 0 1]';
r = norm(x(1:3));
if strcmp(AttType,'DCM')
    Cba = reshape(x(7:15),[3 3]);
    wba = x(16:18);
else
    Cba = Quat2DCM(x(7:10));
    wba = x(11:13);
end
wbaX = crossMatrix(wba);
```

# **Check for Earth Impact and J2 Inclusion**

```
if r<=R
    warning('Earth impact!')
end
% Check For J2 Inclusion
if ~J2on
    J2 = 0;
end</pre>
```

### **Forces and Moments**

```
gravity gradient torque

if gg_model
    tau_gg = (3*mu/r^5)*crossMatrix(Cba*x(1:3))*I*Cba*x(1:3);
else
    tau_gg = 0;
end

% magnetic moment
if mag_model
```

```
telapsed = t+day2sec*(start_epoch-mag_epoch);
    b a = EarthMagField(x(1:3), telapsed);
    tau_mag = crossMatrix(mb_residual)*Cba*b_a;
    tau_mag = 0;
end
% atmospheric pressure force and torque
if atm_model
    [f_atm, tau_atm] = atmosphereMdl(t,x,Cba,params);
else
    f_atm = 0;
    tau atm = 0;
end
% solar radiation pressure force
if SRP model
    f_srp = 0; % placeholder for solar radiation pressure model
               % implementation
else
    f_{srp} = 0;
end
force = f atm+f srp; % sum of forces besides gravity of primary body
mom = tau_gg+tau_mag+tau_atm; % sum of moments imparted on spacecraft
```

#### **Sensors**

```
rate gyroscope
```

```
%wbahat = RateGyroNoisy(wba,t);
% Earth horizon sensor
%rpc_b = EarthSensorNoisy(-x(1:3),Cba,t);
if mag_model
    b_b = MagnetometerNoisy(b_a,Cba,t);
end
```

### **Navigation**

```
if strcmp(est_method,'LDF')
   x_f = x(end-2:end);
   xdot_f = -a*eye(3)*x_f+a*eye(3)*b_b;
   bhatDot = xdot_f;
elseif strcmp(est_method,'none')
   xdot_f = zeros(3,1);
   bhatDot = zeros(3,1);
end
```

#### **Control**

```
if strcmp(ctrl_method,'det1')
```

```
mb = km*wbaX*b_b/sqrt(b_b'*b_b);
elseif strcmp(ctrl_method,'Bdot')
    mb = -km*bhatDot/sqrt(b_b'*b_b);
elseif strcmp(ctrl_method,'bang-bang')
    m_max = [mcoil; mtorquer; mtorquer]; % axes have different max dipoles
    m_max(bhatDot<1e-12) = 0; % dead zone
    mb = -m_max.*sign(bhatDot);
elseif strcmp(ctrl_method,'none')
    mb = 0;
else
    error('Not a valid control method for this function!\n');
end
tau_ctrl = -crossMatrix(b_b)*mb;
mom = mom+tau_ctrl;</pre>
```

### **Orbital Dynamics**

Calculate xdot1 with gravity and other forces

# **Attitude Dynamics**

# **Package Dynamics Together**

```
xdot = [xdot1; xdot2];
end
```

Published with MATLAB® R2019b