Introduction to Computer Networks

IEEE 802.3 Ethernet


 All rights reserved. No part of this publication and file may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of Professor Nen-Fu Huang (E-mail: nfhuang@cs.nthu.edu.tw).

Outline

- **■** Introduction
- Ethernet Topologies
- **■** Ethernet Frame Format
- **Ethernet MAC Protocol -- CSMA/CD**
- 802.3 Ethernet Standards

Ethernet

- Most successful local area networking technology of last 30 years.
- First widely used LAN technology
- kept up with speed race: 10 Mbps 100 Gbps



Metcalfe's Ethernet sketch

Ethernet

- Developed in the mid-1970s by researchers at the Xerox Palo Alto Research Centers (PARC).
- DEC and Intel joined Xerox to define a 10-Mbps Ethernet standard in 1978.
- This standard formed the basis for IEEE standard 802.3
- More recently 802.3 has been extended to include
 - 100-Mbps version called Fast Ethernet,
 - 1000-Mbps version called Gigabit Ethernet,
 - 10 Gigabit Ethernet, and also
 - 100 Gigabit Ethernet

Ethernet: Unreliable, Connectionless


- Connectionless: No handshaking between sending and receiving NICs
- Unreliable: receiving NIC doesn't send ACKs or NACKs to sending NIC
- Ethernet's MAC protocol: Carrier Sense Multiple Access with Collision Detection (CSMA/CD)

Outline

- Introduction
- **■** Ethernet Topologies
- **■** Ethernet Frame Format
- **Ethernet MAC Protocol -- CSMA/CD**
- 802.3 Ethernet Standards

Bus Topology

- Bus topology popular through mid 90s
 - all nodes in same collision domain (can collide with each other)




Ethernet (10Base5)

- An Ethernet segment is implemented on a coaxial cable of up to 500 m.
- Hosts connect to an Ethernet segment by tapping into it.
- A transceiver (a small device directly attached to the tap) detects when the line is idle and drives signal when the host is transmitting.
- The transceiver also receives incoming signal.
- The transceiver is connected to an Ethernet adaptor which is plugged into the host. But now most are built in into the computers.
- The protocol is implemented on the adaptor.




Ethernet (10Base5)




Ethernet transceiver, adaptor, and terminator


Network Configuration Example 1 (Single segment)



Cable Signaling (Manchester Encoding)



Coaxial Cable



Transceiver Cable


- Each bit has a transition
- Allows clocks in sending and receiving nodes to synchronize to each other

Ethernet (10Base5)


10Mbps baseband 500m

- Multiple Ethernet segments can be joined together by repeaters.
- A repeater is a device that forwards digital signals.
- No more than four repeaters may be positioned between any pair of hosts.
 - An Ethernet has a total reach of only 2500 m.

Network Configuration Example 2 (Two segments)



Network Configuration Example 3 (Five segments, maximum)



Ethernet (10Base2)

- New Technologies in Ethernet
 - Instead of using coax cable, an Ethernet can be constructed from a thinner cable known as 10Base2 (the original was 10Base5)
 - ▶ 10 means the network operates at 10 Mbps
 - Base means the cable is used in a baseband system
 - 2 means that a given segment can be no longer than 200 m






Ethernet (10BaseT)

- New Technologies in Ethernet
 - Another cable technology is 10BaseT
 - T stands for twisted pair
 - ▶ Limited to 100 m in length
 - With 10BaseT, the common configuration is to have several point to point segments coming out of a multiway repeater, called Hub






Ethernet





Star Topology

- Today: Star topology prevails
 - active switch in center
 - each "spoke" runs a (separate) Ethernet protocol (nodes do not collide with each other)




Ethernet-Switch

- To speed up the transmission rate of Ethernet Hub without changing the interface cards on stations.
- Ether-Switch Architecture
- Each Ethernet port can have a transmission simultaneously.



Ethernet Switch ASIC example



Block Diagram

Acute Leo AQ6628 24+4 Ethernet Switch ASIC


Outline

- Introduction
- Ethernet Topologies
- **■** Ethernet Frame Format
- **Ethernet MAC Protocol -- CSMA/CD**
- 802.3 Ethernet Standards


Ethernet Frame Format

Frame format

- Preamble (64bits): allows the receiver to synchronize with the signal (sequence of alternating os and 1s).
- Source and Destination MAC Addresses (48bits each).
- Packet type (16bits): acts as demux key to identify the higher level protocol.
- Data (up to 1500 bytes)
 - Minimally a frame must contain at least 46 bytes of data.
 - Frame must be long enough to detect collision.
- FCS: CRC (32bit)



Ethernet Frame Format



- Preamble: (101010...1010) for Synchronization
- SFD: Start Frame Delimiter (10101011)
- DA: Destination MAC Address
- SA: Source MAC Address
- Packet type (16bits): acts as demux key to identify the higher level protocol.
- LLC-Frame: Up to 1500 bytes
- PAD: Padding when LLC-Frame < 46 bytes</p>
- FCS: Frame Check Sequence (CRC-32)
- MAC-frame size -- from DA to FCS
 - Min 64 bytes to distinguish from collision
 - Max 1518 bytes to prevent dominating bandwidth

- Each host on an Ethernet (in fact, every Ethernet host in the world) has a unique Ethernet Address.
- The address belongs to the adaptor, not the host.
 - It is usually burnt into ROM.
- Ethernet addresses are typically printed in a human readable format
 - As a sequence of six numbers separated by colons.
 - Each number corresponds to 1 byte of the 6 byte address and is given by a pair of hexadecimal digits, one for each of the 4-bit nibbles in the byte
 - Leading os are dropped.
 - For example, 8:0:2b:e4:b1:2 is

- To ensure that every adaptor gets a unique address, each manufacturer of Ethernet devices is allocated a different prefix that must be prepended to the address on every adaptor they build
 - AMD has been assigned the 24bit prefix 8:0:20



- Each frame transmitted on an Ethernet is received by every adaptor connected to that Ethernet.
- Each adaptor recognizes those frames addressed to its address and passes only those frames on to the host.
- In addition to unicast address, an Ethernet address consisting of all 1s is treated as a broadcast address.
 - All adaptors pass frames addressed to the broadcast address up to the host.
- Similarly, an address that has the first bit set to 1 but is not the broadcast address is called a multicast address.
 - A given host can program its adaptor to accept some set of multicast addresses.


- To summarize, an Ethernet adaptor receives all frames and accepts
 - Frames addressed to its own address
 - Frames addressed to the broadcast address
 - Frames addressed to a multicast address if it has been instructed

Outline

- Introduction
- Ethernet Topologies
- **■** Ethernet Frame Format
- **Ethernet MAC Protocol -- CSMA/CD**
- 802.3 Ethernet Standards

Ethernet MAC protocol

- Any signal placed on the Ethernet by a host is broadcast over the entire network
 - Signal is propagated in both directions.
 - Repeaters forward the signal on all outgoing segments.
 - Terminators attached to the end of each segment absorb the signal.



CSMA (Carrier Sense Multiple Access)

CSMA: listen before transmit:

If channel sensed idle: transmit entire frame

■ If channel sensed busy, defer transmission


CSMA collisions

collisions can still occur:

propagation delay means two nodes may not hear each other's transmission

collision:

entire packet transmission time wasted




CSMA/CD (Collision Detection)

CSMA/CD: carrier sensing, deferral as in CSMA

- collisions detected within short time
- colliding transmissions aborted, reducing channel wastage
- Collision detection:
 - Measure signal strengths, compare transmitted, received signals

CSMA/CD collision detection



CSMA/CD

- Carrier Sense Multiple Access with Collision Detection (CSMA/CD).
 - A set of nodes send and receive frames over a shared link.
 - Carrier sense means that all nodes can distinguish between an idle and a busy link.
 - Collision detection means that a node listens as it transmits and can therefore detect when a frame it is transmitting has collided with a frame transmitted by another node.

CSMA/CD

- When the adaptor has a frame to send and the line is idle, it transmits the frame immediately.
- When the adaptor has a frame to send and the line is busy, it waits for the line to go idle and then transmits immediately.
- The Ethernet is said to be 1-persistent protocol because an adaptor with a frame to send transmits with probability 1 whenever a busy line goes idle.

CSMA/CD

- Since there is no centralized control it is possible for two (or more) adaptors to begin transmitting at the same time,
 - Either because both found the line to be idle,
 - Or, both had been waiting for a busy line to become idle.
- When this happens, the two (or more) frames are said to be *collide* on the network.


CSMA/CD

- Since Ethernet supports collision detection, each sender is able to determine that a collision is in progress.
- At the moment an adaptor detects that its frame is colliding with another, it first makes sure to transmit a 32-bit jamming sequence and then stops transmission.
 - Thus, a transmitter will minimally send 96 bits in the case of collision
 - ▶ 64-bit preamble + 32-bit jamming sequence

CSMA/CD

- One way that an adaptor will send only 96 bits (called a runt frame) is if the two hosts are close to each other.
- In case the two hosts are farther apart, they would have had to transmit longer, and thus send more bits, before detecting the collision.


- The worst case scenario happens when the two hosts are at opposite ends of the Ethernet.
- To know for sure that the frame its just sent did not collide with another frame, the transmitter may need to send as many as 512 bits.
 - Every Ethernet frame must be at least 512 bits (64 bytes) long.
 - ▶ 14 bytes of header + 46 bytes of data + 4 bytes of CRC



- Why 512 bits (64 bytes)?
 - Why is its length limited to 2500 m?
- Collision Window = round-trip delay (2a)

■ The farther apart two nodes are, the longer it takes for a frame sent by one to reach the other, and the network is vulnerable to collision during this time

Collision Detection Window for CSMA/CD (=2a)



- A begins transmitting a frame at time t
- a denotes the one link latency
- The first bit of A's frame arrives at B at time t + a
- Suppose an instant before host A's frame arrives, host B begins to transmit its own frame
- B's frame will immediately collide with A's frame and this collision will be detected by host B
- Host B will send the 32-bit jamming sequence
- Host A will not know that the collision occurred until B's frame reaches it, which will happen at t + 2a
- Host A must continue to transmit until this time in order to detect the collision
 - Host A must transmit for 2a to be sure that it detects all possible collisions

- Consider that a maximally configured Ethernet is 2500 m long, and there may be up to four repeaters between any two hosts, the round trip delay has been determined to be 51.2 µs
 - Which on 10 Mbps Ethernet corresponds to 512 bits
 - 10 Mbps x 51.2 μs = 512 bits
- The other way to look at this situation,
 - We need to limit the Ethernet's maximum latency to a fairly small value (51.2 μs) for the access algorithm to work
 - Hence the maximum length for the Ethernet is on the order of 2500 m.

Exponential Backoff Algorithm

- Once an adaptor has detected a collision, and stopped its transmission, it waits a certain amount of time and tries again.
- Each time the adaptor tries to transmit but fails, it doubles the amount of time it waits before trying again.
- This strategy of doubling the delay interval between each retransmission attempt is known as Exponential Backoff.

Exponential Backoff Algorithm

- The adaptor first delays either 0 or 51.2 μs, selected at random.
- If this effort fails, it then waits 0, 51.2, 102.4, 153.6 μs (selected randomly) before trying again;
 - This is k * 51.2 for k = 0, 1, 2, 3
- After the third collision, it waits k * 51.2 for $k = 0...2^3 1$ (again selected at random).
- In general, the algorithm randomly selects a k between 0 and $2^n 1$ and waits for $k * 51.2 \mu s$, where n is the number of collisions experienced so far.

CSMA/CD Protocol

- Carrier Sense before transmission
- Carrier Sense while transmission
- Collision: Two or more stations transmitting simultaneously
- Backoff: Random delay after collision
- Deference: Defers transmission if channel is sensed busy
- Collision Window (Slot time): Round-trip propagation delay time plus some carrier sense time. In IEEE 802.3, this value is defined to be 51.2 us.

CSMA/CD Collision Handling


- Collision Signal is generated by Physical layer.
- Jam signal (collision enforcement): To make sure that all stations involved in the collision will detect collision. A pattern of 32 bits.
- Collision backoff and retransmission method (Truncated Binary Exponential Backoff Algorithm, BEBA):
 - n: number of collisions experienced (n <= 16)</p>
 - k : Min (n,10) -- Truncation
 - r: Random delay time (unit: slot time), 0 <= r < 2^k

CSMA/CD Collision Handling

- Slot time = 51.2 us.
- Disadvantage of BEBA:
 - Last-in-First-out effect: Stations with no or few collisions will have a better chance to transmit before stations that have waited longer.

Ethernet Performance

- Ethernets work best under lightly loaded conditions.
- Under heavy loads, too much of the network's capacity is wasted by collisions.




Outline

- Introduction
- Ethernet Topologies
- **■** Ethernet Frame Format
- Ethernet MAC Protocol -- CSMA/CD
- 802.3 Ethernet Standards

802.3 Ethernet Standards: Link & Physical Layers

- Many different Ethernet standards
 - common MAC protocol (CSMA/CD) and frame format
 - different speeds: 2 Mbps, 10 Mbps, 100 Mbps, 1Gbps, 10Gbps, 100Gbps
 - different physical layer media: fiber, cable



Summary

- MAC Protocol -- CSMA/CD
- Connection less, unreliable transmission
- Topology from Bus to Star (switches)
- Half-duplex transmission in Bus topology
 - Work best under lightly loaded conditions
 - Too much collision under heavy load
- Full-duplex transmission in Switch topology (point-to-point)
 - No more collisions !!
 - Excellent performance (wired speed)