

MIPS Instruction Sets

Dr. Heng Yu

AY2022-23, Spring Semester
COMP1047: Systems and Architecture
Week 5



Learning Objectives

- Understand MIPS instruction set and design principle
- Translate a MIPS instruction into machine code



Recap: MIPS ISA

MIPS ISA

- We introduced the MIPS architecture.
 - Developed by John Hennessy and his colleagues at Stanford and in the 1980's.
 - Used in many commercial systems, including Silicon Graphics, Nintendo, and Cisco.
- RISC ISA: Reduced instruction set computing
 - As opposed to CISC (e.g. x86)
- Simple, elegant, easy to implement
 - That's why we choose it in COMP1047.
 - Once you've learned one architecture, it's easy to learn others.
- Designed with decades of continuous ISA design efforts
 - The prototype of a lot of modern ISAs



Think about it:

What's the relationship between von Neumann Architecture and MIPS ISA?

Recap: MIPS ISA

Instruction Set Architecture

- Defines the set of operations that a computer/processor can execute
- The contract between the hardware and software
 - → "Contract": given an ISA, your sw and hw must be designed for the ISA! A glue for high and low levels of the system!
- Example ISAs:
 - x86: intel Xeon, intel Core i7/i5/i3, intel atom, AMD Athlon/Opteron, AMD FX, AMD A-series
 - → ARM: Apple A-Series, Qualcomm Snapdragon, TIOMAP, NVidia Tegra
 - → MIPS: Sony/Toshiba Emotion Engine, MIPS R-4000(PSP)
 - → DEC Alpha, PowerPC, IA-64, SPARC and many more ...



Assembly Language vs Machine Code

- We've been using assembly language
- Recall that an assembler is a program that translates a symbolic version of instructions into the binary versions
- MIPS32: Each machine instruction is 32-bit long and contains several fields

MIPS instruction	add \$s0, \$s1, \$s2
Hexadecimal (machine code)	$0232\ 8020_{16}$
Binary (machine code)	$0000\ 0010\ 0011\ 0010\ 1000\ 0000\ 0010\ 0000_2$

Instructions as numbers

- Currently we worked with words (32-bit blocks):
 - Each register is a word.
 - → lw and sw both access memory one word at a time.
- So how do we represent instructions?
 - → Design principle: Simplicity favors regularity
 - → MIPS wants simplicity: since data is in words, make instructions be in words too...
 - → Best case: define a single format for all types of instructions too restrictive.
 - → In practice: Defined 3 basic types of instruction formats: R-format, I-format, J-format.
- One instruction is in 32 bits
 - → Divide the instruction word into "fields".
 - ➤ Each "field" tells computer the info about the operands and operations.

3 Instruction Formats: all 32 bits wide

OP	\$rs	\$rt	\$rd	sa	funct
OP	\$rs	\$rt	imm	ediate	
OP		jump target			



MIPS ISA as an Example

- All instructions are 32 bits
- 32 32-bit registers
 - \$zero is always o
- 50 opcodes opcode: first 6 digits
 - → Arithmetic/Logic operations
 - Load/store operations
 - → Branch/jump operations
- 3 instruction formats
 - → R-type: all operands are registers
 - → I-type: one of the operands is an immediate value
 - → J-type: non-conditional, nonrelative branches

3 Instruction Formats: all 32 bits wide

OP	\$rs	\$rt	\$rd	sa	funct
ОР	\$rs	\$rt	imme	ediate	
ОР		jump	target		

Simplicity favors regularity

R-format instructions

Define the following fields:

6	5	5	5	5	6
opcode	rs	rt	rd	shamt	funct

- Opcode: partially specifies what instruction it is (Note: '0' for all R-Format instructions)
- funct: combined with opcode to specify the instruction
 - E.g. add: op(o), funct(32). sub: op(o), funct(34).
- S rs (Source Register): used to specify register containing first operand
- > rt (S-next Register): used to specify register containing second operand
- cd (Destination Register): used to specify register which will receive result of calculation
- **Shamt** (shift amount): contains the amount a shift instruction will shift by. Set to zero in other cases.

Think about it:

Why are only 5 bits needed for rs, rt, or rd?

Why 5 for shamt?



Example

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

R	\$s1	\$s2	\$t0	0	add
0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

 $0000001000110010010000000100000_2 = 02324020_{16}$



Table B.1 Instructions, sorted by opcode

Opcode	Name	Description	Operation
000000 (0)	R-type	all R-type instructions	see Table B.2
000001 (1) (rt = 0/1)	bltz/bgez	branch less than zero/ branch greater than or equal to zero	if ([rs] < 0) PC = BTA/ if ([rs] ≥ 0) PC = BTA
000010 (2)	j	jump	PC = JTA
000011 (3)	jal	jump and link	<pre>\$ra = PC+4, PC = JTA</pre>
000100 (4)	beq	branch if equal	if ([rs]==[rt]) PC = BTA
000101 (5)	bne	branch if not equal	if ([rs]!=[rt]) PC = BTA
000110 (6)	blez	branch if less than or equal to zero	if ([rs] \leq 0) PC = BTA
000111 (7)	bgtz	branch if greater than zero	if ([rs] > 0) PC = BTA
001000 (8)	addi	add immediate	[rt] = [rs] + SignImm
001001 (9)	addiu	add immediate unsigned	[rt] = [rs] + SignImm
001010 (10)	slti	set less than immediate	[rs] < SignImm ? [rt] = 1 : [rt] = 0

Table B.1 in Appendix B, in the Harris & Harris Book



Table B.2 R-type instructions, sorted by funct field—Cont'd

Funct	Name	Description	Operation
011011 (27)	divu	divide unsigned	[lo] = [rs]/[rt], [hi] = [rs]%[rt]
100000 (32)	add	add	[rd] = [rs] + [rt]
100001 (33)	addu	add unsigned	[rd] = [rs] + [rt]
100010 (34)	sub	subtract	[rd] = [rs] - [rt]
100011 (35)	subu	subtract unsigned	[rd] = [rs] - [rt]
100100 (36)	and	and	[rd] = [rs] & [rt]
100101 (37)	or	or	[rd] = [rs] [rt]
100110 (38)	xor	xor	$[rd] = [rs] ^ [rt]$
100111 (39)	nor	nor	$[rd] = \sim ([rs] \mid [rt])$
101010 (42)	slt	set less than	[rs] < [rt] ? [rd] = 1 : [rd] = 0
101011 (43)	sltu	set less than unsigned	[rs] < [rt] ? [rd] = 1 : [rd] = 0

Table B.2 in Appendix B, in the Harris & Harris Book

Question: translate the following instruction into machine code (in Hex format)

sub \$s0, \$s1, \$s2

I-format instructions

Define the following fields:

6	5	5	16
opcode	rs	rt	immediate


- opcode: uniquely specifies an I-format instruction
- > rs: specifies the *only* register operand
- > rt: specifies the register which receives the result of calculation (target register)
- immediate: 16-bit signed integer, can represent up to 2¹⁶ different immediate values.

Think about it:

How many different *I-format* instructions can be represented?

What is the maximum number that the immediate field can carry?

Example



decimal representation:


8 22 21 -50

binary representation:

001000 10110 10101 1111111111001110

look up opcode for 'addi' in Table B.1 in Appendix B, in the Harris & Harris Book

Example



Tw \$t0, 1200(\$t1)

decimal representation:

35 9 8 1200

binary representation:

100011 01001 01000 0000010010110000

look up opcode for 'lw' in Table B.1 in Appendix B, in the Harris & Harris Book

Question: translate the following instruction into machine code (in Hex format)

addi \$t0,\$t1,100

J-format instructions

Define the following fields:

6	26
opcode	JTA

- opcode: uniquely specifies an J-format instruction, so far, we've learnt j and jal
- **TTA:** 26-bit jump target address, jump relative to the current PC value, jump in words not in bytes.

Think about it:

What is the range of the jump?



Summary

- MIPS instruction set
- {R, I, J}-type instructions



Stay Tuned.