Instruction Set Architecture

George Herbert

February 11, 2023

Abstract

This document outlines the instruction set architecture (ISA) of the processor simulator. The ISA is a subset of the RISC-V Unprivileged ISA, with several changes. Many of the sections in this document very closely correspond to the sections in 'RISC-V Instruction Set Manual: Volume I: Unprivileged ISA'. While this is deliberate for ease of reference, it is not intended to imply that the ISA is identical.

1 RV32I Version 2.1

1.1 Registers

For RV32I, the 32 x registers are each 32 bits wide (i.e. XLEN=32). Register x0 is hardwired with all bits equal to 0. General purpose registers x1-x31 hold values that various instructions interpret as a collection of Boolean values, or as two's complement signed binary integers or unsigned binary integers.

There is one additional unprivileged register: the program counter pc holds the address of the current instruction.

1.2 Base Instruction Formats

In the base RV32I ISA, there are four core instruction formats (R/I/S/U). All are a fixed 32 bits in length and must be aligned on a four-byte boundary in memory. Immediates are always sign-extended.

RISC-V base instruction formats, with corresponding numbers of bits for each field in brackets:

- R-type: opcode (7), rd (5), funct3 (3), rs1 (5), rs2 (5), funct7 (7)
- I-type: opcode (7), rd (5), funct3 (3), rs1 (5), imm (12)
- S-type: opcode (7), funct3 (3), rs1 (5), rs2 (5), imm (12)
- U-type: opcode(7), rd(5), imm(20)

1.3 Integer Computational Instructions

Most integer computational instructions operate on XLEN bits of values held in the integer register file. Integer computational instructions are either encoded as register-immediate operations using the I-type format or as register-register operations using the R-type format.

1.3.1 Integer Register-Immediate Instructions

Table 1: Integer Register-Immediate Instructions

		•						
31 30 29 28 27 26 25	24 23 22 21 20	19 18 17 16 15	14 13	12	$11\ 10\ 9\ 8\ 7$	$6\ \ 5\ \ 4\ \ 3\ \ 2\ \ 1$	0	
I	-immediate	src	ADDI	[000]	dest	OP-IMM	[0010011]	I-typ
]	-immediate	src	SLTI	[010]	dest	OP-IMM	[0010011]	I-typ
	-immediate	src	SLTIU	[011]	dest	OP-IMM	[0010011]	I-typ
	-immediate	src	ANDI	[111]	dest	OP-IMM	[0010011]	I-typ
I	-immediate	src	ORI	[110]	dest	OP-IMM	[0010011]	I-typ
I	-immediate	src	XORI	[100]	dest	OP-IMM	[0010011]	I-typ
0000000	shamt	src	SLLI	[001]		OP-IMM		I-typ
0000000	shamt	src	SRLI	[101]	dest	OP-IMM	[0010011]	I-typ
0100000	shamt	src	SRAI	[101]	dest	OP-IMM	[0010011]	I-typ
			U-imme	diate	dest	LUI	[0110111]	U-typ
			U-imme	diate	dest	AUIPC	[0010111]	U-typ

ADDI adds the sign-extended 12-bit immediate to register rs1. Arithmetic overflow is ignored and the result is simply the low XLEN bits of the result.

SLTI (set less than immediate) places the value 1 in the register rd if register rs1 is less than the sign-extended immediate when both are treated as signed numbers, else 0 is written to rd. SLTIU is similar, but compares the values as unsigned numbers (i.e. the immediate is first sign-extended to XLEN bits then treated as an unsigned number).

ANDI, ORI, XORI are logical operations that perform bitwise AND, OR and XOR on registers rs1 and the sign-extended 12-bit immediate and place the result in rd.

Shifts by a constant are encoded as a specialisation of the I-type format. The operand to be shifted is in rs1 and the shift amount is encoded in the lower 5 bits of the I-immediate field. SLLI is a logical left shift (zeros are shifted into the lower bits); SRLI is a logical right shift (zeros are shifted into the upper bits); and SRAI is an arithmetic right shift (the original sign bit is copied into the vacated upper bits).

LUI (load upper immediate) is used to build 32-bit constants and uses the U-type format. LUI places the U-immediate value in the top 20 bits of the destination register rd, filling in the lowest 12 bits with zeros.

AUIPC (add upper immediate to pc) is used to build pc-relative addresses and uses the U-type format. AUIPC forms a 32-bit offset from the 20th-bit U-immediate, filling in the lowest 12 bits with zeros, adds this offset to the address of the AUIPC instruction, then places the result in register rd.

1.3.2 Integer Register-Register Operations

RV32I defines several arithmetic R-type operations. All operations read the rs1 and rs2 registers as source operands and write the result into register rd. The funct7 and funct3 fields select the type of operation.

Table 2: Integer Register-Register Operations

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 0000000 ADD 000 dest OP [0110011] src2src1R-type 0000000 src2SLT010 dest OP 0110011 src1R-type 0000000 src2src1 SLTU 011 dest OP 0110011 R-type 0000000 src2src1AND [111 dest OP [0110011] R-type 0000000 src2OR [110] dest OP 0110011 src1R-type dest OP [0110011] 0000000 src2 XOR [100] src1R-type dest OP SLL [001 0000000 src2 0110011 src1SRL [101 dest OP 0000000 src2src10110011 R-type 0100000 src2src1SUB [000] dest OP 0110011 R-type 0100000 SRA [101] dest OP [0110011] src2src1R-type

ADD performs the addition of rs1 and rs2. SUB performs the subtraction of rs2 from rs1. Overflows are ignored and the low XLEN bits of the results are written to the destination rd. SLT and SLTU perform signed and unsigned compares respectively, writing 1 to rd if rs1 < rs2, 0 otherwise. AND, OR and XOR perform bitwise logical operations.

SLL, SRL and SRA perform logical left, logical right and arithmetic right shifts on the value in register rs1 by the shift amount held in the lower 5 bits of register rs2.

1.4 Control Transfer Instructions

RV32I provides two types of control transfer instructions: unconditional jumps and conditional branches.

1.4.1 Unconditional Jumps

Table 3: Unconditional Jumps

3	1	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8 7	6	5	4	3	2	1	0	
																		C	ffs	et			de	est		J	A	L	[1	L10	1111]	U-type
										(offs	et				ba	se		0	00			de	est	J	Α	L	R	[1	L10	0111]	I-type

The jump and link (JAL) instruction uses the U-type format, where the U-immediate encodes a signed offset in multiples of 2 bytes. The offset is

sign-extended and added to the address of the jump instruction to form the jump target address. Jumps can therefore target a ± 1 MiB range. JAL stores the address of the instruction following the jump (pc + 4) into register rd. The standard software calling convention uses x1 as the return address register and x5 as an alternate link register.

The indirect jump instruction JALR (jump and link register) uses the I-type encoding. The target address is obtained by adding the sign-extended 12-bit I-immediate to the register rs1, then setting the least-significant bit of the result to zero. The address of the instruction following the jump (pc + 4) is written to register rd.

1.4.2 Conditional Branches

Table 4: Conditional Branches

 $31 \ \ \, 30 \ \ \, 29 \ \ \, 28 \ \ \, 27 \ \ \, 26 \ \ \, 25 \ \ \, 24 \ \ \, 23 \ \ \, 22 \ \ \, 21 \ \ \, 20 \ \ \, 19 \ \ \, 18 \ \ \, 17 \ \ \, 16 \ \ \, 15 \ \ \, 14 \ \ \, 13 \ \ \, 12 \ \ \, 11 \ \ \, 10 \ \ \, 9 \ \ \, 8$ BEQ [000] BRANCH [1100011] offset src2src1BNE [001] $\mathrm{src}\bar{1}$ offset src2BRANCH [1100011] S-type offset src2src1BLT [100] BRANCH [1100011] S-type offset src2 BLTU [110] BRANCH [1100011] src1S-type offset BGE [101] BRANCH [1100011] src2src1S-type offset src2src1BGEU [111] BRANCH [1100011] S-type

All branch instructions use the S-type instruction format. The 12-bit S-immediate encodes signed offsets in multiples of 2 bytes. The offset is sign-extended and added to the address of the branch instruction to give the target address. The conditional branch range is ± 4 KiB.

Branch instructions compare two registers. BEQ and BNE take the branch if registers rs1 and rs2 are equal or unequal respectively. BLT and BLTU take the branch if rs1 is less than rs2, using signed and unsigned comparison respectively. BGE and BGEU take the branch if rs1 is greater than or equal to rs2, using signed and unsigned comparison respectively. Note, BGT, BGTU, BLE and BLEU can be synthesised by reversing the operands to BLT, BLTU, BGE and BGEU, respectively.

2 Load and Store Instructions

Table 5: Integer Register-Immediate Instructions

		-								
31 30 29 28 27 3	26 25 24 23 22 21 20	19 18 17 16 15	14 13	12	11 10	9 8	7	6 5 4 3 2	1 0	
	offset	base	LW	[010]			dest	LOAD	[0000011]	I-type
	offset	base	LH	[001]			dest	LOAD	[0000011]	I-type
	offset	base	LHU	[101]			dest	LOAD	[0000011]	I-type
	offset	base	LB	[000]			dest	LOAD	[0000011]	I-type
	offset	base	LBU	[100]	1				[0000011]	
	offset	src			base	$\overline{\text{SW}}$	[010]	STORE	[0100011]	S-type
	offset	src							[0100011]	
	offset	src			base	SB	[000]	STORE	[0100011]	S-type

RV32I is a load-store architecture, where only load and store instructions access memory and arithmetic instructions only operate on CPU registers. RV32I provides a 32-bit address space that is byte-addressed.

Load and store instructions transfer a value between the registers and memory. Loads are encoded in the I-type format and stores are S-type. The effective address is obtained by adding registers rs1 to the sign-extended 12-bit offset. Loads copy a value from memory to register rd. Stores copy the value in register rs2 to memory.

The LW instruction loads a 32-bit value from memory into rd. LH loads a 16-bit value from memory, then sign-extends it to 32-bits before storing in rd. LHU loads a 16-bit value from memory but then zero extends it to 32-bits before storing in rd. LB and LBU are defined analogously for 8-bit values. The SW, SH and SB instructions store 32-bit, 16-bit and 8-bit values from the low bits of register rs2 to memory.