6502 Assembly Language

by Ted Kosan

Part of The Professor And Pat series (professorandpat.org)

Copyright © 2007 by Ted Kosan


This work is licensed under the Creative Commons Attribution-NonCommercial-NoDerivs 3.0 License. To view a copy of this license, visit http://creativecommons.org/licenses/by-nc-nd/3.0/

Table of Contents

Assemblers	
The UASM65 Assembler, .S19 Files, and .LST files	
Sending An S19 File To The Emulator	
Models	
Placing Models Into A Computer	
Variables	18
The Status Register	22
How A Computer Makes Decisions	
The JMP Instruction	26
Labels	27
Forward Branches And The Zero Flag	28
Negative Numbers And The Negative Flag	34
Backward Branches And Loops	38
The Carry Flag	44
Indexed Addressing Modes And Commenting Programs	48
Exercises	54
Appendix A - 6502 Instruction Set Reference (minus zero page ad	J ,

1 Assemblers

- 2 I was deep in thought when I heard a knock on the door of my shop.
- 3 "Professor, are you there?" A voice said. "Its Pat and I've come to learn
- 4 about assemblers!"
- 5 "Come in, Pat!" I said.
- 6 When Pat opened the door and entered, I smiled and said "have a seat next
- 7 to the computer and boot it up."
- 8 While the computer was booting I said "So, you want to learn about
- 9 assemblers?"
- 10 "Yes!" said Pat. "I couldn't stop thinking about machine language and
- 11 assembly language since the last time we met and now I really want to
- 12 know what an assembler does and how to use one."
- 13 I looked thoughtfully at Pat for a few moments then said "Okay, let me find
- 14 a whiteboard and then we will discuss assemblers." Then I drew the
- 15 following diagram while Pat watched. (see Fig. 1)



- 16 "An **assembler**," I said "is a program that takes a source code file that
- 17 contains plain ASCII characters and converts it into a file that contains
- 18 machine language. The type of application that is used to create a source

- 19 code file is called a **text editor**. Text editors allow users to create
- 20 documents that are similar to word processing documents, except the files
- 21 are saved using only plain ASCII characters. For this reason, files that only
- 22 contain plain ASCII characters are also called **text files**."
- 23 "Word processors can't be used to create source code files?" asked Pat.
- 24 "No," I replied "and the reason for this is because word processors need to
- save extra information in the files they create, including whether characters 25
- 26 should be in bold or underlined, what font types the characters use, and
- 27 what font sizes they use. Programs that take source code of any kind as
- 28 input are not able to handle this extra information. These programs are
- 29 only able to understand plain ASCII characters and, if a file that was
- 30 created by a word processor was fed into them, the programs would
- 31 produce errors."
- 32 "Can you show me what a text file looks like?" asked Pat.
- 33 "Yes." I replied. I then launched MathRider (http://mathrider.org), typed in
- the following text, and saved it in a file called 'abc123.txt'. 34
- 35 ABC
- 123 36
- 37 Hello Pat!
- 38 (Note: I run the GNU/Linux operating system on my PC and so the
- 39 **hexdump** command I use next will not work in Windows.)
- 40 I ran the **hexdump** command on the **abc123.txt** file and this is the output it
- 41 produced:
- 42 \$ hexdump -C abc123.txt
- 000000000 41 42 43 0d 0a 31 32 33 0d 0a 48 65 6c 6c 6f 20 |ABC..123..Hello | 43 |Pat!..|
- 00000010 50 61 74 21 0d 0a 44
- 45 "The hexdump command is similar to the umon65's Dump command," I said
- 46 "except instead of dumping memory locations, it dumps the contents of
- files." 47
- 48 Pat studied the output for a few moments then said "Its output is arranged
- 49 into 3 columns, just like the Dump command's output is! The first ASCII
- character in the file is a capital letter 'A' and hexdump displayed its value as 50
- 51 41 hex, just like the ASCII table showed. I see that 'B' is 42 hex, the

- 52 numeral '1' is 31 hex, and 'Pat' is 50 hex, 61 hex, and 74 hex. I don't
- 53 understand what the 0d 0a numerals are, though."
- 54 "Look at the source code again and also look for 0d hex and 0a hex in the
- 55 ASCII table." I replied.
- 56 Pat did this then said "Oh, they represent a carriage return and a line
- 57 **feed**! Is that what causes '123' to be placed on the line below 'ABC' and for
- 58 'Hello Pat!' to be placed below '123'?"
- 59 "Yes, Pat, this is exactly what the ASCII carriage return and line feed
- 60 characters do!" I said. "On some operating systems (like Windows) both a
- 61 carriage return and a line feed are used to drop down a line and move the
- 62 cursor to the left side of the screen. On other operating systems, however,
- 63 OA hex is used by itself for both these operations and it is call a **newline**
- 64 instead of a **line feed**. Another way to indicate a **carriage return**
- 65 **followed by a line feed** is by saying or typing **CRLF**."
- 66 "I'm glad I know what hexadecimal and ASCII are now because they are
- 67 helping me to understand how computers work!" said Pat.
- 68 I replied "You are discovering that the more knowledge that you possess,
- 69 the easier it becomes to expand your knowledge. The hexadecimal
- 70 numerals and ASCII characters are fundamental concepts that are used
- 71 throughout the whole field of computing. A sound understanding of how
- 72 they work is very useful for learning more advanced computing concepts."
- 73 After a few moments I said, "Lets get back to assemblers. When an
- 74 assembler opens a file, the file must only contain plain ASCII characters and
- 75 these ASCII characters must conform to the syntax that the assembler
- 76 expects. The assembler will then convert this source code into machine
- 77 language instructions that the target CPU can understand.
- 78 What we will do next is to type in the assembly language version of the
- 79 machine language program we started with, assemble it, and then look at
- 80 the machine language it generated."
- 81 "In the diagram," said Pat "I understand that the assembler is going to
- 82 generate a file that contains machine language, but what is this other '.LST'
- 83 file that it generates?"
- 84 "A .LST file," I replied "contains the original source code version of the

- program that was sent to the assembler, along with the machine language
- 86 that each line of source code was converted into. The purpose of this file is
- 87 to allow the programmer to see exactly how the source code was converted
- 88 into machine language. We will look at a .LST file after we have assembled
- 89 our first program."

90 The UASM65 Assembler, .S19 Files, and .LST files

- 91 I created a new file in MathRider called **u6502 programs.mrw**, typed the
- 92 following assembly language source code into it, and then saved it. (Note:
- 93 This is a %uasm "fold" and folds are explained in the MathRider for
- 94 Newbies book which can be found on the MathRider website.)

```
%uasm65,description="Example 1"
 95
           org 0200h
 96
 97
            lda #10d
 98
            adc #5d
 99
            sta 0208h
100
            brk
101
            end
102
     %/uasm65
```


- 103 "The assembler we will be using is called **uasm65**," I said "and it stands for
- 104 Understandable Assembler for 6500 series CPUs. The assembler is
- 105 built into MathRider and it can be run by pressing **<shift><enter>** inside
- of a **%uasm65** fold (which must be placed into a file which has a .mrw
- 107 **extension**).
- 108 The syntax that Example 1 contains is the syntax that the uasm65 assembler
- 109 understands. The empty space to the left of these commands is
- 110 **important too** and it can be created either with the **space bar** or with the
- 111 **tab kev**. Empty space like this is called **whitespace** and ASCII characters
- that produce whitespace when printed are called **whitespace characters**.
- 113 The complete set of ASCII whitespace characters include the space, tab,
- 114 newline, form feed, and carriage return characters."
- 115 Pat looked at the source code then said "I know that lda, adc, sta, and brk
- are 6502 instruction mnemonics, but what are **org** and **end?**"
- 117 "Those are called **pseudo ops** (which is short for pseudo operations) and
- another name for them is **assembler directives**. They are designed to look
- 119 like instruction mnemonics, but instead of being instructions for a CPU,

- 120 they are instructions which are meant for the assembler. Assembler
- 121 directives allow a programmer to tell the assembler how to assemble the
- 122 program.
- 123 For example, the **org** directive stands for **originate** and it tells the
- assembler what the beginning address of the code that follows it should be.
- 125 In this case, the code will be placed into memory starting at address 0200
- 126 hex."
- 127 "Does the **end** directive tell the assembler where the end of the source code
- 128 is?" asked Pat.
- 129 "Yes." I replied "There are 8 directives that uasm65 uses and we will be
- 130 discussing them as we go. "
- 131 I then placed the cursor inside of the **%uasm65** fold and pressed
- 132 <shift><enter> . Here is a copy of the %uasm65 fold and the output it
- 133 generated:

```
1:%uasm65,description="Example 1"
134
135
      2:
             org 0200h
136
      3:
137
      4:
             lda #10d
138
      5:
             adc #5d
             sta 0208h
139
      6:
140
      7:
             brk
141
      8:
      9:
142
             end
143
     10:%/uasm65
144
     11:
145
     12:
             %output ,preserve="false"
               *** List file ***
146
     13:
147
     14:
148
     15:
               0200
                                           org 0200h
                                000001 |
     16:
149
                                000002
150
               0200 A9 0A
                                000003 İ
                                           lda #10d
     17:
                                           adc #5d
151
               0202 69 05
                                000004
     18:
               0204 8D 08 02
152
     19:
                                000005 I
                                           sta 0208h
153
               0207 00
                                000006
                                           brk
     20:
154
     21:
                                000007
155
     22:
                                000008
                                           end
156
     23:
               *** Executable code ***
157
     24:
158
     25:
159
               %s19,descrption="Execute this fold to send program to U6502 monitor."
     26:
160
                 S007000055415347C8
     27:
```

	v2.05	6502 Assembly Language	8/68
161 162 163 164	28: 29: 30: 31:	\$10B0200A90A69058D0802003A \$9030000FC %/s19 %/output	
165 166 167	under t	ed at the output and said "The .lst file that was gene he title which reads '*** List file ***' and the s19 fi old which is under the title '*** Executable code **	ile is present in a
168 169 170 171 172	ASCII-b text edi languag	ssemblers generate machine language files which a based files like s19 files are and therefore they cannot tor. One reason the uasm65 assembler encodes its ge in ASCII is so that it is easy for humans to read as is so its code can be sent to a microcontroller easier	ot be opened in a machine nd another
173	Pat stud	died the s19 code that was generated:	
174 175 176		955415347C8 9A90A69058D0802003A 9FC	
177	"It look	s like machine language all right." said Pat "What de	oes it all mean?"
178 179 180	S19 file	les consist of what are called S records ," I said "and contains a separate S record. It will be easier to exts of the s19 file if we look at the lst file first." (see	xplain the

Figure 2



- 181 "The original source code is shown to the right along with the source code's
- 182 line numbers." I said. "The machine language codes that each line of source
- 183 code translate into are shown to the left. Notice that the **org** directive
- 184 caused this program to be assembled starting at address 0200 hex.
- Now, look at the machine language codes, which are A9 0A 69 05 8D 08 02
- and 00. Can you see these numbers in the s19 file?"
- 187 Pat studied both files then said " I see them!"
- 188 "Where?" I asked.
- 189 "Right here!" said Pat "And I also found their starting address." Then Pat
- 190 edited the s19 file and put spaces between the machine language codes so I
- 191 could see them easier:
- 192 S007000055415347C8
- 193 S10B 0200 A9 0A 69 05 8D 08 02 00 3A
- 194 S9030000FC
- 195
- 196 "Very good, Pat!" I said. "The purpose of the S19 file format is to allow
- 197 assembled and compiled programs to be sent to small computer systems
- 198 and microcontrollers. The emulator we have been using is also able to
- accept s19 files and our next step is to send this program to the emulator so

- 200 that it can be executed. S19 files contain more detail than we have covered,
- 201 but we will not discuss these details at this time."

202 **Sending An S19 File To The Emulator**

- 203 I opened the U6502 emulator and had it display the help screen by sending
- 204 it a question mark character:

```
205
     ?
206
     Assemble
                     A start address
                     B (+,-,\overline{?}) address
207
     Breakpoint
208
     Dump
                     D [start_address [end address]]
209
                     E address list
     Enter
                     F start address end address list
210
     Fill
                     G [start address]
211
     Go
                     H or ?
212
     Help
213
     Load
214
     Move
                     M start address end address destination address
                     R [PC,A\overline{C},XR,YR,SP,S\overline{R}]
215
     Register
                     S start address end address list
216
     Search
217
     Trace
                     T [start address [value]]
218
     Unassemble
                     U [start address [end address]]
```

- 219 "The command that tells the umon65 monitor to accept a s19 file is the
- 220 **Load** command and this is what the manual says about it." I opened the
- 221 umon65 manual in a text editor and located the section on the Load
- 222 command:
- 223 LOAD COMMAND
- 224 SYNTAX: L
- 225 DESCRIPTION: The purpose of the Load command is to put the monitor into
- 226 a mode that will receive an ASCII-based S19 format file, convert it into
- 227 binary, and place it into memory as directed by the address information
- 228 in the S19 file. After the Load command has been issued, the monitor will
- 229 enter load mode and wait until the file starts arriving through the serial
- 230 connection. The file will be placed into memory one byte at a time as it
- 231 is received and the last byte of the S19 file will place the monitor back
- 232 into command mode.
- 233 "Before I load the program, I will check the area of memory near address
- 234 0200 hex to see what is there." I executed a Dump command and here is
- 235 what it displayed:

```
236
     -d 0200
           237
     0200
238
     "This area of memory has zeros in it and this will make it easier to see the
     program after it is loaded." I said. "When a %s19 fold is executed by
239
240
     pressing <shift><enter> inside of it, the emulator is automatically
241
     placed into Load mode and the code inside of the fold is loaded into
242
     the emulator." This is what was displayed in the monitor after the %s19
243
     fold was executed:
244
     UMON65V1.15 - Understandable Monitor for the 6500 series microprocessors.
245
     PgmCntr(PC) Accum(AC)
                           XReg(XR)
                                     YReg(YR)
                                              StkPtr(SP) NV-BDIZC(SR)
246
       E02C
                   00
                              16
                                       00
                                                FD
                                                         0000000
247
     -L
248
     S007000055415347C8
249
     S10B0200A90A69058D0802003A
250
     S9030000FC
251
     Send S records when you are ready...
252
     S0S1S9
253
     S records successfully loaded (press <enter> if no cursor is shown).
254
255
     "The monitor will display a message that says 'S records successfully
     loaded' after the file has been received." I said.
256
257
     "Is the program in the emulator's memory now?" asked Pat.
     "Yes it is and I will let you verify this." I replied.
258
259
     Pat then executed a Dump command followed by an Unassemble command
     in order to verify that the program was successfully loaded:
260
     -d 0200
261
262
     0200 A9 0A 69 05 8D 08 02 00 - 00 00 00 00 00 00 00 .i......
263
     -u 0200
```

	v2.05	6502 Assembly Language	12/68			
264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280	0200 A9 0A 0202 69 05 0204 8D 08 02 0207 00 0208 00 0209 00 020A 00 020B 00 020C 00 020D 00 020E 00 020F 00 0211 00 0212 00 0213 00 0214 00	LDA #0Ah ADC #05h STA 0208h BRK				
281 282		eried Pat. "The program was successfully loade efinitely easier to work with than machine lang	5			
283 284 285	machine language is," I said "it is much easier to program in than machine					
286 287		w me a fairly large program that is written in a sked Pat. "I would like to see one."	ssembly			
288 289 290 291 292	"and its source code is included in the emulator's download archive file. The file is called umon65uasm and it is located in the examples/u6502/ directory (or examples\u6502\ on Windows systems). The manual for the					
293 294	Pat opened the umon65.uasm file in the text editor and looked at it. You should look at this program now too.					
295 296	After a while Pat said "Wow, the monitor program is almost 4000 lines long!"					
297 298 299	After studying the program for a while, though, Pat's excitement level drained away. Eventually Pat said "It certainly looks complicated and confusing. I don't think I'll ever be able to understand how it all works."					

The Professor And Pat series (professorandpat.org)

I looked at Pat and said "My grandfather came from Hungary and he told

300

- 301 me that the Hungarians have the following saying: 'All beginnings are
- 302 tough.' Over time, I have found this saying to be true and it has often given
- 303 me the courage to push past difficult beginnings to reach the easier parts
- 304 that lie beyond. If you continue to put forth the same level of effort you
- 305 have exerted thus far towards learning these concepts, the day will come
- 306 when you look at this monitor program and not one part of it will remain a
- 307 mystery to you."
- 308 I paused to let these words sink in, then I continued. "Another great saying
- 309 is 'What humans have done, humans can do.' What do you think this saying
- 310 means?"
- 311 Pat thought about the saying for a while then said "I think it means that if
- 312 somebody has already done something, this proves that the something can
- 313 be done and that other people should be able to do it too."
- 314 "Very good, Pat." I said. "In life, you are going to encounter concepts that
- 315 appear beyond your grasp and problems that seem beyond your ability to
- 316 solve them. The message that this saying relays is that most things that
- 317 humans have already done, even very difficult things, you can do to if you
- 318 want it bad enough and are willing to work hard achieve it."
- 319 We sat guietly for a few moments then Pat looked at me and said "I really
- 320 like learning about computers and I want to know everything there is to
- 321 know about them. There are millions of computers in the world and so
- 322 there must be a lot of people who understand them very well. If these
- 323 people were able to figure out how computers work, then I can too!"
- 324 "That is the right attitude to have, Pat!" I said.
- 325 "Anyway," said Pat "now that I know I am learning how computers work
- 326 from a genuine Martian, I am hoping that some of that Martian know-how
- 327 will rub off on me!"
- 328 I gave Pat a questioning look.
- 329 "I didn't know you were Hungarian, Professor. Why didn't you tell me
- 330 before?"
- 331 I smiled and said "There are a great many things that I have not told you
- yet, Pat, but each one is awaiting the right time and place to be passed
- 333 along. You will just have to be patient."

- Pat laughed and said "Okay professor, I'll be patient, but can you at least
- 335 tell me what we will be learning next?"
- 336 "Every particle in the physical universe is constantly moving through space
- and time," I said "and while we have been discussing assemblers, the right
- 338 time for me to tell you about variables has been quickly approaching." I
- 339 looked down at my watch then said "And the time has arrived... right...
- 340 now!"
- 341 Models
- 342 I looked at Pat and said "Before we discuss variables, we need to discuss
- 343 the reason that computers were invented in the first place. In order to
- 344 understand why computers were invented, one must first understand what a
- 345 **model** is."
- 346 "Do you mean like a plastic model car?" Asked Pat.
- "Yes," I replied "a scaled-down plastic model car is one example of a model."
- 348 "What does scaled-down mean?" asked Pat.
- 349 "When a scaled-down version of an object is made," I replied "it means that
- a smaller copy of the object is created, with each of the dimensions of all of
- 351 its parts being shrunken by the same amount. For example, if a scaled-
- down car was 50 times smaller than a given full-size car, then all of the
- 353 parts in the scaled-down car would be 50 times smaller than their analogous
- 354 parts in the full-size car."
- 355 "I have never seen a model car that contained small working copies of all of
- 356 the parts of a real car." Pat said.
- 357 "Why do you think that is?" I asked.
- 358 Pat thought about this question for a while then said "Because it would be
- 359 very difficult to create small working copies of all of the parts in a real car.
- 360 I suppose it could be done, but it would be very expensive."
- 361 "I agree, and this is why **models** are usually used to represent objects
- instead of either scaled or unscaled exact copies of the objects. A **model** is
- 363 a simplified representation of an object that only copies some of its

- 364 attributes. Examples of typical object attributes include weight, height,
- 365 strength, and color.
- 366 The attributes that are selected for copying are chosen for a given purpose.
- 367 The more attributes that are represented in the model, the more expensive
- 368 the model is to make. Therefore, only those attributes that are absolutely
- 369 needed to achieve a given purpose are usually represented in a model. The
- 370 process of selecting a only some of an object's attributes when developing a
- 371 model of it is called **abstraction**."
- 372 "I am not quite following you." said Pat.
- 373 I paused for a few moments then said "Suppose we wanted to build a
- 374 garage that could hold 2 cars along with a workbench, a set of storage
- 375 shelves, and a riding lawn mower. Assuming that the garage will have an
- adequate ceiling height, and that we do not want to build the garage any
- 377 larger than it needs to be for our stated purpose, how could an adequate
- 378 length and width be determined for the garage?"
- 379 Pat thought about this question for a while then said "I'm not sure."
- 380 "One strategy for determining the size of the garage," I said "is to build
- 381 perhaps 10 garages of various sizes in a large field. When the garages are
- 382 finished, take 2 cars to the field along with a workbench, a set of storage
- 383 shelves, and a riding lawn mower. Then, place these items into each garage
- 384 in turn to see which is the smallest one that these items will fit into without
- 385 being too cramped. The test garages in the field can then be discarded and
- 386 a garage which is the same size as the one that was chosen could be built at
- 387 the desired location."
- 388 "Thats ridiculous!" cried Pat. "11 garages would need to be built using this
- 389 strategy instead of just one. This would be very inefficient."
- 390 "Can you think of a way to solve the problem less expensively by using a
- 391 model of the garage and models of the items that will be placed inside it?" I
- 392 asked.
- 393 "I think I am beginning to see how to do this." replied Pat. "Since we only
- 394 want to determine the dimensions of the garage's floor, we can make a
- 395 scaled down model of just its floor, maybe using a piece of paper."
- 396 "Go on." I said.

- 397 "Each of the items that will be placed into the garage could also be
- 398 represented by scaled-down pieces of paper. Then, the pieces of paper that
- 399 represent the items can be placed on top of the the large piece of paper that
- 400 represents the floor and these smaller pieces of paper can be moved around
- 401 to see how they fit. If the items are too cramped, a larger piece of paper
- 402 can be cut to represent the floor and, if the items have too much room, a
- 403 smaller piece of paper for the floor can be cut.
- When a good fit is found, the length and width of the piece of paper that
- 405 represents the floor can be measured and then these measurements can be
- 406 scaled up to the units used for the full-size garage. With this method, only a
- 407 few pieces of paper are needed to solve the problem instead of 10 full-size
- 408 garages that will later be discarded."
- 409 "Very good Pat!" I said. "And what makes these pieces of paper models of
- 410 the full-size objects they represent and not exact scaled-down copies of
- 411 them?"
- 412 Pat thought about this then replied "The only attributes of the full-sized
- 413 objects that were copied to the pieces of paper were the object's length and
- 414 width."
- 415 "What is the process called when only some of an object's attributes are
- 416 placed into a model instead of all of them?" I asked.
- 417 "Abstraction!" replied Pat.

418 Placing Models Into A Computer

- 419 "Now that we have discussed what a model is Pat," I said "you may find it
- 420 interesting to know that the reason one of the first modern programmable
- 421 digital computer was invented was to model the paths of artillery
- 422 projectiles."
- 423 "Really!?" asked Pat. "When was this computer invented and who invented
- 424 it?"
- 425 "The computer was invented in the 1940s by John Mauchly and J. Presper
- 426 Eckert," I replied "and it was called ENIAC. John Von Neumann later joined
- 427 the team that built ENIAC to help them create a second computer called
- 428 EDVAC."

- 429 "Back to Martians again!" cried Pat. "And if John Von Neumann is involved,
- 430 I bet that the Von Neumann architecture can't be far behind!" said Pat.
- 431 I smiled and said "You are very perceptive!"
- 432 "So, ENIAC was used to model the paths of artillery projectiles?" asked Pat.
- 433 "Yes." I replied.
- 434 "I can see how paper can be used to model things," said Pat "but how can a
- 435 computer be used to model things?"
- 436 "Do you remember earlier when I had you think of any idea and then I came
- 437 up with a number that could be placed into a memory location to represent
- 438 it?" I said.
- 439 "I remember," said Pat "I thought of the idea of a boat and the idea of a
- 440 cat."
- 441 "The numbers that I came up with to represent the boat and the cat were
- really just patterns of bits in memory," I said "and these bit patterns were
- 443 very simple models of each of these objects. Any attributes of any object
- 444 can be represented by bit patterns. If the bit patterns are contained within
- 445 a computer's memory, then the computer contains a model of the object."
- 446 Pat's mouth dropped open with surprise.
- 447 "Does this mean that instead of using paper to model the garage floor and
- 448 the items, we could have used bit patterns to model them and then placed
- 449 these bit patterns into a computer?" asked Pat.
- 450 "This is exactly what it means!" I replied. "The length and width values of
- 451 the items could have been used to model them and the length and width
- 452 values of the garage floor could have been used to model the garage'."
- 453 "But how can one keep track of all of these modeled values in a program?"
- 454 asked Pat. "It seems that it would be very easy to become confused about
- 455 which values belonged to which part of each model."
- 456 "It would be confusing if the programmer needed to keep track of every
- 457 address where a value was stored" I replied "and this is why variables were

458 invented."

459 Variables

- 460 "A **variable** allows a programmer to use a **letter** or a **name** instead of an
- **address** to refer to information that is being represented by memory
- 462 locations." I said. "Almost all computer languages that are higher than
- 463 machine language have the ability to use variables."
- 464 "Does this mean that assembly language has the ability to use variables?"
- 465 asked Pat.
- 466 "Yes," I replied "and this is one of the reasons that assembly language is
- 467 more powerful than machine language."
- 468 "Can you show me an example of a variable in assembly language?" asked
- 469 Pat. "I want to see what one looks like."
- 470 "Yes," I replied "but first you need to tell me what you want the variable to
- 471 model."
- 472 "How about modeling the garage floor we have been working with?" asked
- 473 Pat.
- 474 "That is an excellent idea," I said. "but we will need 2 variables to model
- 475 the floor, one to represent its length and one to represent its width."
- 476 I brought up an editor and typed in an assembly language program that had
- 477 2 variables in it. Then, I assembled the program and brought up the
- 478 following .LST file that was generated into the text editor:

0200				000001	org 0200h
				000002	
0200	AD	11	02	000003	lda garage_width
0203	69	01		000004	adc #1d
0205	8D	11	02	000005	sta garage_width
				000006	
0208	AD	12	02	000007	lda garage_length
020B	69	01		800000	adc #1d
020D	8D	12	02	000009	sta garage_length
0210	00			000010	brk
				000011	
0211	09			000012	garage_width dbt 9d
0212	80			000013	garage_length dbt 8d
				000014	
	0200 0203 0205 0208 020B 020D 0210	0200 AD 0203 69 0205 8D 0208 AD 020B 69 020D 8D 0210 00	0200 AD 11 0203 69 01 0205 8D 11 0208 AD 12 0208 69 01 020D 8D 12 0210 00	0200 AD 11 02 0203 69 01 0205 8D 11 02 0208 AD 12 02 0208 69 01 020D 8D 12 02 0210 00	0200 AD 11 02 000003 0203 69 01 000004 0205 8D 11 02 000005 000006 0208 AD 12 02 000007 020B 69 01 000008 020D 8D 12 02 000009 0210 00 000010 0211 09 000012 0212 08 000003

The Professor And Pat series (professorandpat.org)

493

end

000015 |

19/68

494 495 496 497 498 499 500 501 502	While Pat studied the .LST file, I explained how the variables worked. "In this program, a variable called <code>garage_width</code> has been created to hold the width of the garage floor and another variable called <code>garage_length</code> has been created to hold its length. The <code>garage_width</code> variable has been set or <code>initialized</code> to <code>9</code> decimal and the address it has been bound to is 0211h. The <code>garage_length</code> variable has been initialized to <code>8</code> decimal and the address it has been bound to is 0212h. The measurement units that each of these variables are working with is meters. The <code>dbt</code> directive (which stands for <code>Define Byte</code>) is used to create byte-sized variables with this assembler."
503 504 505	"I see that the name garage_width and garage_length have been associated with the addresses 0211h and 0212h," said Pat "but why are these names called variables?"
506 507 508	"Look at the 3 assembly language instructions that have been placed into memory starting at address 0200h and tell me what you think they will do when they are executed." I replied.
509 510 511 512 513 514	Pat studied the instructions then said "The LDA instruction at address 0200h looks like it is copying the 9 that the variable garage_width refers to into register 'A' . The ADC instruction is adding 1 to the 9 and this should result in a 10 decimal being placed into the 'A' register. The STA instruction is then copying the 10 decimal which is in the 'A' register back into memory at the address that garage_width refers to.
515 516 517	Overall, it looks like the result of executing these 3 instructions is to increase the contents of the ${\bf garage_width}$ variable from ${\bf 9}$ to ${\bf 10}$. I am only guessing, though, so I am not completely sure about this."
518	"How can you test your guess?" I asked.
519 520	"I suppose I could load this program into the emulator and trace through these 3 instructions to see what happens." replied Pat.
521 522 523	"That sounds like a good idea Pat." I said. "Load the program into the emulator and then execute a $d\ 0200\ 021f$ command followed by a $u\ 0200$ command then I will help you step through the program."
524	Pat loaded the program and executed the two commands. This is what was

displayed on the screen:

525

- 526 -d 0200 021f 0200 AD 11 02 69 01 8D 11 02 - AD 12 02 69 01 8D 12 02 ...i....i... 527 528 -u 0200 529 AD 11 02 LDA 0211h 530 0200 0203 69 01 ADC #01h 531 532 0205 8D 11 02 STA 0211h 533 0208 AD 12 02 LDA 0212h 534 020B 69 01 ADC #01h 8D 12 02 STA 0212h 535 020D BRK 536 0210 00 ORA #08h 09 08 537 0211 538 0213 00 **BRK** 539 0214 00 **BRK** I said "Look at the contents of memory locations 0211h and 0212h, Pat, and 540 541 tell me what they contain." Pat looked at the contents of these locations then replied "Memory location 542 543 0211h contains a **9** and memory location 0212h contains an **8**! These 544 numbers are what we put into the garage width and the garage length 545 variables!" 546 "That is right," I said "now I want you to look at address 0211h in the output 547 from the Unassemble command and tell me what you see." 548 "The 9 and 8 are still in memory locations 0211h and 0212h," said Pat "but 549 why is the ORA instruction there?"

"Think about it and see if you can figure it out." I replied.

- Pat quietly looked at the screen for a while then said "Oh, I get it! The
- Unassemble command doesn't know that the **9** and the **8** are variables and
- 553 so it interpreted them as an ORA instruction."
- "Correct!" I said. "The Unassemble command can only interpret numbers in
- 555 memory as assembly language instructions because this is the only **context**
- 556 it knows. What do you think is providing the **context** for these two memory
- 557 locations, Pat?"

550

```
The garage floor that is being modeled by the garage_width and
```

- 559 **garage_length** variables." replied Pat after a few moments of thought.
- 560 "Now Pat, you are going to see for yourself why variables are called
- 561 variables." I said. "Execute a Register command and then trace the LDA
- instruction that is at address 0200h."
- 563 Pat did this and here is what was displayed:
- 564 r

```
565 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 566 102C 00 FC 00 FD 00010110
```

567 -t **0200**

- 570 0203 69 01 ADC #01h
- 571 "Was the **9** from the **garage width** variable loaded into the 'A' register?" I
- 572 asked.
- 573 "Yes." replied Pat.
- 574 "Then execute another Trace command," I said "and verify that the ADC
- instruction increases the **9** by **1** then places the resulting **0A** hex into the 'A'
- 576 register."
- Pat executed the Trace command and verified that **0A** hex was placed into
- 578 the 'A' register:
- 579 -t

```
580 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 581 0205 0A FC 00 FD 00010100
```

- 582 0205 8D 11 02 STA 0211h
- 583 "Dump address 0211h to verify that the **9** that we placed into the
- 584 **garage width** variable is still there." I said. Pat executed the Dump
- 585 command and here was the result:

22/68

-d 0211 586 587 0211 09 08 00 00 00 00 00 - 00 00 00 00 00 00 00 588 "Finally," I said "execute the STA instruction with the Trace command then 589 verify that the **garage width** variable was changed from **9** to **0A** hex." Pat 590 executed a Trace command followed by a Dump command and here was the 591 result: 592 -t 593 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 594 0208 ΘA FC 00 FD 00010100 595 0208 AD 12 02 LDA 0212h -d 0211 596 597 "The **garage width** variable was changed from a **9** to a **0A** hex!" exclaimed 598 599 Pat "My guess was right!" 600 "Yes, your guess was correct Pat," I said "and why are variables called 601 variables?" 602 "Because the information they refer to can change!" replied Pat. 603 "Very good, Pat!" I said. "Variables need to change because the models that 604 they are a part of need to change in order to be of maximum use. 605 Here are some final thoughts on variables. Their names need to consist of 606 ASCII characters from 33 decimal through 122 decimal. The one exception 607 to this is that variable names cannot contain a semi-colon with is an ASCII 608 59 decimal. Variables also need to be placed up against the left side

610 **The Status Register**

609

- Pat studied the output from the trace command for a while then said "I
- 612 think I understand what variables are now, and I understand what most of

of the editor window with no spaces or tabs to the left of them.

- 613 the registers do, but what does the SR register do?" Pat pointed to the part
- of the Trace command's output that contained the letters NV-BDIZC(SR).

- 615 "I was wondering when you would ask about those letters." I replied. "SR
- 616 stands for **Status Register** and the bits in this register indicate the current
- 617 state or status of the CPU. These bits are called status flags or **flags** for
- 618 short and, as instructions are executed, certain instructions set or clear
- 619 these flags. **Setting** a flag turns it into a **1** and **clearing** a flag turns it into
- 620 a **0**. When the contents of the status register are displayed, the string of
- bits which are shown directly beneath the letters NV-BDIZC indicate the
- 622 current state of each flag.
- Perhaps the easiest flag to understand is the **zero flag** and therefore we
- 624 will begin with it. The zero flag is represented by a capital letter Z and it is
- affected by about half of the 6502's instructions. When any of these
- 626 instructions results in a 0 being calculated after it is executed, then the Z
- 627 flag is **set**. If these instructions result in a nonzero value being calculated
- after execution, then the Z flag is **cleared**. The complete list of which
- 629 instructions affect which flags is shown in the instruction set reference for
- 630 the 6502."
- 631 I then brought up a web page that contained a 6502 instruction set
- 632 reference and Pat looked at it. A 6502 instruction set reference can also be
- 633 found in Appendix A in this document.
- "One of the instructions that affects the Z flag is the DEX instruction. DEX
- 635 stands for DEcrement X and it takes the contents of the X register and
- 636 subtracts 1 from it. If the X register contained a 3, the DEX instruction
- 637 would change it to a 2, and if it contained a 2, it would change it to a 1. In
- 638 both cases, the Z flag would be set to 0 to indicate that the execution of the
- 639 instruction did not result in a 0.
- 640 If we executed the DEX instruction one more time, however, the contents of
- 641 the X register would go from 01 hex to 00 hex and the Z flag would be set to
- 642 a 1 to indicate this. I will now enter a short program into the emulator that
- 643 demonstrates what happens to the Z flag as the X register is decremented
- 644 from 3 to 0 using the DEX instruction and you can trace it." I then entered
- 645 the following short program into the emulator using the Assemble command
- 646 and Pat traced through it:
- 647 0200 A2 03 LDX #03h
- 648 0202 CA DEX
- 649 0203 CA DEX
- 650 0204 CA DEX

	<u> </u>	Λ	$\overline{}$
V	1.	u	. ``

6502 Assembly Language

24/68

```
651
      0205
                      BRK
            00
652
      - r
653
      PgmCntr(PC)
                   Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                    StkPtr(SP)
                                                                NV-BDIZC(SR)
                      00
                                  FC
                                            00
                                                                00010110
654
         102C
                                                       FD
655
      -t 0200
      PgmCntr(PC)
                   Accum(AC)
                                                    StkPtr(SP)
                                                                NV-BDIZC(SR)
656
                               XReg(XR)
                                         YReg(YR)
657
         0202
                      00
                                  03
                                            00
                                                       FD
                                                                00010100
658
      0202 CA
                      DEX
659
      -t
      PgmCntr(PC)
660
                   Accum(AC)
                               XReq(XR)
                                         YReg(YR)
                                                    StkPtr(SP)
                                                                NV-BDIZC(SR)
                                  02
                                            00
                                                       FD
661
         0203
                      00
                                                                00010100
662
      0203 CA
                      DEX
663
      -t
      PgmCntr(PC)
664
                   Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                    StkPtr(SP)
                                                                NV-BDIZC(SR)
         0204
                                            00
                                                       FD
                                                                00010100
665
                      00
                                  01
      0204 CA
                      DEX
666
667
      -t
668
      PgmCntr(PC)
                   Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                    StkPtr(SP)
                                                                NV-BDIZC(SR)
669
         0205
                       00
                                  00
                                            00
                                                       FD
                                                                00010110
670
      0205
            00
                      BRK
671
      "Notice how the Z flag was set to 0 after the execution of each DEX
      instruction that resulted in a nonzero value," I said "but it was set to 1 as
672
      soon as the X register was decremented to 0."
673
674
      "I see!" said Pat. "You know, those status register flags must have been
675
      changing all the time we have been tracing through programs in the
      emulator, but I never noticed it. Its funny how you can be looking at
676
      something, even for a long time, but not actually see it."
677
678
      "Much of life is like that, Pat." I said. "Amazing and wonderful things lay
      spread before us in open sight, but we are blind to them for want of
679
```

- 680 awareness. Some say that striving for awareness is one of the noblest goals
- that a person can pursue".
- "The goal may be noble," said Pat "but it is definitely not easy to achieve!
- Anyway, I can see how the zero flag works now, but I don't understand what
- 684 it is used for."

685 How A Computer Makes Decisions

- 686 "A CPU's status flags are very subtle but absolutely critical, Pat." I said.
- 687 "Without its status flags, a CPU would be unable to make decisions, and a
- 688 computer that can not make decisions is virtually useless."
- 689 "If computers can't actually think," said Pat "how can they make decisions?"
- 690 "The way that a CPU makes decisions," I replied "is by deciding to either
- 691 execute a section of code or skip it and execute another section of code
- 692 instead."
- 693 "How can a CPU skip a section of code?" asked Pat.
- 694 I replied "As we discussed earlier, a CPU determines where in memory to
- 695 find the next instruction it is going to execute by looking at the contents of
- 696 the Program Counter register. Normally, after the current instruction is
- 697 finished executing, the Program Counter is set to the address of the
- 698 instruction that immediately follows it in memory. However, if the Program
- 699 Counter was not set to the address of the next instruction in memory, but
- 700 rather to the address of an instruction in a different part of memory, then
- 701 the code that was going to be run would be skipped."
- 702 "Can this be done?" asked Pat. "Can the Program Counter be set to a
- 703 different address than that of the next instruction which would normally
- 704 have been executed?"
- 705 "Yes." I said.
- 706 "How?" asked Pat.
- 707 "With the IMP instruction, the Branch instructions, and with a few other
- 708 instructions." I replied. "I will show you some examples of how the JMP and
- 709 the Branch instructions work and the first example will show how the JMP
- 710 instruction can be used to skip over another instruction."

```
711 The JMP Instruction
```

- 712 I brought up the emulator, entered the following program using the
- 713 Assemble command, and then had Pat trace through it:

```
714
      0200
            A9 01
                       LDA #01h
      0202
            4C 07 02
715
                       JMP 0207h
716
      0205
            A2 02
                       LDX #02h
717
            A0 03
                       LDY #03h
      0207
718
      0209
            EΑ
                       NOP
719
      020A
            00
                       BRK
720
      . . .
```

- 721 "As you trace through this program Pat," I said "pay close attention to the
- value of the Program Counter. Tell me what happens to the Program
- 723 Counter when the JMP instruction is executed."
- 724 r
- 725 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 726 102C 00 FC 00 FD 00010110
- 727 -t 0200
- 728 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 729 0202 01 FC 00 FD 00010100
- 730 0202 4C 07 02 JMP 0207h
- 731 -t
- 732 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 733 0207 01 FC 00 FD 00010100
- 734 0207 A0 03 LDY #03h
- 735 -t
- 736 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 737 0209 01 FC 03 FD 00010100
- 738 **0209** EA NOP
- 739 -t
- 740 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 741 020A 01 FC 03 FD 00010100
- 742 020A 00 BRK

- 743 "The Program Counter jumps from 0202h all the way to 0207h. When it did
- 744 this, it skipped the LDX instruction." Pat said. "But how did you know that
- 745 address 0207h was the address of the instruction that you wanted to jump
- 746 to?"
- 747 "I knew that 0207h was the address I needed to pass to the JMP instruction
- 748 because the JMP instruction is 3 bytes long and the next instruction after
- 749 the JMP instruction is 2 bytes long. The JMP instruction was placed in
- 750 memory starting at 0202h and 0202h + 3 + 2 = 0207h."
- 751 "But what if you wanted to jump over a bunch of instructions?" asked Pat.
- 752 "It would be tough to determine the lengths of all of these instructions,
- 753 especially if you have not assembled them yet."
- 754 "You are right, Pat, and this is why assemblers allow a person to use
- 755 something called **Labels** instead of addresses." I replied.

756 Labels

- 757 "Labels are names that can be used in the source code of an assembly
- 758 language program to represent an address of an instruction. Labels, just
- 759 like variables, are replaced with the addresses they represent during the
- 760 assembly process. They make coding the program much easier for the
- 761 programmer, however, because they remove the need for the programmer
- 762 to keep track of the instruction's addresses. I will now create an assembly
- 763 language program that uses labels and jump instructions so you can see
- 764 how they work together." I then created and assembled the following
- 765 program:

766	0200				000001	1	org	0200h
767					000002	İ	_	
768	0200	Α9	01		000003	İ	lda	#01d
769	0202	4C	07	02	000004	İ	jmp	skip1
770					000005	İ		_
771	0205	Α9	02		000006	İ	lda	#02d
772					000007	İ		
773	0207	Α9	03		800000	skip1	lda	#03d
774	0209	4 C	ΘE	02	000009	İ	jmp	skip2
775					000010	İ		
776	020C	Α9	04		000011	İ	lda	#04d
777					000012	İ		
778	020E	00			000013	skip2	brk	
779					000014	Ī		
780					000015		end	

The Professor And Pat series (professorandpat.org)

811

812

781 000016 | 782 "In this listing, you can see how the label **skip1** is bound to address 0207h and the label **skip2** is bound to address 020Eh. A programmer is free to 783 784 place labels on any instruction they want to, but the characters in each each 785 label's name must be taken from the same range of ASCII characters that variable names do. Labels must also be placed against the left side of 786 787 the editor windows with no spaces or tabs on their left sides." 788 Forward Branches And The Zero Flag 789 "I understand now how JMP is able to skip over instructions," said Pat "but 790 since it always jumps when it is executed, then it can't be used for making a 791 decision, can it?" 792 "No Pat," I replied "the JMP instruction will always jump to another location 793 in memory without exception so it can not be used to make a decision. The 794 assembly language instructions that are designed to make decisions are the 795 **branch** instructions." I then wrote all of the 6502's branch instructions on 796 the whiteboard: 797 BCC - Branch on Carry Clear. 798 BCS - Branch on Carry Set. 799 BEQ - Branch on result EQual. BNE - Branch on result Not Equal. 800 801 BMI - Branch on result MInus. 802 BPL - Branch on result PLus. BVC - Branch on oVerflow Clear. 803 804 BVS - Branch on oVerflow Set. 805 "Hev!" cried Pat "Some of these instructions are related to flags in the 806 Status Register." 807 "Actually, all of them are." I said. BCC and BCS are related to the **Carry** 808 flag, BEQ and BNE are related to the **Zero** flag, BMI and BPL are related to 809 the Negative flag, and BVC and BVS are related to the **oVerflow** flag." 810 "How are they related?" asked Pat.

"Each of these 4 flags determines whether or not the 2 instructions they are

associated with will take the branch or not." I replied.

- 813 "I still don't quite understand." said Pat.
- 814 "I think an example will make it clear." I said. "Lets start with the two
- 815 branch instructions which are associated with the Zero flag, which are BEQ
- and BNE. BEQ can be thought of in 2 ways. The first way means 'branch if
- 817 the result equaled zero'. For example, if a BEQ instruction were placed
- 818 directly beneath a DEX instruction, and the DEX instruction just
- 819 decremented register X to zero, then the BEQ instruction would take the
- 820 branch. If the DEX instruction resulted in register X containing a non-zero
- 821 value, then the BEQ instruction would not branch and execution would
- 822 continue with the instruction directly beneath BEQ.
- 823 The second way to think about the BEQ instruction is that it can be used to
- 824 determine if 2 values are equal when used in cooperation with another
- 825 instruction like CMP. The CMP instruction compares a value in the 'A'
- 826 register with a value in memory by **internally subtracting** the value in
- 827 memory from the value in the 'A' register. Internal subtraction means that
- 828 the result is discarded and not placed into a register. If the result of the
- 829 subtraction was 0 (meaning the values were equal) the Zero flag will be
- 830 **set** and if the result was non-zero (meaning the values were not equal), the
- 831 Zero flag will be **cleared**."
- 832 "Do the branch instructions usually need to work in cooperation with other
- 833 instructions?" asked Pat.
- 834 "Yes they do." I replied. "Certain instructions set or clear flags in the Status
- 835 register, and the branch instructions that look at the flags in question must
- 836 be placed near the instructions that affect the flags. There is not much use
- 837 in setting flags if nothing is going to look at them and conversely, there is
- 838 not much use in looking at flags if nothing purposefully set or cleared them.
- 839 I will now create a small assembly language program that will compare 2
- 840 numbers and branch if they are equal or not branch if they are not equal.
- 841 You can then load it into the emulator and trace through it to see what it
- 842 does."
- 843 First, I created the following program:

844 0200 000001 | org 0200h

τ7	つ		U	5
v	_	٠	v	J

6502 Assembly Language

30/68

0.45				000000	•
845				000002	
846	0200	Α9	02	000003	lda #02d
847	0202	С9	02	000004	cmp #02d
848	0204	F0	01	000005	beq Equal1
849				000006	
850	0206			000007	NotEqual1 *
851	0206	EΑ		000008	nop
852				000009	·
853	0207			000010	Equal1 *
854	0207	EΑ		000011	nop
855	0208	Α9	05	000012	lda #05d
856	020A	С9	06	000013	cmp #06d
857	020C	F0	02	000014	beq Equal2
858	020E	EΑ		000015	nop
859				000016	i '
860	020F			000017	NotEqual2 *
861	020F	EΑ		000018	nop
862				000019	<u>'</u>
863	0210			000020	Equal2 *
864				000021	•
865	0210	00		000022	brk
866				000023	end
867				000024	
					I

- Why are the labels on lines by themselves with asterisks instead on lines that have instructions?" asked Pat.
- 870 "This is an alternative way to put labels in a program." I replied "The
- asterisk is a symbol which means 'the address that the following instruction
- 872 will be placed at'. This technique allows the label names to be long without
- 873 pushing the instruction they are associated with too far to the right and out
- 874 of line with the other instructions. It also allows code to be inserted
- 875 immediately after the label easier."
- 876 "Okay." said Pat.
- 877 Pat then loaded the program into the emulator, unassembled it to make
- 878 sure it was loaded correctly, and then traced through it:

```
879
     -u 0200
088
     0200 A9 02
                     LDA #02h
     0202 C9 02
                     CMP #02h
881
     0204 F0 01
                     BEQ 0207h
882
883
     0206 EA
                     NOP
884
     0207
                     NOP
          EΑ
                     LDA #05h
885
     0208 A9 05
```

	v2.05	6502 As	31/68	
886 887 888 889 890 891	020A C9 06 020C F0 02 020E EA 020F EA 0210 00	CMP #06h BEQ 0210h NOP NOP BRK		
892	-t 0200			
893 894	PgmCntr(PC) 0202	Accum(AC) XReg(X	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDI Z C(SR) 000101 <mark>0</mark> 0
895	0202 C9 02	CMP #02h		
896	-t			
897 898	PgmCntr(PC) 0204	Accum(AC) XReg(X 02 FC	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDI Z C(SR) 000101 1 1
899	0204 F0 01	BEQ 0207h		
900	-t			
901 902	PgmCntr(PC) 0207	Accum(AC) XReg(X 02 FC	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDIZC(SR) 00010111
903	0207 EA	NOP		
904	-t			
905 906	PgmCntr(PC) 0208	Accum(AC) XReg(X 02 FC	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDIZC(SR) 00010111
907	0208 A9 05	LDA #05h		
908	-t			
909 910	PgmCntr(PC) 020A	Accum(AC) XReg(X 05 FC	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDI Z C(SR) 000101 <mark>0</mark> 1
911	020A C9 06	CMP #06h		
912	-t			
913 914	PgmCntr(PC) 020C	Accum(AC) XReg(X 05 FC	R) YReg(YR) StkPtr(SP) 00 FD	NV-BDI Z C(SR) 100101 <mark>0</mark> 0
915	020C F0 02	BEQ 0210h		

	\mathbf{r}		Λ	$\overline{}$
₹7	•		()	ה
v	_	٠	v	J

6502 Assembly Language

32/68

916 -t

917 918	PgmCntr(PC) 020E	Accum(AC) 05	XReg(XR) FC	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 10010100
919	020E EA	NOP				
920	-t					
921 922	PgmCntr(PC) 020F	Accum(AC) 05	XReg(XR) FC	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 10010100
923	020F EA	NOP				
924	-t					
925 926	PgmCntr(PC) 0210	Accum(AC) 05	XReg(XR) FC	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 10010100
927	0210 00	BRK				

- 928 "The first BEO instruction made the decision to branch and the second BEO
- 929 instruction made the decision not to branch!" said Pat.
- 930 "That is correct." I said. "Computers perform simple decisions using simple
- 931 branch instructions like this and complex decisions are built up by having 2
- 932 or more branch instructions work together as a team."
- 933 "That's kind of hard to believe." said Pat.
- 934 "It is indeed hard to believe Pat," I said "yet it is true. It takes a while, but
- 935 as you program more you will become comfortable with this concept."
- 936 "What about the BNE instruction?" asked Pat. "What does it do?"
- 937 "The BNE instruction is simply the opposite of the BEQ instruction," I said
- 938 "and it will branch when a result is non-zero and not branch when it is zero.
- 939 There are situations where BEQ is best to use and situations where BNE is
- 940 best and you will learn how to decide when to use each over time."
- 941 "I will have to take your word for it Professor," said Pat "because this all
- 942 still seems fuzzy to me."
- 943 "The more you work with it, the easier it will become." I replied. But now,

- 944 lets look at the program again to see how branch instruction know how far
- 945 ahead in memory to branch."
- 946 I then unassembled the program again:
- 947 -u 0200

```
0200 A9 02
948
                        LDA #02h
949
      0202
            C9 02
                        CMP #02h
950
           F0 01
                        BEQ 0207h
      0204
951
      0206
            EΑ
                        N<sub>O</sub>P
952
      0207
            EΑ
                        NOP
      0208
           A9 05
                        LDA #05h
953
           C9 06
                        CMP #06h
954
      020A
      020C F0 02
955
                        BEQ 0210h
                        N<sub>O</sub>P
956
      020E
            EΑ
957
      020F
            EΑ
                        NOP
      0210
                        BRK
958
            00
```

- 959 "What address is the first BEQ instruction set to branch to?" I asked.
- 960 "Address 207 hex." replied Pat.
- 961 "And what operand does the first BEQ instruction have?" I asked.
- 962 "01." Said Pat. "Hmmm, the address of the next instruction after the branch
- 963 is 206 hex and address 207 hex is 1 memory location away from it.
- 964 The second BEQ instruction has an operand of **02** and it is branching to
- address 210 hex. The address of the next instruction after the second BEO
- 966 is 20E and address 210 is 2 locations away from it. Does this mean that a
- 967 branch command's operand byte tells it how many locations to move ahead
- 968 in memory from the address of the next instruction after it?"
- 969 "Yes, Pat, and that was very good reasoning on your part." I said.
- 970 "How about branching backwards in memory to previous instructions?"
- 971 asked Pat "Can this be done too?"
- 972 "Yes, branches (and also jumps) can move the Program Counter to earlier
- 973 instructions that are lower in memory too," I said "and in fact, a computer
- 974 would be useless if it could not branch backwards in memory. Before we
- 975 discuss branching backwards in memory, however, we must first talk about
- 976 negative numbers."

977 **Negative Numbers And The Negative Flag**

- 978 "How many patterns can be formed by 4 bits, Pat?" I asked.
- 979 Pat thought about this for a few moments then said "2 to the 4th power is
- 980 16 so 16 patterns."
- 981 "If the bit pattern 0000 represents a decimal 0," I asked "what is the highest
- decimal numeral that 4 bits can represent?" 982
- 983 Pat said "Since the first of the 16 4-bit patterns needs to represent decimal
- 984 0, then there are only 15 patterns left to represent the decimal numerals 1
- 985 through 15. This means that the highest decimal numeral that 4 bits can
- 986 represent is 15."
- 987 "Very good Pat," I said "now write the binary numerals 0000 through 1111
- 988 on the whiteboard and place their decimal numeral equivalents next to
- 989 them." Pat then did this. (see Fig. 2)

990	Figure 2	Binary	D	ecimal	"So far we have been working with positive
991		0000	-	0	numbers," I said "but how do you think bit
992		0001	-	1	patterns can be made to represent negative
993		0010	-	2	numbers?" I asked?
		0011	-	3	
994		0100	-	4	Pat studied the numbers on the whiteboard
995		0101	-	5	then said "I'm not sure."
996		0110	-	6	"What do you think would happen," I asked "if
997		0111	-	7	we took the binary numeral 0000 and
998		1000	-	8	subtracted 1 from it?"
		1001	-	9	
999		1010	-	10	Pat thought about this for a while.
4000		1011	-	11	WT131
1000		1100	-	12	"I'll give you a hint," I said "think back to the
1001 1002		1101	-	13	odometer example we discussed earlier and imagine what would happen if we added 1 to
1002		1110	-	14	the bit pattern 1111."
1005		1111	-	15	the bit puttern 1111.

1004 "Well," said Pat "all the 1's in the bit pattern

1005 1111 would roll around to 0's if you added 1 to it so I suppose that if 1 was subtracted from the bit pattern 0000, then all the 0's would roll backwards 1006

to 1111." 1007

1008	Figure 3	Binary	De	ecimal	"Very good Pat." I said. "Now, I am going to
1008		1000	-	-8	make a modified version of the bit pattern table
1010		1001	-		you created by placing 0000 in the middle of
1011		1010	-	-6	the sequence instead of at the beginning.
1012		1011	-	-5	Then, instead of associating all positive decimal
1013		1100	-	-4	numerals with this sequence, I will associate
1014		1101	-	-3	the patterns after 0000 with positive decimal
1015		1110	-	-2	numerals and the patterns before it with
1016 1017		1111	-	-1	negative decimal numerals." I then did this. (see Fig. 3)
1017		0000	-	0	(see Fig. 5)
1018		0001	-	1	After Pat had some time to study the new table
1019		0010	-	2	I asked "Do you notice anything about the
1020		0011	-	3	positive bit patterns and the negative bit
1021		0100	-	4	patterns that can be used to tell them apart?"
1000		0101	-	5	
1022		0110	-	6	"Pat studied the table further then said "Not
1023		0111	-	7	really".

1024 I then erased the leftmost bits in the patterns before and after 0000 and 1025 redrew them with a red marker. "What do you notice now?" I asked.

1026	Figure 4	Binary	Decin	al "All the negative numbers have leftmost bits
1027		1000	8	that are set to 1 and all of the positive
1028		1001	7	numbers have leftmost bits that are set to 0!"
1029			-	said Pat.
		1010	6	
1030		1 011	5	"That is correct." I said. "When dealing with
1031		1 100	4	bit patterns of any size that represent signed
1032		1 101	3	numbers, the leftmost bit indicates whether a
1033		1 110	2	number is negative or not. A 1 in the leftmost
1034		<mark>1</mark> 111	1	bit position indicates that the number is
1035		0000	- 0	negative and a $oldsymbol{0}$ in the leftmost bit position
1036		0001	- 1	indicates that it is positive."
1005		0010	- 2	HII I I ODIII I
1037		0011	- 3	"How does the CPU know when a program is
1038		0100	_	dealing with a signed number or with an
1039			•	unsigned number?" asked Pat.
		0101	- 5	
1040		0 110	- 6	"The CPU does not really 'know' whether it is
1041		0111	- 7	dealing with a signed number or an unsigned

The Professor And Pat series (professorandpat.org)

```
1042
       number. It just executes the instructions it has been given. It is the
1043
       programmer that decides which variables in the program contain signed
1044
       numbers and which variables contain unsigned numbers. It is the object
1045
       that the programmer is modeling with the program that is used to make this
1046
       determination.
1047
       "Since the CPU does not 'know' which values represent signed numbers and
1048
       which values represent unsigned numbers, a flag in the status register
1049
       (called the Negative flag) assumes that all the calculations that are being
1050
       performed by the CPU are with signed numbers. If the value that is the
       result of a calculation has its leftmost bit set to a 1, then the Negative flag
1051
1052
       will also be set to a 1 to indicate the value is negative if it represents a
1053
       signed number. If the leftmost bit is a 0, then the Negative flag will also be
1054
       set to a 0 to indicate the value is positive if it represents a signed number."
1055
       "Do you mean that the Negative flag has been indicating whether results
1056
       have been negative or not the whole time we have been tracing programs?"
1057
       asked Pat.
1058
       I smiled and said "Yes."
       "I missed that too!" said Pat. "Can we enter in a short program into the
1059
1060
       emulator and trace through it so that I can see the Negative flag changing?"
1061
       "Okay." I said. "If you look at the reference information for the LDA
       instruction you will see that every time it loads a number into the 'A'
1062
1063
       register, the Negative flag is set or cleared depending in whether or not the
       number was negative. I will enter a short program which contains 4 LDA
1064
       instructions directly into the emulator. I will have 2 of these instructions
1065
1066
       load positive numbers and have 2 of them load negative numbers."
1067
       I then entered the following program into the emulator using the Assemble
1068
       command:
1069
       0200 A9 05
                      LDA #05h
1070
       0202 A9 80
                      LDA #80h
1071
       0204 A9 27
                      LDA #27h
```

```
1072 0206 A9 C2 LDA #C2h
1073 0208 00 BRK
1074 ...
```

1075 "Which of these numbers are positive and which of them are negative Pat?" 1076 I asked.

1077

Pat looked at the numbers then picked up the whiteboard and wrote the

```
1078
       following:
1079
1080
       0000 0101
1081
         8
1082
       1000 0000
1083
         2
1084
       0010 0111
1085
         С
1086
       1100 0010
1087
       "The 05 is positive," said Pat "the 80 hex is negative, the 27 hex is positive,
1088
       and the c2 hex is negative. Am I right?"
       "Yes, you are right!" I replied. "Now trace through the program and see if
1089
       the Negative flag agrees with you."
1090
       Pat then traced through the program:
1091
1092
       -t 0200
1093
       PgmCntr(PC)
                    Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                   StkPtr(SP)
                                                                NV-BDIZC(SR)
1094
                                  FC
                                            00
                                                                00010100
          0202
                       05
                                                      FD
1095
       0202 A9 80
                       LDA #80h
1096
       -t
                                                   StkPtr(SP)
1097
       PgmCntr(PC)
                    Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                                NV-BDIZC(SR)
1098
          0204
                                  FC
                                            00
                                                      FD
                                                                10010100
1099
       0204 A9 27
                       LDA #27h
1100
       -t
       PgmCntr(PC)
1101
                    Accum(AC)
                               XReg(XR)
                                         YReg(YR)
                                                   StkPtr(SP)
                                                                NV-BDIZC(SR)
          0206
                                  FC
                                            00
                                                      FD
                                                                00010100
1102
                       27
1103
       0206 A9 C2
                       LDA #C2h
1104
       -t
```

- PgmCntr(PC) Accum(AC) XReg(XR) 1105 YReg(YR) StkPtr(SP) NV-BDIZC(SR) 1106 0208 FC 00 FD 10010100 C2 1107 0208 00 **BRK**
- 1108 "The Negative flag agreed with me!" said Pat.
- 1109 "Yes it did." I replied. "Now we can look at how a branch instruction
- 1110 branches backwards in memory."

1111 Backward Branches And Loops

- 1112 "When I was young Pat," I said "I read a story about a man who had found a
- 1113 ring that would send him one minute backwards in time when he pressed it.
- 1114 The ring would not work again until the minute had passed again, so the
- 1115 furtherest he could ever go back in time was just one minute. He eventually
- 1116 figured out how to use the ring to win money at gambling establishments
- and he did this until he was very rich. One day he decided to spend some of
- 1118 his money by taking a trip to a foreign country. While he was on the plane
- 1119 traveling high above the ocean, a meteor hit the plane and ripped a large
- 1120 hole in the fuselage. He was thrown through the hole and knocked
- 1121 unconscious. When he awoke, he found himself falling towards the ocean."
- 1122 "What did he do!? asked Pat.
- 1123 "What do you think he did?" I said.
- "He pressed the ring!" cried Pat "and put himself one minute back in time!"
- "Yes, he did," I said "but after he pressed the ring, he found that he was still
- falling over the ocean, jut higher up than he was before."
- "Oh no!" said Pat. "He couldn't press the ring again until a minute had
- 1128 passed so he was stuck repeating his fall towards the ocean over and over
- 1129 again! How awful!"
- 1130 "I agree," I said "and to this day I can still see the man being placed at the
- top of his fall and then falling, over and over again, in an infinite loop. What
- brought the story to mind was that when a computer uses a branch
- instruction or a jump instruction to move the Program Counter backwards
- in memory, it is similar to the man in the story falling in an infinite loop."

- 1135 "It is?" asked Pat. "How?"
- 1136 "When the Program Counter is set to an earlier part of memory, the
- instructions that have already been executed are executed again. When the
- 1138 branch or the jump instruction is encountered again, it acts like the man's
- ring and sends the Program Counter back to the earlier set of instructions.
- 1140 Sections of code that execute over and over like this are called **loops**.
- 1141 Usually, there is some logic that is placed within a loop that will allow the
- loop to eventually be exited. The word **logic** in this context means a group
- of instructions that work together to accomplish a given purpose. If loop
- exit logic does not exist, or if the logic was written incorrectly, the loop will
- loop forever. Loops that do not contain exit logic are called **infinite loops**."
- "Can an infinite loop really run forever?" asked Pat.
- "Not really." I replied. "An infinite loop can be forced to exit by the
- operating system, by pressing the computer's reset button, or by shutting
- the computer off. Even if the computer were permitted to run continuously,
- a part in it would eventually wear out which would cause it to crash.
- 1151 Therefore, an infinite loop is really only infinite in theory."
- "Can you show me an infinite loop?" asked Pat. "I would like to see one."
- "Yes, an infinite loop is easy to create." I said "I will enter a short program
- 1154 directly into the emulator that contains an infinite loop and then I will let
- 1155 you trace through it. Pay close attention to the contents of the program
- 1156 counter as you trace."
- 1157 I then entered the following program and let Pat trace it:

```
1158
      -u 0200
1159
      0200 A9 01
                      LDA #01h
1160
      0202 A2 02
                      LDX #02h
      0204 4C 00 02 JMP 0200h
1161
      0207
            00
                      BRK
1162
1163
      -t 0200
1164
1165
      PgmCntr(PC) Accum(AC) XReg(XR)
                                        YReg(YR)
                                                  StkPtr(SP)
                                                               NV-BDIZC(SR)
1166
                                                      FD
                                                               00010100
         0202
                      01
                                 FC
                                            00
1167
      0202 A2 02
                      LDX #02h
```

	<u> </u>	Λ	_
V	1.	u	. ``

1168	-t					
1169 1170	PgmCntr(PC) 0204	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1171 1172	0204 4C 00 -t	02 JMP 02 0	0h			
1173 1174	PgmCntr(PC) 0200	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1175 1176	0200 A9 01 -t	LDA #01	.h			
1177 1178	PgmCntr(PC) 0202	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1179 1180	0202 A2 02 -t	LDX #02	th .			
1181 1182	PgmCntr(PC) 0204	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1183 1184	0204 4C 00 -t	02 JMP 020	0h			
1185 1186	PgmCntr(PC) 0200	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1187 1188	0200 A9 01 -t	LDA #01	.h			
1189 1190	PgmCntr(PC) 0202	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1191 1192	0202 A2 02 -t	LDX #02	lh .			
1193 1194	PgmCntr(PC) 0204	Accum(AC) 01	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 00010100
1195	0204 4C 00	02 JMP 020	0 0 h			

T 7	つ	Λ	\Box
V	Z	v	J

41/68

1196 -t

```
XReg(XR)
1197
      PgmCntr(PC)
                    Accum(AC)
                                           YReg(YR)
                                                      StkPtr(SP)
                                                                   NV-BDIZC(SR)
          0200
1198
                        01
                                    02
                                              00
                                                         FD
                                                                   00010100
```

- 1199 0200 A9 01 LDA #01h
- 1200 "Wow, it does run in an infinite loop!" said Pat. "Can you now show me a
- 1201 loop that will run for a while and then exit?"
- "Yes, this is also easy to do." I said. "I will create a small program that will 1202
- 1203 place the number 4 into the X register and then decrement the contents of
- 1204 the X register inside a loop until it reaches 0. When it reaches 0, the loop
- 1205 will exit. This time, pay close attention to the X register, the Program
- 1206 Counter, and the Zero flag."
- 1207 I then created the following program and had Pat trace through it:
- 1208 -u 0200
- 1209 A2 04 LDX #04h 0200
- 1210 0202 CA DEX
- 1211 0203 DO FD BNE **0202h**
- 1212 0205 00 BRK
- 1213 . . .
- 1214 -t 0200
- PgmCntr(PC) Accum(AC) StkPtr(SP) NV-BDIZC(SR) 1215 XReg(XR) YReg(YR)
- 00010100 1216 0202 00 04 00 FD
- 1217 0202 CA DEX
- 1218 -t
- 1219 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 03 00 FD 00010100
- 1220 00 0203
- 1221 BNE 0202h 0203 D0 FD
- 1222 -t
- 1223 PgmCntr(PC) Accum(AC) XReq(XR)YReg(YR) StkPtr(SP) NV-BDIZC(SR) 03 00010100 1224 0202 00 00 FD
- 1225 0202 CA DEX

42/68

1226	-t							
1227 1228	PgmCntr(PC) 0203	Accum(AC) 00	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDI Z C(SR) 000101 <mark>0</mark> 0		
1229	0203 D0 FD	BNE 020	2h					
1230	-t							
1231 1232	PgmCntr(PC) 0202	Accum(AC) 00	XReg(XR) 02	YReg(YR) 00	StkPtr(SP) FD	NV-BDI Z C(SR) 000101 <mark>0</mark> 0		
1233	0202 CA	DEX						
1234	-t							
1235 1236	PgmCntr(PC) 0203	Accum(AC) 00	XReg(XR) 01	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 000101 <mark>0</mark> 0		
1237	0203 D0 FD	BNE 020	2h					
1238	-t							
1239 1240	PgmCntr(PC) 0202	Accum(AC) 00	XReg(XR) 01	YReg(YR) 00	StkPtr(SP) FD	NV-BDIZC(SR) 000101 <mark>0</mark> 0		
1241	0202 CA	DEX						
1242	-t							
1243 1244	PgmCntr(PC) 0203	Accum(AC) 00	XReg(XR)	YReg(YR) 00	StkPtr(SP) FD	NV-BDI <mark>Z</mark> C(SR) 000101 <mark>1</mark> 0		
1245	0203 D0 FD	BNE 020	2h					
1246	-t							
1247 1248	PgmCntr(PC) 0205	Accum(AC) 00	XReg(XR) 00	YReg(YR) 00		NV-BDIZC(SR) 00010110		
1249	0205 00	BRK						
1250	"What did t	he progran	n do?" I as	ked.				
1251 1252 1253	Zero flag was set and the BNE instruction fell through to the next							

The Professor And Pat series (professorandpat.org)

1254 "Correct." I said. "Now, look at the program again and tell me what the

- 1255 operand is for the BNE instruction."
- 1256 Pat looked at the program and then said "FD hex? That seems like too large
- of a number... wait, the BNE is branching **backwards** in memory so it must
- 1258 be a **negative** number!"
- 1259 "It is indeed a negative number, Pat." I said. "Can you determine what the
- 1260 number is in decimal?"
- 1261 "Hmmm," said Pat "FD hex is equal to 11111101 in binary. Just a bit ago
- we created a table which showed 4-bit binary numerals and their positive
- and negative decimal equivalents. I am guessing that if we just extend this
- table to 8 bits and added a column for hex numerals, we can figure out what
- 1265 FD hex is equivalent to in decimal."
- 1266 "Go ahead and extend the table then." I said. Pat then modified the table.
- 1267 (see Fig. 5)

1268	Figure 5	Binary		Hex		Dec	"FD hex is equal to -3
1269		11111000	-	F8	-	-8	decimal!" said Pat.
1270		11111001	-	F9	-	-7	"Look at the program
1271		11111010	-	FΑ	-	-6	again and tell me how
1272		11111011	-	FB	-	-5	many locations backwards
1273		11111100	-	FC	-	-4	in memory the address is
1274		11111101	-	FD	-	-3	that the BNE is branching
1275		11111110	-	FE	-	-2	to from the address of the
1276 1277		11111111	-	FF	-	-1	instruction that is underneath it."
12//		00000000	-	00	-	0	underneam n.
1278		0000001	-	01	-	1	Pat counted the addresses
1279		00000010	-	02	-	2	then said "3 memory
1280		00000011	-	03	-	3	locations, that's cool!"
		00000100	-	04	-	4	
1281		00000101	-	05	-	5	"I agree," I said "the way
1282		00000110	-	06	-	6	loops work is strange,
1283		00000111	-	07	-	7	simple, and exciting!"

1284 "What else can loops do?" asked Pat.


- 1285 "The ability to execute a group of instructions over and over again by
- 1286 looping," I replied "is one of the fundamental capabilities that give a
- 1287 computer its enormous power. In fact, machines of all types derive much of

- their power from the principle of **repeated cycling**.
- 1289 A simple example of this is a car tire. A tire would not be very useful if it
- 1290 could only be rolled through one revolution. This brings to mind the image
- of a person who just purchased a brand new car at a dealership. The
- 1292 papers have been signed, the whole family (including the dog) has just
- 1293 been loaded into the car, and they are ready to drive home. The person
- 1294 starts the car, puts it into drive, moves forward one full revolution of the
- 1295 tires, and stops. The person then jacks up the car, removes the tires,
- 1296 discards them, puts on a set of new ones, lowers the car, then drives
- 1297 forward one more revolution of the tires. This process is continued all the
- 1298 way home!"
- 1299 Pat burst out laughing and I did too!
- 1300 I then continued "Other examples of machines that make use of the
- 1301 repeated cycles principle include internal combustion engines, sewing
- machines, hammers, screws, drills, and pumps. Many more examples exist,
- 1303 but they are too numerous to list."
- 1304 "I hadn't thought about it before," said Pat "but you're right, lots of
- 1305 machines repeat their cycles. I also never would have guessed that
- 1306 computers repeat cycles too because, from the outside, it looks like they just
- 1307 sit there."
- 1308 "In a program," I said "loops are used for all kinds of purposes like adding
- 1309 series of numbers together, repeatedly checking to see if an event (like the
- 1310 pressing of a keyboard key) has occurred, moving graphics across a screen,
- 1311 searching files, generating sounds, and spell checking documents."
- 1312 "Can we create a program that uses a loop to do something useful?" asked
- 1313 Pat. "Maybe something simple like adding a series of numbers together."
- 1314 "Yes, we can do this." I said. "But first we need to talk about the Carry flag,
- indexed addressing modes, and commenting programs.
- 1316 The Carry Flag
- 1317 "What I would like you to do now Pat," I said "is to add 1 to 99 decimal on
- 1318 the whiteboard and explain how carrying works when an addition in a given
- 1319 column results in a number that is too large to fit in that column."

- Pat added 1 to 99 decimal on the whiteboard then said "Starting in the ones
- 1321 column, 1 is added to 9 and the result is 1 ten and 0 ones. The 10 will not
- 1322 fit into the one's column, so it is carried over to the tens column. The 90
- 1323 that is in the tens column is then added to the 10 that was carried over
- there and the result is 1 hundred and 0 tens. The 1 hundred is too large to
- 1325 fit into the tens column, so it is carried over to the hundreds column." (see
- 1326 Fig. 5)

Figure 5


Adding 10 to 90 results in one hundred which consists of 1 hundred and 0 tens. The 1 hundred is carried into the hundreds column.



Adding 1 to 9 results in 10 which consists of 1 ten and 0 ones. The 1 ten is then carried into the tens column.

"Very good Pat." I said "Now I am going to do another addition on the whiteboard except I will be adding 1 to 11111111 binary." (see Fig. 6)


Figure 6



- 1329 "1 + 1 binary equals 10 binary." I said. "Notice how the bits from each
- 1330 addition in each column are carried over to the column to the left of it. Also
- 1331 notice that the result is a 9 bit number, not an 8 bit number."
- 1332 "Uh oh," said Pat "we have a problem."
- 1333 "What is the problem?" I asked.
- 1334 "Our registers are only 8 bits wide so where is the 9th bit going?" replied
- 1335 Pat.

- 1336 "You are very observant." I said. "Our registers are only 8 bits wide and so
- 1337 are our memory locations. Even if our registers were wider, we would still
- 1338 run into a problem like this eventually when we started using larger
- 1339 numbers. This is the problem that the Carry flag has been designed to
- 1340 solve and the way it does it is like this." I then added information about the
- 1341 carry flag to the diagram on the whiteboard (see Fig. 7)

Figure 7



- 1342 Pat studied the diagram then said "But what happens to the bit after it has
- 1343 been placed into the Carry flag?"
- 1344 "Have you ever wondered what the 'C' means in the ADC instruction's
- 1345 name?" I asked.
- 1346 "Yes, I've wondered about it because it always seemed to me that this
- instruction should have been called ADD instead of ADC." replied Pat.
- 1348 "The 'C' stands for Carry," I said "and what this means is that the ADC
- instruction will add the value in the 'A' register with a value in memory **and**
- 1350 to this sum it will add the contents of the Carry flag. Therefore, the
- 1351 correct name of the ADC instruction is ADd with Carry."
- 1352 "Wait a minute!" said Pat. "If the ADC instruction always includes the value
- 1353 of the Carry flag in its calculations, what happens if the Carry flag just
- happens to be set to 1 when a calculation is performed? Wouldn't it result
- 1355 in the answer being one more than it should be?"
- 1356 "Yes," I replied "and this is why a CLC or CLear Carry instruction is always
- 1357 placed just before an ADC instruction unless a multi-byte addition is being
- 1358 performed."
- 1359 "But we haven't been placing a CLC instruction before our ADC

-		\sim	$\overline{}$
٧Z	. !	()	n

47/68

- instructions," said Pat "so why have our answers have been coming out okay?"
- 1362 "The reason that our answers have been correct so far," I said "is because
- 1363 the emulator and the monitor have been programmed to launch with the
- 1364 Carry flag set to 0. I have not been placing a CLC instruction ahead of the
- 1365 ADC instructions we have been using because I was not ready yet to tell you
- 1366 about how the Status register's flags worked."
- 1367 "That was probably a good idea," said Pat "because I don't think I would
- have been able to understand what the flags did if you had told me about
- 1369 them earlier than you did. Now that I know about the Carry flag, though,
- 1370 can you show me how it is used to add together 2 bytes that have a result
- 1371 that is larger than 8 bits?"
- 1372 "Yes." I said "I will create a small program that performs the addition from
- 1373 the example on the whiteboard and you then can trace it."
- 1374 I created the following program:

1375	0200				000001	org 0200h
1376					000002	
1377	0200	FF			000003	number1 dbt 11111111 b
1378	0201	01			000004	number2 dbt 00000001 b
1379					000005	
1380	0205				000006	org 0205h
1381					000007	
1382	0205	ΑD	00	02	800000	lda number1
1383	0208	18			000009	clc
1384	0209	6D	01	02	000010	adc number2
1385					000011	
1386	020C	00			000012	j brk
1387					000013	
1388					000014	end
1389					000015	

- 1390 And then Pat dumped it, unassembled it, and traced through it:
- 1391 -d 0200
- 1392 0200 **FF 01** 00 00 00 AD 00 02 18 6D 01 02 00 00 00 00m......
- 1393 -u 0205
- 1394 0205 AD 00 02 LDA 0200h
- 1395 0208 18 CLC

1414

48/68

```
0209 6D 01 02 ADC 0201h
1396
1397
       020C
             00
                        BRK
1398
       . . .
1399
       -t 0205
1400
       PgmCntr(PC)
                    Accum(AC)
                                XReg(XR)
                                          YReg(YR)
                                                     StkPtr(SP)
                                                                 NV-BDIZC(SR)
1401
                                              00
                                                                  10010100
          0208
                        FF
                                   FC
                                                        FD
                        CLC
1402
       0208
            18
1403
       -t
1404
       PgmCntr(PC)
                    Accum(AC)
                                XReg(XR)
                                          YReg(YR)
                                                     StkPtr(SP)
                                                                 NV-BDIZC(SR)
1405
          0209
                        FF
                                   FC
                                              00
                                                        FD
                                                                  10010100
             6D 01 02 ADC 0201h
1406
       0209
1407
       -t
1408
       PgmCntr(PC)
                    Accum(AC)
                                XReq(XR)
                                          YReg(YR)
                                                     StkPtr(SP)
                                                                 NV-BDIZC(SR)
1409
          020C
                        00
                                   FC
                                              00
                                                        FD
                                                                  00010111
1410
       020C
             00
                        BRK
1411
       "Notice that after the ADC instruction was executed," I said "it resulted in
1412
       00 being placed in the 'A' register and the Carry flag being set to 1. This
```

matches the calculation we made on the whiteboard." (again, see Fig. 7).

Indexed Addressing Modes And Commenting Programs

- 1415 "Now that you know how the Carry flag works Pat," I said "we can create a
- 1416 program that adds a series of numbers together in a loop. In order to do
- 1417 this, however, we will need to use one of the indexed addressing modes."
- 1418 "What does an indexed addressing mode do?" asked Pat.
- 1419 I replied "An indexed addressing mode uses the contents of either the X
- register or the Y register as an offset from some **base address** to determine
- 1421 what is called the **effective address**.
- 1422 For example, with the **Absolute,X** addressing mode, the programmer
- specifies an **absolute address** to use as the **base address** and then the
- 1424 contents of the X register are added to this **base address** to determine the
- 1425 **effective address** that will be accessed by the instruction."

- 1426 "I don't get it." said Pat, with a confused look.
- 1427 "Then I will create a program that shows how Absolute,X addressing works,
- 1428 trace through it, and then we will discuss it."
- 1429 I then created the following program and traced it:

```
1430
      0200
                       000001 |
                                     org 0200h
1431
                       000002
1432
      0200 41
                       000003 | nums dbt 41h, 42h, 43h, 44h, 45h
1433
      0201 42
      0202 43
1434
1435
      0203 44
1436
      0204 45
      0205 46
1437
1438
                       000004 I
      0210
                       000005
1439
                                     org 0210h
1440
                       000006
1441
      0210 A2 02
                       000007
                                     ldx #02d
1442
      0212 BD 00 02
                       800000
                                     lda nums,x
                       000009
1443
1444
      0215 00
                       000010
                                     brk
1445
                       000011
1446
                       000012
                                     end
1447
                       000013 |
1448
      -d 0200
1449
      0200 41 42 43 44 45 46 00 00 - 00 00 00 00 00 00 00 ABCDEF......
1450
      -u 0210
1451
      0210 A2 02
                       LDX #02h
1452
      0212
            BD 00 02 LDA 0200h.X
1453
      0215
            00
                       BRK
1454
       . . .
1455
      -t 0210
1456
      PgmCntr(PC)
                    Accum(AC)
                               XReg(XR)
                                          YReg(YR)
                                                    StkPtr(SP)
                                                                 NV-BDIZC(SR)
                                                       FD
1457
         0212
                       00
                                   02
                                             00
                                                                 00010100
1458
      0212 BD 00 02 LDA 0200h,X
1459
      -t
1460
      PgmCntr(PC) Accum(AC) XReg(XR)
                                         YReg(YR) StkPtr(SP)
                                                                 NV-BDIZC(SR)
```

	v2.05	50/68						
1461	0215	43	02	00	FD	00010100		
1462	0215 00	BRK						
1463 1464 1465 1466 1467 1468 1469	"The LDA instruction in this program uses the Absolute,X addressing mode to determine the memory location which it will copy the value from." I said "This memory location is called the effective address . The base address is 0200 hex and 02 has already been loaded into the X register. The effective address is calculated by adding the base address to the contents of the X register which, in this case, is 0200 hex + 02 which equals 0202 hex."							
1470	"What did I p	lace into m	nemory sta	rting at l	ocation 0	200h, Pat?" I asked.		
1471 1472 1473 1474 1475	nums , but ins a series of 5 k	stead of de bytes in thi hex. I did	efining a si is area of r In't know t	ngle byte nemory w hat the d	at addre vith the fi bt directi	riable there called ss 0200 hex, you placed rst byte being located at ve could be used to g."		
1476 1477 1478 1479	"When a group of values that are related to each other are placed into consecutive memory locations like this," I said "they are referred to as a table , an array , or a list . This array consists of 5 bytes and these bytes just happen to contain the first 5 capital ASCII letters.							
1480 1481 1482 1483 1484	When the instruction lda nums,x was executed, it took the address of nums (which is 0200 hex) and added to it the contents of the X register (which is 02). It then used the resulting sum (0202 hex) to determine which memory location to copy the value from. What number is at address 0202 hex, Pat?"							
1485	Pat looked at	the progra	am and sai	d "43 hex	ζ."			
1486 1487	"And what nu asked.	mber was	loaded int	o the 'A' ı	register w	hen it was traced?" I		
1488	"43 hex!" Pat	replied. "	The Absolı	ıte,X add	ressing m	node worked!"		
1489 1490	"Yes it did," I of an array of	-		reate a p	rogram th	nat determines the sum		
1491	Here is the p	rogram I c	reated:					

```
1492
                              000001 |; The purpose of this program is to calculate the
                              000002 |; sum of the array nums and then to place the
1493
                              000003 I:result into the variable sum.
1494
                              000004
1495
             0200
1496
                              000005 I
                                           org 0200h
1497
                              000006 I
1498
                              000007 |; An array of 10 bytes.
1499
             0200 01
                              000008 | nums dbt 1d,2d,3d,4d,5d,6d,7d,8d,9d,10d
1500
             0201 02
             0202 03
1501
             0203 04
1502
             0204 05
1503
1504
             0205 06
1505
             0206 07
             0207 08
1506
1507
             0208 09
1508
             0209 0A
1509
                              000009
1510
                              000010
1511
                              000011
1512
                              000012
1513
                              000013 I
                              000014 |
1514
1515
                              000015
1516
                              000016
1517
                              000017
1518
                              000018
                              000019 |; Holds the sum of array at nums.
1519
             020A 00
1520
                              000020 Isum dbt 0d
1521
                              000021
1522
             0250
                              000022 |
                                           org 0250h
1523
                              000023
1524
                              000024 |; Initialize the X register so that it offsets 0
1525
                              000025 |; positions into the array nums.
                                           ldx #0d
1526
             0250 A2 00
                              000026
1527
                              000027
                              000028 |; Initialize register 'A' to 0. This needs to
1528
      be done
1529
1530
                              000029 |; so that an old value in 'A' does not produce a
1531
      wrong
1532
                              000030 |; sum during the first loop iteration.
                                           lda #0d
1533
             0252 A9 00
                              000031
1534
                              000032
1535
                              000033 |; This label is the top of the calculation loop.
1536
             0254
                              000034 | AddMore
1537
                              000035
                              000036 |; Clear the carry flag so that it does not cause
1538
1539
      а
```

```
1540
                             000037 |; wrong sum to be calculated by the ADC
1541
      instruction.
             0254 18
1542
                             000038 L
                                           clc
1543
                             000039
                             000040 |;Obtain a value from the array at offset X
1544
1545
      positions
1546
                             000041 |;into the array and add this value to the
      contents
1547
                             000042 |; of the 'A' register.
1548
1549
             0255 7D 00 02
                             000043
                                           adc nums,x
1550
                             000044 I
1551
                             000045 |; Increment X to the next offset position.
1552
             0258 F8
                             000046
1553
                             000047
1554
                             000048 |; If X has been incremented to 10, fall through
1555
      the
                             000049 |; bottom of the loop. If X is less than 10 then
1556
1557
      loop
                             000050 |; back to AddMore and add another value from the
1558
1559
      array.
1560
             0259 E0 0A
                             000051
                                           cpx #10d
1561
             025B D0 F7
                             000052 I
                                           bne AddMore
1562
                             000053
1563
                             000054 |; After the loop has finished calculating the
1564
      sum of
1565
                             000055 |; the array, store this sum into the variable
      called
1566
1567
                             000056 |; 'sum'.
             025D 8D 0A 02
                             000057
1568
                                           sta sum
1569
                             000058 I
1570
                             000059 |; Return program control back to the monitor.
             0260 00
                             000060
                                           brk
1571
1572
                             000061
                             000062 |; The end command must have at least 1 blank line
1573
1574
                             000063 |;underneath it.
1575
                             000064
1576
                             000065 I
                                           end
```

1577 "What are all those lines that begin with semicolons for?" asked Pat

1578 "Those are called **comments**, I replied "and their purpose is to explain what 1579 the various parts of a program do. The semicolon tells the assembler 1580 to ignore everything after them on the line. Comment lines are 1581 ignored by the assembler and none of their content makes it into the 1582 program. Up to this point our programs have been small enough that they 1583 did not need commenting, but from here on the programs will be more 1584 sophisticated. If sophisticated programs are not commented, it is very 1585 difficult to keep track of what they are doing."

```
1586
      "I can believe that," said Pat "because I was even having trouble keeping
1587
      track of what the smaller programs were doing."
      After Pat had finished studying the program and reading the comments it
1588
      contained. I loaded it into the emulator and executed it with a Go command:
1589
      -d 0200
1590
      0200 01 02 03 04 05 06 07 08 - 09 0A 00 00 00 00 00 00
1591
1592
1593
      -u 0250
1594
      0250 A2 00
                     LDX #00h
1595
      0252
            A9 00
                     LDA #00h
      0254
            18
                     CLC
1596
            7D 00 02
                     ADC 0200h, X
1597
      0255
      0258
            E8
                      INX
1598
1599
      0259
            F0 0A
                     CPX #0Ah
1600
      025B
            D0 F7
                     BNE 0254h
1601
      025D
            8D 0A 02
                     STA 020Ah
1602
      0260
            00
                     BRK
1603
1604
      PgmCntr(PC)
                             XReg(XR)
1605
                  Accum(AC)
                                      YReg(YR)
                                                StkPtr(SP)
                                                           NV-BDIZC(SR)
                                                   FD
1606
         102C
                      00
                                FC
                                         00
                                                           00010110
1607
      -g 0250
1608
      PgmCntr(PC)
                  Accum(AC)
                             XReg(XR)
                                      YReg(YR)
                                                StkPtr(SP)
                                                           NV-BDIZC(SR)
1609
                                         FF
         0260
                     37
                                0Α
                                                   FD
                                                           00010111
1610
      -d 0200
      1611
1612
      "What values were in the 'A' register and in the variable 'sum' before the
      program was executed?" I asked.
1613
1614
      "0 and 0." replied Pat.
1615
      "And what values were in the 'A' register and in the variable 'sum' after the
      program was executed?" I asked.
1616
1617
      "37 hex and 37 hex." replied Pat.
```

- 1618 "What is 37 hex in decimal?" I asked.
- 1619 Pat picked up the calculator that was on the table, pressed some of its
- 1620 buttons then said "55."
- 1621 "Finally," I asked "what is the sum of 1+2+3+4+5+6+7+8+9+10?"
- 1622 Pat calculated the sum on the calculator then said "55! It worked! But now
- 1623 I want to trace through the program so I can see it work step-by-step."
- 1624 Pat then did this and so should you.
- 1625 Exercises
- 1626 1) The source code for the umon65 monitor is in the the
- mathrider/examples/u6502 directory in the download file that contained the
- 1628 emulator. Open this file and study it.
- 1629 2) Write an **assembly language** program that adds the numbers 1,2,3,4,5,
- and 6 together and places the sum into location 0275h. Have the program
- start at 0200h in memory. Assemble the program, load it into the emulator,
- 1632 run it, and verify that it works correctly.

addressing)

1633

1634

Appendix A - 6502 Instruction Set Reference (minus zero page

1635 Registers: 1636 PC program counter (16 bit) accumulator 1637 AC (8 bit) 1638 Χ X register (8 bit) 1639 Υ Y register (8 bit) SR status register [NV-BDIZC] (8 bit) 1640 stack pointer 1641 SP (8 bit) 1642 1643 Status Register (SR) Flags (bit 7 to bit 0): 1644 Negative **Overflow** 1645 ٧ 1646 ignored 1647 В Break Decimal (use BCD for arithmetics) 1648 1649 Ι Interrupt (IRQ disable) Ζ Zero 1650 Carry 1651 C 1652 Processor Stack: Top down, 0x0100 - 0x01FF 1653 1654 Words: 1655 16 bit words in lowbyte-highbyte representation (Little-Endian). 1656 Addressing Modes: 1657 1658 Immediate / OPC #\$BB / Operand is byte (BB). 1659 Accumulator / OPC A / Operand is AC. Α Absolute / OPC \$HHLL / Operand is address \$HHLL. 1660 abs 1661 abs,X Absolute, X-indexed / OPC \$HHLL, X / Operand is address incremented by X 1662 with carry. 1663 abs.Y Absolute, Y-indexed / OPC \$HHLL, Y / Operand is address incremented by Y 1664 with carry. Implied / OPC / Operand implied. impl 1665 Indirect / OPC (\$HHLL) / Operand is effective address, effective 1666 ind 1667 address is value of address. X,ind X-indexed,indirect / OPC (\$BB,X) / Operand is effective zeropage 1668 address, effective address is byte (BB) incremented by X without 1669 1670 carry. 1671 ind.Y Indirect,Y-indexed / OPC (\$LL),Y / Operand is effective address incremented by Y with carry, effective address is word at zeropage 1672 1673 1674 rel Relative / OPC \$BB / Branch target is PC + offset (BB), bit 7

signifies negative offset.

```
1676 Instructions:
      Legend to Flags:
1677
      + .... modified
1678
      - .... not modified
1679
1680
     1 .... set
      0 .... cleared
1681
      M6 .... memory bit 6
1682
1683
      M7 .... memory bit 7
1684
      ADC Add Memory to Accumulator with Carry
          A + M + C \rightarrow A, C
                                   N Z C I D V
1685
1686
                                   +++--+
1687
          addressing assembler opc bytes
1688
1689
          immediate ADC #oper
                                   69
                                           2
                       ADC oper
1690
          absolute
                                     6D
                                          3
         absolute,X
absolute,Y
                                        3
1691
                       ADC oper,X
                                     7D
                       ADC oper,Y
                                     79
                                         3
1692
                                          2
1693
          (indirect,X) ADC (oper,X)
                                     61
          (indirect), Y ADC (oper), Y 71
1694
                                          2
      AND AND Memory with Accumulator
1695
                                   N\ Z\ C\ I\ D\ V
          A AND M \rightarrow A
1696
1697
                                   + + - - - -
1698
          addressing assembler opc bytes
1699
          -----
          immediate AND #oper absolute AND oper
                                    29
1700
                                          2
1701
                                     2D
                                          3
                                          3
1702
          absolute,X
                       AND oper,X
                                     3D
                                     39 3
          absolute,Y
                       AND oper,Y
1703
          (indirect,X)
                                     21
                                          2
1704
                       AND (oper,X)
          (indirect), Y AND (oper), Y 31
                                          2
1705
1706
      ASL Shift Left One Bit (Memory or Accumulator)
          C <- [76543210] <- 0
                                   NZCIDV
1707
1708
                                   +++---
```

v2.05

57/68

1709 1710		addressing		орс	bytes	
1711 1712 1713		accumulator absolute absolute,X	ASL oper	0E	3	
1714	всс	Branch on Ca	rry Clear			
1715 1716		branch on C =	0	N Z C	I D V	
1717 1718		addressing		орс	bytes	
		relative		90	2	
1720	BCS	Branch on Ca	rry Set			
1721 1722		branch on C =	1	N Z C	I D V	
1723 1724		addressing		орс	bytes	
1725		relative	BCS oper	В0	2	
1726	BEQ	Branch on Re	sult Zero			
1727 1728		branch on Z =	1	N Z C	I D V	
1729 1730		addressing		•	-	
1731		relative				
1732	BIT	Test Bits in	Memory with	Accumi	ulator	
1733 1734						to bit 7 and 6 of SR (N,V); perand AND accumulator.
1735 1736		A AND M, M7 -	> N, M6 -> V		C I D '	
1737 1738		addressing	assembler	opc	bytes	
1739		absolute	BIT oper	2C	3	

1740	BMI	Branch on Re	sult Minus		
1741 1742		branch on $N =$	1	N Z C	I D V
1743 1744 1745		addressing relative			
1746	BNE	Branch on Re	sult not Zer	0	
1747 1748		branch on $Z =$	0	N Z C	I D V
1749		addressing	assembler	орс	bytes
1750 1751		relative		D0	2
1752	BPL	Branch on Re	sult Plus		
1753 1754		branch on $N =$	0	N Z C	I D V
1755		addressing		орс	bytes
1756 1757		relative		10	2
1758	BRK	Force Break			
1759 1760		interrupt, push PC+2, pu	sh SR	N Z C	I D V 1
1761 1762		addressing	assembler	opc	bytes
1763		implied	BRK	00	1
1764	вус	Branch on Ove	erflow Clear		
1765 1766		branch on $V =$	0	N Z C	I D V
1767		addressing		opc	bytes
1768 1769		relative	BVC oper	50	2

1770	BVS	Branch on Ov	erflow Set		
1771 1772		branch on V =	1	N Z C	I D V
1773		addressing	assembler	орс	bytes
1774 1775		relative	BVC oper	70	2
1776	CLC	Clear Carry	Flag		
1777 1778		0 -> C			I D V
1779 1780		addressing	assembler	орс	bytes
1781		implied		18	1
1782	CLD	Clear Decima	l Mode		
1783 1784		0 -> D		N Z C	I D V - 0 -
1785		addressing		орс	bytes
1785 1786 1787		addressing implied		opc D8	
1786	CLI		CLD	D8	
1786 1787	CLI	implied	CLD		
1786 1787 1788 1789 1790 1791	CLI	implied Clear Interr	CLD upt Disable	D8 Bit N Z C	1 I D V 0
1786 1787 1788 1789 1790	CLI	<pre>implied Clear Interr 0 -> I addressing</pre>	CLD upt Disable assembler	D8 Bit N Z C	1 I D V 0
1786 1787 1788 1789 1790 1791 1792		<pre>implied Clear Interr 0 -> I addressing implied</pre>	CLD upt Disable assembler CLI	D8 Bit N Z C opc	I D V 0
1786 1787 1788 1789 1790 1791 1792 1793		<pre>implied Clear Interr 0 -> I addressing implied</pre>	CLD upt Disable assembler CLI	D8 Bit N Z C opc 58	I D V 0
1786 1787 1788 1789 1790 1791 1792 1793 1794 1795		<pre>implied Clear Interr 0 -> I addressing implied Clear Overfl</pre>	CLD upt Disable assembler CLI ow Flag	D8 Bit N Z C opc 58	I D V 0 bytes

```
1800
     CMP Compare Memory with Accumulator
1801
         A - M
                                NZCIDV
1802
                                +++---
1803
         addressing assembler
                              opc bytes
1804
         ------
         immediate CMP #oper C9 absolute CMP oper CD
1805
                                       2
                                 CD
1806
         absolute
                     CMP oper
                                       3
         absolute,X
                     CMP oper,X
                                       3
1807
                                 DD
                                 D9
                                     3
1808
         absolute,Y
                     CMP oper,Y
                                      2
1809
         (indirect,X)
                     CMP (oper,X) C1
1810
         (indirect),Y CMP (oper),Y D1
1811
     CPX Compare Memory and Index X
         X - M
                                NZCIDV
1812
1813
                                +++---
1814
         addressing
                     assembler opc bytes
1815
1816
         immediate
                     CPX #oper E0
                                       2
                     CPX oper
                                 EC
                                       3
1817
         absolute
     CPY Compare Memory and Index Y
1818
                                NZCIDV
         Y - M
1819
1820
                                +++---
1821
         addressing
                   assembler opc bytes
1822
1823
         immediate
                     CPY #oper C0
                                       2
1824
         absolute
                     CPY oper
                                 CC
                                      3
1825
     DEC Decrement Memory by One
1826
         M - 1 -> M
                                NZCIDV
1827
                                + + - - - -
1828
         addressing
                     assembler
                                opc bytes
1829
                     DEC oper CE
         absolute
1830
                                       3
1831
         absolute,X
                     DEC oper,X
                                 DE
                                       3
1832
     DEX Decrement Index X by One
```

61/68

1833 1834		X - 1 -> X		N Z C + + -	I D V
1835 1836 1837			assembler DEC	opc CA	bytes 1
1838	DEY	Decrement Ind	dex Y by One		
1839 1840		Y - 1 -> Y		N Z C + + -	I D V
1841 1842		addressing	assembler	opc	bytes
1843		implied	DEC	88	1
1844	EOR	Exclusive-OR	Memory with	Accumu	ılator
1845 1846		A EOR M -> A		N Z C + + -	I D V
1847 1848		addressing	assembler	opc	bytes
1849		immediate			2
1850 1851		absolute absolute,X		4D 5D	3 3 3
1852		absolute,Y	EOR oper,Y	59	3
1853 1854		<pre>(indirect,X) (indirect),Y</pre>			2 2
1855	INC	Increment Mer	mory by One		
1856 1857		M + 1 -> M		N Z C + + -	I D V
1858 1859		addressing	assembler	opc	bytes
1860 1861		absolute absolute,X	INC oper INC oper,X	EE FE	3
1862	INX	Increment Inc	dex X by One		
1863 1864		X + 1 -> X		N Z C + + -	I D V
1865		addressing	assembler	opc	bytes

v2.05	
-------	--

62/68

1866 1867		implied	INX	E8	1
1868	INY	Increment Inc	dex Y by One		
1869 1870		Y + 1 -> Y		N Z C I + +	
1871 1872		addressing		opc by	ytes
1873		implied		C8	1
1874	JMP	Jump to New	Location		
1875 1876		(PC+1) -> PCL (PC+2) -> PCH		N Z C I	D V
1877 1878		addressing			ytes
1879 1880		absolute indirect	JMP oper	4C	3 3
1881	JSR	Jump to New	Location Savi	ing Retu	rn Address
1881 1882 1883 1884		Jump to New I push (PC+2), (PC+1) -> PCL (PC+2) -> PCH		ing Retu	
1882 1883 1884 1885		push (PC+2), (PC+1) -> PCL		NZCI	D V
1882 1883 1884		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH	assembler 	N Z C I	D V ytes
1882 1883 1884 1885 1886 1887		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH addressing	assembler JSR oper	N Z C I opc by	D V ytes
1882 1883 1884 1885 1886 1887		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH addressing absolute	assembler JSR oper	N Z C I opc by	D V ytes
1882 1883 1884 1885 1886 1887 1888 1889 1890		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH addressingabsolute Load Accumula	assembler JSR oper	N Z C I opc by 20 nory N Z C I + +	D V ytes 3
1882 1883 1884 1885 1886 1887 1888 1889 1890 1891 1892 1893		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH addressing absolute Load Accumula M -> A addressing immediate	assembler JSR oper ator with Men assembler LDA #oper	N Z C I opc by 20 N Z C I + + opc by	D V 3 D V ytes 2
1882 1883 1884 1885 1886 1887 1888 1889 1890 1891 1892		push (PC+2), (PC+1) -> PCL (PC+2) -> PCH addressing absolute Load Accumula M -> A addressing	assembler JSR oper ator with Men assembler	N Z C I opc by 20 N Z C I + + opc by	D V ytes 3 D V ytes

1899	LDX	Load Index X	with Memory		
1900 1901		M -> X		N Z C I + +	
1902 1903		addressing		opc by	/tes
1904 1905 1906		immediate absolute absolute,Y	LDX #oper LDX oper LDX oper,Y	A2 AE BE	2 3 3
1907	LDY	Load Index Y	with Memory		
1908 1909		M -> Y		N Z C I + +	
1910 1911		addressing	assembler	opc by	/tes
1912 1913		immediate absolute absolute,X	LDY #oper LDY oper	A0 AC	2 3
1015	I CD	Shift One Bi	+ Diab+ (Mom	ory or A	coumulator)
1915	LSK	SHILL OHE DI	t Kignit (Heili	OIY OI AC	.cumu ca cor ,
1913 1916 1917	LSK	0 -> [7654321	_	_	D V
1916 1917 1918		0 -> [7654321	0] -> C assembler	N Z C I - + + -	D V ⁄tes
1916 1917 1918 1919 1920		<pre>0 -> [76543210 addressing</pre>	0] -> C assembler	N Z C I - + + - opc by	D V /tes
1916 1917 1918 1919 1920		0 -> [76543210 addressing	0] -> C assembler	N Z C I - + + - opc by	D V /tes
1916 1917 1918 1919 1920 1921 1922		<pre>0 -> [76543210 addressing</pre>	0] -> C assembler	N Z C I - + + - opc by	D V /tes
1916 1917 1918 1919 1920 1921 1922		<pre>0 -> [76543210 addressing</pre>	0] -> C assembler	N Z C I - + + - opc by	D V
1916 1917 1918 1919 1920 1921 1922 1923 1924 1925 1926		<pre>0 -> [76543210 addressing</pre>	assembler LSR A LSR oper LSR oper,X	N Z C I - + + - opc by 4A 4E 5E	D V 1 3 3 3
1916 1917 1918 1919 1920 1921 1922 1923 1924 1925		<pre>0 -> [76543210 addressing</pre>	assembler LSR A LSR oper LSR oper,X	N Z C I - + + - opc by 4A 4E 5E	D V
1916 1917 1918 1919 1920 1921 1922 1923 1924 1925 1926 1927	NOP	<pre>0 -> [76543210] addressing accumulator absolute absolute,X No Operation addressing addressing</pre>	assembler LSR A LSR oper LSR oper,X assembler	N Z C I - + + - opc by 4A 4E 5E N Z C I opc by	D V

The Professor And Pat series (${\it professor}$ and ${\it pat.org}$)

v2.05	
-------	--

1931				+ +	
1932 1933 1934 1935 1936 1937 1938 1939		addressing immediate absolute absolute,X absolute,Y (indirect,X)	ORA #oner	09 2	
1940	РНА	Push Accumul	ator on Stac	k	
1941 1942		push A		N Z C I D V	
1943 1944		addressing	assembler	opc bytes	
1945		implied	РНА	48 1	
1946	PHP	Push Process	or Status on	Stack	
1947 1948		push SR		N Z C I D V	
1949 1950		addressing	assembler	opc bytes	
1951		implied	PHP	08 1	
1952	PLA	Pull Accumul	ator from St	ack	
1953 1954		pull A		N Z C I D V	
1955 1956		addressing	assembler	opc bytes	
1957		implied	PLA	68 1	
1958	PLP	Pull Process	or Status fr	om Stack	
1959 1960		pull SR		N Z C I D V from stack	
1961 1962		addressing		opc bytes	
1963		implied	PHP	28 1	4

1964	ROL	Rotate One Bit	t Left (Memo	ry or A	ccumulator)
1965 1966		C <- [76543210]] <- C	N Z C I + + + -	
1967 1968		addressing a		opc b	ytes
1969 1970 1971		accumulator F absolute F absolute,X F	ROL A ROL oper ROL oper,X	2A 2E 3E	1 3 3
1972	ROR	Rotate One Bit	t Right (Men	nory or	Accumulator)
1973 1974		C -> [76543210]] -> C	N Z C I + + + -	
1975 1976		addressing a		opc b	ytes
1977		accumulator F	ROR A	6A	1
1978 1979		absolute F absolute,X F	ROR oper ROR oper,X	6E 7E	3
1980	RTI	Return from In	nterrupt		
1981 1982		pull SR, pull F	PC	N Z C I from st	
1983 1984		addressing a	assembler	opc b	ytes
1985		implied F	RTI	40	1
1986	RTS	Return from Su	ubroutine		
1987 1988		pull PC, PC+1 -	-> PC	NZCI	D V
1989 1990		addressing a	assembler	opc b	ytes
1991		implied F	RTS	60	1
1992	SBC	Subtract Memor	ry from Accu	ımulator	with Borrow
1993 1994		A - M - C -> A		N Z C I + + + -	

1995 1996			essing	assembler	(эрс	3	by	/te	es
1997 1998 1999 2000 2001 2002		immed absol absol absol (indi	diate Lute Lute,X Lute,Y	SBC #oper SBC oper,X SBC oper,Y SBC (oper,X))	FC FS E3))] [2 3 3 2 2	
2003	SEC	Set	Carry Fl	ag						
2004 2005		1 ->	С			Z -		I -	D -	V -
2006 2007		addre	essing	assembler		эрс	C 	by	/te	es
2008		impli	ied	SEC		38	3		1	
2009	SED	Set	Decimal	Flag						
2010 2011		1 ->	D		N -		C -	Ι	D 1	
2012			essing	assembler		op o	: 	by	/te	es
2012 2013 2014						оро F8		b <u>y</u>	/te	es
2013	SEI	impli	ied			F8		by		es
2013 2014	SEI	impli	ied Interrup	SED	atı	F8	3	I	1	
2013 2014 2015 2016 2017 2018	SEI	impli Set 1 ->	ied Interrup I	SED	atı N	F8	C -	I 1	1 D	V -
2013 2014 2015 2016 2017	SEI	impli Set 1 ->	Interrup I	SED t Disable S ta	atı N	F8	C -	I 1	1 D	V -
2013 2014 2015 2016 2017 2018 2019		Set 1 -> addre	Interrup I essing	SED t Disable Sta	N -	F8 JS Z 78	C -	I 1	D -	V -
2013 2014 2015 2016 2017 2018 2019 2020		Set 1 -> addre	Interrup I essing ied	SED t Disable Sta	N - (F8 Z 78	C -	I 1	D - /te	V -
2013 2014 2015 2016 2017 2018 2019 2020 2021 2022		Set 1 -> addre impli Stor	Interrup I essing ied Te Accumu	SED t Disable Sta	N - ()	F8 Z - - 78	C - C -	I by	D - 1	V -

7	ΔE
V /	w

67/68

2028 2029 2030		<pre>absolute,Y (indirect,X) (indirect),Y</pre>	STA oper,Y STA (oper,X STA (oper),	99) 81 Y 91	3 2 2
2031	STX	Store Index	X in Memory		
2032 2033		X -> M		N Z C	
2034		addressing			
2035 2036		absolute			
2037	STY	Sore Index Y	in Memory		
2038 2039		Y -> M		N Z C	I D V
2040		addressing			
2041 2042		absolute			
2043	TAX	Transfer Acc	umulator to	Index X	(
2043 2044 2045	TAX	Transfer Acc	umulator to	Index > N Z C + + -	I D V
2044 2045 2046	TAX	A -> X addressing	assembler	N Z C + + -	I D V
2044 2045	TAX	A -> X	assembler	N Z C + + -	I D V
2044 2045 2046 2047 2048		A -> X addressing	assembler TAX	N Z C + + - opc 	I D V
2044 2045 2046 2047 2048	TAY	A -> X addressingimplied Transfer Acc	assembler TAX	NZC ++- opc AA	I D V bytes 1
2044 2045 2046 2047 2048 2049 2050 2051 2052	TAY	A -> X addressingimplied Transfer Acc	assembler TAX umulator to	N Z C + + opc 	I D V bytes 1
2044 2045 2046 2047 2048 2049 2050 2051	TAY	A -> X addressingimplied Transfer Acc A -> Y	assembler TAX umulator to assembler	N Z C + + opc 	I D V bytes I D V bytes
2044 2045 2046 2047 2048 2049 2050 2051 2052 2053 2054	TAY	A -> X addressingimplied Transfer Acc A -> Y addressing	assembler TAX umulator to assembler TAY	N Z C + + opc AA Index Y N Z C + + - opc A8	I D V bytes I I D V bytes

2	\sim	$\overline{}$
\mathbf{v}	. ()	ה

_	_		_
\sim	റ	IC	റ
n	×	m	×

2058 2059		addressing	assembler	орс	bytes
2060		implied	TSX	ВА	1
2061	TXA	Transfer In	dex X to Accı	umulato	r
2062 2063		X -> A		N Z C + + -	I D V
2064 2065		addressing	assembler	орс	bytes
2066		implied	TXA	8A	1
2067	TXS	Transfer In	dex X to Sta	ck Regi	ster
2068 2069		X -> SP		N Z C + + -	I D V
2070 2071		addressing	assembler	орс	bytes
2072		implied	TXS	9A	1
2073	TYA	Transfer In	dex Y to Accı	umulato	r
2074 2075		Y -> A		N Z C + + -	I D V
2076		addrassing	assembler	onc	hvtes
2070					