# 6502 Machine Language

by Ted Kosan

Part of The Professor And Pat series (professorandpat.org)

Copyright © 2008 by Ted Kosan


This work is licensed under the Creative Commons Attribution-ShareAlike 3.0 License. To view a copy of this license, visit http://creativecommons.org/licenses/bysa/3.0/

## **Table of Contents**

How The Dump Command Displays Memory Locations	
American Standard Code For Information Interchange (ASCII)	
The Dump Command And The Enter Command	
The Register Command	11
A Simple Machine Language Program	
Addressing Modes	14
The Unassemble Command	
The Go Command	18
The Trace Command	20
Exercises	24

#### 1 How The Dump Command Displays Memory Locations

- 2 "Now that you understand what binary numerals and hexadecimal numerals
- 3 are Pat," I said "we can go back to the output from the Dump command and
- 4 study it. By the way, the word **hex** is often used as a shorter version of
- 5 hexadecimal and we will using both words from now on. The Dump
- 6 command shows the contents of a computer's memory locations and its
- 7 output is arranged in 3 columns." I recreated the Dump command's output
- 8 on the whiteboard and labeled each column. (see Fig. 1)



- 9 "Each row in the **center** column shows the contents of 16 consecutive
- 10 memory locations," I said "and each row in the **left** column contains the
- 11 address of the first byte in that row. For example, the byte **4C** hex is in
- memory location E000, **1B** hex is in location E001, and **E0** hex is in location
- 13 E002. Toward the end of the top row, **F3** hex is in location E00E and **4C**
- 14 hex is in location E00F. We will discuss the **right** column in a moment." As
- 15 I said this I wrote the addresses for some of the bytes in the first row and
- 16 drew arrows pointing from the addresses to the bytes they contained.
- 17 Pat studied the output for a while then asked "What address comes after
- 18 E00F hex?"
- 19 "The same counting rules that we used with decimal numerals and binary
- 20 numerals also apply to hexadecimal numerals." I said "In this case, when 1

- 21 is added to E00F hex, the 'F' roles around to 0 and 1 is added to the column
- 22 to its left. The result is E010 hex and notice how this is the address of the
- 23 first byte in the second row." I circled locations E00F hex and E010 hex in
- 24 red and then drew a red line pointing from location E00F hex to location
- 25 E010 hex. (again, see Fig. 1)
- 26 Then I said "What numeral is in memory location E010 hex, Pat?"
- 27 "A7 hex." said Pat.
- 28 "Very good, now what are the contents of memory locations E04E hex, E076
- 29 hex, and E08C hex?" I asked.
- 30 Pat looked at the output again and replied "Memory location E04E hex
- 31 contains C8 hex, location E076 hex contains CD hex, and location E08C hex
- 32 contains F8 hex."
- 33 "Excellent!" I said "I think you now understand how the Dump command
- 34 displays memory locations."
- 35 "What's the little dash for that is in the middle of each row?" asked Pat.
- 36 "The dash," I replied "divides each row into 2 groups of 8 bytes. It is added
- 37 to the output to make it easier to find a given address in a row. For
- 38 example, if I wanted to know what the contents of location E028 hex was, I
- 39 would find the row which began with address E020 hex, then I would locate
- 40 the address that was to the immediate right of the dash."
- 41 "Okay," said Pat "That makes sense. I think I understand how the first two
- 42 columns work, but what is in the third column?"

#### 43 American Standard Code For Information Interchange (ASCII)

- 44 "Do you remember our discussion about contextual meaning and how
- 45 numerals in a computer can be made to represent any idea one can think
- 46 of?" I asked.
- 47 "Yes," replied Pat "I remember".
- 48 "There is a specification called the **American Standard Code for**
- 49 **Information Interchange**, or **ASCII**, which associates all of the symbols

- 50 (or **characters**) on a keyboard with the numerals between 0 and 127 in
- 51 the decimal numeral system. Since 0 through 127 in the decimal numeral
- 52 system is equivalent to 0 through 7F in the hexadecimal numeral system,
- 53 the ASCII characters can also be thought of as being associated with these
- 54 hexadecimal numerals too."
- 55 "Does this mean that the ASCII characters are also associated with a range
- of binary numerals?" asked Pat.
- 57 "Yes," I replied "and the binary numerals that they are associated with are
- 58 00000000 through 011111111. I will draw a table on the whiteboard which
- 59 shows most of the ASCII characters along with the decimal and hexadecimal
- 60 numerals that they are associated with. We could have also included the
- 61 binary numerals in this table but it is so easy to convert the hexadecimal
- 62 numerals to binary that we will leave them off." I then created the table
- 63 while Pat watched. (see Table 1)

ASCII (American Standard Code for Information Interchange ) Chart

Dec	Hex	Char	Dec	Hex	Char	Dec		Char
10	0a	Linefeed/Newline	63	3F	?	96	60	`
13	0d	Carriage Return	64	40	@	97	61	a
32	20	Space	65	41	Α	98	62	b
33	21	!	66	42	В	99	63	С
34	22	"	67	43	С	100	64	d
35	23	#	68	44	D	101	65	е
36	24	\$	69	45	Ε	102	66	f
37	25	%	70	46	F	103	67	g
38	26	&	71	47	G	104	68	h
39	27	'	72	48	Н	105	69	i
40	28	(	73	49	I	106	6A	j
41	29	)	74	4A	J	107	6B	k
42	2A	*	75	4B	K	108	6C	ı
43	2B	+	76	4C	L	109	6D	m
44	2C	,	77	4D	M	110	6E	n
45	2D	-	78	4E	Ν	111	6F	0
46	2E		79	4F	0	112	70	р
47	2F	1	80	50	Р	113	71	q
48	30	0	81	51	Q	114	72	r
49	31	1	82	52	R	115	73	S
50	32	2	83	53	S	116	74	t
51	33	3	84	54	Τ	117	75	u
52	34	4	85	55	U	118	76	V
53	35	5	86	56	V	119	77	W
54	36	6	87	57	W	120	78	Х
55	37	7	88	58	Χ	121	79	У
56	38	8	89	59	Υ	122	7A	Z
57	39	9	90	5A	Z	123	7B	{
58	3A	:	91	5B	[	124	7C	
59	3B	;	92	5C	\	125	7D	}
60	3C	<	93	5D	]	126	7E	~
61	3D	=	94	5E	۸			
62	3E	>	95	5F	_			
			Т	Γable 1	_			

"Each row in the **right** column of the Dump command's output contains 16
ASCII characters," I said "and each of these characters is matched with one
of the 16 bytes in the **center** column. The leftmost byte is matched with the
leftmost ASCII character, the next byte to the right is matched with the next
ASCII character, and so on. The ASCII characters that are **periods** are
either actual periods or they represent a number that is not matched with
any of the ASCII characters."

71 "Why is the last ASCII character in the second row blank?" asked Pat.

- 72 "What byte is that blank associated with?" I asked.
- 73 Pat matched the blank character with the last byte in the second row then
- 74 said "the blank is matched with 20 hex."
- 75 "And what character is the 20 hex matched with in the ASCII table?" I
- 76 asked.
- 77 Pat located 20 hex in the ASCII table then said "A space! The blank
- 78 character is really a space!"
- 79 "Correct!" I said. "This is the ASCII character that is associated with the
- 80 space on a keyboard."
- 81 Pat looked at the 2 ASCII characters that were associated with the decimal
- 82 numerals 10 and 13 then said "What are the Newline and Carriage Return
- 83 characters?"
- 84 I replied "The ASCII characters that are associated with the decimal
- 85 numerals between 0 and 31 are called **control characters**. These
- 86 characters do not print symbols and instead they were created to control
- 87 the old mechanical teletypes that use to be used as input/output devices for
- 88 computers. These control characters are still used to control a text
- 89 interface to a computer and I have included the 2 most commonly used ones
- 90 in the table.
- 91 When a display receives a **Carriage Return**, it moves the cursor to the left
- 92 side of the display. When it receives a **Linefeed** character, it drops the
- 93 cursor down to the next line. Some computers use the **Linefeed** character
- 94 to move the cursor to the left side of the display, and also drop it down one
- 95 line, in one operation. When it is used in this manner it is called a **Newline**
- 96 character."
- 97 Pat looked at the column of ASCII characters in the memory dump for a
- 98 while then said "It does not seem like there are very many ASCII characters
- 99 in this area of memory. Why is that?"
- 100 "The reason could be that we are looking at an area of memory that has
- 101 garbage in it," I said "or these bytes may be associated with some other
- 102 context than the ASCII character context."

- 103 "Can we look at an area of memory that does have some ASCII characters in
- 104 it?" asked Pat.
- 105 "We can do something even better than that!" I said. "Lets put some
- 106 numerals in memory ourselves that represent ASCII characters and then
- 107 use the Dump command to look at them."
- 108 "Okay!" said Pat "How do we do that?

#### 109 The Dump Command And The Enter Command

- 110 "First, we must launch MathRider then open the U6502 emulator. What I
- 111 usually do after opening the U6502 emulator is to send a question mark
- 112 character to the UMON65 monitor that is running on it. If the monitor
- 113 responds with the help message, then we know that the emulator is running
- 114 correctly." I did these operations and the monitor displayed the following
- 115 help message. Feel free to work along with Pat and I on your own system
- 116 as we explore the monitor.

```
117
        ?
      Assemble A start_address
Breakpoint B (+,-,?) address
Dump D [start_address [end_address]]
Enter E address list
Fill F start_address end_address lis
118
119
120
121
122
       Fill
                              F start address end address list
                               G [start address]
123
       Go
124
                              H or ?
       Help
125
       Load
       Move M start_address end_address destination_address
Register R [PC,AC,XR,YR,SP,SR]
Search S start_address end_address list
Trace T [start address [value]]
126
127
128
129
       Unassemble U [start_address [end_address]]
130
```

- 131 "The monitor program is called **umon65** and it has a manual that describes
- 132 what each command does. Lets see what it has to say about the Dump
- 133 command." I located the manual for umon65 and here is the information it
- 134 contained about the Dump command:

```
135 DUMP COMMAND
```

- 136 SYNTAX: D [START\_ADDRESS [END\_ADDRESS]] where START\_ADDRESS and END\_ADDRESS
- 137 are 4 digit hexadecimal numbers.
- 138 DESCRIPTION: The purpose of the dump command is to allow the user to dump
- 139 (print) the contents of the specified address locations. Each line of the
- 140 dump command's output consists of a starting dump address, the contents of

176

177

EXAMPLE:

E 0200 F6

E 0200 23,6C,3A,D1

the 16 address locations beginning with the start address, and the ASCII 142 conversion for each of the 16 dumped addresses. If no end address is 143 specified then only 1 line is dumped starting at the start address. If no 144 start address is specified then 1 line is dumped starting at the user's 145 current Program Counter. 146 EXAMPLE: 147 D 1000 E0FF 148 D 1000 149 "What are the brackets for after the command?" asked Pat. 150 "Information in brackets like [START ADDRESS [END ADDRESS]] indicate 151 optional parameters that can be passed to a command." I replied. "In this 152 case, passing a **start address** is optional and if a **start address** is passed, 153 then including an end address is optional." 154 155 "Okay," said Pat "I understand." 156 "Now," I said "lets use the Dump command to look at a section of memory 157 that does not have a context associated with it yet." I entered d 0200 024f and the emulator displayed the contents of these memory locations: 158 159 -d 0200 024f 160 161 162 163 164 165 "The command that allows the user to enter bytes into memory is called the Enter command," I said "and here is the information that the umon65 166 167 manual contains on this command." I then located the Enter command's 168 section in the manual and this is what it contained: 169 ENTER COMMAND 170 SYNTAX: E ADDRESS LIST where ADDRESS is a 4 digit hexadecimal number and 171 LIST is one 2 digit hexadecimal number or up to five 2 digit hexadecimal 172 numbers separated by commas. 173 DESCRIPTION: The purpose of the Enter command is to allow the user to 174 enter one byte or a list of bytes directly into memory at a specified address.

- 178 "Now Pat," I said "use the Enter command to place the hexadecimal
- 179 numeral that represents an ASCII 'A' into memory location 0200 hex. Then
- 180 use the Dump command to see if the number was indeed placed there."
- 181 Pat looked at the ASCII table on the whiteboard and determined that 41 hex
- represented a capital letter 'A'. Pat then typed e 0200 41 <enter>
- 183 followed by **d 0200 024f <enter>** in the telnet window and the following
- 184 information was displayed:

- 192 Pat looked at the 41 that was placed into location 0200 hex and then looked
- 193 at the capital letter 'A' that was now present in the beginning of the first
- 194 row of ASCII characters.
- 195 "There's the 41 hex and there's the capital letter 'A' that goes with it!" cried
- 196 Pat. "This is fun!"
- 197 "Yes, this is fun!" I said "I was just as thrilled as you are when I placed a
- 198 capital 'A' in memory for the first time and I still enjoy manually placing
- 199 data into memory. Go ahead and place a capital letter 'B' into memory
- 200 location 0201hex and a capital letter 'C' into memory location 0202 hex."
- 201 Pat typed the following to enter the two values into memory and to verify
- 202 that the values were indeed present in the specified memory locations:


```
203
-e 0201 42
204
-е 0202 43
205
-d 0200 024f
206
207
208
209
210
```

- 211 "I think I understand how to view the contents of memory locations and how
- 212 to change the contents of memory locations." said Pat "Now I would like to
- 213 see how to view and change the contents of registers."

#### 214 The Register Command

- 215 "The monitor's **Register** command is used to view and change the contents
- of registers and here is what the umon65's manual says about it." I said. I
- 217 then brought up the Register command's section on the computer screen:
- 218 REGISTER COMMAND
- 219 SYNTAX: R [PC, AC, XR, YR, SP, SR]
- 220 DESCRIPTION: The purpose of the Register command is to dump (print) the
- 221 contents of all the microprocessor's user accessible registers or to modify
- 222 any of these registers individually. If R is entered without specifying a
- 223 register to be modified, then the contents of all the registers are shown.
- 224 If a specific register is given after the R command, then the current
- 225 contents of this register are shown and an opportunity is given to change the
- 226 contents of this register.
- 227 EXAMPLE:
- 228 F
- 229 R AC
- 230 "Send either an upper case or lower case 'R' to the monitor," I said "and lets
- 231 see what it displays."
- 232 Pat did this and the following information was printed:
- 233 r
- 234 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 235 102C 00 FC 00 FD 00010110
- 236 "We have already discussed the **Program Counter** register and the 'A'
- 237 register but there four registers in this listing we have not discussed vet and
- 238 one register we have discussed which is missing. The register which is
- 239 missing is the **Instruction Register** and the reason for this is because it is
- 240 not directly accessible by the programmer.
- In addition to the 'A' register, the 6502 contains 2 **index** registers called
- 242 register **X** (**XR** in the listing) and register **Y** (**YR** in the listing). The
- 243 index registers can be used for a number of purposes. One purpose they
- 244 serve is to allow the CPU to access a desired memory location by holding a
- value which indicates how many locations ahead in memory from a 'base'

- address this memory location is. These two index registers can also be used as counters and to temporarily hold values.
- 248 The Stack Pointer register (SP in the listing) and the Status Register
- 249 (SR in the listing) are special registers which we will discuss later. I will
- 250 now draw a version of the CPU and memory diagram we used earlier which
- 251 contains the new registers and which also has its numerals expressed in
- 252 hexadecimal." I then drew the diagram on the whiteboard. (see Fig. 2)



- 253 "Notice that all of the registers and memory locations are 8 bits wide except
- 254 for the program counter, which is 16 bits wide." I said.
- 255 "Why is the program counter 16 bits wide?" asked Pat.
- 256 "How many patterns can be formed by 16 bits?" I asked.
- 257 Pat picked up the calculator, entered 2<sup>16</sup> then said "65536."

- 13/25
- 258 "This means that the program counter is able to point to a maximum of
- 259 65536 memory locations." I said. "The lowest address it can point to is 0
- 260 and the highest address it can point to is 65535 decimal or FFFF hex."
- 261 "That makes sense," said Pat "because if the program counter was only 8
- bits wide, it would only be able to point to 2<sup>8</sup> or 256 memory locations. 262
- 263 This wouldn't be very many memory locations to have in a computer."
- 264 Pat then said "How can we change the number that is in the 'A' register?"
- 265 "First enter a Register command to see what value is currently in the 'A'
- 266 register, then enter **r** ac and when the colon ':' is displayed enter the byte
- you want to have placed into the 'A' register." Pat then did as I suggested: 267

```
268
   PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR)
269
270
     E02C 00 FC 00 FD 00010110
271
   -r ac
272
   00
273
   :41
274
   -r
275
   PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR)
    E02C 41 FC 00 FD 00010110
276
```

- 277 "It worked!" cried Pat.
- 278 "Yes, it did!" I replied. "Our next step is to have you enter your first
- machine language program." 279

#### A Simple Machine Language Program

- 281 "Earlier, we created a small machine language program that added 10
- 282 decimal to 5 decimal then placed the sum into a memory location. I will
- 283 write this program on the whiteboard and include the assembly language
- 284 version of each instruction along with the address in memory which each
- instruction starts at. Instead of starting a 0, this program will start at 0200 285
- 286 hex." (see Fig. 3)

280

Figure 3

288

289

290


291

292

293

294

295



#### Addressing Modes

"In this program, the opcode for the LDA instruction is A9 hex and it is in memory location 0200 hex. Earlier, we had used 169 decimal to represent this instruction because we had not discussed hexadecimal yet. Another topic we did not discuss earlier is that some assembly language instructions are able to access memory locations in different ways. These different ways are called **addressing modes** and I will draw a table on the whiteboard which shows most of the addressing modes that the LDA instruction can use.

This table will contain the name of the addressing mode, an example of what its assembly language syntax looks like, the opcode that is associated with the addressing mode, and the number of bytes that each version of the instruction takes." I then created the following table:

### 300 LDA ( LoaD A register ) Instruction

301	MODE	ODE SYNTAX		<b>BYTES</b>
302	Immediate	LDA #41h	A9	2
303	Absolute	LDA 02A0h	AD	3
304	Absolute,X	LDA 02A0h,X	BD	3
305	Absolute,Y	LDA 02A0h,Y	В9	3
306	Indirect,X	LDA (20h, X)	A1	2
307	Indirect.Y	LDA (20h),Y	В1	2

308 "What does syntax mean?" asked Pat.

"Syntax refers to the rules that determine how to properly type an instruction." I replied. "If a programmer does not follow the language's syntax rules when typing in a program, the software that transforms the source code into machine language will become confused and then issue

- 313 what is called a syntax error. For example, typing LMA instead of LDA
- 314 would be considered a syntax error."
- 315 "Okay." said Pat. "Now, can you tell me more about these addressing
- 316 modes?"
- 317 "The **immediate** addressing mode indicates that the data the instruction is
- 318 going to work on has been placed **immediately** after the **opcode** in
- 319 memory. I said. "In our program, the number 10 decimal will be copied
- 320 into the 'A' register when the instruction is executed, therefore I placed a
- 321 OA hex into memory location 0201 hex. This is a 2 byte instruction because
- 322 it consists of an opcode and 1 byte of immediate data.
- 323 In the assembly language we are using, a pound sign '#' is placed before a
- 324 piece of data to indicate that immediate addressing mode should be used to
- 325 access it. Also notice that when a 'd' is placed at the end of a numeral, it
- 326 indicates that it is a **decimal** numeral. An 'h' at the end of a numeral
- 327 indicates that it is a **hexadecimal** numeral and a 'b' at the end of a numeral
- 328 indicates that it is a **binary** numeral.
- 329 **Absolute** addressing mode allows the programmer to specify the address of
- 330 the memory location that an instruction will either copy a byte from or copy
- 331 a byte to. The absolute mode example in the syntax column indicates that
- 332 the LDA instruction will copy the numeral that is in location 020A hex into
- 333 the 'A' register when it is executed.
- 334 The **Absolute, X** and **Absolute, Y** addressing modes are similar to the
- 335 normal **Absolute** addressing mode except that the contents of either the 'X'
- 336 register or the 'Y' register are added to the absolute address that the
- 337 programmer specified in order to determine which location in memory will
- 338 have a byte copied from it or copied into it.
- 339 The **Indirect,X** and **Indirect,Y** addressing modes are somewhat advanced
- 340 and therefore I will wait until you have gained some programming
- 341 experience before explaining them."
- 342 "The Immediate and Absolute addressing modes make sense to me," said
- 343 Pat "but I am a bit fuzzy on how the Absolute,X and Absolute,Y addressing
- 344 modes work."
- 345 "That is okay, Pat." I replied "It is normal for machine language and
- 346 assembly language to be confusing when it is first being learned. All these

```
347
     addressing modes will become clearer to you when you start using them.
     For now, though, I suggest that you use the Enter command to place the
348
349
     machine language instructions for this simple program into memory."
350
     Here is what Pat typed while entering the program:
351
     -e 0200 a9
352
     -е 0201 0a
     -е 0202 69
353
     -е 0203 05
354
355
     -e 0204 8d
356
     -е 0205 08
     -е 0206 02
357
358
     -е 0207 00
359
     -d 0200
     0200 A9 0A 69 05 8D 08 02 00 - 00 00 00 00 00 00 00 .i......
360
361
     The Unassemble Command
     Pat looked at the output from the Dump command then said "There's my
362
363
     first machine language program! Looking at just the machine language
     version of a program's instructions, without having their assembly language
364
365
     equivalent available, is difficult though."
      "It is difficult," I agreed "but fortunately the monitor has a command that
366
     will display a machine language program's instructions along with the
367
368
     assembly language version of these instructions."
      "There is?!" asked Pat. "Which command is it?"
369
370
      "It is called Unassemble and here is what the umon65's manual has to say
371
     about it." I then brought up the section of the manual that contained
     information about the Unassemble command:
372
373
     UNASSEMBLE COMMAND
374
     SYNTAX: U [START ADDRESS [END ADDRESS]] where START ADDRESS and
```

END ADDRESS are 4 digit hexadecimal numbers.

```
DESCRIPTION: The purpose of the Unassemble command is to convert machine
377
     language instructions present in memory into their assembly language
     equivalents and display them. If the U command is given with no starting address, then approximately 1 screen full of instructions will be unassembled
378
     starting at the current user's Program Counter. If a start address is given,
381
     then approximately 1 screen full of instructions will be unassembled starting
382
     at this start address. If an end address is specified, than all instructions
383
     between the start address and the end address will be unassembled.
384
     EXAMPLE:
385
386
     U 1000
     U 1000 10FF
387
```

388 "Enter the command **u 0200** Pat and see what happens." I said and this is what the Unassemble command displayed:

```
390
     -u 0200
391
     0200 A9 0A
                      LDA #0Ah
           69 05 ADC #05h
8D 08 02 STA 0208h
392
     0202
393
     0204
394
     0207
           00
                      BRK
395
     0208
           00
                      BRK
396
     0209
           00
                      BRK
397
     020A
           00
                      BRK
398
     020B
           00
                      BRK
399
     020C
           00
                      BRK
400
     020D
           00
                      BRK
401
     020E
           00
                      BRK
402
     020F
           00
                      BRK
403
     0210
           00
                      BRK
404
    0211
           00
                      BRK
405
     0212
           00
                      BRK
406
     0213
           00
                      BRK
407
     0214
          00
                      BRK
```

- 408 "That's amazing!" said Pat. "This programming stuff just keeps getting
- 409 more and more interesting!"
- 410 Pat studied the output from the Unassemble command for a while then said
- 411 "I know what the LDA, ADC, and STA instructions do, but what does the
- 412 BRK command do?"
- 413 "The BRK command generates what is called a **software interrupt** and an
- 414 interrupt causes the Program Counter to be set to a predefined address in
- 415 memory where a special program called an **interrupt handler** has been
- 416 placed. We will discuss interrupts later but for now you can think of the
- 417 BRK command as the instruction that ends a program. When a BRK

- 418 instruction is executed, control will be transferred from the program back to
- 419 the monitor."
- 420 "How do we run a program?" asked Pat.
- 421 "We will cover that next". I replied.

#### 422 The Go Command

- 423 "The command that is used to execute a program with the monitor is the Go
- 424 command," I said "and here is the section in the umon65 manual that talks
- 425 about it." I then located the section on the Go command in the manual:
- 426 GO COMMAND
- 427 SYNTAX: G [START ADDRESS] where START ADDRESS is a 4 digit hexadecimal
- 428 number.
- 429 DESCRIPTION: The purpose of the Go command is to allow the user to start
- 430 execution of a program that was placed into memory. Execution will begin at
- 431 START ADDRESS or if a start address is not given then execution will begin at
- 432 the user's current Program Counter.
- 433 EXAMPLE:
- **434** G
- **435** G 1000
- 436 "Before running the program with the Go command," I said "the first thing
- 437 you should do is to dump the 16 bytes starting at 0200 hex so that we can
- 438 verify that the program is indeed in memory and also that location 0208 hex
- 439 contains 00. The reason for making sure that 0208 hex has 00 in it is so we
- 440 can watch it change when the program places the sum it calculates into it."
- 441 Pat dumped the memory starting at address 0200 hex and we both verified
- that the program was there and that 0208 hex had 00 in it:
- **443** -d 0200
- 444 0200 A9 0A 69 05 8D 08 02 00 **00** 00 00 00 00 00 00 .i......
- 445 "The next thing you should do is to look at the contents of the 'A' register
- 446 before running the program so you can see what it is changed to after the
- 447 program is finished." Pat did this too:
- 448 -r

- 451 "Now, execute the program by entering **g 0200**." I said. Pat ran the
- 452 program and this was the result:
  - **453** -g 0200
- 454 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 455 0207 **0F** FE FF FD 00010100
- 456 -
- 457 "When you ran the program," I said "each of the instructions was executed
- 458 one after the other and when the BRK command was executed, control was
- 459 transferred back to the monitor and the monitor displayed the contents of
- 460 the registers. The monitor then displayed the dash prompt '-' indicating
- 461 that it was ready to accept commands again."
- Pat compared the contents of the 'A' register before the program was
- 463 executed and after it was executed. After a while Pat asked "why does the
- 464 'A' register have a 0F hex in it?"
- 465 "When 10 decimal is added to 5 decimal, what is the sum?" I asked.
- 466 "15 decimal." replied Pat.
- 467 "And what is the hexadecimal equivalent of 15 decimal?" I asked.
- 468 Pat looked at the binary/decimal/hexadecimal table we had created earlier,
- 469 located the row that contained 15 decimal then said "0F is the hex
- 470 equivalent of 15 decimal! I understand now, the monitor can only display
- 471 hexadecimal numerals and, if a person wants to know what a value is in
- 472 decimal, they have to do the conversion themselves."
- 473 "Correct, Pat." I said. "The nice thing is that most scientific calculators are
- 474 able to convert between decimal, binary, and hexadecimal very easily. The
- 475 Windows operating system also has a calculator application that can do
- 476 these conversions if it is placed into scientific mode."
- 477 "I didn't know that!" cried Pat. Then Pat picked up the calculator we had
- 478 been using and looked at it with new eyes. I explained how to use the
- 479 calculator to convert between the numeral systems and Pat was very
- 480 excited about this.
- 481 "When I get home," said Pat "the first thing I am going to do is to find my

- 482 scientific calculator and see if it can do numeral conversions!"
- 483 I smiled at this then said "We need to check one last thing with this
- program, Pat." I said. 484
- "What's that?" asked Pat. 485
- 486 "We need to see if the sum that was calculated was placed into location
- 487 0208 hex." I replied.
- 488 "That's right!" said Pat. Then Pat dumped the area of memory that
- contained location 0208 hex and we both looked at it: 489
- -d 0200 490
- 491 0200 A9 0A 69 05 8D 08 02 00 - **0F** 00 00 00 00 00 00 .i.....
- 492 "There's the sum 0F hex, sitting in location 0208 hex just like it should be!"
- 493 said Pat. "It would be nice, though, to be able to run a program 1
- 494 instruction at a time like we did when we were stepping through this
- 495 program on the whiteboard."
- 496 "The monitor is able to run 1 instruction at a time Pat," I said "and what we
- 497 will do is to create a program that adds 3 numbers together and then step
- 498 through it to see how it works."
- 499 The Trace Command
- 500 "The monitor command that allows a program to be executed 1 instruction
- 501 at a time is called the **Trace** and here is its section in the umon65 manual."
- I brought up this section on the monitor and we both read it: 502
- 503 TRACE COMMAND
- 504 SYNTAX: T [START ADDRESS [STEPS]] where START ADDRESS is a 4 digit
- 505 hexadecimal number and STEPS is a 2 digit hexadecimal number.
- DESCRIPTION: The purpose of the Trace command is to allow the user to
- 507 execute a program in memory 1 instruction at a time and dump the contents of
- all the registers after each instruction is executed. Entering the 508
- 509 command without a start address will execute 1 instruction starting at
- 510 user's current Program Counter. If a start address is given without any
- 511 steps, then 1 instruction is executed at the start address. If a number of
- 512 steps is given with a start address, then the number of instructions
- 513 indicated by the steps count will be executed starting at the start address.
- Once the first instruction has been Traced, simply typing T then <enter> will 514
- execute the next instruction in memory.

EXAMPLE:

516

549

```
517
518
     T 1000
     T 1000 OC
519
     "The Trace command is very powerful because it allows one to see exactly
520
     what happens in the registers and in memory after each instruction is
521
522
     executed. Now, I would like you to enter the following program into
     memory using the Enter command." I then wrote this program on the
523
524
     whiteboard and Pat entered into memory:
525
     0200 A9 0A 69 05 69 02 8D 0A 02 00
526
     "Lets see what this machine language program looks like in assembly
527
     language Pat." I said. "Do you remember how to do this?
528
     "Yes," replied Pat "the Unassemble command is used to view the assembly
     language equivalent of a machine language program." Pat then entered
529
530
     the following command:
531
     -u 0200
     0200 A9 0A LDA #0Ah
532
     0202 69 05 ADC #05h
0204 69 02 ADC #02h
533
534
535
     0206 8D 0A 02 STA 020Ah
536
     0209 00
                   BRK
537
     020A 00
                    BRK
538
     020B 00
                     BRK
539
     "What does this program do Pat?" I asked?
540
     Pat studied the program then said "It looks like the program is adding 10
541
     decimal and 5 together and then adding 2 to their sum. The final sum is
542
     then being copied into memory location 020A hex."
543
     "Very good, Pat." I said. "Now, the first step I would like you to perform is
544
     to dump the area of memory which contains location 020A hex so that we
545
     can see what it contains before we copy a number into it." Pat used the
546
     Dump command to do this as follows:
547
     -d 0200
548
     0200 A9 0A 69 05 69 02 8D 0A - 02 00 00 00 00 00 00 .i.i......
```

"The next step is to view the registers so that we can see what they contain

- before the program changes them." I said and then Pat executed a Register 550 command:
- 551
- 552
- 553 PqmCntr(PC) Accum(AC) XReq(XR) YReq(YR) StkPtr(SP) NV-BDIZC(SR) 554 E02C 00 00 00010110 FC
- 555 "Now," I said "enter a t 0200 command and this will execute the LDA #0A
- 556 instruction which is at memory location 0200 hex." Pat entered the Trace
- command and here was the result: 557
- 558 -t 0200
- 559 PgmCntr(PC) Accum(AC) XReq(XR) YReq(YR) StkPtr(SP) NV-BDIZC(SR) 560 **OA** FC 00 FD 0202 00010100
- 0202 69 05 561 ADC #05h
- 562 "Notice that the 'A' register now has the number 0A hex in it because the
- LDA instruction copied it there." I said. "Also notice that the Trace 563
- 564 command unassembled the next instruction to be executed so that we could
- 565 see what will happen during the next trace."
- "This is exciting!" said Pat. "Can I trace the next instruction?" 566
- 567 "In a moment," I replied "but first tell me what you think the result of
- 568 executing the next instruction will be."
- 569 Pat studied the output from the Trace command for a while then said "The
- 570 ADC instruction is going to add 5 to the contents of the 'A' register and then
- 571 place the result back into the 'A' register. The 'A' register currently holds
- 572 0A hex which is 10 decimal and 10 plus 5 is 15 decimal. 15 decimal is 0F
- hex so after we trace this instruction the number 0F hex should be present 573
- 574 in register 'A'.
- "Okay, perform another trace and lets see if you are right." I said. Pat 575
- traced the next instruction and this was the result: 576
- 577
- 578 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR) 579 0204 0F FC 0.0 FD 00010100
- 580 0204 69 02 ADC #02h
- 581 "I was right!" cried Pat.

- 582 "Yes, you were right," I said "now what will be the result of executing the
- 583 next instruction?
- "Well," said Pat "2 is going to be added to the 0F hex that is currently in the
- 585 'A' register and the result will be placed back into the 'A' register. OF hex
- 586 plus 1 is 10 hex and 10 hex plus 1 is 11 hex so the number 11 hex should be
- 587 present in the 'A' register after the next instruction is executed." Pat then
- 588 entered another Trace command and this was the result:

```
589 -t

590 PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR)
591 0206 11 FC 00 FD 00010100

592 0206 8D 0A 02 STA 020Ah
```

- 593 Pat smiled then said "I was right again! So far machine language is not as
- hard as I thought it was going to be, but it is very different than I thought it
- 595 would be. I would have never imagined that this was how a computer really
- 596 worked at its lowest levels."
- 597 "Sometimes I still find it hard to believe that all of the complex things
- 598 computers are able to do are made possible by a small set of very simple
- 599 machine language instructions." I said. "Lets finish this program by tracing
- 600 the last instruction which will copy the final sum from the 'A' register to
- 601 memory location 020A hex. We will not need to trace the BRK instruction
- 602 because the Trace command already brings us back into the monitor when
- 603 it is done executing." Pat then traced the last instruction and this was the
- 604 result:

```
605
    PgmCntr(PC) Accum(AC) XReg(XR) YReg(YR) StkPtr(SP) NV-BDIZC(SR)
606
       0209
               11
                         FC
                                  00 FD
                                                    00010100
607
    0209 00
                  BRK
608
    -d 0200
609
    0200 A9 0A 69 05 69 02 8D 0A - 02 00 11 00 00 00 00 0 ..i.i.......
610
```

- After we verified that the number 11 hex was copied from the 'A' register
- 612 into memory location 020A hex I said "This was your first experience with
- 613 programming a computer in machine language. Understanding how a
- 614 computer works at the machine language level will help you to write better
- 615 programs when you start learning how to program in higher level

- 616 languages. The next time we meet, we will be taking one step towards
- 617 those higher level languages by learning how to program in assembly
- 618 language."
- 619 "I can't wait!" said Pat.
- 620 Exercises
- 621 1) The umon65 monitor program is written in 6502 assembly language and
- 622 it is located in memory starting at address E000h. Use the Unassemble
- 623 command to look at the beginning part of this program. Note: You can type
- 624 'u E000' to begin the unassemble process and then just type a 'u' with no
- parameters to unassemble further sections of the program.
- 626 2) Write a machine language program that adds the numbers 1,2,3,4,5, and
- 627 6 together and places the sum into location 0280h. Begin the program at
- 628 0200h. Run the program and verify that it works correctly (if you would
- 629 like to save your program, unassemble it, highlight the unassembled
- 630 program with the mouse, and then type <ctrl>c to copy it. It can then be
- 631 pasted into another application such as a text editor.)
- 632 3) Enter in the following short machine language programs into the
- 633 emulator one at a time and execute each one using the Trace command.
- 634 Look closely at what happens to the register or memory location that is
- being worked with after each trace is executed. Also, pay close attention to what happens to the program counter.

```
; (a)
     0200 A2 00
639
                      ldx #0h
640
     0202 E8
                      inx
641
     0203 E8
                      inx
642
     0204 E8
                      inx
643
    0205 E8
                      inx
644
    0206 E8
                      inx
645
     0207 00
                      brk
646
647
     ; (b)
648
     0200 A0 00
                      ldy #0h
649
    0202 C8
                      iny
650
    0203 C8
                      inv
651
    0204 C8
                      inv
652
     0205 C8
                      iny
653
     0206 C8
                      iny
     0207 00
654
                      brk
655
656
     ; (c)
657
     0200 A2 04
                      ldx #04h
658
     0202 CA
                      dex
```

```
6502 Machine Language
     v2.03
                                                                         25/25
659
     0203 CA
                     dex
660
     0204 CA
                     dex
661
     0205 CA
                     dex
662
     0206 CA
                     dex
663
     0207 CA
                     dex
664
     0208 CA
                     dex
665
     0209 00
                     brk
666
667
     ; (d)
668
669
     0200 A9 00
                     lda #0h
     0202 8D 20 02
                    sta 0220h
670
                    inc 0220h
671
     0205 EE 20 02
                    inc 0220h
672
     0208 EE 20 02
673
     020B EE 20 02
                     inc 0220h
674
     020E 00
                     brk
675
676
677
     ; (e)
     0200 A2 08
678
                     ldx #8d
679
     0202 CA
                     dex
680
    0203 D0 FD
                     bne 0202h
681
     0205 00
                     brk
682
683
    4) Launch a DOS shell window and type the following at the command prompt:
684
     debug
685
686
     -d 0000 ffff
687
    (On Windows machines, select Start -> Run and then type "command" or "cmd" in
```

the Run window's text box in order to launch the shell.)

688