50.002 Computation Structures Software Abstraction & Assembly Language

Oliver Weeger

2018 Term 3, Week 5, Session 1





β machine language: 32-bit instructions



3 registers:

OPCODE \mathbf{r}_c \mathbf{r}_{a} r_b unused

arithmetic: ADD, SUB, MUL, DIV compare: CMPEQ, CMPLT, CMPLE

boolean: AND, OR, XOR shift: SHL, SHR, SRA

Ra and Rb are the operands,

Rc is the destination.

R31 reads as O, unchanged by writes

2 registers, 1 const:

16-bit signed constant OPCODE

arithmetic: ADDC, SUBC, MULC, DIVC

compare: CMPEQC, CMPLTC, CMPLEC

boolean: ANDC, ORC, XORC

Two's complement 16-bit constant for numbers from -32768 to 32767; sign-extended to 32 bits before use.

shift: SHLC, SHRC, SRAC branch: BNE/BT, BEQ/BF (const = word displacement from PC_{NEXT})

jump: JMP (const not used)

memory access: LD, ST (const = byte offset from Reg[ra])

6-bit OPCODES:

2:0								
5:3	000	001	010	011	100	101	110	111
000								
001								
010								
011	LD	ST		JMP		BEQ	BNE	LDR
100	ADD	SUB	MUL*	DIV*	CMPEQ	CMPLT	CMPLE	
101	AND	OR	XOR		SHL	SHR	SRA	
110	ADDC	SUBC	MULC*	DIVC*	CMPEQC	CMPLTC	CMPLEC	
111	ANDC	ORC	XORC		SHLC	SHRC	SRAC	·

β [Mem] instructions: LD & ST



- Load: "Load into \mathbf{r}_c the contents of the memory location whose address is the content of \mathbf{r}_a plus CONST"
- $Reg[r_c] \leftarrow Mem[Reg[r_a] + sxt(CONST)]$
- LD(ra, Const, rc)or LD(Const, rc) = LD(R31, Const, rc)

OPCODE	r _c	ra	16-bit signed CONST
6 bits	5 bits	5 bits	16 bits

- Store: "Store the contents of \mathbf{r}_{c} into the memory location whose address is the content of \mathbf{r}_{a} plus CONST"
- Mem[Reg[r_a] + sxt(CONST)] \leftarrow Reg[r_c]
- ST(rc, Const, ra)
 or ST(rc, Const) = ST(rc, Const, R31)

BYTE ADDRESSES, but only 32-bit/4-byte word accesses to word-aligned addresses are supported. Low two address bits are ignored!

β [PC] instructions: BEQ, BNE & JMP



• Branch instructions for conditionals: "If \mathbf{r}_a is 0 (not 0), save the current location (PC) into \mathbf{r}_c and continue at **label** location (add CONST to PC)"

```
BNE (ra, label, rc) (branch if not equal)
• BEQ(ra, label, rc) (branch if equal)
 PC = PC + 4;
                                                    PC = PC + 4;
 Reg[\mathbf{r}_c] = PC;
                                                    Reg[\mathbf{r}_c] = PC;
 if (REG[r_a] == 0)
                                                    if (REG[r_a] != 0)
      PC = PC + 4*CONST
                                                        PC = PC + 4*CONST
               5 bits
                                     16 bits
       6 bits
                      5 bits
                                                          CONST = (label - < addr of BNE/BEQ > )/4 - 1
                                                           (up to 32767 instructions before/after BNE/BEQ)
      OPCODE
                r
                       r_a
                                16-bit signed CONST
```

• Here, the <u>label</u> refers directly to an address, which needs to be converted to the **CONST** that specifies the word offset of the address from the current PC.

```
    Abbreviations:
        BEQ(ra,label) = BEQ(ra,label,R31) = BF(...)
        BNE(ra,label) = BNE(ra,label,R31) = BT(...)
    Unconditional branches:
        BR(label,rc) = BEQ(R31,label,rc)
        BR(label) = BEQ(R31,label,R31)
```

Encoding binary instructions



What we want to do:

"Add the contents of R1 to the contents of R2 and store the result in R3"

$$Reg[3] \leftarrow Reg[1] + Reg[2]$$


• 32-bit β instruction:

Assembler language:

• High-level language (C):

c = a+b;

Compilation




IBM 1130 Fortran punched card https://en.wikipedia.org/wiki/Punched card

Interpretation and Compliation




Turing's model of *Interpretation*:



- Start with some hard-to-program universal machine, say M₁
- Write a single program for M₁ which mimics the behavior of some easier machine, say M₂
- Result: a "virtual" M₂


"Layers" of interpretation:



Model of *Compilation*:

- Given some hard-to-program machine, say M₁...
- Find some easier-to-program language L₂ (perhaps for a more complicated machine, M_2); write programs in that language
- Build a translator (compiler) that translates programs from M₂'s language

to M_1 's language. May run on M_1 , M_2 , or some other machine.



Interpretation vs. Compliation



Interpretation & Compilation improve programmability! Both ...

- allow changes in programming model
- afford programming applications in platform (e.g., processor) independent languages
- are widely used in modern computer systems!

	Interpretation	Compilation
How it treats input "x+2"	computes x+2	generates a program that computes x+2
When it happens	During execution	Before execution
What it complicates/slows	Program Execution	Program Development
Decisions made at	Run Time	Compile Time

Design choice: do it at Compile time or at Run time?


Software Abstraction Strategy



- Initial steps: compilation tools
 - <u>Assembler</u> (**UASM**): symbolic representation of machine language Hides: bit-level representations, hex locations, binary values
 - Compiler (C): symbolic representation of algorithm
 Hides: Machine instructions, registers, machine architecture
- Subsequent steps: interpretive tools
 - Operating system
 Hides: Resource (memory, CPU, I/O) limitiations and details
 - Apps (e.g., Browser)
 Hides: Network, location, local parameters

UASM Assembly Language





UASM is

- a program for writing programs ©
- a symbolic **LANGUAGE** for representing strings of bits
- a **PROGRAM** for translating UASM source to binary ("assembler" = primitive compiler)

See beta.uasm in lab files!

UASM Source Language: Byte values



UASM source (text) file:

<u>Translated byte code:</u>

```
in hex:
```

```
-3 127 0b1010 0xA9 10101001
37+0b10-0x10 24-0x1 4*0b110-1 00010111
0xF7&0x1F 33
```

```
1010(bin) 127 -3

10101001 00001010 01111111 11111101 0xA90A7FFD

00010111 00010111 00010111 00010111 0x17171717

00100001 0x00000021
```

- Values of successive bytes to be loaded into memory
- Interpreted from left to right as least to most significant bytes
- Values can be decimal, binary (0b), hexadecimal (0x) or **expressions** (+,-,*,/,%,<<,>>,&,|)

UASM Source Language: Symbols



UASM source (text) file:

Symbol	value
а	0x1000
X	123
R0	0
У	0x1008

Translated byte code in memory (in hex):

0x1000: 00 00 00 08

0x1004: 7F 7B F3 01

0x1008: FE 02 01 B0



- Symbols (x = ...) for values, stored in symbol table
- References to current byte address (.),
- Labels (y:) symbols that take the value of current memory address

UASM Source Language: Macros



Macros are parameterized symbols:

Confusing! 32-bit is the word size of the β !

• Macros for writing 16-bit (WORD) and 32-bit (LONG) words:

```
.macro WORD(x) x\%256 (x/256) %256

WORD(0x1234) \rightarrow 12 34

WORD(345) \rightarrow 01 59

.macro LONG(x) WORD(x) WORD(x>>16)

LONG(0x123456) \rightarrow 00 12 34 56
```

• Little/big endian formats: least/most significant byte is stored at lowest memory address:

```
OPCODE
           RC
                    RA
                             RB
                                        UNUSED
```

110000 00000 01111 10000000000000000

```
Assemble Beta op instructions
.macro betaop(OP,RA,RB,RC) {
    .align 4
    LONG((OP<<26)+((RC%32)<<21)+((RA%32)<<16)+((RB%32)<<11))
                                                                 ".align 4" ensures instructions will begin on
 Assemble Beta opc instructions
                                                                word boundary (i.e., address = 0 mod 4)
.macro betaopc(OP,RA,CC,RC) {
    .align 4
    LONG ((OP << 26) + ((RC %32) << 21) + ((RA %32) << 16) + (CC %0 x 10000))
 Assemble Beta branch instructions
.macro betabr(OP,RA,RC,LABEL) betaopc(OP,RA,((LABEL-(.+4))>>2),RC)
```

For Example:

ADDC(R15, -32768, R0) --> betaopc(0×30 , 15, -32768, 0)

The β instructions



```
BETA Instructions:
                              betaop (0x20, RA, RB, RC)
.macro ADD(RA, RB, RC)
                              betaopc (0x30, RA, C, RC)
.macro ADDC (RA, C, RC)
.macro LD(RA,CC,RC)
                              betaopc (0x18, RA, CC, RC)
.macro LD(CC,RC)
                              betaopc (0x18, R31, CC, RC)
.macro ST(RC,CC,RA)
                              betaopc (0x19, RA, CC, RC)
.macro ST(RC,CC)
                              betaopc (0x19,R31,CC,RC)
                             betabr (0x1D, RA, RC, LABEL)
.macro BEQ(RA, LABEL, RC)
                             betabr (0x1D, RA, r31, LABEL)
.macro BEQ(RA, LABEL)
```

More convenience macros (BR, JMP, BF, BT, LDR, MOVE, PUSH, POP, CALL, ...) ... see beta.uasm!

Example assembly

 0×0.4

 0×2.3



```
ADDC (R3, 1234, R17)
    expand ADDC macro with RA=R3, C=1234, RC=R17
betaopc (0x30, R3, 1234, R17)
    expand betaopc macro with OP=0x30, RA=3, CC=1234, RC=17
.aliqn 4
LONG ((0x30 << 26) + ((17832) << 21) + ((3832) << 16) + (1234 % 0x10000))
    expand LONG macro with X=0xC22304D2
WORD (0xC22304D2) WORD (0xC22304D2 >> 16)
    expand first WORD macro with X=0\times C22304D2
0xC22304D28256 (0xC22304D2/256)8256 WORD (0xC223)
    evaluate expressions, expand second WORD macro with X=0xC223
0 \times D2
                0xC223\%256 (0xC223/256)\%256
        0 \times 0.4
    evaluate expressions
```

Example assembler code




Add two numbers x = 35 and y = 99:

Assembly Assembler code: Instructions in memory: 0x0000 LD(x,R1)011000 00001 11111 0000000000010100 $0 \times 0 0 0 4$ LD(y,R2)0000000000011000 00010 ADD (R1, R2, R0) 0x0008 code ST(R0,Z)0x000C 00000 0000000000011100 0x0010 00 0000000 0000000 0000000 0000000 HALT() 0.023 $0 \times 0 0 1 4$ LONG (35) 00000000 00000000 0000000 LONG (99) 0x0018 data 0000000 0000000 0000000 LONG(0) 0x001C 00000000 00000000 00000000 0000000

→ Bsim demo

Programmes and Operating Systems





- Assembly code
- Compiled local: C, C++, Fortran, ...
- Interpreted: Java, Python, ...
- Loaded at reset and running perpetually
- Manages programmes
- Virtual machines for interpreting code

- Writing an OS in assembly is tedious, since instructions are chip/machine-dependent
- → We need machine-independent, high-level programming languages
- C language, developed at Bell Labs in 1972 for programming the UNIX OS
- \rightarrow (Machine-dependent) **Compiler** that directly translates \mathbb{C} code into byte code

C language overview: an example



```
int f(int a, int b) {
                                            — (local) variable identifier
 procedure identifier
                        int (c)=1
                                         literal
                        return a+b+c;
                                                   expression
 return type
                                          operator
                     int(g)(int a, int(b)
                                                   parameter
        procedures
                        return a-b;
                                          data type
        (functions)
                                                   statement
                     int main(int argc, char* argv[]) {
programme
entry point
                        int a,b;
                                           reference to address
                        printf("a=")
    output to
                        scanf("%d", &a);
                        printf("b=")
console/screen
                        scanf("%d", &b);
                                                                        comments
                        if (a>b)
     input from
                           printf("%d\n", g(a,b));
                                                    // returns a-b
console/keyboard
                        else
                           conditional
                        return 0;
 (control statement)
```

Summary



- Software abstraction: Interpretation and Compliation
- Assembler (UASM): symbolic representation of machine language
 - Values of successive bytes to be loaded into memory
 - Symbols, labels, macros
 - \rightarrow Assembly of 32-bit β instructions
- High-level languages and compilation