Mark3 Realtime Kernel

Generated by Doxygen 1.8.11

# **Contents**

1	The	Mark3 Realtime Kernel	1
2	Lice	nse	3
	2.1	License	3
3	Con	figuring The Mark3 Kernel	5
	3.1	Overview	5
	3.2	Timer Options	5
	3.3	Blocking Objects	7
	3.4	Inter-process/thread Communication	7
	3.5	Debug Features	8
	3.6	Enhancements, Security, Miscellaneous	8
4	Buile	ding Mark3	11
	4.1	Source Layout	11
	4.2	Building the kernel	12
	4.3	Building on Windows	13
	4.4	Exporting the kernel source	14

iv CONTENTS

5	Getti	ing Started With The Mark3 API					
	5.1	Kernel Setup					
	5.2	Threads				18	
		5.2.1 Thread Setup				18	
		5.2.2 Entry Function	ns			19	
	5.3	Timers				20	
	5.4	Semaphores				20	
	5.5	Mutexes				21	
	5.6	Event Flags				22	
	5.7	Messages				22	
		5.7.1 Message Obje	ects			23	
		5.7.2 Global Messa	ge Pool			23	
		5.7.3 Message Que	eues			24	
		5.7.4 Messaging Ex	ample			24	
	5.8	Mailboxes				24	
		5.8.1 Mailbox Exam	ple			25	
	5.9	Notification Objects .				25	
		5.9.1 Notification Ex	kample			25	
	5.10	Sleep				26	
	5.11	Round-Robin Quantui	m			26	
6	Why	Mark3?				27	
٠	•••••	Walko.				Li	
7	Whe	n should you use an l	RTOS?			29	
	7.1	The reality of system of	code			29	
	7.2	Superloops, and their	limitations			30	
		7.2.1 Intro to Super	loops			30	
		7.2.2 The simplest l	oop			31	
		7.2.3 Interrupt-Drive	en Super-loop			31	
		7.2.4 Cooperative n	nulti-tasking			33	
		7.2.5 Hybrid cooper	rative/preemptive multi-task	ing		34	
	7.3	Problems with superlo	oops			35	
		7.3.1 Hidden Costs				35	
		7.3.2 Tightly-couple	ed code			35	
		7.3.3 No blocking C	alls			35	
		7.3.4 Difficult to gua	arantee responsiveness			35	
		7.3.5 Limited preem	nption capability			36	

CONTENTS

8	Can	you affo	ord an RTOS?	37
	8.1	Intro .		37
	8.2	Applica	ation description	38
	8.3	Runtim	e Overhead	39
	8.4	Analys	is	40
9	Mark	3 Desig	gn Goals	41
	9.1	Overvi	ew	41
		9.1.1	Services Provided by an RTOS Kernel	41
		9.1.2	Guiding Principles of Mark3	41
		9.1.3	Be feature competitive	41
		9.1.4	Be highly configuration	41
		9.1.5	No external dependencies, no new language features	42
		9.1.6	Target the most popular hobbyist platforms available	42
		9.1.7	Maximize determinism – but be pragmatic	42
		9.1.8	Apply engineering principles – and that means discipline, measurement and verification	42
		9.1.9	Use Virtualization For Verification	43
10	Mark	3 Kerne	el Architecture	45
	10.1	Overvi	ew	45
	10.2	Thread	s and Scheduling	47
		10.2.1	A Bit About Threads	48
		10.2.2	Thread States and ThreadLists	49
		10.2.3	Blocking and Unblocking	49
		10.2.4	Blocking Objects	49
	10.3	Inside	the Mark3 Scheduler	50
		10.3.1	Considerations for Round-Robin Scheduling	52
		10.3.2	Context Switching	53
		10.3.3	Putting It All Together	53
	10.4	Timers		53
		10.4.1	Tick-based Timers	55

vi

		10.4.2	Tickless Timers	55
		10.4.3	Timer Processing Algorithm	55
	10.5	Synchro	onization and IPC	56
	10.6	Blocking	g Objects	56
		10.6.1	Semaphores	57
		10.6.2	Mutex	57
		10.6.3	Event Flags	57
		10.6.4	Notification Objects	58
	10.7	Messag	ges and Global Message Queue	58
		10.7.1	Messages	58
		10.7.2	Message Objects	58
		10.7.3	Global Message Pool	59
		10.7.4	Message Queues	59
		10.7.5	Mailboxes	59
		10.7.6	Atomic Operations	60
		10.7.7	Drivers	61
	10.8	Kernel I	Proper and Porting	63
11	Build	d Systen	n	71
			ction	
	11.2	Mark3 I	Build Process Overview	72
		11.2.1	Pre-Build Phase:	73
		11.2.2	Build Phase	73
		11.2.3	Test and Profile	74
		11.2.4	Release	74
12	Mark	:3C - C-I	anguage API bindings for the Mark3 Kernel.	75
			nventions	75
	12.2	Allocati	ng Objects	76
			in Mark3C	

CONTENTS vii

13	Release Notes	79
	13.1 R5 Release	79
	13.2 R4 Release	80
	13.3 R3 Release	80
	13.4 R2	80
	13.5 R1 - 2nd Release Candidate	81
	13.6 R1 - 1st Release Candidate	81
14	Profiling Results	83
	14.1 Date Performed	83
	14.2 Compiler Information	83
	14.3 Profiling Results	83
15	Code Size Profiling	85
	15.1 Information	QΕ
	13.1 information	00
	15.2 Compiler Version	85
	15.3 Profiling Results	86
16	Hierarchical Index	87
	16.1 Class Hierarchy	87
17	Class Index	89
	17.1 Class List	89
18	File Index	91
	18.1 File List	91

viii CONTENTS

19	Clas	s Docur	mentation	95
	19.1	Blockin	ngObject Class Reference	95
		19.1.1	Detailed Description	95
		19.1.2	Member Function Documentation	96
			19.1.2.1 Block(Thread *pclThread_)	96
			19.1.2.2 BlockPriority(Thread *pclThread_)	96
			19.1.2.3 UnBlock(Thread *pclThread_)	96
	19.2	Circula	arLinkList Class Reference	97
		19.2.1	Detailed Description	97
		19.2.2	Member Function Documentation	97
			19.2.2.1 Add(LinkListNode *node_)	97
			19.2.2.2 InsertNodeBefore(LinkListNode *node_, LinkListNode *insert_)	98
			19.2.2.3 PivotBackward()	98
			19.2.2.4 PivotForward()	98
			19.2.2.5 Remove(LinkListNode *node_)	98
	19.3	DevNu	III Class Reference	99
		19.3.1	Detailed Description	99
		19.3.2	Member Function Documentation	100
			19.3.2.1 Close()	100
			19.3.2.2 Control(uint16_t u16Event_, void *pvDataln_, uint16_t u16Sizeln_, void *pv← DataOut_, uint16_t u16SizeOut_)	100
			19.3.2.3 Init()	100
			19.3.2.4 Open()	101
			19.3.2.5 Read(uint16_t u16Bytes_, uint8_t *pu8Data_)	101
			19.3.2.6 Write(uint16_t u16Bytes_, uint8_t *pu8Data_)	101
	19.4	Double	eLinkList Class Reference	102
		19.4.1	Detailed Description	102
		19.4.2	Constructor & Destructor Documentation	103
			19.4.2.1 DoubleLinkList()	103
		19.4.3	Member Function Documentation	103
			19.4.3.1 Add(LinkListNode *node_)	103

CONTENTS

		19.4.3.2	Remove(LinkListNode *node_)	103
19	9.5 Driver	Class Refe	erence	103
	19.5.1	Detailed	Description	104
	19.5.2	? Member	Function Documentation	105
		19.5.2.1	Close()=0	105
		19.5.2.2	Control(uint16_t u16Event_, void *pvDataln_, uint16_t u16Sizeln_, void *pv← DataOut_, uint16_t u16SizeOut_)=0	105
		19.5.2.3	GetPath()	105
		19.5.2.4	Init()=0	106
		19.5.2.5	Open()=0	106
		19.5.2.6	Read(uint16_t u16Bytes_, uint8_t *pu8Data_)=0	106
		19.5.2.7	SetName(const char *pcName_)	106
		19.5.2.8	Write(uint16_t u16Bytes_, uint8_t *pu8Data_)=0	107
19	0.6 Driver	List Class I	Reference	107
	19.6.1	Detailed	Description	108
	19.6.2	? Member	Function Documentation	108
		19.6.2.1	Add(Driver *pclDriver_)	108
		19.6.2.2	FindByPath(const char *m_pcPath)	108
		19.6.2.3	Init()	108
		19.6.2.4	Remove(Driver *pclDriver_)	108
19	9.7 Event	Flag Class	Reference	109
	19.7.1	Detailed	Description	110
	19.7.2	? Member	Function Documentation	110
		19.7.2.1	Clear(uint16_t u16Mask_)	110
		19.7.2.2	GetMask()	110
		19.7.2.3	Set(uint16_t u16Mask_)	111
		19.7.2.4	Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_)	111
		19.7.2.5	Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS ← _)	111
		19.7.2.6	Wait_i(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeM ← S_)	112
		19.7.2.7	WakeMe(Thread *pclOwner_)	112

CONTENTS

19.8 FakeThread_t Struct Reference
19.8.1 Detailed Description
19.9 GlobalMessagePool Class Reference
19.9.1 Detailed Description
19.9.2 Member Function Documentation
19.9.2.1 GetHead()
19.9.2.2 GetPool()
19.9.2.3 Init()
19.9.2.4 Pop()
19.9.2.5 Push(Message *pclMessage_)
19.10 Kernel Class Reference
19.10.1 Detailed Description
19.10.2 Member Function Documentation
19.10.2.1 GetIdleThread(void)
19.10.2.2 GetThreadContextSwitchCallout(void)
19.10.2.3 GetThreadCreateCallout(void)
19.10.2.4 GetThreadExitCallout(void)
19.10.2.5 Init(void)
19.10.2.6 IsPanic()
19.10.2.7 IsStarted()
19.10.2.8 Panic(uint16_t u16Cause_)11
19.10.2.9 SetIdleFunc(IdleFunc_t pfIdle_)
19.10.2.10SetPanic(PanicFunc_t pfPanic_)
19.10.2.11SetThreadContextSwitchCallout(ThreadContextCallout_t pfContext_) 11
19.10.2.12SetThreadCreateCallout(ThreadCreateCallout_t pfCreate_)
19.10.2.13SetThreadExitCallout(ThreadExitCallout_t pfExit_)
19.10.2.14Start(void)
19.11 Kernel Aware Class Reference
19.11.1 Detailed Description
19.11.2 Member Function Documentation

CONTENTS xi

19.11.2.1 ExitSimulator(void)	122
19.11.2.2 IsSimulatorAware(void)	122
19.11.2.3 Print(const char *szStr_)	122
19.11.2.4 ProfileInit(const char *szStr_)	123
19.11.2.5 ProfileReport(void)	123
19.11.2.6 ProfileStart(void)	123
19.11.2.7 ProfileStop(void)	123
19.11.2.8 Trace(uint16_t u16File_, uint16_t u16Line_)	124
19.11.2.9 Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)	124
19.11.2.10Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16↔ Arg2_)	124
19.11.2.11Trace_i(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16⊷ Arg2_, KernelAwareCommand_t eCmd_)	125
19.12KernelAwareData_t Union Reference	125
19.12.1 Detailed Description	126
19.13 Kernel SWI Class Reference	126
19.13.1 Detailed Description	127
19.13.2 Member Function Documentation	127
19.13.2.1 Clear(void)	127
19.13.2.2 Config(void)	127
19.13.2.3 DI()	127
19.13.2.4 RI(bool bEnable_)	127
19.13.2.5 Start(void)	128
19.13.2.6 Stop(void)	128
19.13.2.7 Trigger(void)	128
19.14KernelTimer Class Reference	128
19.14.1 Detailed Description	129
19.14.2 Member Function Documentation	129
19.14.2.1 ClearExpiry(void)	129
19.14.2.2 Config(void)	129
19.14.2.3 DI(void)	130

xii CONTENTS

19.14.2.4 El(void)	130
19.14.2.5 GetOvertime(void)	130
19.14.2.6 Read(void)	130
19.14.2.7 RI(bool bEnable_)	130
19.14.2.8 SetExpiry(uint32_t u32Interval_)	131
19.14.2.9 Start(void)	131
19.14.2.10Stop(void)	131
19.14.2.11SubtractExpiry(PORT_TIMER_COUNT_TYPE uInterval_)	131
19.14.2.12TimeToExpiry(void)	132
19.15LinkList Class Reference	132
19.15.1 Detailed Description	133
19.15.2 Member Function Documentation	133
19.15.2.1 GetHead()	133
19.15.2.2 GetTail()	133
19.15.2.3 Init()	134
19.16LinkListNode Class Reference	134
19.16.1 Detailed Description	135
19.16.2 Member Function Documentation	135
19.16.2.1 ClearNode()	135
19.16.2.2 GetNext(void)	135
19.16.2.3 GetPrev(void)	135
19.17 Mailbox Class Reference	136
19.17.1 Detailed Description	137
19.17.2 Member Function Documentation	137
19.17.2.1 CopyData(const void *src_, const void *dst_, uint16_t len_)	137
19.17.2.2 GetHeadPointer(void)	138
19.17.2.3 GetTailPointer(void)	138
19.17.2.4 Init(void *pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_) 1	138
19.17.2.5 MoveHeadBackward(void)	138
19.17.2.6 MoveHeadForward(void)	139

CONTENTS xiii

19.17.2.7 MoveTailBackward(void)	139
19.17.2.8 MoveTailForward(void)	139
19.17.2.9 Receive(void *pvData_)	139
19.17.2.10Receive(void *pvData_, uint32_t u32TimeoutMS_)	139
19.17.2.11Receive_i(const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_)	140
19.17.2.12ReceiveTail(void *pvData_)	140
19.17.2.13ReceiveTail(void *pvData_, uint32_t u32TimeoutMS_)	140
19.17.2.14Send(void *pvData_)	141
19.17.2.15Send(void *pvData_, uint32_t u32TimeoutMS_)	141
19.17.2.16Send_i(const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_)	142
19.17.2.17SendTail(void *pvData_)	142
19.17.2.18SendTail(void *pvData_, uint32_t u32TimeoutMS_)	143
19.17.3 Member Data Documentation	143
19.17.3.1 m_clSendSem	143
19.18Message Class Reference	143
19.18.1 Detailed Description	144
19.18.2 Member Function Documentation	144
19.18.2.1 GetCode()	144
19.18.2.2 GetData()	145
19.18.2.3 Init()	145
19.18.2.4 SetCode(uint16_t u16Code_)	145
19.18.2.5 SetData(void *pvData_)	145
19.19MessagePool Class Reference	146
19.19.1 Detailed Description	146
19.19.2 Member Function Documentation	147
19.19.2.1 GetHead()	147
19.19.2.2 Init()	147
19.19.2.3 Pop()	147
19.19.2.4 Push(Message *pclMessage_)	147
19.20MessageQueue Class Reference	148

xiv CONTENTS

19.20.1 Detailed Description	148
19.20.2 Member Function Documentation	149
19.20.2.1 GetCount()	149
19.20.2.2 Init()	149
19.20.2.3 Receive()	149
19.20.2.4 Receive(uint32_t u32TimeWaitMS_)	149
19.20.2.5 Receive_i(uint32_t u32TimeWaitMS_)	150
19.20.2.6 Send(Message *pclSrc_)	150
19.21 Mutex Class Reference	151
19.21.1 Detailed Description	152
19.21.2 Member Function Documentation	152
19.21.2.1 Claim()	152
19.21.2.2 Claim(uint32_t u32WaitTimeMS_)	152
19.21.2.3 Claim_i(uint32_t u32WaitTimeMS_)	153
19.21.2.4 Init()	153
19.21.2.5 Release()	153
19.21.2.6 WakeMe(Thread *pclOwner_)	154
19.21.2.7 WakeNext()	154
19.22Notify Class Reference	154
19.22.1 Detailed Description	155
19.22.2 Member Function Documentation	155
19.22.2.1 Init(void)	155
19.22.2.2 Signal(void)	155
19.22.2.3 Wait(bool *pbFlag_)	155
19.22.2.4 Wait(uint32_t u32WaitTimeMS_, bool *pbFlag_)	156
19.22.2.5 WakeMe(Thread *pclChosenOne_)	156
19.23PriorityMap Class Reference	157
19.23.1 Detailed Description	157
19.23.2 Constructor & Destructor Documentation	157
19.23.2.1 PriorityMap()	157

CONTENTS xv

19.23.3 Member Function Documentation	57
19.23.3.1 Clear(PORT_PRIO_TYPE uXPrio_)	57
19.23.3.2 HighestPriority(void)	58
19.23.3.3 Set(PORT_PRIO_TYPE uXPrio_)	58
19.24Profiler Class Reference	58
19.24.1 Detailed Description	59
19.24.2 Member Function Documentation	59
19.24.2.1 GetEpoch()	59
19.24.2.2 Init()	59
19.24.2.3 Process()	59
19.24.2.4 Read()	59
19.24.2.5 Start()	59
19.24.2.6 Stop()	60
19.25ProfileTimer Class Reference	60
19.25.1 Detailed Description	61
19.25.2 Member Function Documentation	61
19.25.2.1 ComputeCurrentTicks(uint16_t u16Count_, uint32_t u32Epoch_) 16	61
19.25.2.2 GetAverage()	61
19.25.2.3 GetCurrent()	61
19.25.2.4 Init()	62
19.25.2.5 Start()	62
19.25.2.6 Stop()	62
19.26Quantum Class Reference	62
19.26.1 Detailed Description	63
19.26.2 Member Function Documentation	63
19.26.2.1 AddThread(Thread *pclThread_)	63
19.26.2.2 ClearInTimer(void)	63
19.26.2.3 RemoveThread()	63
19.26.2.4 SetInTimer(void)	63
19.26.2.5 SetTimer(Thread *pclThread_)	63

xvi CONTENTS

19.26.2.6 UpdateTimer()	164
19.27 Scheduler Class Reference	164
19.27.1 Detailed Description	165
19.27.2 Member Function Documentation	165
19.27.2.1 Add(Thread *pclThread_)	165
19.27.2.2 GetCurrentThread()	165
19.27.2.3 GetNextThread()	166
19.27.2.4 GetStopList()	166
19.27.2.5 GetThreadList(PORT_PRIO_TYPE uXPriority_)	166
19.27.2.6 Init()	166
19.27.2.7 IsEnabled()	167
19.27.2.8 QueueScheduler()	167
19.27.2.9 Remove(Thread *pclThread_)	167
19.27.2.10Schedule()	167
19.27.2.11SetScheduler(bool bEnable_)	167
19.28Semaphore Class Reference	168
19.28.1 Detailed Description	169
19.28.2 Member Function Documentation	169
19.28.2.1 GetCount()	169
19.28.2.2 Init(uint16_t u16InitVal_, uint16_t u16MaxVal_)	169
19.28.2.3 Pend()	170
19.28.2.4 Pend(uint32_t u32WaitTimeMS_)	170
19.28.2.5 Pend_i(uint32_t u32WaitTimeMS_)	170
19.28.2.6 Post()	171
19.28.2.7 WakeMe(Thread *pclChosenOne_)	171
19.28.2.8 WakeNext()	171
19.29Thread Class Reference	172
19.29.1 Detailed Description	174
19.29.2 Member Function Documentation	175
19.29.2.1 ContextSwitchSWI(void)	175

CONTENTS xvii

19.29.2.2 Exit()
19.29.2.3 GetCurPriority(void)
19.29.2.4 GetCurrent(void)
19.29.2.5 GetEventFlagMask()
19.29.2.6 GetEventFlagMode()
19.29.2.7 GetExpired()
19.29.2.8 GetExtendedContext()
19.29.2.9 GetID()
19.29.2.1@etOwner(void)
19.29.2.11GetPriority(void)
19.29.2.12GetQuantum(void)
19.29.2.13GetStack()
19.29.2.14GetStackSize()
19.29.2.15GetStackSlack()
19.29.2.16GetState()
19.29.2.17InheritPriority(PORT_PRIO_TYPE uXPriority_)
19.29.2.17InheritPriority(PORT_PRIO_TYPE uXPriority_)
19.29.2.18nit(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX↔
19.29.2.18nit(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX↔ Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)
19.29.2.18nit(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)
19.29.2.18nit(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX←         Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)       179         19.29.2.19nitIdle()       179         19.29.2.20SetCurrent(ThreadList *pclNewList_)       179         19.29.2.21SetEventFlagMask(uint16_t u16Mask_)       180
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_) 179   19.29.2.19InitIdle() 179   19.29.2.20SetCurrent(ThreadList *pclNewList_) 179   19.29.2.21SetEventFlagMask(uint16_t u16Mask_) 180   19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_) 180
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_) 179  19.29.2.19InitIdle() 179  19.29.2.20SetCurrent(ThreadList *pclNewList_) 179  19.29.2.21SetEventFlagMask(uint16_t u16Mask_) 180  19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_) 180  19.29.2.23SetExpired(bool bExpired_) 180  19.29.2.24SetExtendedContext(void *pvData_) 180
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)       179         19.29.2.19InitIdle()       179         19.29.2.20SetCurrent(ThreadList *pclNewList_)       179         19.29.2.21SetEventFlagMask(uint16_t u16Mask_)       180         19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_)       180         19.29.2.23SetExpired(bool bExpired_)       180         19.29.2.24SetExtendedContext(void *pvData_)       180         19.29.2.25SetID(uint8_t u8ID_)       181
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)       179         19.29.2.19InitIdle()       179         19.29.2.20SetCurrent(ThreadList *pclNewList_)       179         19.29.2.21SetEventFlagMask(uint16_t u16Mask_)       180         19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_)       180         19.29.2.23SetExpired(bool bExpired_)       180         19.29.2.24SetExtendedContext(void *pvData_)       180         19.29.2.25SetID(uint8_t u8ID_)       181         19.29.2.26SetOwner(ThreadList *pclNewList_)       181
19.29.2.18nit(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX← Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_) 179  19.29.2.19nitIdle() 179  19.29.2.20SetCurrent(ThreadList *pclNewList_) 179  19.29.2.21SetEventFlagMask(uint16_t u16Mask_) 180  19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_) 180  19.29.2.23SetExpired(bool bExpired_) 180  19.29.2.24SetExtendedContext(void *pvData_) 180  19.29.2.25SetID(uint8_t u8ID_) 181  19.29.2.25SetOwner(ThreadList *pclNewList_) 181  19.29.2.25SetPriority(PORT_PRIO_TYPE uXPriority_) 181
19.29.2.18Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uX↔ Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)  179.29.2.19InitIdle()  179.29.2.20SetCurrent(ThreadList *pclNewList_)  19.29.2.21SetEventFlagMask(uint16_t u16Mask_)  19.29.2.22SetEventFlagMode(EventFlagOperation_t eMode_)  19.29.2.23SetExpired(bool bExpired_)  19.29.2.24SetExtendedContext(void *pvData_)  19.29.2.25SetID(uint8_t u8ID_)  19.29.2.25SetID(uint8_t u8ID_)  19.29.2.25SetPriority(PORT_PRIO_TYPE uXPriority_)  181  19.29.2.25SetPriorityBase(PORT_PRIO_TYPE uXPriority_)  182

xviii CONTENTS

19.29.2.32Start()	83
19.29.2.33Stop()	83
19.29.2.34USleep(uint32_t u32TimeUs_)	83
19.29.2.35Yield(void)	84
19.30ThreadList Class Reference	84
19.30.1 Detailed Description	85
19.30.2 Constructor & Destructor Documentation	85
19.30.2.1 ThreadList()	85
19.30.3 Member Function Documentation	85
19.30.3.1 Add(LinkListNode *node_)	85
19.30.3.2 Add(LinkListNode *node_, PriorityMap *pclMap_, PORT_PRIO_TYPE uX↔ Priority )	85
19.30.3.3 AddPriority(LinkListNode *node )	86
19.30.3.4 HighestWaiter()	86
19.30.3.5 Remove(LinkListNode *node_)	86
19.30.3.6 SetMapPointer(PriorityMap *pclMap_)	
19.30.3.7 SetPriority(PORT_PRIO_TYPE uXPriority_)	
19.31ThreadPort Class Reference	87
19.31.1 Detailed Description	88
19.31.2 Member Function Documentation	88
19.31.2.1 InitStack(Thread *pstThread_)	88
19.31.2.2 StartThreads()	88
19.32Timer Class Reference	88
19.32.1 Detailed Description	90
19.32.2 Constructor & Destructor Documentation	90
19.32.2.1 Timer()	90
19.32.3 Member Function Documentation	90
19.32.3.1 GetInterval()	90
19.32.3.2 Init()	90
19.32.3.3 SetCallback(TimerCallback_t pfCallback_)	90
19.32.3.4 SetData(void *pvData_)	91

CONTENTS xix

19.32.3.5 SetFlags(uint8_t u8Flags_)	191
19.32.3.6 SetIntervalMSeconds(uint32_t u32MSeconds_)	191
19.32.3.7 SetIntervalSeconds(uint32_t u32Seconds_)	192
19.32.3.8 SetIntervalTicks(uint32_t u32Ticks_)	192
19.32.3.9 SetIntervalUSeconds(uint32_t u32USeconds_)	192
19.32.3.10SetOwner(Thread *pclOwner_)	192
19.32.3.11SetTolerance(uint32_t u32Ticks_)	193
19.32.3.12Start(bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_, void *pvData_)	193
19.32.3.13Start(bool_bRepeat_,_uint32_t_u32IntervalMs_,_uint32_t_u32ToleranceMs_←, TimerCallback_t pfCallback_, void *pvData_)	193
19.32.3.14Start()	194
19.32.3.15Stop()	194
19.33TimerList Class Reference	194
19.33.1 Detailed Description	195
19.33.2 Member Function Documentation	195
19.33.2.1 Add(Timer *pclListNode_)	195
19.33.2.2 Init()	195
19.33.2.3 Process()	196
19.33.2.4 Remove(Timer *pclListNode_)	196
19.34TimerScheduler Class Reference	196
19.34.1 Detailed Description	197
19.34.2 Member Function Documentation	197
19.34.2.1 Add(Timer *pclListNode_)	197
19.34.2.2 Init()	197
19.34.2.3 Process()	197
19.34.2.4 Remove(Timer *pclListNode_)	197

CONTENTS

20	File Documentation		199
	20.1 /home/moslevin/projects/mark3-source/kernel/atomic.cpp File Reference		199
	20.1.1 Detailed Description		199
	20.2 atomic.cpp		199
	20.3 /home/moslevin/projects/mark3-source/kernel/autoalloc.cpp File Reference		201
	20.3.1 Detailed Description		201
	20.4 autoalloc.cpp		201
	20.5 /home/moslevin/projects/mark3-source/kernel/blocking.cpp File Reference		203
	20.5.1 Detailed Description		204
	20.6 blocking.cpp		204
	20.7 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp File Re		205
	ence		
	20.7.1 Detailed Description		
	20.8 kernelprofile.cpp		
	20.9 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp File Refer		
	20.9.1 Detailed Description		
	20.10kernelswi.cpp		207
	20.11/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp File Reence		207
	20.11.1 Detailed Description		208
	20.12kerneltimer.cpp		208
	20.13/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h	File	210
	20.13.1 Detailed Description		
	20.14kernelprofile.h		210
	20.15/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h File Fernece		211
	20.15.1 Detailed Description		211
	20.16kernelswi.h		212
	20.17/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h Reference	File	212
	20.17.1 Detailed Description		212
	20.18kerneltimer.h		213

CONTENTS xxi

20.19/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/portcfg.h File Reference
20.19.1 Detailed Description
20.19.2 Macro Definition Documentation
20.19.2.1 AVR
20.19.2.2 K_WORD
20.19.2.3 PORT_PRIO_TYPE
20.19.2.4 PORT_SYSTEM_FREQ
20.19.2.5 PORT_TIMER_COUNT_TYPE
20.19.2.6 PORT_TIMER_FREQ
20.20portcfg.h
20.21/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/threadport.h File Reference
20.21.1 Detailed Description
20.21.2 Macro Definition Documentation
20.21.2.1 CS ENTER
20.21.3 Function Documentation
20.21.3.1mark3_clz8(uint8_t in_)
20.22threadport.h
20.23/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/threadport.cpp File Reference22
20.23.1 Detailed Description
20.24threadport.cpp
20.25/home/moslevin/projects/mark3-source/kernel/driver.cpp File Reference
20.25.1 Detailed Description
20.25.2 Function Documentation
20.25.2.1 DrvCmp(const char *szStr1_, const char *szStr2_)
20.26driver.cpp
20.27/home/moslevin/projects/mark3-source/kernel/eventflag.cpp File Reference
20.27.1 Detailed Description
20.27.2 Function Documentation
20.27.2.1 TimedEventFlag_Callback(Thread *pclOwner_, void *pvData_)

xxii CONTENTS

20.28 eventflag.cpp
20.29/home/moslevin/projects/mark3-source/kernel/kernel.cpp File Reference
20.29.1 Detailed Description
20.30kernel.cpp
20.31/home/moslevin/projects/mark3-source/kernel/kernelaware.cpp File Reference
20.31.1 Detailed Description
20.31.2 Variable Documentation
20.31.2.1 g_blsKernelAware
20.31.2.2 g_stKAData
20.32kernelaware.cpp
20.33/home/moslevin/projects/mark3-source/kernel/ksemaphore.cpp File Reference
20.33.1 Detailed Description
20.33.2 Function Documentation
20.33.2.1 TimedSemaphore_Callback(Thread *pclOwner_, void *pvData_) 23
20.34ksemaphore.cpp
20.35/home/moslevin/projects/mark3-source/kernel/II.cpp File Reference
20.35.1 Detailed Description
20.36II.cpp
20.37/home/moslevin/projects/mark3-source/kernel/mailbox.cpp File Reference
20.37.1 Detailed Description
20.38mailbox.cpp
20.39/home/moslevin/projects/mark3-source/kernel/message.cpp File Reference
20.39.1 Detailed Description
20.40 message.cpp
20.41/home/moslevin/projects/mark3-source/kernel/mutex.cpp File Reference
20.41.1 Detailed Description
20.41.2 Function Documentation
20.41.2.1 TimedMutex_Calback(Thread *pclOwner_, void *pvData_)
20.42 mutex.cpp
20.43/home/moslevin/projects/mark3-source/kernel/notify.cpp File Reference
20.43/home/moslevin/projects/mark3-source/kernel/notify.cpp File Reference

CONTENTS xxiii

20.43.1 Detailed Description	54
20.44notify.cpp	54
20.45/home/moslevin/projects/mark3-source/kernel/priomap.cpp File Reference	56
20.45.1 Detailed Description	56
20.46priomap.cpp	57
20.47/home/moslevin/projects/mark3-source/kernel/profile.cpp File Reference	58
20.47.1 Detailed Description	58
20.48profile.cpp	58
20.49/home/moslevin/projects/mark3-source/kernel/public/atomic.h File Reference	60
20.49.1 Detailed Description	60
20.50atomic.h	60
20.51/home/moslevin/projects/mark3-source/kernel/public/autoalloc.h File Reference	61
20.51.1 Detailed Description	61
20.52 autoalloc.h	61
20.53/home/moslevin/projects/mark3-source/kernel/public/blocking.h File Reference	62
20.53.1 Detailed Description	63
20.54blocking.h	63
20.55/home/moslevin/projects/mark3-source/kernel/public/buffalogger.h File Reference	64
20.55.1 Detailed Description	64
20.56buffalogger.h	64
20.57/home/moslevin/projects/mark3-source/kernel/public/driver.h File Reference	65
20.57.1 Detailed Description	65
20.57.2 Intro	65
20.57.3 Driver Design	65
20.57.4 Driver API	66
20.58driver.h	66
20.59/home/moslevin/projects/mark3-source/kernel/public/eventflag.h File Reference	67
20.59.1 Detailed Description	67
20.60 eventflag.h	68
20.61/home/moslevin/projects/mark3-source/kernel/public/kernel.h File Reference	68

xxiv CONTENTS

20.61.1 Detailed Description
20.62kernel.h
20.63/home/moslevin/projects/mark3-source/kernel/public/kernelaware.h File Reference
20.63.1 Detailed Description
20.63.2 Enumeration Type Documentation
20.63.2.1 KernelAwareCommand_t
20.64kernelaware.h
20.65/home/moslevin/projects/mark3-source/kernel/public/kerneldebug.h File Reference
20.65.1 Detailed Description
20.66kerneldebug.h
20.67/home/moslevin/projects/mark3-source/kernel/public/kerneltypes.h File Reference
20.67.1 Detailed Description
20.67.2 Enumeration Type Documentation
20.67.2.1 EventFlagOperation_t
20.68kerneltypes.h
20.69/home/moslevin/projects/mark3-source/kernel/public/ksemaphore.h File Reference
20.69.1 Detailed Description
20.70ksemaphore.h
20.71/home/moslevin/projects/mark3-source/kernel/public/II.h File Reference
20.71.1 Detailed Description
20.72ll.h
20.73/home/moslevin/projects/mark3-source/kernel/public/mailbox.h File Reference
20.73.1 Detailed Description
20.74mailbox.h
20.75/home/moslevin/projects/mark3-source/kernel/public/manual.h File Reference
20.75.1 Detailed Description
20.76manual.h
20.77/home/moslevin/projects/mark3-source/kernel/public/mark3.h File Reference
20.77.1 Detailed Description
20.78mark3.h

CONTENTS xxv

20.79/home/moslevin/projects/mark3-source/kernel/public/mark3cfg.h File Reference	87
20.79.1 Detailed Description	89
20.79.2 Macro Definition Documentation	89
20.79.2.1 GLOBAL_MESSAGE_POOL_SIZE	89
20.79.2.2 KERNEL_AWARE_SIMULATION	89
20.79.2.3 KERNEL_ENABLE_LOGGING	89
20.79.2.4 KERNEL_ENABLE_USER_LOGGING	89
20.79.2.5 KERNEL_EXTRA_CHECKS	90
20.79.2.6 KERNEL_NUM_PRIORITIES	90
20.79.2.7 KERNEL_TIMERS_MINIMUM_DELAY_US	90
20.79.2.8 KERNEL_TIMERS_TICKLESS	90
20.79.2.9 KERNEL_USE_ATOMIC	90
20.79.2.10KERNEL_USE_AUTO_ALLOC	91
20.79.2.11KERNEL_USE_DYNAMIC_THREADS	91
20.79.2.12KERNEL_USE_EVENTFLAG	91
20.79.2.13KERNEL_USE_IDLE_FUNC	91
20.79.2.14KERNEL_USE_MAILBOX	91
20.79.2.15KERNEL_USE_MESSAGE	92
20.79.2.16KERNEL_USE_PROFILER	92
20.79.2.17KERNEL_USE_QUANTUM	92
20.79.2.18KERNEL_USE_SEMAPHORE	92
20.79.2.19KERNEL_USE_STACK_GUARD	92
20.79.2.20KERNEL_USE_THREAD_CALLOUTS	93
20.79.2.21KERNEL_USE_THREADNAME	93
20.79.2.22KERNEL_USE_TIMEOUTS	93
20.79.2.23KERNEL_USE_TIMERS	93
20.79.2.24SAFE_UNLINK	93
20.79.2.25THREAD_QUANTUM_DEFAULT	94
20.80 mark3cfg.h	94
20.81/home/moslevin/projects/mark3-source/kernel/public/message.h File Reference	95

xxvi CONTENTS

20.81.1 Detailed Description
20.81.2 using Messages, Queues, and the Global Message Pool
20.82message.h
20.83/home/moslevin/projects/mark3-source/kernel/public/mutex.h File Reference
20.83.1 Detailed Description
20.83.2 Initializing
20.83.3 Resource protection example
20.84mutex.h
20.85/home/moslevin/projects/mark3-source/kernel/public/notify.h File Reference
20.85.1 Detailed Description
20.86notify.h
20.87/home/moslevin/projects/mark3-source/kernel/public/paniccodes.h File Reference
20.87.1 Detailed Description
20.88 paniccodes.h
20.89/home/moslevin/projects/mark3-source/kernel/public/priomap.h File Reference
20.89.1 Detailed Description
20.90 priomap.h
20.91/home/moslevin/projects/mark3-source/kernel/public/profile.h File Reference
20.91.1 Detailed Description
20.92profile.h
20.93/home/moslevin/projects/mark3-source/kernel/public/quantum.h File Reference
20.93.1 Detailed Description
20.94quantum.h
20.95/home/moslevin/projects/mark3-source/kernel/public/scheduler.h File Reference
20.95.1 Detailed Description
20.96scheduler.h
20.97/home/moslevin/projects/mark3-source/kernel/public/thread.h File Reference
20.97.1 Detailed Description
20.98thread.h
20.99/home/moslevin/projects/mark3-source/kernel/public/threadlist.h File Reference

CONTENTS xxvii

20.99.1 Detailed Description
20.10 <b>6</b> hreadlist.h
20.10/home/moslevin/projects/mark3-source/kernel/public/timer.h File Reference
20.101. Detailed Description
20.101.2Macro Definition Documentation
20.101.2.1TIMERLIST_FLAG_EXPIRED
20.101.3 Typedef Documentation
20.101.3.1TimerCallback_t
20.10 <b>2</b> mer.h
20.102home/moslevin/projects/mark3-source/kernel/public/timerlist.h File Reference
20.103. Detailed Description
20.10 <b>4</b> merlist.h
20.105 home/moslevin/projects/mark3-source/kernel/public/timerscheduler.h File Reference
20.105. Detailed Description
20.10 <b>6</b> merscheduler.h
20.107/home/moslevin/projects/mark3-source/kernel/public/tracebuffer.h File Reference
20.107. Detailed Description
20.10 <b>8</b> *acebuffer.h
20.10@home/moslevin/projects/mark3-source/kernel/quantum.cpp File Reference
20.109. Detailed Description
20.109. Function Documentation
20.109.2.1QuantumCallback(Thread *pclThread_, void *pvData_)
20.11 <b>q</b> uantum.cpp
20.11/home/moslevin/projects/mark3-source/kernel/scheduler.cpp File Reference
20.111. Detailed Description
20.118cheduler.cpp
20.112home/moslevin/projects/mark3-source/kernel/thread.cpp File Reference
20.113. Detailed Description
20.11 <b>#</b> hread.cpp
20.11 \$\mathrm{E}\moslevin/projects/mark3-source/kernel/threadlist.cpp File Reference

xxviii CONTENTS

20.115. Detailed Description
20.11 <b>6</b> hreadlist.cpp
20.117/home/moslevin/projects/mark3-source/kernel/timer.cpp File Reference
20.117. Detailed Description
20.118mer.cpp
20.11 home/moslevin/projects/mark3-source/kernel/timerlist.cpp File Reference
20.119. Detailed Description
20.12 <b>6</b> merlist.cpp
20.12/home/moslevin/projects/mark3-source/kernel/tracebuffer.cpp File Reference
20.121. Detailed Description
20.122racebuffer.cpp
20.122home/moslevin/projects/mark3-source/libs/mark3c/public/fake_types.h File Reference
20.123. Detailed Description
20.12 <b>fa</b> ke_types.h
20.125home/moslevin/projects/mark3-source/libs/mark3c/public/mark3c.h File Reference
20.125. Detailed Description
20.125. Function Documentation
20.125.2.1Alloc_EventFlag(void)
20.125.2.2Alloc_Mailbox(void)
20.125.2.3Alloc_Message(void)
20.125.2.4Alloc_MessageQueue(void)
20.125.2.5Alloc_Mutex(void)
20.125.2.6Alloc_Notify(void)
20.125.2.7Alloc_Semaphore(void)
20.125.2.8Alloc_Thread(void)
20.125.2.9Alloc_Timer(void)
20.125.2.1AutoAlloc(uint16_t u16Size_)
20.125.2.1 EventFlag_Clear(EventFlag_t handle, uint16_t u16Mask_)
20.125.2.12ventFlag_GetMask(EventFlag_t handle)
20.125.2.1BventFlag_Init(EventFlag_t handle)

CONTENTS xxix

20.125.2.1 eventFlag_Set(EventFlag_t handle, uint16_t u16Mask_)	350
20.125.2.15ventFlag_TimedWait(EventFlag_t handle, uint16_t u16Mask_, EventFlag← Operation_t eMode_, uint32_t u32TimeMS_)	350
20.125.2.1 SventFlag_Wait(EventFlag_t handle, uint16_t u16Mask_, EventFlagOperation_t eMode_)	351
20.125.2.1GlobalMessagePool_Pop(void)	351
20.125.2.18lobalMessagePool_Push(Message_t handle)	351
20.125.2.116ernel_GetThreadContextSwitchCallout(void)	352
20.125.2.26ernel_GetThreadCreateCallout(void)	352
20.125.2.24ernel_GetThreadExitCallout(void)	352
20.125.2.2126ernel_Init(void)	352
20.125.2.26ernel_IsPanic(void)	353
20.125.2.24ernel_IsStarted(void)	353
20.125.2.25ernel_Panic(uint16_t u16Cause_)	353
20.125.2.26ernel_SetIdleFunc(IdleFunc_t pfIdle_)	353
20.125.2.27kernel_SetPanic(PanicFunc_t pfPanic_)	354
20.125.2.26ernel_SetThreadContextSwitchCallout(thread_context_callout_t pfContext_)	354
20.125.2.26ernel_SetThreadCreateCallout(thread_create_callout_t pfCreate_)	354
20.125.2.36ernel_SetThreadExitCallout(thread_exit_callout_t pfExit_)	355
20.125.2.31(ernel_Start(void)	355
20.125.2.32ernelAware_ExitSimulator(void)	355
20.125.2.36ernelAware_IsSimulatorAware(void)	355
20.125.2.34ernelAware_Print(const char *szStr_)	355
20.125.2.35ernelAware_ProfileInit(const char *szStr_)	356
20.125.2.36ernelAware_ProfileReport(void)	356
20.125.2.37ernelAware_ProfileStart(void)	356
20.125.2.36ernelAware_ProfileStop(void)	356
20.125.2.36ernelAware_Trace(uint16_t u16File_, uint16_t u16Line_)	356
20.125.2.46ernelAware_Trace1(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_) .	357
20.125.2.4 Gernel Aware_Trace2(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_ , uint16_t u16Arg2_)	357
20.125.2.4121ailbox_GetFreeSlots(Mailbox_t handle)	357

CONTENTS

20.125.2.4134ailbox_Init(Mailbox_t handle, void *pvBuffer_, uint16_t u16BufferSize_ , uint16_t u16ElementSize_)	358
20.125.2.4Mailbox_IsEmpty(Mailbox_t handle)	358
20.125.2.4151ailbox_lsFull(Mailbox_t handle)	358
20.125.2.4161ailbox_Receive(Mailbox_t handle, void *pvData_)	359
20.125.2.4Mailbox_ReceiveTail(Mailbox_t handle, void *pvData_)	359
20.125.2.416/ailbox_Send(Mailbox_t handle, void *pvData_)	359
20.125.2.4191ailbox_SendTail(Mailbox_t handle, void *pvData_)	360
20.125.2.501ailbox_TimedReceive(Mailbox_t handle, void *pvData_, uint32_t u32Timeout ↔ MS_)	360
20.125.2.5 Mailbox_TimedReceiveTail(Mailbox_t handle, void *pvData_, uint32_t u32↔ TimeoutMS_)	361
20.125.2.52 ailbox_TimedSend(Mailbox_t handle, void *pvData_, uint32_t u32TimeoutM↔ S_)	361
20.125.2.5⊠ailbox_TimedSendTail(Mailbox_t handle, void *pvData_, uint32_t u32↔ TimeoutMS_)	361
20.125.2.514essage_GetCode(Message_t handle)	362
20.125.2.56 essage_GetData(Message_t handle)	362
20.125.2.56 essage_Init(Message_t handle)	362
20.125.2.5 Message_SetCode(Message_t handle, uint16_t u16Code_)	363
20.125.2.56 essage_SetData(Message_t handle, void *pvData_)	363
20.125.2.59 essageQueue_GetCount(void)	363
20.125.2.60dessageQueue_Init(MessageQueue_t handle)	364
20.125.2.6 Message Queue_Receive (Message Queue_t handle)	364
20.125.2.612essageQueue_Send(MessageQueue_t handle, Message_t hMessage_)	364
20.125.2.6 Glessage Queue_Timed Receive (Message Queue_t handle, uint 32_t u32 Time ↔ Wait MS_)	365
20.125.2.6Mutex_Claim(Mutex_t handle)	365
20.125.2.615 lutex_Init(Mutex_t handle)	365
20.125.2.66 utex_Release(Mutex_t handle)	365
20.125.2.67 utex_TimedClaim(Mutex_t handle, uint32_t u32WaitTimeMS_)	366
20.125.2.6%otify_Init(Notify_t handle)	366
20.125.2.69otify_Signal(Notify_t handle)	366

CONTENTS xxxi


	$20.125.2.7 \textbf{N} otify\_TimedWait(Notify\_t \ handle, \ uint 32\_t \ u 32 Wait TimeMS\_, \ bool \ *pbFlag\_)  .$	367
	20.125.2.7Notify_Wait(Notify_t handle, bool *pbFlag_)	367
	20.125.2.78cheduler_Enable(bool bEnable_)	367
	20.125.2.73cheduler_GetCurrentThread(void)	368
	20.125.2.73cheduler_lsEnabled(void)	368
	20.125.2.75 emaphore_Init(Semaphore_t handle, uint16_t u16InitVal_, uint16_t u16Max↔ Val_)	368
	20.125.2.76emaphore_Pend(Semaphore_t handle)	369
	20.125.2.75/emaphore_Post(Semaphore_t handle)	369
	20.125.2.78emaphore_TimedPend(Semaphore_t handle, uint32_t u32WaitTimeMS_)	369
	20.125.2.79 hread_Exit(Thread_t handle)	369
	20.125.2.80hread_GetCurPriority(Thread_t handle)	370
	20.125.2.8iihread_GetExtendedContext(Thread_t handle)	370
	20.125.2.8Phread_GetID(Thread_t handle)	370
	20.125.2.8Bhread_GetPriority(Thread_t handle)	371
	20.125.2.87thread_GetQuantum(Thread_t handle)	371
	20.125.2.85hread_GetStackSlack(Thread_t handle)	371
	20.125.2.86 hread_GetState(Thread_t handle)	372
	20.125.2.817hread_Init(Thread_t handle, K_WORD *pwStack_, uint16_t u16StackSize_, P↔ ORT_PRIO_TYPE uXPriority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)	372
	20.125.2.88hread_SetExtendedContext(Thread_t handle, void *pvData_)	373
	20.125.2.89hread_SetID(Thread_t handle, uint8_t u8ID_)	373
	$20.125.2.9 \hbox{Dhread\_SetPriority} (Thread\_t \ handle, \ PORT\_PRIO\_TYPE \ uXPriority\_) \ . \ . \ . \ . \ .$	373
	20.125.2.9Thread_SetQuantum(Thread_t handle, uint16_t u16Quantum_)	373
	20.125.2.9Phread_Sleep(uint32_t u32TimeMs_)	374
	20.125.2.98hread_Start(Thread_t handle)	374
	20.125.2.974hread_Stop(Thread_t handle)	374
	20.125.2.95hread_USleep(uint32_t u32TimeUs_)	375
	20.125.2.96hread_Yield(void)	375
	20.125.2.97imer_Init(Timer_t handle)	375
	20.125.2.98imer_Restart(Timer_t handle)	375
	20.125.2.9Bimer_Start(Timer_t handle, bool bRepeat_, uint32_t u32IntervalMs_, uint32_← t u32ToleranceMs_, TimerCallbackC_t pfCallback_, void *pvData_)	376
	20.125.2.170i@ner_Stop(Timer_t handle)	376
20.12 <b>6</b> nark3c	.h	376

xxxii CONTENTS

21	Example Documentation	383
	21.1 buffalogger/main.cpp	383
	21.2 lab10_notifications/main.cpp	385
	21.3 lab11_mailboxes/main.cpp	386
	21.4 lab1_kernel_setup/main.cpp	388
	21.5 lab2_idle_function/main.cpp	390
	21.6 lab3_round_robin/main.cpp	391
	21.7 lab4_semaphores/main.cpp	393
	21.8 lab5_mutexes/main.cpp	394
	21.9 lab6_timers/main.cpp	396
	21.10lab7_events/main.cpp	397
	21.11lab8_messages/main.cpp	399
	21.12lab9_dynamic_threads/main.cpp	401
Ind	dex	405

# **Chapter 1**

### The Mark3 Realtime Kernel



Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved. See license for more information

The Mark3 Realtime Kernel is a completely free, open-source, real-time operating system aimed at bringing powerful, easy-to-use multitasking to microcontroller systems without MMUs.

It uses modern programming languages and concepts to minimize code duplication, and its object-oriented design enhances readibility. The API is simple – in six function calls, you can set up the kernel, initialize two threads, and start the scheduler.

The source is fully-documented with example code provided to illustrate concepts. The result is a performant RTOS, which is easy to read, easy to understand, and easy to extend to fit your needs.

But Mark3 is bigger than just a real-time kernel, it also contains a number of class-leading features:

- Native implementation in C++, with C-language bindings.
- Device driver HAL which provides a meaningful abstraction around device-specific peripherals.
- Capable recursive-make driven build system which can be used to build all libraries, examples, tests, documentation, and user-projects for any number of targets from the command-line.
- Graphics and UI code designed to simplify the implementation of systems using displays, keypads, joysticks, and touchscreens
- Standards-based custom communications protocol used to simplify the creation of host tools
- A bulletproof, well-documented bootloader for AVR microcontrollers Support for kernel-aware simulators, incluing Funkenstein's own flAVR.

# **Chapter 2**

### License

#### 2.1 License

Copyright (c) 2012-2016, Funkenstein Software Consulting All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Funkenstein Software Consulting, nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL FUNKENSTEIN SOFTWARE AND/OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED

AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

4 License

## **Chapter 3**

# **Configuring The Mark3 Kernel**

## 3.1 Overview

The Mark3 Kernel features a large number of compile-time options that can be set by the user. In this way, the user can build a custom OS kernel that provides only the necessary feature set required by the application, and reduce the code and data requirements of the kernel.

Care has been taken to ensure that all valid combinations of features can be enabled or disabled, barring direct dependencies.

When Mark3 is built, the various compile-time definitions are used to alter how the kernel is compiled, and include or exclude various bits and pieces in order to satisfy the requirements of the selected features. As a result, the kernel must be rebuilt whenever changes are made to the configuration header.

Note that not all demos, libraries, and tests will build successfully if the prerequisite features are not included.

Kernel options are set by modifying mark3cfg.h, located within the /kernel/public folder.

In the following sections, we will discuss the various configuration options, grouped by functionality.

## 3.2 Timer Options

## KERNEL USE TIMERS

This option is related to all kernel time-tracking:

- Timers provide a way for events to be periodically triggered in a lightweight manner. These can be periodic, or one-shot.
- Thread Quantum (usedd for round-robin scheduling) is dependent on this module, as is Thread Sleep functionality.

Setting this option to 0 disables all timer-based functionality within the kernel.

## KERNEL\_TIMERS\_TICKLESS

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

Tick-based timers provide a "traditional" RTOS timer implementation based on a fixed-frequency timer interrupt. While this provides very accurate, reliable timing, it also means that the CPU is being interrupted far more often than may be necessary (as not all timer ticks result in "real work" being done).

Tick-less timerLs still rely on a hardware timer interrupt, but uses a dynamic expiry interval to ensure that the interrupt is only called when the next timer expires. This increases the complexity of the timer interrupt handler, but reduces the number and frequency.

Note that the CPU port (kerneltimer.cpp) must be implemented for the particular timer variant desired.

Set this option to 1 to use the tickless timer implementation, 0 to use the traditional tick-based approach. Tickless timers are a bit more heavy weight (larger code footprint), but can yield significant power savings as the CPU does not need to wake up at a fixed, high frequency.

#### KERNEL USE TIMEOUTS

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it. This support comes at a small cost to code size, but a slightly larger cost to realtime performance - as checking for the use of timers in the underlying internal code costs some cycles.

As a result, the option is given to the user here to manually disable these timeout-based APIs if desired by the user for performance and code-size reasons.

Set this option to 1 to enable timeout-based APIs for blocking calls.

## KERNEL\_USE\_QUANTUM

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way. This allows equal tasks to use unequal amounts of the CPU, which is a great way to set up CPU budgets per thread in a round-robin scheduling system. If enabled, you can specify a number of ticks that serves as the default time period (quantum). Unless otherwise specified, every thread in a priority will get the default quantum.

Set this option to 1 to enable round-robin scheduling.

## THREAD\_QUANTUM\_DEFAULT

This value defines the default thread quantum when KERNEL\_USE\_QUANTUM is enabled. The value defined is a time in milliseconds.

### KERNEL USE SLEEP

This define enables the Thread::Sleep() API, which allows a thread to suspend its operation for a defined length of time, specified in ms.

3.3 Blocking Objects 7

## 3.3 Blocking Objects

## KERNEL\_USE\_NOTIFY

This is a simple blocking object, where a thread (or threads) are guaranteed to block until an asynchronous event signals the object.

#### KERNEL USE SEMAPHORE

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h. If you have to pick one blocking mechanism, this is the one to choose.

Note that all IPC mechanisms (mailboxes, messages) rely on semaphores, so keep in mind that this is a prerequisite for many other features in the kernel.

#### KERNEL\_USE\_MUTEX

Do you want the ability to use mutual exclusion semaphores (mutex) for resource/block protection? Enabling this feature provides mutexes, with priority inheritence, as declared in mutex.h.

#### KERNEL USE EVENTFLAG

Provides additional event-flag based blocking. This relies on an additional per-thread flag-mask to be allocated, which adds 2 bytes to the size of each thread object.

## 3.4 Inter-process/thread Communication

## KERNEL\_USE\_MESSAGE

Enable inter-thread messaging using message queues. This is the preferred mechanism for IPC for serious multithreaded communications; generally anywhere a semaphore or event-flag is insufficient.

#### GLOBAL\_MESSAGE\_POOL\_SIZE

If Messages are enabled, define the size of the default kernel message pool. Messages can be manually added to the message pool, but this mechanisms is more convenient and automatic. All message queues can share their message objects from this global pool to maximize efficiency and simplify data management.

## KERNEL\_USE\_MAILBOX

Enable inter-thread messaging using mailboxes. A mailbox manages a blob of data provided by the user, that is partitioned into fixed-size blocks called envelopes. The size of an envelope is set by the user when the mailbox is initialized. Any number of threads can read-from and write-to the mailbox. Envelopes can be sent-to or received-from the mailbox at the head or tail. In this way, mailboxes essentially act as a circular buffer that can be used as a blocking FIFO or LIFO queue.

## 3.5 Debug Features

#### KERNEL USE THREADNAME

Provide Thread method to allow the user to set a name for each thread in the system. Adds a const char\* pointer to the size of the thread object.

#### KERNEL USE DEBUG

Provides extra logic for kernel debugging, and instruments the kernel with extra asserts, and kernel trace functionality.

#### KERNEL\_ENABLE\_LOGGING

Set this to 1 to enable very chatty kernel logging. Since most important things in the kernel emit logs, a large log-buffer and fast output are required in order to keep up. This is a pretty advanced power-user type feature, so it's disabled by default.

#### KERNEL ENABLE USER LOGGING

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently. This allows for user-code to benefit from the built-in kernel logging macros without having to account for the super-high-volume of logs generated by kernel code.

#### KERNEL EXTRA CHECKS

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations. This is especially helpful during development, and can help catch problems at development time, instead of in the field.

#### KERNEL\_USE\_STACK\_GUARD

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch. Enabling this is the most effective means to guard against stack corruption and stack overflow in the kernel, at the cost of increased context

## 3.6 Enhancements, Security, Miscellaneous

## KERNEL USE DRIVER

Enabling device drivers provides a posix-like filesystem interface for peripheral device drivers.

#### KERNEL\_USE\_DYNAMIC\_THREADS

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime. useful for designs implementing worker threads, or threads that can be restarted after encountering error conditions.

## KERNEL\_USE\_PROFILER

Provides extra classes for profiling the performance of code. useful for debugging and development, but uses an additional hardware timer.

## KERNEL\_USE\_ATOMIC

Provides support for atomic operations, including addition, subtraction, set, and test-and-set. Add/Sub/Set contain 8, 16, and 32-bit variants.

### SAFE\_UNLINK

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists. This goes beyond pointer checks, adding a layer of structural and metadata validation to help detect system corruption early.

#### KERNEL AWARE SIMULATION

Include support for kernel-aware simulation. Enabling this feature adds advanced profiling, trace, and environment-aware debugging and diagnostic functionality when Mark3-based applications are run on the flAVR AVR simulator.

## KERNEL\_USE\_IDLE\_FUNC

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality. This saves a full thread stack, but also requires a bit extra static data. This also adds a slight overhead to the context switch and scheduler, as a special case has to be taken into account.

#### KERNEL\_USE\_AUTO\_ALLOC

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory). Note that auto-alloc memory cannot be reclaimed.

## **AUTO ALLOC SIZE**

Size (in bytes) of the static pool of memory reserved from RAM for use by the auto allocator (if enabled).

#### KERNEL USE THREAD CALLOUTS

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited. This is useful for implementing low-level instrumentation based on information held in the threads.

#### KERNEL USE EXTENDED CONTEXT

Allocate an extra pointer's worth of storage within a Thread object (and corresponding accessor methods) to provide the user with a means to implement arbitrary Thread-local storage.

## **Chapter 4**

# **Building Mark3**

Mark3 is distributed with a recursive makefile build system, allowing the entire source tree to be built into a series of libraries with simple make commands.

The way the scripts work, every directory with a valid makefile is scanned, as well as all of its subdirectories. The build then generates binary components for all of the components it finds -libraries and executables. All libraries that are generated can then be imported into an application using the linker without having to copy-and-paste files on a module-by-module basis. Applications built during this process can then be loaded onto a device directly, without requiring a GUI-based IDE. As a result, Mark3 integrates well with 3rd party tools for continuous-integration and automated testing.

This modular framework allows for large volumes of libraries and binaries to be built at once - the default build script leverages this to build all of the examples and unit tests at once, linking against the pre-built kernel, services, and drivers. Whatever can be built as a library is built as a library, promoting reuse throughout the platform, and enabling Mark3 to be used as a platform, with an ecosystem of libraries, services, drivers and applications.

## 4.1 Source Layout

One key aspect of Mark3 is that system features are organized into their own separate modules. These modules are further grouped together into folders based on the type of features represented:

```
Root
              Base folder, contains recursive makefiles for build system
  arduino
                Arduino-specific headers and API documentation files
  bootloader Mark3 Bootloader code for AVR microcontrollers
  build Makefiles and device : docs Documentation (including this)
                  Makefiles and device-configuration data for various platforms
  drivers
                  Device driver code for various supported devices
                 Example applications
  example
  export
                Platform specific output folder, used when running export.sh
 kernel Basic Mark3 Components (the focus of this manual)
cpu CPU-specific porting code
scripts Scripts used to simplify build, documentation, and profiling
libs Utility code and services, extended system features
stage Staging directory, where the build system plane.
                  Bitmap fonts converted from TTF, used by Mark3 graphics library
  fonts
             Unit tests, written as C/C++ applications
  tests
                  .net-based font converter, terminal, programmer, config util
```

12 Building Mark3

## 4.2 Building the kernel

There are 3 main components of the recursive makefile system used to build Mark3 and its associated middleware libraries and examples. The components are the files "base.mak", "platform.mak", and "build.mak"

The base.mak file determines how the kernel, drivers, and libraries are built, for what targets, and with what options. These options are set as variables that are included in a "platform.mak" file for your target, located under the /builds directory. "platform.mak" is included for all build steps, and is the place where all chip/board-specific toolchain configuration takes place.

Build.mak contains the base logic which is used to perform a recursive make in all project directories. Unless you really know what you're doing, it's best to leave this as-is.

Beyond the essential makefiles, the build system uses a series of environment variables to configure a recursive make-based build system appropriately for a given target part and toolchain.

Below is an overview of the main variables used to configure the build.

```
STAGE - Location in the filesystem where the build output is stored

ROOT_DIR - The location of the root source tree

ARCH - The CPU architecture to build against

VARIANT - The variant of the above CPU to target

TOOLCHAIN - Which toolchain to build with (dependent on ARCH and VARIANT)
```

You must make sure that all required toolchain paths are set in your system environment variables so that they are accessible directly through from the command-line

Once a sane environment has been created, the kernel, libraries, examples and tests can be built by running ./scripts/build.sh from the root directory. By default, Mark3 builds for the atmega328p target, but the target can be selected by manually configuring the above environment variables, or by running the included ./scripts/set\_target.sh script as follows:

```
. ./scripts/set_target.sh <architecture> <variant> <toolchain>
```

## Where:

```
<architecture> is the target CPU architecture(i.e. avr, msp430, cm0, cm3, cm4f)
<variant> is the part name (i.e. atmega328p, msp430f2274, generic)
<toolchain> is the build toolchain (i.e. gcc)
```

Once configured, you can build the source tree using the various make targets:

- · make headers
  - copy all headers in each module's /public subdirectory to the location specified by STAGE environment variable's ./inc subdirectory.
- · make library
  - regenerate all objects copy marked as libraries (i.e. the kernel + drivers). Resulting binaries are copied into STAGE's ./lib subdirectory.
- make binary
  - build all executable projects in the root directory structure. In the default distribution, this includes the basic set of demos.

These steps are chained together automatically as part of the build.sh script found under the /scripts subdirectory. Running ./scripts/build.sh from the root of the embedded source directory will result in all headers being exported, libraries built, and applications built. This script will also default to building for atmega328p using GCC if none of the required environment variables have previously been configured.

To add new components to the recursive build system, simply add your code into a new folder beneath the root install location.

Source files, the module makefile and private header files go directly in the new folder, while public headers are placed in a ./public subdirectory. Create a ./obj directory to hold the output from the builds.

The contents of the module makefile looks something like this:

Once you've placed your code files in the right place, and configured the makefile appropriately, call the following sequence to guarantee that your code will be built.

```
> make headers
> make library
> make binary
```

Note that library or app-specific environment variables can be set (or modified from the defaults) from within the body of the makefile. For example, the CFLAGS, CPPFLAGS, and LFLAGS variables can be used to supply additional chip-specific toolchain flags. The flags can be used to allow a user to reference chip-specific startup code, headers, middleware, or linker scripts that aren't part of the standard Mark3 distribution.

## 4.3 Building on Windows

Building Mark3 on Windows is the same as on Linux, but there are a few prerequisites that need to be taken into consideration before the build scripts and makefiles will work as expected.

Below is an example of setting up the AVR toolchain on Windows:

#### Step 1 - Install Latest Atmel Studio IDE

Atmel Studio contains the AVR8 GCC toolchain, which contains the necessary compilers, assemblers, and platform support required to turn the source modules into libraries and executables.

To get Atmel Studio, go to the Atmel website (http://www.atmel.com) and register to download the latest version. This is a free download (and rather large). The included IDE (if you choose to use it) is very slick, as it's based on Visual Studio, and contains a wonderful cycle-accurate simulator for AVR devices. In fact, the simulator is so good that most of the kernel and its drivers were developed using this tool.

Once you have downloaded and installed Atmel Studio, you will need to add the location of the AVR toolcahin to the PATH environment variable.

To do this, go to Control Panel -> System and Security -> System -> Advanced System Settings, and edit the PATH variable. Append the location of the toolchain bin folder to the end of the variable.

On Windows x64, it should look something like this:

14 Building Mark3

C:\Program Files (x86)\Atmel\Atmel Toolchain\AVR8 GCC\Native\3.4.2.1002\avr8-gnu-toolchain\bin

#### Step 2 - Install MinGW and MinSys

MinGW (and MinSys in particular) provide a unix-like environment that runs under windows. Some of the utilities provided include a version of the bash shell, and GNU standard make - both which are required by the Mark3 recursive build system.

The MinGW installer can be downloaded from its project page on SourceForge. When installing, be sure to select the "MinSys" component.

Once installed, add the MinSys binary path to the PATH environment variable, in a similar fashion as with Atmel Studio in Step 1.

#### Step 3 - Setup Include Paths in Platform Makefile

The AVR header file path must be added to the "platform.mak" makefile for each AVR Target you are attempting to build for. These files can be located under /embedded/build/avr/atmegaXXX/. The path to the includes directory should be added to the end of the CFLAGS and CPPFLAGS variables, as shown in the following:

```
TEST_INC="/c/Program Files (x86)/Atmel/Atmel Toolchain/AVR8 GCC/Native/3.4.2.1002/avr8-gnu-toolchain/include" CFLAGS += -I$ (TEST_INC)
CPPFLAGS += -I$ (TEST_INC)
```

#### Step 4 - Build Mark3 using Bash

Launch a terminal to your Mark3 base directory, and cd into the "embedded" folder. You should now be able to build Mark3 by running "bash ./build.sh" from the command-line.

Alternately, you can run bash itself, building Mark3 by running ./build.sh or the various make targets using the same synatx as documented previously.

Note - building on Windows is *slow*. This has a lot to do with how "make" performs under windows. There are faster substitutes for make (such as cs-make) that are exponentially quicker, and approach the performance of make on Linux. Other mechanisms, such as running make with multiple concurrent jobs (i.e. "make -j4") also helps significantly, especially on systems with multicore CPUs.

## 4.4 Exporting the kernel source

While the build system is flexible enough to adapt to any toolchain, it may be desireable to integrate the Mark3 kernel and associated drivers/libraries into another build system.

Mark3 provides a script (the aptly-named export.sh) which allow for the source for any supported port to be exported for this purpose. This script will also generate appropriate doxygen documentation, and package the whole of it together in a zip file. The files in the archive are placed in a "flat" heirarchy, and do not require any specific path structure to be maintained when imported into another build system.

As a special feature, if the "arduino" AVR target is specified, additional pre-processing is done on the source to turn the standard Mark3 kernel into a library that can be imported directly into Arudino IDE. This is also how the official Mark3 arduino-compatible releases are generated (hosted on mark3os.com and sourceforge.net)

To exercise the build system, type the following from the main mark3 embedded source directory:

```
> ./scripts/export.sh <target>
```

Where:

Target is one of the following:

atmega328p atmega644 atmega1280 atmega2560 atmega1284p atxmega256a3 arduino arduino2560 samd20 cortex\_m0 cortex\_m3 cortex\_m4f msp430f2274

If successful, the generated artifacats will be placed in an output folder under the ./export directory.

Additionally, if doxygen is found on the host system's PATH, a copy of the manual (using the specific port's source code) will be generated and archived with the source release. If pdflatex is also found on the host's PATH, a PDF copy of the manual will be generated, tailored to the selected target.

16 Building Mark3

## **Chapter 5**

# **Getting Started With The Mark3 API**

## 5.1 Kernel Setup

This section details the process of defining threads, initializing the kernel, and adding threads to the scheduler.

If you're at all familiar with real-time operating systems, then these setup and initialization steps should be familiar. I've tried very hard to ensure that as much of the heavy lifting is hidden from the user, so that only the bare minimum of calls are required to get things started.

The examples presented in this chapter are real, working examples taken from the ATmega328p port.

First, you'll need to create the necessary data structures and functions for the threads:

- 1. Create a Thread object for all of the "root" or "initial" tasks.
- 2. Allocate stacks for each of the Threads
- 3. Define an entry-point function for each Thread

This is shown in the example code below:

```
#include "thread.h"
#include "kernel.h"

//1) Create a thread object for all of the "root" or "initial" tasks
static Thread AppThread;
static Thread IdleThread;

//2) Allocate stacks for each thread
#define STACK_SIZE_APP (192)
#define STACK_SIZE_IDLE (128)

static uint8_t aucAppStack[STACK_SIZE_APP];
static uint8_t aucIdleStack[STACK_SIZE_IDLE];

//3) Define entry point functions for each thread
void AppThread(void);
void IdleThread(void);
```

Next, we'll need to add the required kernel initialization code to main. This consists of running the Kernel's init routine, initializing all of the threads we defined, adding the threads to the scheduler, and finally calling Kernel::

Start(), which transfers control of the system to the RTOS.

These steps are illustrated in the following example.

```
int main (void)
    //1) Initialize the kernel prior to use
                                   // MUST be before other kernel ops
    Kernel::Init();
    //2) Initialize all of the threads we've defined
                      STACK_SIZE_APP, // Size of +1:
    AppThread.Init( aucAppStack,
                                   // Thread priority
                      (void*)AppEntry, // Entry function
NULL); // Entry function argument
                      NULL );
                       aucIdleStack, // Pointer to the stack STACK_SIZE_IDLE, // Size of the stack
    IdleThread.Init( aucIdleStack,
                                   // Thread priority
                       (void*)IdleEntry, // Entry function
NULL); // Entry function argument
                       NULL );
    //3) Add the threads to the scheduler
    AppThread.Start();
                                   // Actively schedule the threads
    IdleThread.Start();
    //4) Give control of the system to the kernel
    Kernel::Start();
                                   // Start the kernel!
```

Not much to it, is there? There are a few noteworthy points in this code, though.

In order for the kernel to work properly, a system must always contain an idle thread; that is, a thread at priority level 0 that never blocks. This thread is responsible for performing any of the low-level power management on the CPU in order to maximize battery life in an embedded device. The idle thread must also never block, and it must never exit. Either of these operations will cause undefined behavior in the system.

The App thread is at a priority level greater-than 0. This ensures that as long as the App thread has something useful to do, it will be given control of the CPU. In this case, if the app thread blocks, control will be given back to the Idle thread, which will put the CPU into a power-saving mode until an interrupt occurs.

Stack sizes must be large enough to accommodate not only the requirements of the threads, but also the requirements of interrupts - up to the maximum interrupt-nesting level used. Stack overflows are super-easy to run into in an embedded system; if you encounter strange and unexplained behavior in your code, chances are good that one of your threads is blowing its stack.

## 5.2 Threads

Mark3 Threads act as independent tasks in the system. While they share the same address-space, global data, device-drivers, and system peripherals, each thread has its own set of CPU registers and stack, collectively known as the thread's **context**. The context is what allows the RTOS kernel to rapidly switch between threads at a high rate, giving the illusion that multiple things are happening in a system, when really, only one thread is executing at a time.

#### 5.2.1 Thread Setup

Each instance of the Thread class represents a thread, its stack, its CPU context, and all of the state and metadata maintained by the kernel. Before a Thread will be scheduled to run, it must first be initialized with the necessary configuration data.

The Init function gives the user the opportunity to set the stack, stack size, thread priority, entry-point function, entry-function argument, and round-robin time quantum:

Thread stacks are pointers to blobs of memory (usually char arrays) carved out of the system's address space. Each thread must have a stack defined that's large enough to handle not only the requirements of local variables in the thread's code path, but also the maximum depth of the ISR stack.

5.2 Threads

Priorities should be chosen carefully such that the shortest tasks with the most strict determinism requirements are executed first - and are thus located in the highest priorities. Tasks that take the longest to execute (and require the least degree of responsiveness) must occupy the lower thread priorities. The idle thread must be the only thread occupying the lowest priority level.

The thread quantum only aplies when there are multiple threads in the ready queue at the same priority level. This interval is used to kick-off a timer that will cycle execution between the threads in the priority list so that they each get a fair chance to execute.

The entry function is the function that the kernel calls first when the thread instance is first started. Entry functions have at most one argument - a pointer to a data-object specified by the user during initialization.

An example thread initallization is shown below:

Once a thread has been initialized, it can be added to the scheduler by calling:

```
clMyThread.Start();
```

The thread will be placed into the Scheduler's queue at the designated priority, where it will wait its turn for execution.

### 5.2.2 Entry Functions

Mark3 Threads should not run-to-completion - they should execute as infinite loops that perform a series of tasks, appropriately partitioned to provide the responsiveness characteristics desired in the system.

The most basic Thread loop is shown below:

Threads can interact with eachother in the system by means of synchronization objects (Semaphore), mutual-exclusion objects (Mutex), Inter-process messaging (MessageQueue), and timers (Timer).

Threads can suspend their own execution for a predetermined period of time by using the static Thread::Sleep() method. Calling this will block the Thread's executin until the amount of time specified has ellapsed. Upon expiry, the thread will be placed back into the ready queue for its priority level, where it awaits its next turn to run.

## 5.3 Timers

Timer objects are used to trigger callback events periodic or on a one-shot (alarm) basis.

While extremely simple to use, they provide one of the most powerful execution contexts in the system. The timer callbacks execute from within the timer callback ISR in an interrupt-enabled context. As such, timer callbacks are considered higher-priority than any thread in the system, but lower priority than other interrupts. Care must be taken to ensure that timer callbacks execute as quickly as possible to minimize the impact of processing on the throughput of tasks in the system. Wherever possible, heavy-lifting should be deferred to the threads by way of semaphores or messages.

Below is an example showing how to start a periodic system timer which will trigger every second:

## 5.4 Semaphores

Semaphores are used to synchronized execution of threads based on the availability (and quantity) of application-specific resources in the system. They are extremely useful for solving producer-consumer problems, and are the method-of-choice for creating efficient, low latency systems, where ISRs post semaphores that are handled from within the context of individual threads. (Yes, Semaphores can be posted - but not pended - from the interrupt context).

The following is an example of the producer-consumer usage of a binary semaphore:

```
Semaphore clSemaphore; // Declare a semaphore shared between a producer and a consumer thread.

void Producer()
{
    clSemaphore.Init(0, 1);
    while(1)
    {
        // Do some work, create something to be consumed

        // Post a semaphore, allowing another thread to consume the data
        clSemaphore.Post();
    }
}

void Consumer()
{
    // Assumes semaphore initialized before use...
    While(1)
    {
        // Wait for new data from the producer thread
        clSemaphore.Pend();
        // Consume the data!
    }
}
```

5.5 Mutexes 21

And an example of using semaphores from the ISR context to perform event- driven processing.

```
Semaphore clSemaphore;
__interrupt__ MyISR()
{
    clSemaphore.Post(); // Post the interrupt. Lightweight when uncontested.
}

void MyThread()
{
    clSemaphore.Init(0, 1); // Ensure this is initialized before the MyISR interrupt is enabled.
    while(1)
    {
        // Wait until we get notification from the interrupt
        clSemaphore.Pend();

        // Interrupt has fired, do the necessary work in this thread's context
        HeavyLifting();
    }
}
```

### 5.5 Mutexes

Mutexes (Mutual exclusion objects) are provided as a means of creating "protected sections" around a particular resource, allowing for access of these objects to be serialized. Only one thread can hold the mutex at a time - other threads have to wait until the region is released by the owner thread before they can take their turn operating on the protected resource. Note that mutexes can only be owned by threads - they are not available to other contexts (i.e. interrupts). Calling the mutex APIs from an interrupt will cause catastrophic system failures.

Note that these objects are also not recursive- that is, the owner thread can not attempt to claim a mutex more than once.

Prioritiy inheritence is provided with these objects as a means to avoid priority inversions. Whenever a thread at a priority than the mutex owner blocks on a mutex, the priority of the current thread is boosted to the highest-priority waiter to ensure that other tasks at intermediate priorities cannot artificically prevent progress from being made.

Mutex objects are very easy to use, as there are only three operations supported: Initialize, Claim and Release. An example is shown below.

```
Mutex clMutex; // Create a mutex globally.
void Init()
    // Initialize the mutex before use.
    clMutex.Init();
// Some function called from a thread
void Thread1Function()
    clMutex.Claim();
    // Once the mutex is owned, no other thread can
    // enter a block protect by the same mutex
    my_protected_resource.do_something();
    my_protected_resource.do_something_else();
    clMutex.Release();
}
// Some function called from another thread
void Thread2Function()
    clMutex.Claim();
    // Once the mutex is owned, no other thread can
    // enter a block protect by the same mutex
    my_protected_resource.do_something();
    my_protected_resource.do_different_things();
    clMutex.Release();
```

## 5.6 Event Flags

Event Flags are another synchronization object, conceptually similar to a semaphore.

Unlike a semaphore, however, the condition on which threads are unblocked is determined by a more complex set of rules. Each Event Flag object contains a 16-bit field, and threads block, waiting for combinations of bits within this field to become set.

A thread can wait on any pattern of bits from this field to be set, and any number of threads can wait on any number of different patterns. Threads can wait on a single bit, multiple bits, or bits from within a subset of bits within the field.

As a result, setting a single value in the flag can result in any number of threads becoming unblocked simultaneously. This mechanism is extremely powerful, allowing for all sorts of complex, yet efficient, thread synchronization schemes that can be created using a single shared object.

Note that Event Flags can be set from interrupts, but you cannot wait on an event flag from within an interrupt.

Examples demonstrating the use of event flags are shown below.

```
// Simple example showing a thread blocking on a multiple bits in the
// fields within an event flag.
EventFlag clEventFlag;
int main()
    clEventFlag.Init(); // Initialize event flag prior to use
void MyInterrupt()
    // Some interrupt corresponds to event 0x0020
    clEventFlag.Set (0x0020);
void MyThreadFunc()
    while(1)
         uint16_t u16WakeCondition;
         // Allow this thread to block on multiple flags
         u16WakeCondition = clEventFlag.Wait(0x00FF, EVENT_FLAG_ANY);
         // Clear the event condition that caused the thread to wake (in this case, // u16WakeCondtion will equal 0x20 when triggered from the interrupt above)
         clEventFlag.Clear(u16WakeCondition);
         // <do something>
```

## 5.7 Messages

Sending messages between threads is the key means of synchronizing access to data, and the primary mechanism to perform asynchronous data processing operations.

Sending a message consists of the following operations:

• Obtain a Message object from the global message pool

5.7 Messages 23

- · Set the message data and event fields
- · Send the message to the destination message queue

While receiving a message consists of the following steps:

- · Wait for a messages in the destination message queue
- · Process the message data
- Return the message back to the global message pool

These operations, and the various data objects involved are discussed in more detail in the following section.

## 5.7.1 Message Objects

Message objects are used to communicate arbitrary data between threads in a safe and synchronous way.

The message object consists of an event code field and a data field. The event code is used to provide context to the message object, while the data field (essentially a void \* data pointer) is used to provide a payload of data corresponding to the particular event.

Access to these fields is marshalled by accessors - the transmitting thread uses the SetData() and SetCode() methods to seed the data, while the receiving thread uses the GetData() and GetCode() methods to retrieve it.

By providing the data as a void data pointer instead of a fixed-size message, we achieve an unprecedented measure of simplicity and flexibility. Data can be either statically or dynamically allocated, and sized appropriately for the event without having to format and reformat data by both sending and receiving threads. The choices here are left to the user - and the kernel doesn't get in the way of efficiency.

It is worth noting that you can send messages to message queues from within ISR context. This helps maintain consistency, since the same APIs can be used to provide event-driven programming facilities throughout the whole of the OS.

#### 5.7.2 Global Message Pool

To maintain efficiency in the messaging system (and to prevent over-allocation of data), a global pool of message objects is provided. The size of this message pool is specified in the implementation, and can be adjusted depending on the requirements of the target application as a compile-time option.

Allocating a message from the message pool is as simple as calling the GlobalMessagePool::Pop() Method.

Messages are returned back to the GlobalMessagePool::Push() method once the message contents are no longer required.

One must be careful to ensure that discarded messages always are returned to the pool, otherwise a resource leak can occur, which may cripple the operating system's ability to pass data between threads.

## 5.7.3 Message Queues

Message objects specify data with context, but do not specify where the messages will be sent. For this purpose we have a MessageQueue object. Sending an object to a message queue involves calling the MessageQueue::Send() method, passing in a pointer to the Message object as an argument.

When a message is sent to the queue, the first thread blocked on the queue (as a result of calling the Message Queue Receive() method) will wake up, with a pointer to the Message object returned.

It's worth noting that multiple threads can block on the same message queue, providing a means for multiple threads to share work in parallel.

#### 5.7.4 Messaging Example

```
// Message queue object shared between threads
MessageQueue clMsgQ;
// Function that initializes the shared message queue
void MsgQInit()
    clMsgQ.Init();
// Function called by one thread to send message data to
void TxMessage()
    // Get a message, initialize its data
Message *pclMesg = GlobalMessagePool::Pop();
    pclMesg->SetCode(0xAB);
    pclMesg->SetData((void*)some_data);
    // Send the data to the message queue
    clMsgQ.Send(pclMesg);
// Function called in the other thread to block until
// a message is received in the message queue.
void RxMessage()
    Message *pclMesq;
    // Block until we have a message in the queue
    pclMesg = clMsgQ.Receive();
    // Do something with the data once the message is received
    pclMesq->GetCode();
    // Free the message once we're done with it.
    GlobalMessagePool::Push(pclMesg);
```

## 5.8 Mailboxes

Another form of IPC is provided by Mark3, in the form of Mailboxes and Envelopes.

Mailboxes are similar to message queues in that they provide a synchronized interface by which data can be transmitted between threads.

Where Message Queues rely on linked lists of lightweight message objects (containing only message code and a void\* data-pointer), which are inherently abstract, Mailboxes use a dedicated blob of memory, which is carved up into fixed-size chunks called Envelopes (defined by the user), which are sent and received. Unlike message queues, mailbox data is copied to and from the mailboxes dedicated pool.

Mailboxes also differ in that they provide not only a blocking "receive" call, but also a blocking "send" call, providing the opportunity for threads to block on "mailbox full" as well as "mailbox empty" conditions.

All send/receive APIs support an optional timeout parameter if the KERNEL\_USE\_TIMEOUTS option has been configured in mark3cfg.h

## 5.8.1 Mailbox Example

```
// Create a mailbox object, and define a buffer that will be used to store the
// mailbox' envelopes.
static Mailbox clMbox;
static uint8_t aucMBoxBuffer[128];
void InitMailbox(void)
    // Initialize our mailbox, telling it to use our defined buffer for envelope
    // storage. Pass in the size of the buffer, and set the size of each // envelope to 16 bytes. This gives u16 a mailbox capacity of (128 / 16) = 8 \,
    // envelopes.
    clMbox.Init((void*)aucMBoxBuffer, 128, 16);
void SendThread(void)
    // Define a buffer that we'll eventually send to the
    \ensuremath{//} mailbox. Note the size is the same as that of an
    // envelope.
    uint8_t aucTxBuf[16];
    while(1)
         // Copy some data into aucTxBuf, a 16-byte buffer, the
         \ensuremath{//} same size as a mailbox envelope.
         // Deliver the envelope (our buffer) into the mailbox
        clMbox.Send((void*)aucTxBuf);
}
void RecvThred(void)
    uint8_t aucRxBuf[16];
    while(1)
         // Wait until there's a message in our mailbox. Once
         // there is a message, read it into our local buffer.
         cmMbox.Receive((void*)aucRxBuf);
         // Do something with the contents of aucRxBuf, which now
        \ensuremath{//} contains an envelope of data read from the mailbox.
         . . .
```

## 5.9 Notification Objects

Notification objects are the most lightweight of all blocking objects supplied by Mark3.

using this blocking primative, one or more threads wait for the notification object to be signalled by code elsewhere in the system (i.e. another thread or interrupt). Once the the notification has been signalled, all threads currently blocked on the object become unblocked.

## 5.9.1 Notification Example

```
static Notify clNotifier;
...
void MyThread(void *unused_)
{
    // Initialize our notification object before use clNotifier.Init();
    while (1)
```

```
{
    // Wait until our thread has been notified that it
    // can wake up.
    clNotify.Wait();
    ...
    // Thread has woken up now -- do something!
}
}
...
void SignalCallback(void)
{
    // Something in the system (interrupt, thread event, IPC,
    // etc.,) has called this function. As a result, we need
    // our other thread to wake up. Call the Notify object's
    // Signal() method to wake the thread up. Note that this
    // will have no effect if the thread is not presently
    // blocked.
    clNotify.Signal();
}
```

## 5.10 Sleep

There are instances where it may be necessary for a thread to poll a resource, or wait a specific amount of time before proceeding to operate on a peripheral or volatile piece of data.

While the Timer object is generally a better choice for performing time-sensitive operations (and certainly a better choice for periodic operations), the Thread::Sleep() method provides a convenient (and efficient) mechanism that allows for a thread to suspend its execution for a specified interval.

Note that when a thread is sleeping it is blocked, during which other threads can operate, or the system can enter its idle state.

```
int GetPeripheralData();
{
    int value;
    // The hardware manual for a peripheral specifies that
    // the "foo()" method will result in data being generated
    // that can be captured using the "bar()" method.
    // However, the value only becomes valid after 10ms
    peripheral.foo();
    Thread::Sleep(10); // Wait 10ms for data to become valid
    value = peripheral.bar();
    return value;
}
```

## 5.11 Round-Robin Quantum

Threads at the same thread priority are scheduled using a round-robin scheme. Each thread is given a timeslice (which can be configured) of which it shares time amongst ready threads in the group. Once a thread's timeslice has expired, the next thread in the priority group is chosen to run until its quantum has expired - the cycle continues over and over so long as each thread has work to be done.

By default, the round-robin interval is set at 4ms.

This value can be overridden by calling the thread's SetQuantum() with a new interval specified in milliseconds.

## **Chapter 6**

# Why Mark3?

My first job after graduating from university in 2005 was with a small company that had a very old-school, low-budget philosophy when it came to software development.

Every make-or-buy decision ended with "make" when it came to tools. It was the kind of environment where vendors cost us money, but manpower was free. In retrospect, we didn't have a ton of business during the time that I worked there, and that may have had something to do with the fact that we were constantly short on ready cash for things we could code ourselves.

Early on, I asked why we didn't use industry-standard tools - like JTAG debuggers or IDEs. One senior engineer scoffed that debuggers were tools for wimps - and something that a good programmer should be able to do without. After all - we had serial ports, GPIOs, and a bi-color LED on our boards. Since these were built into the hardware, they didn't cost us a thing. We also had a single software "build" server that took 5 minutes to build a 32k binary on its best days, so when we had to debug code, it was a painful process of trial and error, with lots of Youtube between iterations. We complained that tens of thousands of dollars of productivity was being flushed away that could have been solved by implementing a proper build server - and while we eventually got our wish, it took far more time than it should have.

Needless to say, software development was painful at that company. We made life hard on ourselves purely out of pride, and for the right to say that we walked "up-hills both ways through 3 feet of snow, everyday". Our code was tied ever-so-tightly to our hardware platform, and the system code was indistinguishable from the application. While we didn't use an RTOS, we had effectively implemented a 3-priority threading scheme using a carefully designed interrupt nesting scheme with event flags and a while(1) superloop running as a background thread. Nothing was abstracted, and the code was always optimized for the platform, presumably in an effort to save on code size and wasted cycles. I asked why we didn't use an RTOS in any of our systems and received dismissive scoffs - the overhead from thread switching and maintaining multiple threads could not be tolerated in our systems according to our chief engineers. In retrospect, our ad-hoc system was likely as large as my smallest kernel, and had just as much context switching (althrough it was hidden by the compiler).

And every time a new iteration of our product was developed, the firmware took far too long to bring up, because the algorithms and data structures had to be re-tooled to work with the peripherals and sensors attached to the new boards. We worked very hard in an attempt to reinvent the wheel, all in the name of producing "efficient" code.

Regardless, I learned a lot about embedded software development.

Most important, I learned that good design is the key to good software; and good design doesn't have to come at a price. In all but the smallest of projects, the well-designed, well-abstracted code is not only more portable, but it's usually smaller, easier to read, and easier to reuse.

Also, since we had all the time in the world to invest in developing our own tools, I gained a lot of experience building them, and making use of good, free PC tools that could be used to develop and debug a large portion of our code. I ended up writing PC-based device and peripheral simulators, state-machine frameworks, and abstractions for our

28 Why Mark3?

horrible ad-hoc system code. At the end of the day, I had developed enough tools that I could solve a lot of our development problems without having to re-inventing the wheel at each turn. Gaining a background in how these tools worked gave me a better understanding of how to use them - making me more productive at the jobs that I've had since.

I am convinced that designing good software takes honest effort up-front, and that good application code cannot be written unless it is based on a solid framework. Just as the wise man builds his house on rocks, and not on sand, wise developers write applications based on a well-defined platforms. And while you can probably build a house using nothing but a hammer and sheer will, you can certainly build one a lot faster with all the right tools.

This conviction lead me to development my first RTOS kernel in 2009 - FunkOS. It is a small, yet surprisingly full-featured kernel. It has all the basics (semaphores, mutexes, round-robin and preemptive scheduling), and some pretty advanced features as well (device drivers and other middleware). However, it had two major problems - it doesn't scale well, and it doesn't support many devices.

While I had modest success with this kernel (it has been featured on some blogs, and still gets around 125 downloads a month), it was nothing like the success of other RTOS kernels like uC/OS-II and FreeRTOS. To be honest, as a one-man show, I just don't have the resources to support all of the devices, toolchains, and evaluation boards that a real vendor can. I had never expected my kernel to compete with the likes of them, and I don't expect Mark3 to change the embedded landscape either.

My main goal with Mark3 was to solve the technical shortfalls in the FunkOS kernel by applying my experience in kernel development. As a result, Mark3 is better than FunkOS in almost every way; it scales better, has lower interrupt latency, and is generally more thoughtfully designed (all at a small cost to code size).

Another goal I had was to create something easy to understand, that could be documented and serve as a good introduction to RTOS kernel design. The end result of these goals is the kernel as presented in this book - a full source listing of a working OS kernel, with each module completely documented and explained in detail.

Finally, I wanted to prove that a kernel written entirely in C++ could perform just as well as one written in C. Mark3 is fully benchmarked and profiled – you can see exactly how much it costs to call certain APIs or include various features in the kernel.

And in addition, the code is more readable and easier to understand as a result of making use of object-oriented concepts provided by C++. Applications are easier to write because common concepts are encapsulated into objects (Threads, Semaphores, Mutexes, etc.) with their own methods and data, as opposed to APIs which rely on lots of explicit pointer or handle-passing, type casting, and other operations that are typically considered "unsafe" or "advaned" topics in C.

## **Chapter 7**

# When should you use an RTOS?

## 7.1 The reality of system code

System code can be defined as the program logic required to manage, synchronize, and schedule all of the resources (CPU time, memory, peripherals, etc.) used by the application running on the CPU. And it's true that a significant portion of the code running on an embedded system will be system code. No matter how simple a system is, whether or not this logic is embedded directly into the application (bare-metal system), or included as part of a well-defined stack on which an application is written (RTOS-based); system code is still present, and it comes with a cost.

As an embedded systems is being designed, engineers have to decide which approach to take: Bare-metal, or RTOS. There are advantages and disadvantages to each – and a reasonable engineer should always perform a thorough analysis of the pros and cons of each - in the context of the given application - before choosing a path.

The following figure demonstrates the differences between the architecture of a bare-metal system and RTOS based system at a high level:




Figure 7.1 Arch

As can be seen, the RTOS (And associated middleware + libraries) captures a certain fixed size.

As a generalization, bare-metal systems typically have the advantage in that the system code overhead is small to start – but grows significantly as the application grows in complexity. At a certain point, it becomes extremely difficult and error-prone to add more functionality to an application running on such a system. There's a tipping point, where the cost of the code used to work-around the limitations of a bare-metal system outweigh the cost of a capable RTOS. Bare-metal systems also generally take longer to implement, because the system code has to be written from scratch (or derived from existing code) for the application. The resulting code also tend to be less portable, as it takes serious discipline to keep the system-specific elements of the code separated – in an RTOS-based system, once the kernel and drivers are ported, the application code is generally platform agnostic.

Conversely, an RTOS-based system incurs a slightly higher fixed cost up-front, but scales infinitely better than a bare-metal system as application's complexity increases. Using an RTOS for simple systems reduces application development time, but may cause an application not to fit into some extremely size-constrained microcontroller. An RTOS can also cause the size of an application to grow more slowly relative to a bare-metal system – especially as a result of applying synchronization mechanisms and judicious IPC. As a result, an RTOS makes it significantly easier to "go agile" with an application – iteratively adding features and functionality, without having to consider refactoring the underlying system at each turn.

Some of these factors may be more important than others. Requirements, specifications, schedules, chip-selection, and volume projections for a project should all be used to feed into the discussions to decide whether or to go bare-metal or RTOS as a result.

Consider the following questions when making that decision:

- · What is the application?
- · How efficient is efficient enough?
- · How fast is fast enough?
- · How small is small enough?
- · How responsive is responsive enough?
- · How much code space/RAM/etc is available on the target system?
- How much code space/RAM do I need for an RTOS?
- · How much code space/RAM do I think I'll need for my application?
- · How much time do I have to deliver my system?
- · How many units do we plan to sell?

## 7.2 Superloops, and their limitations

## 7.2.1 Intro to Superloops

Before we start taking a look at designing a real-time operating system, it's worthwhile taking a look through one of the most-common design patterns that developers use to manage task execution in bare-metal embedded systems - Superloops.

Systems based on superloops favor the system control logic baked directly into the application code, usually under the guise of simplicity, or memory (code and RAM) efficiency. For simple systems, superloops can definitely get the job done. However, they have some serious limitations, and are not suitable for every kind of project. In a lot of cases you can squeak by using superloops - especially in extremely constrained systems, but in general they are not a solid basis for reusable, portable code.

Nonetheless, a variety of examples are presented here- from the extremely simple, to cooperative and liimted-preemptive multitasking systems, all of which are examples are representative of real-world systems that I've either written the firmware for, or have seen in my experience.

#### 7.2.2 The simplest loop

Let's start with the simplest embedded system design possible - an infinite loop that performs a single task repeatedly:

```
int main()
{
    while(1)
    {
        Do_Something();
    }
}
```

Here, the code inside the loop will run a single function forever and ever. Not much to it, is there? But you might be surprised at just how much embedded system firmware is implemented using essentially the same mechanism - there isn't anything wrong with that, but it's just not that interesting.

Despite its simplicity we can see the beginnings of some core OS concepts. Here, the while(1) statement can be logically seen as the he operating system kernel - this one control statement determines what tasks can run in the system, and defines the constraints that could modify their execution. But at the end of the day, that's a big part of what a kernel is - a mechanism that controls the execution of application code.

The second concept here is the task. This is application code provided by the user to perform some useful purpose in a system. In this case Do\_something() represents that task - it could be monitoring blood pressure, reading a sensor and writing its data to a terminal, or playing an MP3; anything you can think of for an embedded system to do. A simple round-robin multi-tasking system can be built off of this example by simply adding additional tasks in sequence in the main while-loop. Note that in this example the CPU is always busy running tasks - at no time is the CPU idle, meaning that it is likely burning a lot of power.

While we conceptually have two separate pieces of code involved here (an operating system kernel and a set of running tasks), they are not logically separate. The OS code is indistinguishable from the application. It's like a single-celled organism - everything is crammed together within the walls of an indivisible unit; and specialized to perform its given function relying solely on instinct.

#### 7.2.3 Interrupt-Driven Super-loop

In the previous example, we had a system without any way to control the execution of the task- it just runs forever. There's no way to control when the task can (or more importantly can't) run, which greatly limits the usefulness of the system. Say you only want your task to run every 100 miliseconds - in the previous code, you have to add a hard-coded delay at the end of your task's execution to ensure your code runs only when it should.

Fortunately, there is a much more elegant way to do this. In this example, we introduce the concept of the synchronization object. A Synchronization object is some data structure which works within the bounds of the operating system to tell tasks when they can run, and in many cases includes special data unique to the synchronization event.

There are a whole family of synchronization objects, which we'll get into later. In this example, we make use of the simplest synchronization primitive

the global flag.

With the addition of synchronization brings the addition of event-driven systems. If you're programming a microcontroller system, you generally have scores of peripherals available to you - timers, GPIOs, ADCs, UARTs, ethernet, USB, etc. All of which can be configured to provide a stimulus to your system by means of interrupts. This stimulus gives us the ability not only to program our micros to do\_something(), but to do\_something() if-and-only-if a corresponding trigger has occurred.

The following concepts are shown in the example below:

```
volatile K_BOOL something_to_do = false;
__interrupt__ My_Interrupt_Source(void)
{
    something_to_do = true;
}
int main()
{
    while (1)
{
        if (something_to_do)
        {
            Do_something();
            something_to_do = false;
        }
        else
        {
             Idle();
        }
}
```

So there you have it - an event driven system which uses a global variable to synchronize the execution of our task based on the occurrence of an interrupt. It's still just a bare-metal, OS-baked-into-the-application system, but it's introduced a whole bunch of added complexity (and control!) into the system.

The first thing to notice in the source is that the global variable, something\_to\_do, is used as a synchronization object. When an interrupt occurs from some external event, triggering the My\_Interrupt\_Source() ISR, program flow in main() is interrupted, the interrupt handler is run, and something\_to\_do is set to true, letting us know that when we get back to main(), that we should run our Do\_something() task.

Another new concept at play here is that of the idle function. In general, when running an event driven system, there are times when the CPU has no application tasks to run. In order to minimize power consumption, CPUs usually contain instructions or registers that can be set up to disable non-essential subsets of the system when there's nothing to do. In general, the sleeping system can be re-activated quickly as a result of an interrupt or other external stimulus, allowing normal processing to resume.

Now, we could just call Do\_something() from the interrupt itself - but that's generally not a great solution. In general, the more time we spend inside an interrupt, the more time we spend with at least some interrupts disabled. As a result, we end up with interrupt latency. Now, in this system, with only one interrupt source and only one task this might not be a big deal, but say that Do\_something() takes several seconds to complete, and in that time several other interrupts occur from other sources. While executing in our long-running interrupt, no other interrupts can be processed - in many cases, if two interrupts of the same type occur before the first is processed, one of these interrupt events will be lost. This can be utterly disastrous in a real-time system and should be avoided at all costs. As a result, it's generally preferable to use synchronization objects whenever possible to defer processing outside of the ISR.

Another OS concept that is implicitly introduced in this example is that of task priority. When an interrupt occurs, the normal execution of code in main() is preempted: control is swapped over to the ISR (which runs to completion), and then control is given back to main() where it left off. The very fact that interrupts take precedence over what's running shows that main is conceptually a "low-priority" task, and that all ISRs are "high-priority" tasks. In this example, our "high-priority" task is setting a variable to tell our "low-priority" task that it can do something useful. We will investigate the concept of task priority further in the next example.

Preemption is another key principle in embedded systems. This is the notion that whatever the CPU is doing when an interrupt occurs, it should stop, cache its current state (referred to as its context), and allow the high-priority event to be processed. The context of the previous task is then restored its state before the interrupt, and resumes processing. We'll come back to preemption frequently, since the concept comes up frequently in RTOS-based systems.

## 7.2.4 Cooperative multi-tasking

Our next example takes the previous example one step further by introducing cooperative multi-tasking:

```
// Bitfield values used to represent three distinct tasks
#define TASK_1_EVENT (0x01)
#define TASK_2_EVENT (0x02)
#define TASK_3_EVENT (0x04)
volatile K_UCHAR event_flags = 0;
// Interrupt sources used to trigger event execution
 _interrupt__ My_Interrupt_1(void)
    event flags |= TASK 1 EVENT;
 _interrupt__ My_Interrupt_2(void)
    event_flags |= TASK_2_EVENT;
 _interrupt__ My_Interrupt_3(void)
    event_flags |= TASK_3_EVENT;
// Main tasks
int main(void)
    while(1)
       while (event_flags)
            if( event_flags & TASK_1_EVENT)
                Do_Task_1();
                event_flags &= ~TASK_1_EVENT;
            } else if( event_flags & TASK_2_EVENT) {
                Do Task 2();
                event_flags &= ~TASK_2_EVENT;
            } else if( event_flags & TASK_3_EVENT) {
                Do_Task_3();
                event_flags &= ~TASK_3_EVENT;
        Idle();
```

This system is very similar to what we had before - however the differences are worth discussing. First, we have stimulus from multiple interrupt sources: each ISR is responsible for setting a single bit in our global event flag, which is then used to control execution of individual tasks from within main().

Next, we can see that tasks are explicitly given priorities inside the main loop based on the logic of the if/else if structure. As long as there is something set in the event flag, we will always try to execute Task1 first, and only when Task1 isn't set will we attempt to execute Task2, and then Task3. This added logic provides the notion of priority. However, because each of these tasks exist within the same context (they're just different functions called from our main control loop), we don't have the same notion of preemption that we have when dealing with interrupts.

That means that even through we may be running Task2 and an event flag for Task1 is set by an interrupt, the CPU still has to finish processing Task2 to completion before Task1 can be run. And that's why this kind of scheduling is referred to as cooperative multitasking: we can have as many tasks as we want, but unless they cooperate by means of returning back to main, the system can end up with high-priority tasks getting starved for CPU time by lower-priority, long-running tasks.

This is one of the more popular Os-baked-into-the-application approaches, and is widely used in a variety of real-time embedded systems.

## 7.2.5 Hybrid cooperative/preemptive multi-tasking

The final variation on the superloop design utilizes software-triggered interrupts to simulate a hybrid cooperative/preemptive multitasking system. Consider the example code below.

```
// Bitfields used to represent high-priority tasks. Tasks in this group
// can preempt tasks in the group below - but not eachother.
#define HP_TASK_1(0x01)
#define HP_TASK_2(0x02)
volatile K_UCHAR hp_tasks = 0;
// Bitfields used to represent low-priority tasks.
#define LP_TASK_1(0x01)
#define LP_TASK_2(0x02)
volatile K_UCHAR lp_tasks = 0;
// Interrupt sources, used to trigger both high and low priority tasks.
__interrupt__ System_Interrupt_1(void)
    // Set any of the other tasks from here...
hp_tasks |= HP_TASK_1;
// Trigger the SWI that calls the High_Priority_Tasks interrupt handler
  _interrupt__ System_Interrupt_n...(void)
// Set any of the other tasks from here...
// Interrupt handler that is used to implement the high-priority event context
 _interrupt__ High_Priority_Tasks(void)
    // Enabled every interrupt except this one
    Disable_My_Interrupt();
    Enable_Interrupts();
    while( hp_tasks)
        if( hp_tasks & HP_TASK_1)
        {
            HP_Task1();
            hp_tasks &= ~HP_TASK_1;
        else if (hp_tasks & HP_TASK_2)
            HP_Task2();
            hp_tasks &= ~HP_TASK_2;
    Restore_Interrupts();
    Enable_My_Interrupt();
// Main loop, used to implement the low-priority events
int main(void)
    // Set the function to run when a SWI is triggered
    Set_SWI(High_Priority_Tasks);
    // Run our super-loop
    while(1)
        while (lp_tasks)
             if (lp_tasks & LP_TASK_1)
                 LP_Task1();
                 lp_tasks &= ~LP_TASK_1;
            else if (lp_tasks & LP_TASK_2)
                 LP_Task2();
                 lp_tasks &= ~LP_TASK_2;
        Idle();
}
```

In this example, High\_Priority\_Tasks() can be triggered at any time as a result of a software interrupt (SWI),. When a high-priority event is set, the code that sets the event calls the SWI as well, which instantly preempts whatever is happening in main, switching to the high-priority interrupt handler. If the CPU is executing in an interrupt handler already, the current ISR completes, at which point control is given to the high priority interrupt handler.

Once inside the HP ISR, all interrupts (except the software interrupt) are re-enabled, which allows this interrupt to be preempted by other interrupt sources, which is called interrupt nesting. As a result, we end up with two distinct execution contexts (main and HighPriorityTasks()), in which all tasks in the high-priority group are guaranteed to preempt main() tasks, and will run to completion before returning control back to tasks in main(). This is a very basic preemptive multitasking scenario, approximating a "real" RTOS system with two threads of different priorities.

## 7.3 Problems with superloops

As mentioned earlier, a lot of real-world systems are implemented using a superloop design; and while they are simple to understand due to the limited and obvious control logic involved, they are not without their problems.

#### 7.3.1 Hidden Costs

It's difficult to calculate the overhead of the superloop and the code required to implement workarounds for blocking calls, scheduling, and preemption. There's a cost in both the logic used to implement workarounds (usually involving state machines), as well as a cost to maintainability that comes with breaking up into chunks based on execution time instead of logical operations. In moderate firmware systems, this size cost can exceed the overhead of a reasonably well-featured RTOS, and the deficit in maintainability is something that is measurable in terms of lost productivity through debugging and profiling.

## 7.3.2 Tightly-coupled code

Because the control logic is integrated so closely with the application logic, a lot of care must be taken not to compromise the separation between application and system code. The timing loops, state machines, and architecture-specific control mechanisms used to avoid (or simulate) preemption can all contribute to the problem. As a result, a lot of superloop code ends up being difficult to port without effectively simulating or replicating the underlying system for which the application was written. Abstraction layers can mitigate the risks, but a lot of care should be taken to fully decouple the application code from the system code.

## 7.3.3 No blocking Calls

In a super-loop environment, there's no such thing as a blocking call or blocking objects. Tasks cannot stop midexecution for event-driven I/O from other contexts - they must always run to completion. If busy-waiting and polling are used as a substitute, it increases latency and wastes cycles. As a result, extra code complexity is often times necessary to work-around this lack of blocking objects, often times through implementing additional state machines. In a large enough system, the added overhead in code size and cycles can add up.

## 7.3.4 Difficult to guarantee responsiveness

Without multiple levels of priority, it may be difficult to guarantee a certain degree of real-time responsiveness without added profiling and tweaking. The latency of a given task in a priority-based cooperative multitasking system is the length of the longest task. Care must be taken to break tasks up into appropriate sized chunks in order to ensure that higher- priority tasks can run in a timely fashion - a manual process that must be repeated as new tasks are added in the system. Once again, this adds extra complexity that makes code larger, more difficult to understand and maintain due to the artificial subdivision of tasks into time-based components.

## 7.3.5 Limited preemption capability

As shown in the example code, the way to gain preemption in a superloop is through the use of nested interrupts. While this isn't unwiedly for two levels of priority, adding more levels beyond this is becomes complicated. In this case, it becomes necessary to track interrupt nesting manually, and separate sets of tasks that can run within given priority loops - and deadlock becomes more difficult to avoid.

## **Chapter 8**

# Can you afford an RTOS?

#### 8.1 Intro

Of course, since you're reading the manual for an RTOS that I've been developing over the course of the several years, you can guess that the conclusion that I draw.

If your code is of any sort of non-trivial complexity (say, at least a few- thousand lines), then a more appropriate question would be "can you afford not\* to use an RTOS in your system?".

In short, there are simply too many benefits of an RTOS to ignore, the most important being:

Threading, along with priority and time-based scheduling Sophisticated synchronization objects and IPC Flexible, powerful Software Timers Ability to write more portable, decoupled code

Sure, these features have a cost in code space and RAM, but from my experience the cost of trying to code around a lack of these features will cost you as much - if not more. The results are often far less maintainable, error prone, and complex. And that simply adds time and cost. Real developers ship, and the RTOS is quickly becoming one of the standard tools that help keep developers shipping.

One of the main arguments against using an RTOS in an embedded project is that the overhead incurred is too great to be justified. Concerns over "wasted" RAM caused by using multiple stacks, added CPU utilization, and the "large" code footprint from the kernel cause a large number of developers to shun using a preemptive RTOS, instead favoring a non-preemptive, application-specific solution.

I believe that not only is the impact negligible in most cases, but that the benefits of writing an application with an RTOS can lead to savings around the board (code size, quality, reliability, and development time). While these other benefits provide the most compelling case for using an RTOS, they are far more challenging to demonstrate in a quantitative way, and are clearly documented in numerous industry-based case studies.

While there is some overhead associated with an RTOS, the typical arguments are largely unfounded when an RTOS is correctly implemented in a system. By measuring the true overhead of a preemptive RTOS in a typical application, we will demonstrate that the impact to code space, RAM, and CPU usage is minimal, and indeed acceptable for a wide range of CPU targets.

To illustrate just how little an RTOS impacts the size of an embedded software design we will look at a typical microcontroller project and analyze the various types of overhead associated with using a pre-emptive realtime kernel versus a similar non-preemptive event-based framework.

RTOS overhead can be broken into three distinct areas:

- Code space: The amount of code space eaten up by the kernel (static)
- Memory overhead: The RAM associated with running the kernel and application threads.
- Runtime overhead: The CPU cycles required for the kernel's functionality (primarily scheduling and thread switching)

While there are other notable reasons to include or avoid the use of an RTOS in certain applications (determinism, responsiveness, and interrupt latency among others), these are not considered in this discussion - as they are difficult to consider for the scope of our "canned" application.

## 8.2 Application description

For the purpose of this comparison, we first create an application using the standard preemptive Mark3 kernel with 2 system threads running: A foreground thread and a background thread. This gives three total priority levels in the system - the interrupt level (high), and two application priority threads (medium and low), which is quite a common paradigm for microcontroller firmware designs. The foreground thread processes a variety of time-critical events at a fixed frequency, while the background thread processes lower priority, aperiodic events. When there are no background thread events to process, the processor enters its low-power mode until the next interrupt is acknowledged.

The contents of the threads themselves are unimportant for this comparison, but we can assume they perform a variety of realtime I/O functions. As a result, a number of device drivers are also implemented.

Code Space and Memory Overhead:

The application is compiled for an ATMega328p processor which contains 32kB of code space in flash, and 2kB of RAM, which is a lower-mid-range microcontroller in Atmel's 8-bit AVR line of microcontrollers. Using the AVR GCC compiler with -Os level optimizations, an executable is produced with the following code/RAM utilization:

Program: 27914 bytes Data: 1313 bytes

An alternate version of this project is created using a custom "super-loop" kernel, which uses a single application thread and provides 2 levels of priority (interrupt and application). In this case, the event handler processes the different priority application events to completion from highest to lowest priority.

This approach leaves the application itself largely unchanged. Using the same optimization levels as the preemptive kernel, the code compiles as follows:

Program: 24886 bytes Data: 750 bytes

At first glance, the difference in RAM utilization seems quite a lot higher for the preemptive mode version of the application, but the raw numbers don't tell the whole story.

The first issue is that the cooperative-mode total does not take into account the system stack - whereas these values are included in the totals for RTOS version of the project. As a result, some further analysis is required to determine how the stack sizes truly compare.

In cooperative mode, there is only one thread of execution - so considering that multiple event handlers are executed in turn, the stack requirements for cooperative mode is simply determined by those of the most stack-intensive event handler (ignoring stack use contributions due to interrupts).

In contrast, the preemptive kernel requires a separate stack for each active thread, and as a result the stack usage of the system is the sum of the stacks for all threads.

Since the application and idle events are the same for both preemptive and cooperative mode, we know that their (independent) stack requirements will be the same in both cases.

For cooperative mode, we see that the idle thread stack utilization is lower than that of the application thread, and so the application thread's determines the stack size requirement. Again, with the preemptive kernel the stack utilization is the sum of the stacks defined for both threads.

As a result, the difference in overhead between the two cases becomes the extra stack required for the idle thread - which in our case is (a somewhat generous) 128 bytes.

The numbers still don't add up completely, but looking into the linker output we see that the rest of the difference comes from the extra data structures used to manage the kernel in preemptive mode, and the kernel data itself.

Fixed kernel data costs:

8.3 Runtime Overhead 39

```
--- 134 Bytes Kernel data
--- 26 Bytes Kernel Vtables
```

#### Application (Variable) data costs:

```
--- 24 Bytes Driver Vtables --- 123 Bytes - statically-allocated kernel objects (semaphores, timers, etc.)
```

With this taken into account, the true memory cost of a 2-thread system ends up being around 428 bytes of  $R \leftarrow AM$  - which is about 20% of the total memory available on this particular microcontroller. Whether or not this is reasonable certainly depends on the application, but more importantly, it is not so unreasonable as to eliminate an RTOS-based solution from being considered. Also note that by using the "simulated idle" feature provided in Mark3 R3 and onward, the idle thread (and its associated stack) can be eliminated altogether to reduce the cost in constrained devices.

The difference in code space overhead between the preemptive and cooperative mode solutions is less of an issue. Part of this reason is that both the preemptive and cooperative kernels are relatively small, and even an average target device (like the Atmega328 we've chosen) has plenty of room.

Mark3 can be configured so that only features necessary for the application are included in the RTOS - you only pay for the parts of the system that you use. In this way, we can measure the overhead on a feature-by-feature basis, which is shown below for the kernel as configured for this application:

The configuration tested in this comparison uses the thread/port module with timers, drivers, and semaphores, and mutexes, for a total kernel size of 5052 Bytes, with the rest of the code space occupied by the application.

As can be seen from the compiler's output, the difference in code space between the two versions of the application is 3028 bytes - or about 9% of the available code space on the selected processor. While nearly all of this comes from the added overhead of the kernel, the rest of the difference comes the changes to the application necessary to facilitate the different frameworks. This also demonstrates that the system-software code size in the cooperative case is about 2024 bytes.

#### 8.3 Runtime Overhead

On the cooperative kernel, the overhead associated with running the thread is the time it takes the kernel to notice a pending event flag and launch the appropriate event handler, plus the timer interrupt execution time.

Similarly, on the preemptive kernel, the overhead is the time it takes to switch contexts to the application thread, plus the timer interrupt execution time.

The timer interrupt overhead is similar for both cases, so the overhead then becomes the difference between the following:

Preemptive mode:

- Posting the semaphore that wakes the high-priority thread
- Performing a context switch to the high-priority thread

#### Cooperative mode:

- · Setting the event flag from the timer interrupt
- · Acknowledging the event from the event loop

coop - 438 cycles preempt - 764 cycles

Using a cycle-accurate AVR simulator (flAVR) running with a simulated speed of 16MHz, we find the end-to-end event sequence time to be 27us for the cooperative mode scheduler and 48us for the preemptive, and a raw difference of 20us.

With a fixed high-priority event frequency of 30Hz, we achieve a runtime overhead of 611us per second, or 0.06% of the total available CPU time. Now, obviously this value would expand at higher event frequencies and/or slower CPU frequencies, but for this typical application we find the difference in runtime overhead to be neglible for a preemptive system.

## 8.4 Analysis

For the selected test application and platform, including a preemptive RTOS is entirely reasonable, as the costs are low relative to a non-preemptive kernel solution. But these costs scale relative to the speed, memory and code space of the target processor. Because of these variables, there is no "magic bullet" environment suitable for every application, but Mark3 attempts to provide a framework suitable for a wide range of targets.

On the one hand, if these tests had been performed on a higher-end microcontroller such as the ATMega1284p (containing 128kB of code space and 16kB of RAM), the overhead would be in the noise. For this type of resource-rich microcontroller, there would be no reason to avoid using the Mark3 preemptive kernel.

Conversely, using a lower-end microcontroller like an ATMega88pa (which has only 8kB of code space and 1kB of RAM), the added overhead would likely be prohibitive for including a preemptive kernel. In this case, the cooperative-mode kernel would be a better choice.

As a rule of thumb, if one budgets 25% of a microcontroller's code space/RAM for system code, you should only require at minimum a microcontroller with 16k of code space and 2kB of RAM as a base platform for an RTOS. Unless there are serious constraints on the system that require much better latency or responsiveness than can be achieved with RTOS overhead, almost any modern platform is sufficient for hosting a kernel. In the event you find yourself with a microprocessor with external memory, there should be no reason to avoid using an RTOS at all.

# **Chapter 9**

# **Mark3 Design Goals**

#### 9.1 Overview

#### 9.1.1 Services Provided by an RTOS Kernel

At its lowest-levels, an operating system kernel is responsible for managing and scheduling resources within a system according to the application. In a typical thread-based RTOS, the resources involved is CPU time, and the kernel manages this by scheduling threads and timers. But capable RTOS kernels provide much more than just threading and timers.

In the following section, we discuss the Mark3 kernel architecture, all of its features, and a thorough discussion of how the pieces all work together to make an awesome RTOS kernel.

#### 9.1.2 Guiding Principles of Mark3

Mark3 was designed with a number of over-arching principles, coming from years of experience designing, implementing, refining, and experimenting with RTOS kernels. Through that process I not only discovered what features I wanted in an RTOS, but how I wanted to build those features to look, work, and "feel". With that understanding, I started with a clean slate and began designing a new RTOS. Mark3 is the result of that process, and its design goals can be summarized in the following guiding principles.

#### 9.1.3 Be feature competitive

To truly be taken seriously as more than just a toy or educational tool, an RTOS needs to have a certain feature suite. While Mark3 isn't a clone of any existing RTOS, it should at least attempt parity with the most common software in its class.

Looking at its competitors, Mark3 as a kernel supports most, if not all of the compelling features found in modern RTOS kernels, including dynamic threads, tickless timers, efficient message passing, and multiple types of synchronization primatives.

#### 9.1.4 Be highly configuration

Mark3 isn't a one-size-fits-all kernel – and as a result, it provides the means to build a custom kernel to suit your needs. By configuring the kernel at compile-time, Mark3 can be built to contain the optimal feature set for a given application. And since features can be configured individually, you only pay the code/RAM footprint for the features you actually use.

42 Mark3 Design Goals

# 9.1.5 No external dependencies, no new language features

To maximize portability and promote adoption to new platforms, Mark3 is written in a widely supported subset of C++ that lends itself to embedded applications. It avoids RTTI, exceptions, templates, and libraries (C standard, STL, etc.), with all fundamental data structures and types implemented completely for use by the kernel. As a result, the portable parts of Mark3 should compile for any capable C++ toolchain.

## 9.1.6 Target the most popular hobbyist platforms available

Realistically, this means supporting the various Arduino-compatible target CPUs, including AVR and ARM Cortex-M series microcontrollers. As a result, the current default target for Mark3 is the atmega328p, which has 32KB of flash and 2KB of RAM. All decisions regarding default features, code size, and performance need to take that target system into account.

Mark3 integrates cleanly as a library into the Arduino IDE to support atmega328-based targets. Other AVR and Cortex-M targets can be supported using the port code provided in the source package.

# 9.1.7 Maximize determinism – but be pragmatic

Guaranteeing deterministic and predictable behavior is tough to do in an embedded system, and often comes with a heavy price tag in either RAM or code-space. With Mark3, we strive to keep the core kernel APIs and features as lightweight as possible, while avoiding algorithms that don't scale to large numbers of threads. We also achieve minimal latency by keeping interrupts enabled (operating out of the critical section) wherever possible.

In Mark3, the most important parts of the kernel are fixed-time, including thread scheduling and context switching. Operations that are not fixed time can be characterized as a function of their dependent data data. For instances, the Mutex and Semaphore APIs operate in fixed time in the uncontested case, and execute in linear time for the contested case – where the speed of execution is dependent on the number of threads currently waiting on that object.

The caveat here is that while we want to minimize latency and time spent in critical sections, that has to be balanced against increases in code size, and uncontested-case performance.

#### 9.1.8 Apply engineering principles – and that means discipline, measurement and verification

My previous RTOS, FunkOS, was designed to be very ad-hoc. The usage instructions were along the lines of "drag and drop the source files into your IDE and compile". There was no regression/unit testing, no code size/speed profiling, and all documentation was done manually. It worked, but the process was a bit of a mess, and resulted in a lot of re-spins of the software, and a lot of time spent stepping through emulators to measure parameters.

We take a different approach in Mark3. Here, we've designed not only the kernel-code, but the build system, unit tests, profiling code, documentation and reporting that supports the kernel. Each release is built and tested using automation in order to ensure quality and correctness, with supporting documentation containing all critical metrics. Only code that passes testing is submitted to the repos and public forums for distribution. These metrics can be traced from build-to-build to ensure that performance remains consistent from one drop to the next, and that no regressions are introduced by new/refactored code.

And while the kernel code can still be exported into an IDE directly, that takes place with the knowledge that the kernel code has already been rigorously tested and profiled. Exporting source in Mark3 is also supported by scripting to ensure reliable, reproducible results without the possibility for human-error.

9.1 Overview 43

#### 9.1.9 Use Virtualization For Verification

Mark3 was designed to work with automated simulation tools as the primary means to validate changes to the kernel, due to the power and flexibility of automatic tests on virtual hardware. I was also intrigued by the thought of extending the virtual target to support functionality useful for a kernel, but not found on real hardware.

When the project was started, simavr was the tool of choice- however, its simulation was found to be incorrect compared to execution on a real MCU, and it did not provide the degree of extension that I desired for use with kernel development.

The flAVR AVR simulator was written to replace the dependency on that tool, and overcome those limitations. It also provides a GDB interface, as well as its own built-in debugger, profilers, and trace tools.

The example and test code relies heavily on flAVR kernel aware messaging, so it is recommended that you familiarize yourself with that tool if you intend to do any sort of customizations or extensions to the kernel.

flAVR is hosted on sourceforge at http://www.sourceforge.net/projects/flavr/ . In its basic configuration, it builds with minimal external dependencies.

- · On linux, it requires only pthreads.
- On Windows, it rquires pthreads and ws2 32, both satisfied via MinGW.
- Optional SDL builds for both targets (featuring graphics and simulated joystick input) can be built, and rely on libSDL.

44 Mark3 Design Goals

# **Chapter 10**

# **Mark3 Kernel Architecture**

#### 10.1 Overview

At a high level, the Mark3 RTOS is organized into the following features, and layered as shown below:




Figure 10.1 Overview

Everything in the "green" layer represents the Mark3 public API and classes, beneath which lives all hardware abstraction and CPU-specific porting and driver code, which runs on a given target CPU.

The features and concepts introduced in this diagram can be described as follows:

**Threads:** The ability to multiplex the CPU between multiple tasks to give the perception that multiple programs are running simultaneously. Each thread runs in its own context with its own stack.

**Scheduler:** Algorithm which determines the thread that gets to run on the CPU at any given time. This algorithm takes into account the priorites (and other execution parameters) associated with the threads in the system.

**IPC:** Inter-process-communications. Message-passing and Mailbox interfaces used to communicate between threads synchronously or asynchronously.

**Synchronization Objects:** Ability to schedule thread execution relative to system conditions and events, allowing for sharing global data and resources safely and effectively.

**Timers:** High-resolution software timers that allow for actions to be triggered on a periodic or one-shot basis.

**Profiler:** Special timer used to measure the performance of arbitrary blocks of code.

Debugging: Realitme logging and trace functionality, facilitating simplified debugging of systems using the OS.

Atomics: Support for UN-interruptble arithmatic operations.

**Driver API:** Hardware abstraction interface allowing for device drivers to be written in a consistent, portable manner.

**Hardware Abstraction Layer:** Class interface definitions to represent threading, context-switching, and timers in a generic, abstracted manner.

Porting Layer: Class interface implementation to support threading, context-switching, and timers for a given CPU.

**User Drivers:** Code written by the user to implement device-specific peripheral drivers, built to make use of the Mark3 driver API.

Each of these features will be described in more detail in the following sections of this chapter.

The concepts introduced in the above architecture are implemented in a variety of source modules, which are logically broken down into classes (or in some cases, groups of functions/macros). The relationship between objects in the Mark3 kernel is shown below:




Figure 10.2 Overview

The objects shown in the preceding table can be grouped together by feature. In the table below, we group each feature by object, referencing the source module in which they can be found in the Mark3 source tree.

Feature	Kernel Object	Source Files
Profiling	ProfileTimer	profile.cpp/.h
Threads + Scheduling	Thread	thread.cpp/.h
	Scheduler	scheduler.cpp/.h
	PriorityMap	priomap.cpp/.h
	Quantum	quantum.cpp/.h

Feature	Kernel Object	Source Files
	ThreadPort	threadport.cpp/.h **
	KernelSWI	kernelswi.cpp/.h **
Timers	Timer	timer.h/timer.cpp
	TimerScheduler	timerscheduler.h
	TimerList	timerlist.h/cpp
	KernelTimer	kerneltimer.cpp/.h **
Synchronization	BlockingObject	blocking.cpp/.h
	Semaphore	ksemaphore.cpp/.h
	EventFlag	eventflag.cpp/.h
	Mutex	mutex.cpp/.h
	Notify	notify.cpp/.h
IPC/Message-passing	Mailbox	mailbox.cpp/.h
	MessageQueue	message.cpp/.h
	GlobalMessagePool	message.cpp/.h
Debugging	Miscellaneous Macros	kerneldebug.h
	KernelAware	kernelaware.cpp/.h
	TraceBuffer	tracebuffer.cpp/.h
	Buffalogger	buffalogger.h
Device Drivers	Driver	driver.cpp/.h
Atomic Operations	Atomic	atomic.cpp/.h
Kernel	Kernel	kernel.cpp/.h

# 10.2 Threads and Scheduling

The classes involved in threading and scheudling in Mark3 are highlighted in the following diagram, and are discussed in detail in this chapter:

<sup>\*\*</sup> implementation is platform-dependent, and located under the kernel's \*\* /cpu/<arch>/<variant>/<toolchain> folder in the source tree




Figure 10.3 Threads and Scheduling

#### 10.2.1 A Bit About Threads

Before we get started talking about the internals of the Mark3 scheduler, it's necessary to go over some background material - starting with: what is a thread, anyway?

Let's look at a very basic CPU without any sort of special multi-threading hardware, and without interrupts. When the CPU is powered up, the program counter is loaded with some default location, at which point the processor core will start executing instructions sequentially - running forever and ever according to whatever has been loaded into program memory. This single instance of a simple program sequence is the only thing that runs on the processor, and the execution of the program can be predicted entirely by looking at the CPU's current register state, its program, and any affected system memory (the CPU's "context").

It's simple enough, and that's exactly the definition we have for a thread in an RTOS.

Each thread contains an instance of a CPU's register context, its own stack, and any other bookkeeping information necessary to define the minimum unique execution state of a system at runtime. It is the job of a RTOS to multiplex the execution of multiple threads on a single physical CPU, thereby creating the illusion that many programs are being executed simultaneously. In reality there can only ever be one thread truly executing at any given moment on a CPU core, so it's up to the scheduler to set and enforce rules about what thread gets to run when, for how long, and under what conditions. As mentioned earlier, any system without an RTOS exeuctes as a single thread, so at least two threads are required for an RTOS to serve any useful purpose.

Note that all of this information is is common to pretty well every RTOS in existence - the implementation details, including the scheduler rules, are all part of what differentiates one RTOS from another.

#### 10.2.2 Thread States and ThreadLists

Since only one thread can run on a CPU at a time, the scheduler relies on thread information to make its decisions. Mark3's scheduler relies on a variety of such information, including:

- · The thread's current priority
- · Round-Robin execution quanta
- · Whether or not the thread is blocked on a synchronization object, such as a mutex or semaphore
- · Whether or not the thread is currently suspended

The scheduler further uses this information to logically place each thread into 1 of 4 possible states:

```
Ready - The thread is currently running
Running - The thread is able to run
Blocked - The thread cannot run until a system condition is met
Stopped - The thread cannot run because its execution has been suspended
.
```

In order to determine a thread's state, threads are placed in "buckets" corresponding to these states. Ready and running threads exist in the scheduler's buckets, blocked threads exist in a bucket belonging to the object they're blocked on, and stopped threads exist in a separate bucket containing all stopped threads.

In reality, the various buckets are just doubly-linked lists of Thread objects - implemented in something called the ThreadList class. To facilitate this, the Thread class directly inherits from a LinkListNode class, which contains the node pointers required to implement a doubly-linked list. As a result, Threads may be effortlessly moved from one state to another using efficient linked-list operations built into the ThreadList class.

#### 10.2.3 Blocking and Unblocking

While many developers new to the concept of an RTOS assume that all threads in a system are entirely separate from eachother, the reality is that practical systems typically involve multiple threads working together, or at the very least sharing resources. In order to synchronize the execution of threads for that purpose, a number of synchronization primatives (blocking objects) are implemented to create specific sets of conditions under which threads can continue execution. The concept of "blocking" a thread until a specific condition is met is fundamental to understanding RTOS applications design, as well as any highly-multithreaded applications.

#### 10.2.4 Blocking Objects

Blocking objects and primatives provided by Mark3 include:

- · Semaphores (binary and counting)
- Mutexes
- · Event Flags
- Thread Notification Objects
- · Thread Sleep
- Message Queues

· Mailboxes

The relationship between these objects in the system are shown below:




Figure 10.4 Blocking Objects

Each of these objects inherit from the BlockingObject class, which itself contains a ThreadList object. This class contains methods to Block() a thread (remove it from the Scheduler's "Ready" or "Running" ThreadLists), as well as UnBlock() a thread (move a thread back to the "Ready" lists). This object handles transitioning threads from list-to-list (and state-to-state), as well as taking care of any other Scheduler bookkeeping required in the process. While each of the Blocking types implement a different condition, they are effectively variations on the same theme. Many simple Blocking objects are also used to build complex blocking objects - for instance, the Thread Sleep mechanism is essentially a binary semaphore and a timer object, while a message queue is a linked-list of message objects combined with a semaphore.

#### 10.3 Inside the Mark3 Scheduler

At this point we've covered the following concepts:

- · Threads
- Thread States and Thread Lists
- · Blocking and Un-Blocking Threads

Thankfully, this is all the background required to understand how the Mark3 Scheduler works. In technical terms, Mark3 implements "strict priority scheduling, with round-robin scheduling among threads in each priority group". In plain English, this boils down to a scheduler which follows a few simple rules:

```
Find the highest-priority "Ready" list that has at least one Threads. If the first thread in that bucket is not the current thread, select it to run next. Otherwise, rotate the linked list, and choose the next thread in the list to run
```

Since context switching is one of the most common and frequent operation performed by an RTOS, this needs to be as fast and deterministic as possible. While the logic is simple, a lot of care must be put into optimizing the scheduler to achieve those goals. In the section below we discuss the optimization approaches taken in Mark3.

There are a number of ways to find the highest-priority thread. The naive approach would be to simply iterate through the scheduler's array of ThreadLists from highest to lowest, stopping when the first non-empty list is found, such as in the following block of code:

While that would certainly work and be sufficient for a variety of systems, it's a non-deterministic approach (complexity O(n)) whose cost varies substantially based on how many priorities have to be evaluated. It's simple to read and understand, but it's non-optimal.

Fortunatley, a functionally-equivalent and more deterministic approach can be implemented with a few tricks.

In addition to maintaining an array of ThreadLists, Mark3 also maintains a bitmap (one bit per priority level) that indicates which thread lists have ready threads. This bitmap is maintained automatically by the ThreadList class, and is updated every time a thread is moved to/from the Scheduler's ready lists.

By inspecting this bitmap using a technique to count the leading zero bits in the bitmap, we determine which threadlist to choose in fixed time.

Now, to implement the leading-zeros check, this can once again be performed iteratively using bitshifts and compares (which isn't any more efficient than the raw list traversal), but it can also be evaluated using either a lookup table, or via a special CPU instruction to count the leading zeros in a value. In Mark3, we opt for the lookup-table approach since we have a limited number of priorities and not all supported CPU architectures support a count leading zero instruction. To achieve a balance between performance and memory use, we use a 4-bit lookup table (costing 16 bytes) to perform the lookup.

(As a sidenote - this is actually a very common approach in OS schedulers. It's actually part of the reason why modern ARM cores implement a dedicated count-leading-zeros [CLZ] instruction!)

With a 4-bit lookup table and an 8-bit priority-level bitmap, the priority check algorithm looks something like this:

```
// Check the highest 4 priority levels, represented in the
// upper 4 bits in the bitmap
priority = priority_lookup_table[(priority_bitmap >> 4)];

// priority is non-zero if we found something there
if( priority )
{
    // Add 4 because we were looking at the higher levels
    priority += 4;
}
else
{
    // Nothing in the upper 4, look at the lowest 4 priority levels
    // represented by the lowest 4 bits in the bitmap
    priority = priority_lookup_table[priority_bitmap & 0x0F];
}
```

Deconstructing this algorithm, you can see that the priority lookup will have on O(1) complexity - and is extremely low-cost.

This operation is thus fully deterministic and time bound - no matter how many threads are scheduled, the operation will always be time-bound to the most expensive of these two code paths. Even with only 8 priority levels, this is still much faster than iteratively checking the thread lists manually, compared with the previous example implementation.

Once the priority level has been found, selecting the next thread to run is trivial, consisting of something like this:

next\_thread = thread\_list[prio].get\_head();

In the case of the get\_head() calls, this evaluates to an inline-load of the "head" pointer in the particular thread list.

One important thing to take away from this analysis is that the scheduler is only responsible for selecting the next-torun thread. In fact, these two operations are totally decoupled - no context switching is performed by the scheduler, and the scheduler isn't called from the context switch. The scheduler simply produces new "next thread" values that are consumed from within the context switch code.

#### 10.3.1 Considerations for Round-Robin Scheduling

One thing that isn't considered directly from the scheduler algorithm is the problem of dealing with multiple threads within a single priority group; all of the alorithms that have been explored above simply look at the first Thread in each group.

Mark3 addresses this issue indirectly, using a software timer to manage round-robin scheduling, as follows.

In some instances where the scheduler is run by the kernel directly (typically as a result of calling Thread::Yield()), the kernel will perfom an additional check after running the Scheduler to determine whether or there are multiple ready Threadsin the priority of the next ready thread.

If there are multiple threads within that priority, the kernel adds a one-shot software timer which is programmed to expire at the next Thread's configured quantum. When this timer expires, the timer's callback function executes to perform two simple operations:

"Pivot" the current Thread's priority list. Set a flag telling the kernel to trigger a Yield after exiting the main Timer Scheduler processing loop

Pivoting the thread list basically moves the head of a circular-linked-list to its next value, which in our case ensures that a new thread will be chosen the next time the scheduler is run (the scheduler only looks at the head node of the priority lists). And by calling Yield, the system forces the scheduler t run, a new round-robin software timer to be installed (if necssary), and triggers a context switch SWI to load the newly-chosen thread. Note that if the thread attached to the round-robin timer is pre-empted, the kernel will take steps to abort and invalidate that round-robin software timer, installing a new one tied to the next thread to run if necessary.

Because the round-robin software timer is dynamically installed when there are multiple ready threads at the highest ready priority level, there is no CPU overhead with this feature unless that condition is met. The cost of round-robin scheduling is also fixed - no matter how many threads there are, and the cost is identical to any other one-shot software timer in the system.

10.4 Timers 53

# 10.3.2 Context Switching

There's really not much to say about the actual context switch operation at a high level. Context switches are triggered whenever it has been determined that a new thread needs to be swapped into the CPU core when the scheduler is run. Mark3 implements also context switches as a call to a software interrupt - on AVR platforms, we typically use INT0 or INT2 for this (although any pin-change GPIO interrupt can be used), and on ARM we achieve this by triggering a PendSV exception.

However, regardless of the architecture, the contex-switch ISR will perform the following three operations:

Save the current Thread's context to the current Thread stack Make the "next to run" thread the "currently running" thread Restore the context of the next Thread from the Thread stack

The code to implement the context switch is entirely architecture-specific, so it won't be discussed in detail here. It's almost always gory inline-assembly which is used to load and store various CPU registers, and is highly-optimized for speed. We dive into an example implementation for the ARM Cortex-M0 microcontroller in a later section of this book.

### 10.3.3 Putting It All Together

In short, we can say that the Mark3 scheduler works as follows:

- The scheduler is run whenever a Thread::Yield() is called by a user, as part of blocking calls, or whenever a new thread is started
- The Mark3 scheduler is deterministic, selecting the next thread to run in fixed-time
- The scheduler only chooses the next thread to run, the context switch SWI consumes that information to get that thread running
- Where there are multiple ready threads in the highest populated priority level, a software timer is used to manage round-robin scheduling

While we've covered a lot of ground in this section, there's not a whole lot of code involved. However, the code that performs these operations is nuanced and subtle. If you're interested in seeing how this all works in practice, I suggest reading through the Mark3 source code (which is heavily annotated), and stepping through the code with a simulator/emulator.

# 10.4 Timers

Mark3 implements one-shot and periodic software-timers via the Timer class. The user configures the timer for duration, repetition, and action, at which point the timer can be activated. When an active timer expires, the kernel calls a user-specified callback function, and then reloads the timer in the case of periodic timers. The same timer objects exposed to the user are also used within the kernel to implement round-robin scheduling, and timeout-based APIs for seamphores, mutexes, events, and messages.

Timers are implemented using the following components in the Mark3 Kernel:




Figure 10.5 Timers

The Timer class provides the basic periodic and one-shot timer functionality used by application code, blocking objects, and IPC.

The TimerList class implements a doubly-linked list of Timer objects, and the logic required to implement a timer tick (tick-based kernel) or timer expiry (tickless kernel) event.

The TimerScheduler class contains a single TimerList object, implementing a single, system-wide list of Timer objects within the kernel. It also provides hooks for the hardware timer, such that when a timer tick or expiry event occurs, the TimerList expiry handler is run.

The KernelTimer class (kerneltimer.cpp/.h) implements the CPU specific hardware timer driver that is used by the kernel and the TimerScheduler to implement software timers.

While extremely simple to use, they provide one of the most powerful execution contexts in the system.

The software timers implemented in Mark3 use interrupt-nesting within the kernel timer's interrupt handler. This context is be considered higher-priority than the highest priority user thread, but lower-priority than other interrupts in the system. As a result, this minimizes critical interrupt latency in the system, albeit at the expense of responsiveness of the user-threads.

For this reason, it's critical to ensure that all timer callback events are kept as short as possible to prevent adding thread-level latency. All heavy-lifting should be left to the threads, so the callback should only implement signalling via IPC or synchronization object.

The time spent in this interrupt context is also dependent on the number of active timers at any given time. However, Mark3 also can be used to minimize the frequency of these interrupts wakeups, by using an optional "tolerance" parameter in the timer API calls. In this way, periodic tasks that have less rigorous real-time constraints can all be grouped together – executing as a group instead of one-after-another.

Mark3 also contains two different timer implementations that can be configured at build-time, each with their own advantages.

10.4 Timers 55

# 10.4.1 Tick-based Timers

In a tick-based timing scheme, the kernel relies on a system-timer interrupt to fire at a relatively-high frequency, on which all kernel timer events are derived. On modern CPUs and microcontrollers, a 1kHz system tick is common, although quite often lower frequencies such as 60Hz, 100Hz, or 120Hz are used. The resolution of this timer also defines the maximum resolution of timer objects as a result. That is, if the timer frequency is 1kHz, a user cannot specify a timer resolution lowerthan 1ms.

The advantage of a tick-based timer is its sheer simplicity. It typically doesn't take much to set up a timer to trigger an interrupt at a fixed-interval, at which point, all system timer intervals are decremented by 1 count. When each system timer interval reaches zero, a callback is called for the event, and the events are either reset and restarted (repeated timers) or cleared (1-shot).

Unfortunately, that simplicity comes at a cost of increased interrupt count, which cause frequent CPU wakeups and utilization, and power consumption.

#### 10.4.2 Tickless Timers

In a tickless system, the kernel timer only runs when there are active timers pending expiry, and even then, the timer module only generates interrupts when a timer expires, or a timer reaches its maximum count value. Additionally, when there are no active timer objects, the timer can is completely disabled – saving even more cycles, power, and CPU wakeups. These factors make the tickless timer approach a highly-optimal solution, suitable for a wide array of low-power applications.

Also, since tickless timers do not rely on a fixed, periodic clock, they can potentially be higher resolution. The only limitation in timer resolution is the precision of the underlying hardware timer as configured. For example, if a 32kHz hardware timer is being used to drive the timer scheduler, the resolution of timer objects would be in the  $\sim$ 33us range.

The only downside of the tickless timer system is an added complexity to the timer code, requiring more code space, and slightly longer execution of the timer routines when the timer interrupt is executed.

## 10.4.3 Timer Processing Algorithm

Timer interrupts occur at either a fixed-frequency (tick-based), or at the next timer expiry interval (tickless), at which point the timer processing algorithm runs. While the timer count is reset by the timer-interrupt, it is still allowed to accumulate ticks while this algorithm is executed in order to ensure that timer-accuracy is kept in real-time. It is also important to note that round-robin scheduling changes are disabled during the execution of this algorithm to prevent race conditions, as the round-robin code also relies on timer objects.

All active timer objects are stored in a doubly-linked list within the timer-scheduler, and this list is processed in two passes by the alogirthm which runs from the timer-interrupt (with interrupt nesting enabled). The first pass determines which timers have expired and the next timer interval, while the second pass deals with executing the timer callbacks themselves. Both phases are discussed in more detail below.

In the first pass, the active timers are decremented by either 1 tick (tick-based), or by the duration of the last elapsed timer interval (tickless). Timers that have zero (or less-than-zero) time remaining have a "callback" flag set, telling the algorithm to call the timer's callback function in the second pass of the loop. In the event of a periodic timer, the timer's interval is reset to its starting value.

For the tickless case, the next timer interval is also computed in the first-pass by looking for the active timer with the least amount of time remaining in its interval. Note that this calculation is irrelevant in the tick-based timer code, as the timer interrupt fires at a fixed-frequency.

56 Mark3 Kernel Architecture

In the second pass, the algorithms loops through the list of active timers, looking for those with their "callback" flag set in the first pass. The callback function is then executed for each expired timer, and the "callback" flag cleared. In the event that a non-periodic (one-shot) timer expires, the timer is also removed from the timer scheduler at this time.

In a tickless system, once the second pass of the loop has been completed, the hardware timer is checked to see if the next timer interval has expired while processing the expired timer callbacks. In that event, the complete algorithm is re-run to ensure that no expired timers are missed. Once the algorithm has completed without the next timer expiring during processing, the expiry time is programmed into the hardware timer. Round-robin scheduling is re-enabled, and if a new thread has been scheduled as a result of action taken during a timer callback, a context switch takes place on return from the timer interrupt.

# 10.5 Synchronization and IPC




Figure 10.6 Synchronization and IPC

# 10.6 Blocking Objects

A Blocking object in Mark3 is essentially a thread list. Any blocking object implementation (being a semaphore, mutex, event flag, etc.) canbe built on top of this class, utilizing the provided functions to manipulate thread location within the Kernel.

Blocking a thread results in that thread becoming de-scheduled, placed in the blocking object's own private list of threads which are waiting on the object.

Unblocking a thread results in the reverse: The thread is moved back to its original location from the blocking list.

The only difference between a blocking object based on this class is the logic used to determine what consitutes a Block or Unblock condition.

10.6 Blocking Objects 57

For instance, a semaphore Pend operation may result in a call to the Block() method with the currently-executing thread in order to make that thread wait for a semaphore Post. That operation would then invoke the UnBlock() method, removing the blocking thread from the semaphore's list, and back into the appropriate thread inside the scheduler.

Care must be taken when implementing blocking objects to ensure that critical sections are used judiciously, otherwise asynchronous events like timers and interrupts could result in non-deterministic and often catastrophic behavior

Mark3 implements a variety of blocking objects including semaphores, mutexes, event flags, and IPC mechanisms that all inherit from the basic Blocking-object class found in blocking.h/cpp, ensuring consistency and a high degree of code-reuse between components.

## 10.6.1 Semaphores

Semaphores are used to synchronized execution of threads based on the availability (and quantity) of application-specific resources in the system. They are extremely useful for solving producer-consumer problems, and are the method-of-choice for creating efficient, low latency systems, where ISRs post semaphores that are handled from within the context of individual threads. Semaphores can also be posted (but not pended) from within the interrupt context.

#### 10.6.2 Mutex

Mutexes (Mutual exclusion objects) are provided as a means of creating "protected sections" around a particular resource, allowing for access of these objects to be serialized. Only one thread can hold the mutex at a time

• other threads have to wait until the region is released by the owner thread before they can take their turn operating on the protected resource. Note that mutexes can only be owned by threads - they are not available to other contexts (i.e. interrupts). Calling the mutex APIs from an interrupt will cause catastrophic system failures.

Note that these objects are recursive in Mark3 - that is, the owner thread can claim a mutex more than once. The caveat here is that a recursively-held mutex will not be released until a matching "release" call is made for each "claim" call.

Priority inheritence is provided with these objects as a means to avoid priority inversions. Whenever a thread at a priority than the mutex owner blocks on a mutex, the priority of the current thread is boosted to the highest-priority waiter to ensure that other tasks at intermediate priorities cannot artificically prevent progress from being made.

#### 10.6.3 Event Flags

Event Flags are another synchronization object, conceptually similar to a semaphore.

Unlike a semaphore, however, the condition on which threads are unblocked is determined by a more complex set of rules. Each Event Flag object contains a 16-bit field, and threads block, waiting for combinations of bits within this field to become set.

A thread can wait on any pattern of bits from this field to be set, and any number of threads can wait on any number of different patterns. Threads can wait on a single bit, multiple bits, or bits from within a subset of bits within the field.

As a result, setting a single value in the flag can result in any number of threads becoming unblocked simultaneously. This mechanism is extremely powerful, allowing for all sorts of complex, yet efficient, thread synchronization schemes that can be created using a single shared object.

Note that Event Flags can be set from interrupts, but you cannot wait on an event flag from within an interrupt.

# 10.6.4 Notification Objects

Notification objects are the most lightweight of all blocking objects supplied by Mark3.

using this blocking primative, one or more threads wait for the notification object to be signalled by code elsewhere in the system (i.e. another thread or interrupt). Once the notification has been signalled, all threads currently blocked on the object become unblocked and moved into the ready list.

Signalling a notification object that has no actively-waiting threads has no effect.

# 10.7 Messages and Global Message Queue

#### 10.7.1 Messages

Sending messages between threads is the key means of synchronizing access to data, and the primary mechanism to perform asynchronous data processing operations.

Sending a message consists of the following operations:

- · Obtain a Message object from the global message pool
- · Set the message data and event fields
- Send the message to the destination message queue

While receiving a message consists of the following steps:

- · Wait for a messages in the destination message queue
- · Process the message data
- Return the message back to the global message pool

These operations, and the various data objects involved are discussed in more detail in the following section.

# 10.7.2 Message Objects

Message objects are used to communicate arbitrary data between threads in a safe and synchronous way.

The message object consists of an event code field and a data field. The event code is used to provide context to the message object, while the data field (essentially a void \* data pointer) is used to provide a payload of data corresponding to the particular event.

Access to these fields is marshalled by accessors - the transmitting thread uses the SetData() and SetCode() methods to seed the data, while the receiving thread uses the GetData() and GetCode() methods to retrieve it.

By providing the data as a void data pointer instead of a fixed-size message, we achieve an unprecedented measure of simplicity and flexibility. Data can be either statically or dynamically allocated, and sized appropriately for the event without having to format and reformat data by both sending and receiving threads. The choices here are left to the user - and the kernel doesn't get in the way of efficiency.

It is worth noting that you can send messages to message queues from within ISR context. This helps maintain consistency, since the same APIs can be used to provide event-driven programming facilities throughout the whole of the OS.

#### 10.7.3 Global Message Pool

To maintain efficiency in the messaging system (and to prevent over-allocation of data), a global pool of message objects is provided. The size of this message pool is specified in the implementation, and can be adjusted depending on the requirements of the target application as a compile-time option.

Allocating a message from the message pool is as simple as calling the

GlobalMessagePool::Pop() Method.

Messages are returned back to the GlobalMessagePool::Push() method once the message contents are no longer required.

One must be careful to ensure that discarded messages always are returned to the pool, otherwise a resource leak will occur, which may cripple the operating system's ability to pass data between threads.

# 10.7.4 Message Queues

Message objects specify data with context, but do not specify where the messages will be sent. For this purpose we have a MessageQueue object. Sending an object to a message queue involves calling the MessageQueue::Send() method, passing in a pointer to the Message object as an argument.

When a message is sent to the queue, the first thread blocked on the queue (as a result of calling the Message ← Queue Receive() method) will wake up, with a pointer to the Message object returned.

It's worth noting that multiple threads can block on the same message queue, providing a means for multiple threads to share work in parallel.

# 10.7.5 Mailboxes

Another form of IPC is provided by Mark3, in the form of Mailboxes and Envelopes. Mailboxes are similar to message queues in that they provide a synchronized interface by which data can be transmitted between threads.

Where Message Queues rely on linked lists of lightweight message objects (containing only message code and a void\* data-pointer), which are inherently abstract, Mailboxes use a dedicated blob of memory, which is carved up into fixed-size chunks called Envelopes (defined by the user), which are sent and received. Unlike message queues, mailbox data is copied to and from the mailboxes dedicated pool.

Mailboxes also differ in that they provide not only a blocking "receive" call, but also a blocking "send" call, providing the opportunity for threads to block on "mailbox full" as well as "mailbox empty" conditions.

All send/receive APIs support an optional timeout parameter if the KERNEL\_USE\_TIMEOUTS option has been configured in mark3cfg.h

# 10.7.6 Atomic Operations




Figure 10.7 Atomic operations

This utility class provides primatives for atomic operations - that is, operations that are guaranteed to execute uninterrupted. Basic atomic primatives provided here include Set/Add/Delete for 8, 16, and 32-bit integer types, as well as an atomic test-and-set.

#### 10.7.7 Drivers




Figure 10.8 Drivers

This is the basis of the driver framework. In the context of Mark3, drivers don't necessarily have to be based on physical hardware peripherals. They can be used to represent algorithms (such as random number generators), files, or protocol stacks. Unlike FunkOS, where driver IO is protected automatically by a mutex, we do not use this kind of protection - we leave it up to the driver implementor to do what's right in its own context. This also frees up the driver to implement all sorts of other neat stuff, like sending messages to threads associated with the driver. Drivers are implemented as character devices, with the standard array of posix-style accessor methods for reading, writing, and general driver control.

A global driver list is provided as a convenient and minimal "filesystem" structure, in which devices can be accessed by name.

#### **Driver Design**

A device driver needs to be able to perform the following operations:

- · Initialize a peripheral
- · Start/stop a peripheral
- · Handle I/O control operations
- · Perform various read/write operations

At the end of the day, that's pretty much all a device driver has to do, and all of the functionality that needs to be presented to the developer.

We abstract all device drivers using a base-class which implements the following methods:

- · Start/Open
- · Stop/Close
- Control
- Read
- Write

A basic driver framework and API can thus be implemented in five function calls - that's it! You could even reduce that further by handling the initialize, start, and stop operations inside the "control" operation.

#### **Driver API**

In C++, we can implement this as a class to abstract these event handlers, with virtual void functions in the base class overridden by the inherited objects.

To add and remove device drivers from the global table, we use the following methods:

```
void DriverList::Add( Driver *pclDriver_ );
void DriverList::Remove( Driver *pclDriver_ );
```

DriverList::Add()/Remove() takes a single argument - the pointer to the object to operate on.

Once a driver has been added to the table, drivers are opened by NAME using DriverList::FindBy Name("/dev/name"). This function returns a pointer to the specified driver if successful, or to a built in /dev/null device if the path name is invalid. After a driver is open, that pointer is used for all other driver access functions.

This abstraction is incredibly useful - any peripheral or service can be accessed through a consistent set of APIs, that make it easy to substitute implementations from one platform to another. Portability is ensured, the overhead is negligible, and it emphasizes the reuse of both driver and application code as separate entities.

Consider a system with drivers for I2C, SPI, and UART peripherals - under our driver framework, an application can initialize these peripherals and write a greeting to each using the same simple API functions for all drivers:

```
pclI2C = DriverList::FindByName("/dev/i2c");
pclUART = DriverList::FindByName("/dev/tty0");
pclSPI = DriverList::FindByName("/dev/spi");
pclI2C->Write(12, "Hello World!");
pclUART->Write(12, "Hello World!");
pclSPI->Write(12, "Hello World!");
```

# 10.8 Kernel Proper and Porting




Figure 10.9 Kernel Proper and Porting

The Kernel class is a static class with methods to handle the initialization and startup of the RTOS, manage errors, and provide user-hooks for fatal error handling (functions called when Kernel::Panic() conditions are encountered), or when the Idle function is run.

Internally, Kernel::Init() calls the initialization routines for various kernel objects, providing a single interface by which all RTOS-related system initialization takes place.

Kernel::Start() is called to begin running OS funcitonality, and does not return. Control of the CPU is handed over to the scheduler, and the highest-priority ready thread begins execution in the RTOS environment.

#### **Harware Abstraction Layer**

Almost all of the Mark3 kernel (and middleware) is completely platform independent, and should compile cleanly on any platform with a modern C++ compiler. However, there are a few areas within Mark3 that can only be implemented by touching hardware directly.

These interfaces generally cover four features:

- · Thread initializaiton and context-switching logic
- Software interrupt control (used to generate context switches)
- Hardware timer control (support for time-based functionlity, such as Sleep())
- Code-execution profiling timer (not necessary to port if code-profiling is not compiled into the kernel)

The hardware abstraction layer in Mark3 provides a consistent interface for each of these four features. Mark3 is ported to new target architectures by providing an implementation for all of the interfaces declared in the abstraction layer. In the following section, we will explore how this was used to port the kernel to ARM Cortex-M0.

#### Real-world Porting Example - Cortex M0

This section serves as a real-world example of how Mark3 can be ported to new architectures, how the Mark3 abstraction layer works, and as a practical reference for using the RTOS support functionality baked in modern  $A \leftarrow RM$  Cortex-M series microcontrollers. Most of this documentation here is taken directly from the source code found in the /kernel/cpu/cm0/ ports directory, with additional annotations to explain the port in more detail. Note that a familiarity with Cortex-M series parts will go a long way to understanding the subject matter presented, especially a basic understanding of the ARM CPU registers, exception models, and OS support features (PendSV, SysTick and SVC). If you're unfamiliar with ARM architecture, pay attention to the comments more than the source itself to illustrate the concepts.

Porting Mark3 to a new architecture consists of a few basic pieces; for developers familiar with the target architecture and the porting process, it's not a tremendously onerous endeavour to get Mark3 up-and-running somewhere new. For starters, all non-portable components are completely isolated in the source-tree under:

/embedded/kernel/CPU/VARIANT/TOOLCHAIN/,

where CPU is the architecture, VARIANT is the vendor/part, and TOOLCHAIN is the compiler tool suite used to build the code.

From within the specific port folder, a developer needs only implement a few classes and headers that define the port-specific behavior of Mark3:

- KernelSWI (kernelswi.cpp/kernelswi.h) Provides a maskable software-triggered interrupt used to perform context switching.
- KernelTimer (kerneltimer.cpp/kerneltimer.h) Provides either a fixed-frequency or programmable-interval timer, which triggers an interrupt on expiry. This is used for implementing round-robin scheduling, thread-sleeps, and generic software timers.
- Profiler (kprofile.cpp/kprofile.h) Contains code for runtime code-profiling. This is optional and may be stubbed out if left unimplemented (we won't cover profiling timers here).
- ThreadPort (threadport.cpp/threadport.h) The meat-and-potatoes of the port code lives here. This class contains architecture/part-specific code used to initialize threads, implement critical-sections, perform context-switching, and start the kernel. Most of the time spent in this article focuses on the code found here.

Summarizing the above, these modules provide the following list of functionality:

```
Thread stack initialization
Kernel startup and first thread entry
Context switch and SWI
Kernel timers
Critical Sections
```

The implementation of each of these pieces will be analyzed in detail in the sections that follow.

#### Thread Stack Initialization

Before a thread can be used, its stack must first be initialized to its default state. This default state ensures that when the thread is scheduled for the first time and its context restored, that it will cause the CPU to jump to the user's specified entry-point function.

All of the platform independent thread setup is handled by the generic kernel code. However, since every CPU architecture has its own register set, and stacks different information as part of an interrupt/exception, we have to implement this thread setup code for each platform we want the kernel to support (Combination of Architecture + Variant + Toolchain).

In the ARM Cortex-M0 architecture, the stack frame consists of the following information:

#### a) Exception Stack Frame

Contains the 8 registers which the ARM Cortex-M0 CPU automatically pushes to the stack when entering an exception. The following registers are included (in stack'd order):

```
[ XPSR ] <-- Highest address in context
[ PC     ]
[ LR     ]
[ R12     ]
[ R3     ]
[ R2     ]
[ R1     ]
[ R0     ]</pre>
```

XPSR – This is the CPU's status register. We need to set this to 0x01000000 (the "T" bit), which indicates that the CPU is executing in "thumb" mode. Note that ARMv6m and ARMv7m processors only run thumb2 instructions, so an exception is liable to occur if this bit ever gets cleared.

PC – Program Counter. This should be set with the initial entry point (function pointer) for that the user wishes to start executing with this thread.

LR - The base link register. Normally, this register contains the return address of the calling function, which is where the CPU jumps when a function returns. However, our threads generally don't return (and if they do, they're placed into the stop state). As a result we can leave this as 0.

The other registers in the stack frame are generic working registers, and have no special meaning, with the exception that R0 will hold the user's argument value passed into the entrypoint.

b) Complimentary CPU Register Context

```
[ R11 ]
...
[ R4 ] <-- Lowest address in context</pre>
```

These are the other general-purpose CPU registers that need to be backed up/ restored on a context switch, but aren't stacked by default on a Cortex-M0 exception. If there were any additional hardware registers to back up, then we'd also have to include them in this part of the context as well.

As a result, these registers all need to be manually pushed to the stack on stack creation, and will need to be explicitly pushed and pop as part of a normal context switch.

With this default exception state in mind, the following code is used to initialize a thread's stack for a Cortex-M0.

```
void ThreadPort::InitStack(Thread *pclThread_)
   K_ULONG *pulStack;
   K_ULONG *pulTemp;
   K ULONG ulAddr:
   K USHORT i:
   // Get the entrypoint for the thread
   ulAddr = (K_ULONG) (pclThread_->m_pfEntryPoint);
   // Get the top-of-stack pointer for the thread
   pulStack = (K_ULONG*)pclThread_->m_pwStackTop;
    // Initialize the stack to all FF's to aid in stack depth checking
   pulTemp = (K_ULONG*)pclThread_->m_pwStack;
   for (i = 0; i < pclThread_->m_usStackSize / sizeof(K_ULONG); i++)
       pulTemp[i] = 0xFFFFFFF;
   PUSH_TO_STACK(pulStack, 0);
                                          // Apply one word of padding
   //-- Simulated Exception Stack Frame --
                                         // XSPR; set "T" bit for thumb-mode
   PUSH_TO_STACK(pulStack, 0x01000000);
   PUSH_TO_STACK(pulStack, ulAddr);
   PUSH_TO_STACK(pulStack, 0);
   PUSH_TO_STACK(pulStack, 0x12);
   PUSH_TO_STACK(pulStack, 0x3);
   PUSH_TO_STACK(pulStack, 0x2);
   PUSH_TO_STACK(pulStack, 0x1);
   //-- Simulated Manually-Stacked Registers --
   PUSH_TO_STACK(pulStack, 0x11);
   PUSH_TO_STACK(pulStack, 0x10);
   PUSH_TO_STACK (pulStack, 0x09);
   PUSH TO STACK (pulStack, 0x08);
   PUSH_TO_STACK(pulStack, 0x07);
   PUSH_TO_STACK(pulStack, 0x06);
   PUSH_TO_STACK(pulStack, 0x05);
   PUSH_TO_STACK (pulStack, 0x04);
   pulStack++;
   pclThread_->m_pwStackTop = pulStack;
```

#### **Kernel Startup**

The same general process applies to starting the kernel on an ARM Cortex-M0 as on other platforms. Here, we initialize and start the platform specific timer and software-interrupt modules, find the first thread to run, and then jump to that first thread.

Now, to perform that last step, we have two options:

1) Simulate a return from an exception manually to start the first thread, or.. 2) Use a software interrupt to trigger the first "Context Restore/Return from Interrupt"

For 1), we basically have to restore the whole stack manually, not relying on the CPU to do any of this for us. That's certainly doable, but not all Cortex parts support this (other members of the family support privileged modes, etc.). That, and the code required to do this is generally more complex due to all of the exception-state simulation. So, we will opt for the second option instead.

To implement a software to start our first thread, we will use the SVC instruction to generate an exception. From that exception, we can then restore the context from our first thread, set the CPU up to use the right "process" stack, and return-from-exception back to our first thread. We'll explore the code for that later.

But, before we can call the SVC exception, we're going to do a couple of things.

First, we're going to reset the default MSP stack pointer to its original top-of-stack value. The rationale here is that we no longer care about the data on the MSP stack, since calling the SVC instruction triggers a chain of events from which we never return. The MSP is also used by all exception-handling, so regaining a few words of stack here can be useful. We'll also enable all maskable exceptions at this point, since this code results in the kernel being started with the CPU executing the RTOS threads, at which point a user would expect interrupts to be enabled.

Note, the default stack pointer location is stored at address 0x00000000 on all ARM Cortex M0 parts. That explains the code below...

```
void ThreadPort_StartFirstThread( void )
{
    asm(
        " ldr r1, [r0] \n" // Reset the MSP to the default base address
        " msr msp, r1 \n"
        " cpsie i \n" // Enable interrupts
        " svc 0 \n" // Jump to SVC Call
    );
}
```

#### First Thread Entry

This handler has the job of taking the first thread object's stack, and restoring the default state data in a way that ensures that the thread starts executing when returning from the call.

We also keep in mind that there's an 8-byte offset from the beginning of the thread object to the location of the thread stack pointer. This offset is a result of the thread object inheriting from the linked-list node class, which has 8-bytes of data. This is stored first in the object, before the first element of the class, which is the "stack top" pointer.

The following assembly code shows how the SVC call is implemented in Mark3 for the purpose of starting the first thread.

```
get thread stack:
    ; Get the stack pointer for the current thread
    ldr r0, g_pstCurrent
    ldr r1, [r0]
    add r1, #8
   ldr r2, [r1]
                         : r2 contains the current stack-top
load_manually_placed_context_r11_r8:
   ; Handle the bottom 32-bytes of the stack frame
    ; Start with r11-r8, because only r0-r7 can be used
    ; with ldmia on CMO.
    add r2. #16
    ldmia r2!, {r4-r7}
    mov r11, r7
    mov r10, r6
    mov r9, r5
   mov r8, r4
set psp:
    ; Since r2 is coincidentally back to where the stack pointer should be,
    ; Set the program stack pointer such that returning from the exception handler
load_manually_placed_context_r7_r4:
    ; Get back to the bottom of the manually stacked registers and pop.
    sub r2, #32
    ldmia r2!, {r4-r7} ; Register r4-r11 are restored.
set_thread_and_privilege_modes:
    ; Also modify the control register to force use of thread mode as well
    ; For CM3 forward-compatibility, also set user mode.
    mrs r0, control
   mov r1, #0x03
    orr r0, r1
    control, r0
    ; Set up the link register such that on return, the code operates
    ; in thread mode using the PSP. To do this, we or 0x0D to the value stored
    ; in the lr by the exception hardware EXC_RETURN. Alternately, we could
    ; just force lr to be 0xFFFFFFFD (we know that's what we want from the
    ; hardware, anyway)
   mov r0, #0x0D
mov r1, lr
    orr r0, r1
   ; Return from the exception handler.
    ; The CPU will automagically unstack R0-R3, R12, PC, LR, and xPSR \,
              If all goes well, our thread will start execution at the
    : for us.
    ; entrypoint, with the us-specified argument.
    bx r0
```

68 Mark3 Kernel Architecture

On ARM Cortex parts, there's dedicated hardware that's used primarily to support RTOS (or RTOS-like) funcationlity. This functionality includes the SysTick timer, and the PendSV Exception. SysTick is used for a tick-based kernel timer, while the PendSV exception is used for performing context switches. In reality, it's a "special SVC" call that's designed to be lower-overhead, in that it isn't mux'd with a bunch of other system or application functionality.

So how do we go about actually implementing a context switch here? There are a lot of different parts involved, but it essentially comes down to 3 steps:

#### 1) Saving the context.

```
Thread's top-of-stack value is stored, all registers are stacked. We're good to go!
```

#### 2) Swap threads

```
We swap the Scheduler's "next" thread with the "current" thread.
```

#### 3) Restore Context

```
This is more or less identical to what we did when restoring the first context. Some operations may be optimized for data already stored in registers.
```

The code used to implement these steps on Cortex-M0 is presented below:

```
void PendSV_Handler(void)
     // Thread_SaveContext()
" ldr r1, CURR_ \n"
" ldr r1, [r1] \n "
" mov r3, r1 \n "
" add r3, #8 \n "
     // Grab the psp and adjust it by 32 based on extra registers we're going
     // to be manually stacking. " mrs r2, psp \n " sub r2, #32 \n "
     // While we're here, store the new top-of-stack value
     " str r2, [r3] \n
     // And, while r2 is at the bottom of the stack frame, stack r7-r4
     " stmia r2!, {r4-r7} n "
     // Stack r11-r8
     " mov r7, r11 \n "
     " mov r6, r10 \n "
     " mov r5, r9 \n "
     " mov r4, r8 \n "
     " stmia r2!, {r4-r7} \n "
     // Equivalent of Thread_Swap() - performs g_pstCurrent = g_pstNext
     " ldr r1, CURR_ \n"
" ldr r0, NEXT_ \n"
" ldr r0, [r0] \n"
" str r0, [r1] \n"
     // Thread_RestoreContext()
     // Get the pointer to the next thread's stack
     " add r0, #8 \n "
" ldr r2, [r0] \n "
     // Stack pointer is in r2, start loading registers from // the "manually-stacked" set \ensuremath{\mbox{\sc holimstate}}
     // Start with r\bar{1}1-r8, since these can't be accessed directly.
     " add r2, #16 \n "
     " ldmia r2!, {r4-r7} \n "
" mov r11, r7 \n "
" mov r10, r6 \n "
     " mov r9, r5 \n "
     " mov r8, r4 \n "
```

```
// After subbing R2 #16 manually, and #16 through ldmia, our PSP is where it
// needs to be when we return from the exception handler
" msr psp, r2 \n "

// Pop manually-stacked R4-R7
" sub r2, #32 \n "
" ldmia r2!, {r4-r7} \n "

// Ir contains the proper EXC_RETURN value
// we're done with the exception, so return back to newly-chosen thread
" bx lr \n "
" nop \n "

// Must be 4-byte aligned.
" NEXT_: .word g_pstNext \n"
" CURR_: .word g_pstCurrent \n"
);
```

#### **Kernel Timers**

ARM Cortex-M series microcontrollers each contain a SysTick timer, which was designed to facilitate a fixed-interval RTOS timer-tick. This timer is a precise 24-bit down-count timer, run at the main CPU clock frequency, that can be programmed to trigger an exception when the timer expires. The handler for this exception can thus be used to drive software timers throughout the system on a fixed interval.

Unfortunately, this hardware is extremely simple, and does not offer the flexibility of other timer hardware commonly implemented by MCU vendors - specifically a suitable timer prescalar that can be used to generate efficient, long-counting intervals. As a result, while the "generic" port of Mark3 for Cortex-M0 leverages the common SysTick timer interface, it only supports the tick-based version of the kernel's timer (note that specific Cortex-M0 ports such as the Atmel SAMD20 do have tickless timers).

Setting up a tick-based KernelTimer class to use the SysTick timer is, however, extremely easy, as is illustrated below:

```
void KernelTimer::Start(void)
    SysTick Config(PORT SYSTEM FREO / 1000); // 1KHz fixed clock...
    NVIC_EnableIRQ(SysTick_IRQn);
In this instance, the call to SysTick_Config() generates a 1kHz system-tick
signal, and the NVIC\_EnableIRQ() call ensures that a SysTick exception is
generated for each tick. All other functions in the Cortex version of the
KernelTimer class are essentially stubbed out (see the source for more details).
Note that the functions used in this call are part of the ARM Cortex
\hbox{\tt Microcontroller Software Interface Standard (cmsis), and are supplied by all}\\
parts vendors selling Cortex hardware. This greatly simplifies the design
of our port-code, since we can be reasonably assured that these APIs will
work the same on all devices.
The handler code called when a SysTick exception occurs is basically the
same as on other platforms (such as AVR), except that we explicitly clear the
"exception pending" bit before returning. This is implemented in the
following code:
\code{.cpp}
void SysTick_Handler(void)
#if KERNEL_USE_TIMERS
   TimerScheduler::Process();
#endif
#if KERNEL_USE_QUANTUM
    Quantum::UpdateTimer();
#endif
    // Clear the systick interrupt pending bit.
    SCB->ICSR |= SCB_ICSR_PENDSTCLR_Msk;
```

#### **Critical Sections**

A "critical section" is a block of code whose execution cannot be interrupted by means of context switches or an interrupt. In a traditional single-core operating system, it is typically implemented as a block of code where the interrupts are disabled - this is also the approach taken by Mark3. Given that every CPU has its own means of disabling/enabling interrupts, the implementation of the critical section APIs is also non-portable.

In the Cortex-M0 port, we implement the two critical section APIs (CS\_ENTER() and CS\_EXIT()) as function-like macros containing inline assembly. All uses of these calls are called in pairs within a function and must take place at the same level-of-scope. Also, as nesting may occur (critical section within a critical section), this must be taken into account in the code.

In general, CS\_ENTER() performs the following tasks:

```
    Cache the current interrupt-enabled state within a local variable in the thread's state
    Disable interrupts
```

Conversely, CS EXIT() performs the following tasks:

```
    Read the original interrupt-enabled state from the cached value
    Restore interrupts to the original value
```

On Cortex-M series microontrollers, the PRIMASK special register contains a single status bit which can be used to enable/disable all maskable interrupts at once. This register can be read directly to examine or modify its state. For convenience, ARMv6m provides two instructions to enable/disable interrupts

• cpsid (disable interrupts) and cpsie (enable interrupts). Mark3 Implements these steps according to the following code:

#### Summary

In this section we have investigated how the main non-portable areas of the Mark3 RTOS are implemented on a Cortex-M0 microcontroller. Mark3 leverages all of the hardware blocks designed to enable RTOS functionality on ARM Cortex-M series microcontrollers: the SVC call provides the mechanism by which we start the kernel, the PendSV exception provides the necessary software interrupt, and the SysTick timer provides an RTOS tick. As a result, Mark3 is a perfect fit for these devices - and as a result of this approach, the same RTOS port code should work with little to no modification on all ARM Cortex-M parts.

We have discussed what functionality in the RTOS is not portable, and what interfaces must be implemented in order to complete a fully-functional port. The five specific areas which are non-portable (stack initialization, kernel startup/entry, kernel timers, context switching, and critical sections) have been discussed in detail, with the platform-specific source provided as a practical reference to ARM-specific OS features, as well as Mark3's porting infrastructure. From this example (and the accompanying source), it should be possible for an experienced developers to create a port Mark3 to other microcontroller targets.

# **Chapter 11**

# **Build System**

In addition to providing a complete RTOS kernel with a variety of middleware, tests, and example code, Mark3 also provides a robust architecture to efficiently build these components.

The build system – including its design and use, are discussed in the following sections.

#### 11.1 Introduction

As developers, we spend an awful lot of time talking about how our source code is written, but devote very little energy to what happens to the code after it's been written... aside from producing running executables. When I refer to "building better software", I'm not talking about writing code — I'm talking about the technologies and processes that can be applied to manipulate source into a variety of products, including libraries, applications, tests, documentation, and performance data.

For a lot of developers – embedded or otherwise – a typical build process might look something like this:

Open the IDE, load a project and click "build". Sometime later, check the output window and look to see that there aren't any red exclamation points to indicate build failure. Browse to your project's output folder to collect your prize: A brand new .elf file containing your new firmware! Click on the arrow to give it a quick run on your dev board, test it for a few minutes, and make sure it seems sane. Pass it off to the manufacturing guys to load it on the line, and move on. Next!

Okay, that's a bit of an exaggeration, but not too far-fetched; and not that much different from standard procedure at places I've worked in the past.

Indeed - I've come across many developers over the years who know about how their software gets built beyond the "black box" that turns their code from text to binaries with the click of the button – and they like it that way. It's entirely understandable, too. Developing from an IDE hides all those messy configuration details, command-line options, symbol definitions and environment variables that would otherwise take away from time spent actively churning out code. We all want to be more productive, of course, and it takes time to learn to make, or anything specific to an embedded toolchain.

And from a product delivery perspective, binaries are the ultimate work-products from a software team – these are the pieces that drive the microcontrollers, DSPs and CPUs in an embedded system. When its crunch time, try convincing management to back off on release date in order to ensure that documentation gets updated to reflect the as-built nature of a project. Or fix the gaps in test coverage. Or update wikis containing profiling and performance metrics. You get the picture.

72 Build System

But software is a living entity – it's constantly changing as it develops and is refined by individuals and teams. And source code is a medium that carries different information across multiple channels all at once – while one channel contains information about building an application, another contains information on building libraries. Another carriers information on testing, and another still provides documentation relevant to consumers of the code. While not as glamorous a role as the "living firmware", these pieces of critical metadata are absolutely necessary as they ensure that the firmware products maintain a degree of quality, performance, and conformance, and gives a degree of confidence before formal test and release activities take place.

This is especially necessary when developing for an organizations that is accountable for their development and documentation practices (for example, ISO shops), or to shareholders who expect the companies they support with their wallets to apply engineering rigour to their products.

But getting the kind of flexibility required to produce these alternative work products form the "example IDE" is not trivial, and can be difficult to apply consistently from project-to-project/IDE-to-IDE. Automating these test and documentation tasks should be considered mandatory if you care about making the most of your development hours; manually generating and updating documentation, tests, and profiling results wastes time that you could be spending solving the right kinds of problems.

The good news, though, is that using common tools available on any modern OS, you can create frameworks that make these tasks for any project, on any toolchain providing command-line tools. With a bit of make, shell-script, and python, you can automate any number of build processes in a way that yields consistent, reliable results that are transferrable from project to project.

This is the approach taken in the Mark3 project, which integrates build, testing, profiling, documentation and release processes together in order to produce predictable, verifiable, output that can be validated against quality gates prior to formal testing and release. Only code revisions that pass all quality gate can be released. In the following sections, we'll explore the phased build approach, and how it's used by the Mark3 project.

## 11.2 Mark3 Build Process Overview

Building software is by and large a serial process, as outputs from each build step are required in subsequent steps. We start from our source code, scripts, and makefiles, configure our environment, and use our tools to turn the source code from one form to another, leveraging the outputs from each stage in the generation of further work products – whether it be creating binaries, running tests, or packaging artifacts for release.

To simplify the design and illustrate the concepts involved, we can break down these serial process into the following distinct phases:

- · Pre-build Environment configuration, target selection, and header-file staging
- Build Compiling libraries, and building binaries for applications and tests
- Test + Profiling Running unit tests, integration tests, profiling code
- Release Generation of documentation from source code and test results, packaging of build artifacts and headers

Each phase and associated activities are described in detail in the following subsections.

#### 11.2.1 Pre-Build Phase:

#### **Target Selection**

Inputs: CPU Architecture, Variant, Toolchain variables Outputs: Environment, makefile configuration

In this phase, we select the runtime environment and configure all environment-specific variables. Specifying environment variables at this phase ensures that when the build scripts are run, the correct makefiles, libraries, binaries, and config files are used when generating outputs. This can also be used to ensure that common build setting are applied to all platform specific binaries, including optimization levels, debug symbols, linker files, and CPU flags.

#### **Staging Headers**

Inputs: All files with a .h extension, located in library or binary project /public folders Output: Headers copied to a common staging directory

In this step, header files from all platform libraries are copied to a common staging directory referenced by the build system.

This simplifies makefiles and build scripts, ensuring only a single include directory needs to be specified to gain access to all common platform libraries. This keeps library and application code clean, as relative paths can be completely avoided. As an added benefit, these headers can later be deployed with the corresponding libraries to customers, giving them access to a set of pre-compiled libraries with APIs, but without providing the source.

#### 11.2.2 Build Phase

#### **Building Libraries**

Input: Source code for all common libraries, staged headers Output: Static libraries that can be linked against applications Gate: All mandatory libraries must be built successfully

The project root directory is scanned recursively for directories containing makefiles. When a makefile is found in the root of a subdirectory and a library tag is encountered (in Mark3, this corresponds to the declaration "IS\_LIB=1"), the project is built using the library-specific make commands for the platform. Libraries can reference other libraries implicitly, and include headers from the common include directory. Since references are resolved when building executable binary images, the executable projects are responsible for including the dependent libs.

#### **Building Binaries**

Input: Source code for individual applications, precompiled libraries, staged headers Output: Executable application and test binaries Gate: All mandatory binaries (applications and tests) must be built successfully

The project root directory is scanned recursively for directories containing makefiles. When a makefile is found in the root of a subdirectory and a binary tag is encountered (in Mark3, this corresponds to the declaration "IS\_APP=1"), the project is built using the executable-specific make commands for the platform. Applications can reference all platform and toolchain libraries, and include headers from the common include directory. Care must be taken to ensure that all library dependencies are explicitly specified in the application's makefile's list.

This step will fail if necessary dependencies are not met (i.e. required libraries failed to build in a prior step).

# Static Analysis:

Input: Source code for libraries/binaries Output: Static source analysis output Gate: N/A

Static analysis tools such as clang, klocwork, and lint can be run on the source to ensure that there are no critical or catastrophic problems (null pointer exceptions, variables used before initialization, incorrect argument usage, etc.) that wouldn't necessarily be caught at compile-time. Since tool availability and configurability varies, this isn't something that is enforced in the Mark3 builds. A user may opt to use clang to perform static code analysis on the build, however. The part-specific makefile contains a CLANG environment variable for this purpose.

Potential quality gates could be set up such that a failure during static analysis aborts the rest of the build.

Test + Profiling Sanity Tests

Input: Executable test binaries, CPU simulator/embedded target system Output: Text output indicating test pass/failure status

74 Build System

#### 11.2.3 Test and Profile

#### **Unit Tests**

Input: Executable test binaries, CPU simulator/embedded target system Output: Text output indicating test pass/failure status

#### **Code Performance Profiling**

Input: Executable test binaries, CPU simulator/embedded target system Output: Text output containing critical code performance metrics

#### **Code Size Profiling**

Input: Precompiled static libraries and binaries Output: Text output containing critical code size metrics

#### 11.2.4 Release

#### **Documentation**

Input: Library source code and headers, commented with Doxygen tags, Profiling results, Test results Output: Doxygen-generated HTML and PDF documentation

#### **Packaging**

Input: Static libraries and application/test binaries, staged headers, compiled documentation Output: Archive (.zip) containing relevant build outputs

# **Chapter 12**

# Mark3C - C-language API bindings for the Mark3 Kernel.

Mark3 now includes an optional additional library with C language bindings for all core kernel APIs, known as Mark3C.

This library alllows applications to be written in C, while still enjoying all of the benefits of the clean, modular design of the core RTOS kernel.

The C-language Mark3C APIs map directly to their Mark3 counterparts using a simple set of conventions, documented below. As a result, explicit API documentation for Mark3C is not necessary, as the functions map 1-1 to their C++ counterparts.

## 12.1 API Conventions

#### 1) Static Methods:

#### 2) Kernel Object Methods:

In short, any class instance is represented using an object handle, and is always passed into the relevant APIs as the first argument. Further, any method that returns a pointer to an object in the C++ implementation now returns a handle to that object.

#### 3) Overloaded Methods:

#### a) Methods overloaded with a Timeout parameter:

#### b) Methods overloaded based on number of arguments:

```
<Object>.<MethodName>()
                                          Becomes
                                                      <ClassName>_<MethodName>(<ObjectHandle>)
<Object>.<MethodName>(<arg1>)
                                                      <ClassName>_<MethodName>1(<ObjectHandle>, <arg1>)
                                          Becomes
<Object>.<MethodName>(<arg1>, <arg2>)
                                          Becomes
                                                      <ClassName>_<MethodName>2(<ObjectHandle>, <arg1>, <arg2>
                                                      <ClassName>_<MethodName>(<ObjectHandle>)
<ClassName>::<MethodName>()
                                          Becomes
                                                      <ClassName>_<MethodName>1(<ObjectHandle>, <argl>)
<ClassName>::<MethodName>(<arg1>)
                                          Becomes
<ClassName>::<MethodName>(<arq1>, <arq2>) Becomes
                                                      <ClassName>_<MethodName>2(<ObjectHandle>, <arg1>, <arg2>
```

# c) Methods overloaded base on parameter types:

```
<Object>.<MethodName>(<arg type_a>)
Becomes <ClassName>=<MethodName>(type_a>)(cobjectHandle>, <arg type_b>)
ClassName>::<MethodName>((carg type_a>))
Becomes <ClassName>=<MethodName>(type_b>)(cobjectHandle>, <arg type_a>)
ClassName>::<MethodName>((carg type_a>))
Becomes <ClassName>=<MethodName>(type_a>)(carg type_a>)
ClassName>=<MethodName>(type_a>)(carg type_a>)
<ClassName>=<MethodName>(type_b>)(carg type_b>)
```

#### d) Allocate-once memory allocation APIs

```
AutoAlloc::New<ObjectName> Becomes Alloc_<ObjectName> AutoAlloc::Allocate(uint16_t u16Size_) Becomes AutoAlloc(uint16_t u16Size_)
```

# 12.2 Allocating Objects

Aside from the API name translations, the object allocation scheme is the major different between Mark3C and Mark3. Instead of instantiating objects of the various kernel types, kernel objects must be declared using Declaration macros, which serve the purpose of reserving memory for the kernel object, and provide an opaque handle to that object memory. This is the case for statically-allocated objects, and objects allocated on the stack.

#### Example: Declaring a thread

```
#include "mark3c.h"

// Statically-allocated
DECLARE_THREAD(hMyThread1);
...

// On stack
int main(void)
{
    DECLARE_THREAD(hMyThread2);
    ...
}

Where:

hMyThread1 - is a handle to a statically-allocated thread
hMyThread2 - is a handle to a thread allocated from the main stack.
```

Alternatively, the AutoAlloc APIs can be used to dynamically allocate objects, as demonstrated in the following example.

```
void Allocate_Example(void)
{
    Thread_t hMyThread = AutoAlloc_Thread();

    Thread_Init(hMyThread, awMyStack, sizeof(awMyStack), 1, MyFunction, 0);
}
```

Note that the relevant kernel-object Init() function *must* be called prior to using any kernel object, whether or not they have been allocated statically, or dynamically.

12.3 Drivers in Mark3C 77

# 12.3 Drivers in Mark3C

Because the Mark3 driver framework makes extensive use of inheritence and virtual functions in C++, it is difficult to wrap for use with C. In addition, all derived drivers types would still need to have their custom interfaces wrapped with C-language bindings in order to be accessible from C, which is cumbersome and inelegant, and duplicates large portions of code. As a result, it's probably less work to write a Mark3C specific driver module with a similar interface to Mark3, on which drivers can be ported where necessary, or implemented directly on for efficiency. The APIs presented in driver3c.h provide such an interface for use in Mark3c.

Mari	k3C - C-la	nguage <i>i</i>	API bindi	ngs for t	he Mark3	Kernel.

78

# **Chapter 13**

# **Release Notes**

#### 13.1 R5 Release

- New: Shell library for creating responsive CLIs for embedded applications (M3Shell)
- · New: Streamer library for creating thread-safe buffered streams (streamer)
- New: Blocking UART implementation for AVR (drvUARTplus)
- · New: "Extended context" kernel feature, which is used to implement thread-local storage
- · New: "Extra Checks" kernel feature, which enforces safe API usage under pain of Kernel Panic
- · New: Realtime clock library
- New: Example application + bsp for the open-hardware Mark3no development board (mark3no)
- New: Kernel objects descoped/destroyed while still in active use will now cause kernel panic
- · New: Kernel callouts for thread creation/destruction/context switching, used for time tracking
- · New: Simple power management class
- · New: WIP software-based I2C + SPI drivers
- · Optimized thread scheduling via target-optimized "count-leading-zero" macros
- · Expanded memutil library
- · Various optimizations of ARM Cortex-M assembly code
- · Various bugfixes to Timer code
- Improved stack overflow checking + warning (stack guard kernel feature)
- AVR bootloader now supports targets with more than 64K of flash
- · Moved some port configuration out of platform.mak into header files in the kernel port code
- The usual minor bugfixes and "gentle refactoring"

80 Release Notes

#### 13.2 R4 Release

- · New: C-language bindings for Mark3 kernel (mark3c library)
- · New: Support for ARM Cortex-M3 and Cortex-M4 (floating point) targets
- · New: Support for Atmel AVR atmega2560 and arduino pro mega
- · New: Full-featured, lightweight heap implementation
- · New: Mailbox IPC class
- · New: Notification object class
- · New: lighweight tracelogger/instrumentation implementation (buffalogger), with sample parser
- New: High-performance AVR Software UART implementation
- · New: Allocate-once "AutoAlloc" memory allocator
- · New: Fixed-time blocking/unblocking operations added to ThreadList/Blocking class
- · Placement-new supported for all kernel objects
- Scheduler now supports up to 1024 levels of thread priority, up from 8 (configurable at build-time)
- Kernel now uses stdint.h types for standard integers (instead of K\_CHAR, K\_ULONG, etc.)
- · Greatly expanded documentation, with many new examples covering all key kernel features
- · Expanded unit test coverage on AVR
- · Updated build system and scripts for easier kernel configuration
- · Updated builds to only attempt to build tests for supported platforms

#### 13.3 R3 Release

- · New: Added support for MSP430 microcontrollers
- New: Added Kernel Idle-Function hook to eliminate the need for a dedicated idle-thread (where supported)
- · New: Support for kernel-aware simulation and testing via flAVR AVR simulator
- Updated AVR driver selection
- · General bugfixes and maintenance
- · Expanded documentation and test coverage

#### 13.4 R2

- Experimental release, using a "kernel transaction queue" for serializing kernel calls
- Works as a proof-of-concept, but abandoned due to overhead of the transaction mechanism in the general case.

# 13.5 R1 - 2nd Release Candidate

- New: Added support for ARM Cortex-M0 targets
- New: Added support for variuos AVR targets
- New: Timers now support a "tolerance" parameter for grouping timers with close expiry times
- Expanded scripts and auotmation used in build/test
- · Updated and expanded graphics APIs
- Large number of bugfixes

# 13.6 R1 - 1st Release Candidate

• Initial release, with support for AVR microcontrollers

82 Release Notes

# Chapter 14

# **Profiling Results**

The following profiling results were obtained using an ATMega328p @ 16MHz.

The test cases are designed to make use of the kernel profiler, which accurately measures the performance of the fundamental system APIs, in order to provide information for user comparison, as well as to ensure that regressions are not being introduced into the system.

# 14.1 Date Performed

Thu Dec 29 20:13:25 EST 2016

# 14.2 Compiler Information

The kernel and test code used in these results were built using the following compiler:

# 14.3 Profiling Results

```
- Semaphore Initialization: 48 cycles (averaged over 42 iterations)
- Semaphore Post (uncontested): 192 cycles (averaged over 42 iterations)
- Semaphore Pend (uncontested): 72 cycles (averaged over 42 iterations)
- Semaphore Flyback Time (Contested Pend): 1792 cycles (averaged over 42 iterations)
- Mutex Init: 248 cycles (averaged over 42 iterations)
- Mutex Claim: 216 cycles (averaged over 42 iterations)
- Mutex Release: 168 cycles (averaged over 42 iterations)
- Thread Initialize: 10551 cycles (averaged over 42 iterations)
- Thread Start: 824 cycles (averaged over 41 iterations)
- Context Switch: 176 cycles (averaged over 41 iterations)
- Thread Schedule: 72 cycles (averaged over 41 iterations)
```

84 Profiling Results

# **Chapter 15**

# **Code Size Profiling**

The following report details the size of each module compiled into the kernel.

The size of each component is dependent on the flags specified in mark3cfg.h at compile time. Note that these sizes represent the maximum size of each module before dead code elimination and any additional link-time optimization, and represent the maximum possible size that any module can take.

The results below are for profiling on Atmel AVR atmega328p-based targets using gcc. Results are not necessarily indicative of relative or absolute performance on other platforms or toolchains.

#### 15.1 Information

Subversion Repository Information:

• Repository Root: svn+ssh://m0slevin.code.sf.net/p/mark3/source

· Revision: 396

• URL: svn+ssh://m0slevin.code.sf.net/p/mark3/source/trunk Relative URL: ^/trunk

Date Profiled: Thu Dec 29 20:13:26 EST 2016

# 15.2 Compiler Version

avr-gcc (GCC) 4.9.2 Copyright (C) 2014 Free Software Foundation, Inc. This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

86 Code Size Profiling

# 15.3 Profiling Results

#### Mark3 Module Size Report:

```
Synchronization Objects - Base Class.....: 164 Bytes
Device Driver Framework (including /dev/null)...: 230 Bytes
Synchronization Object - Event Flag......: 742 Bytes
Fundamental Kernel Linked-List Classes.....: 598
Message-based IPC..... : 480 Bytes
Mutex (Synchronization Object).....: 698 Bytes
Notification Blocking Object.....: 494 Bytes
Performance-profiling timers.....: 516 Bytes 2D Priority Map Object - Scheduler....: 112 Bytes
Round-Robin Scheduling Support.....: 274 Bytes
Thread Scheduling....: 324 Bytes
Semaphore (Synchronization Object).....: 512 Bytes
Mailbox IPC Support.....: 1452 Bytes
Thread Implementation.....: 1585 Bytes
Fundamental Kernel Thread-list Data Structures..: 254 Bytes
Mark3 Kernel Base Class.....: 145 Bytes
Software Timer Kernel Object.....: 552 Bytes
Software Timer Management.....: 613 Bytes
Runtime Kernel Trace Implementation.....: 0 Bytes
Atmel AVR - Kernel Aware Simulation Support....: 184 Bytes
Atmel AVR - Basic Threading Support.....: 638 Bytes
Atmel AVR - Kernel Interrupt Implemenation. . . : 56 Bytes
Atmel AVR - Kernel Timer Implementation. . . : 302 Bytes
Atmel AVR - Profiling Timer Implementation.....: 216 Bytes
```

#### Mark3 Kernel Size Summary:

```
- Kernel : 3182 Bytes
- Synchronization Objects : 2432 Bytes
- Port : 3342 Bytes
- Features : 2185 Bytes
- Total Size : 11141 Bytes
```

# **Chapter 16**

# **Hierarchical Index**

# 16.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

BlockingObject	95
EventFlag	09
Mutex	51
Notify	
Semaphore	68
DriverList	07
FakeThread_t 1	13
GlobalMessagePool	
Kernel	
KernelAware	
KernelAwareData_t	
KernelSWI	
KernelTimer	
LinkList	
CircularLinkList	
ThreadList	84
DoubleLinkList	02
TimerList	94
LinkListNode	34
Driver	03
DevNull	99
Message	43
Thread	
Timer	88
Mailbox	36
MessagePool	46
MessageQueue	48
PriorityMap	57
Profiler	58
ProfileTimer	60
Quantum	62
Scheduler	64
ThreadPort	
TimerScheduler	96

88 Hierarchical Index

# **Chapter 17**

# **Class Index**

# 17.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

BlockingObject	
Class implementing thread-blocking primatives	95
CircularLinkList	
Circular-linked-list data type, inherited from the base LinkList type	97
DevNull	
This class implements the "default" driver (/dev/null)	99
DoubleLinkList	
Doubly-linked-list data type, inherited from the base LinkList type	102
Driver	
Base device-driver class used in hardware abstraction	103
DriverList	
List of Driver objects used to keep track of all device drivers in the system	107
EventFlag	
Blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread exe-	
cution based on events occurring within the system	109
FakeThread_t	
If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data	
structure to "simulate" the effect of having an idle thread in the system	113
GlobalMessagePool	
Implements a list of message objects shared between all threads	113
Kernel	
Class that encapsulates all of the kernel startup functions	116
KernelAware	404
The KernelAware class	121
KernelAwareData_t	4.01
This structure is used to communicate between the kernel and a kernel- aware host	125
KernelSWI	400
Class providing the software-interrupt required for context-switching in the kernel	126
KernelTimer	4.00
Hardware timer interface, used by all scheduling/timer subsystems	128
LinkList  Abstract data type from which all other linked lists are derived.	100
Abstract-data-type from which all other linked-lists are derived	132
Rasic linked-list node data structure	13/

90 Class Index

Mailhay	
Mailbox Implements an IPC mechnism based on envelopes containing data of a fixed size (configured initialization) that reside within a buffer of memory provided by the user	
Message	
Class to provide message-based IPC services in the kernel	143
Implements a list of message objects	146
List of messages, used as the channel for sending and receiving messages between threads  Mutex	s . 148
Mutual-exclusion locks, based on BlockingObject	151
Blocking object type, that allows one or more threads to wait for an event to occur before resum operation	
PriorityMap	
The PriorityMap class	157
System profiling timer interface	158
Profiling timer	160
Quantum	
Static-class used to implement Thread quantum functionality, which is a key part of round-	
Scheduler  Priority has a discount on him Through a shaduling a saint Through into fear has a discount on the saint of the	101
Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping Semaphore	164
Binary & Counting semaphores, based on BlockingObject base class	168
Thread  Object providing fundamental multitasking support in the kernel	172
ThreadList  This class is used for building thread-management facilities, such as schedulers, and block objects	•
ThreadPort	104
Class defining the architecture specific functions required by the kernel	187
Timer  Kernel-managed software timers	188
TimerList	
TimerList class - a doubly-linked-list of timer objects	194
"Static" Class used to interface a global TimerList with the rest of the kernel	196

# **Chapter 18**

# File Index

# 18.1 File List

Here is a list of all documented files with brief descriptions:

/home/moslevin/projects/mark3-source/kernel/atomic.cpp	
· ·	99
/home/moslevin/projects/mark3-source/kernel/autoalloc.cpp	
Automatic memory allocation for kernel objects	201
/home/moslevin/projects/mark3-source/kernel/blocking.cpp	
Implementation of base class for blocking objects	203
/home/moslevin/projects/mark3-source/kernel/driver.cpp	
Device driver/hardware abstraction layer	225
/home/moslevin/projects/mark3-source/kernel/eventflag.cpp	
Event Flag Blocking Object/IPC-Object implementation	227
/home/moslevin/projects/mark3-source/kernel/kernel.cpp	
Kernel initialization and startup code	232
/home/moslevin/projects/mark3-source/kernel/kernelaware.cpp	
Kernel aware simulation support	234
/home/moslevin/projects/mark3-source/kernel/ksemaphore.cpp	
	237
/home/moslevin/projects/mark3-source/kernel/II.cpp	
Core Linked-List implementation, from which all kernel objects are derived	241
/home/moslevin/projects/mark3-source/kernel/mailbox.cpp	
Mailbox + Envelope IPC mechanism	243
/home/moslevin/projects/mark3-source/kernel/message.cpp	
Inter-thread communications via message passing	247
/home/moslevin/projects/mark3-source/kernel/mutex.cpp	
	250
/home/moslevin/projects/mark3-source/kernel/notify.cpp	
• • •	254
/home/moslevin/projects/mark3-source/kernel/priomap.cpp	
	256
/home/moslevin/projects/mark3-source/kernel/profile.cpp	
	258
/home/moslevin/projects/mark3-source/kernel/quantum.cpp	
Thread Quantum Implementation for Round-Robin Scheduling	318
/home/moslevin/projects/mark3-source/kernel/scheduler.cpp	
·	321
/home/moslevin/projects/mark3-source/kernel/thread.cpp	
·	322

92 File Index

/home/moslevin/projects/mark3-source/kernel/threadlist.cpp	
Thread linked-list definitions	330
/home/moslevin/projects/mark3-source/kernel/timer.cpp	
Timer implementations	331
/home/moslevin/projects/mark3-source/kernel/timerlist.cpp	
Implements timer list processing algorithms, responsible for all timer tick and expiry logic	334
/home/moslevin/projects/mark3-source/kernel/tracebuffer.cpp	
Kernel trace buffer class definition	338
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp	
ATMega328p Profiling timer implementation	205
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp	
Kernel Software interrupt implementation for ATMega328p	206
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp	
Kernel Timer Implementation for ATMega328p	207
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/threadport.cpp	201
ATMega328p Multithreading	222
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h	222
Profiling timer hardware interface	010
	210
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h	011
Kernel Software interrupt declarations	211
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h	040
Kernel Timer Class declaration	212
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/portcfg.h	0.40
Mark3 Port Configuration	213
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/threadport.h	
ATMega328p Multithreading support	216
/home/moslevin/projects/mark3-source/kernel/public/atomic.h	
Basic Atomic Operations	260
/home/moslevin/projects/mark3-source/kernel/public/autoalloc.h	
Automatic memory allocation for kernel objects	261
/home/moslevin/projects/mark3-source/kernel/public/blocking.h	
Blocking object base class declarations	262
/home/moslevin/projects/mark3-source/kernel/public/buffalogger.h	
Super-efficient, super-secure logging routines	264
/home/moslevin/projects/mark3-source/kernel/public/ <b>dbg_file_list.h</b>	??
/home/moslevin/projects/mark3-source/kernel/public/driver.h	
Driver abstraction framework	265
/home/moslevin/projects/mark3-source/kernel/public/eventflag.h	
Event Flag Blocking Object/IPC-Object definition	267
/home/moslevin/projects/mark3-source/kernel/public/kernel.h	
Kernel initialization and startup class	268
/home/moslevin/projects/mark3-source/kernel/public/kernelaware.h	
Kernel aware simulation support	270
/home/moslevin/projects/mark3-source/kernel/public/kerneldebug.h	
Macros and functions used for assertions, kernel traces, etc	272
/home/moslevin/projects/mark3-source/kernel/public/kerneltypes.h	_,_
Basic data type primatives used throughout the OS	277
/home/moslevin/projects/mark3-source/kernel/public/ksemaphore.h	211
Semaphore Blocking Object class declarations	279
	213
/home/moslevin/projects/mark3-source/kernel/public/ll.h	001
Core linked-list declarations, used by all kernel list types	281
/home/moslevin/projects/mark3-source/kernel/public/mailbox.h	
Mailbox + Envelope IPC Mechanism	283
/home/moslevin/projects/mark3-source/kernel/public/manual.h	
/brief Ascii-format documentation, used by doxygen to create various printable and viewable	
forms	285
/home/moslevin/projects/mark3-source/kernel/public/mark3.h	
Single include file given to users of the Mark3 Kernel API	286

18.1 File List 93

94 File Index

# **Chapter 19**


# **Class Documentation**

# 19.1 BlockingObject Class Reference

Class implementing thread-blocking primatives.

```
#include <blocking.h>
```

Inheritance diagram for BlockingObject:



# **Protected Member Functions**

- void Block (Thread \*pclThread\_)
  - Block
- void BlockPriority (Thread \*pclThread\_)

BlockPriority.

void UnBlock (Thread \*pclThread\_)

UnBlock.

#### **Protected Attributes**

• ThreadList m\_clBlockList

ThreadList which is used to hold the list of threads blocked on a given object.

#### 19.1.1 Detailed Description

Class implementing thread-blocking primatives.

used for implementing things like semaphores, mutexes, message queues, or anything else that could cause a thread to suspend execution on some external stimulus.

Definition at line 70 of file blocking.h.

# 19.1.2 Member Function Documentation

19.1.2.1 void BlockingObject::Block ( Thread \* pclThread\_ ) [protected]

Block.

Blocks a thread on this object. This is the fundamental operation performed by any sort of blocking operation in the operating system. All semaphores/mutexes/sleeping/messaging/etc ends up going through the blocking code at some point as part of the code that manages a transition from an "active" or "waiting" thread to a "blocked" thread.

The steps involved in blocking a thread (which are performed in the function itself) are as follows;

1) Remove the specified thread from the current owner's list (which is likely one of the scheduler's thread lists) 2) Add the thread to this object's thread list 3) Setting the thread's "current thread-list" point to reference this object's threadlist.

#### **Parameters**

pcl⇔	Pointer to the thread object that will be blocked.
Thread_	

Definition at line 41 of file blocking.cpp.

19.1.2.2 void BlockingObject::BlockPriority ( Thread \* pclThread\_ ) [protected]

BlockPriority.

Same as Block(), but ensures that threads are added to the block-list in priority-order, which optimizes the unblock procedure.

#### **Parameters**

pcl⊷	Pointer to the Thread to Block.
Thread_	

Definition at line 57 of file blocking.cpp.

19.1.2.3 void BlockingObject::UnBlock ( Thread \* pclThread\_ ) [protected]

UnBlock.

Unblock a thread that is already blocked on this object, returning it to the "ready" state by performing the following steps:

#### **Parameters**

pcl⇔	Pointer to the thread to unblock.
Thread	

1) Removing the thread from this object's threadlist 2) Restoring the thread to its "original" owner's list

Definition at line 73 of file blocking.cpp.

The documentation for this class was generated from the following files:


- · /home/moslevin/projects/mark3-source/kernel/public/blocking.h
- /home/moslevin/projects/mark3-source/kernel/blocking.cpp

# 19.2 CircularLinkList Class Reference

Circular-linked-list data type, inherited from the base LinkList type.

```
#include <11.h>
```

Inheritance diagram for CircularLinkList:



#### **Public Member Functions**

void Add (LinkListNode \*node\_)

Add the linked list node to this linked list.

void Remove (LinkListNode \*node\_)

Remove.

void PivotForward ()

PivotForward.

void PivotBackward ()

PivotBackward.

void InsertNodeBefore (LinkListNode \*node\_, LinkListNode \*insert\_)

InsertNodeBefore.

#### **Additional Inherited Members**

# 19.2.1 Detailed Description

Circular-linked-list data type, inherited from the base LinkList type.

Definition at line 187 of file II.h.

### 19.2.2 Member Function Documentation

19.2.2.1 void CircularLinkList::Add ( LinkListNode \* node\_ )

Add the linked list node to this linked list.

#### **Parameters**

node↩	Pointer to the node to add
_	

Definition at line 98 of file II.cpp.

19.2.2.2 void CircularLinkList::InsertNodeBefore ( LinkListNode \* node\_, LinkListNode \* insert\_ )

InsertNodeBefore.

Insert a linked-list node into the list before the specified insertion point.

#### **Parameters**

node⊷	Node to insert into the list
<u> </u>	
insert⇔	Insert point.
_	

Definition at line 172 of file II.cpp.

19.2.2.3 void CircularLinkList::PivotBackward ( )

PivotBackward.

Pivot the head of the circularly linked list backward ( Head = Head->prev, Tail = Tail->prev )

Definition at line 163 of file II.cpp.

19.2.2.4 void CircularLinkList::PivotForward ( )

PivotForward.

Pivot the head of the circularly linked list forward ( Head = Head->next, Tail = Tail->next )

Definition at line 154 of file II.cpp.

19.2.2.5 void CircularLinkList::Remove ( LinkListNode \* node\_ )

Remove.

Add the linked list node to this linked list

#### **Parameters**

er to the node to remove

Definition at line 120 of file II.cpp.


The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/ll.h
- /home/moslevin/projects/mark3-source/kernel/II.cpp

# 19.3 DevNull Class Reference

This class implements the "default" driver (/dev/null)

Inheritance diagram for DevNull:



#### **Public Member Functions**

```
• virtual void Init ()
```

Init.

• virtual uint8\_t Open ()

Open.

• virtual uint8\_t Close ()

Close.

virtual uint16\_t Read (uint16\_t u16Bytes\_, uint8\_t \*pu8Data\_)

Read.

• virtual uint16\_t Write (uint16\_t u16Bytes\_, uint8\_t \*pu8Data\_)

Write

virtual uint16\_t Control (uint16\_t u16Event\_, void \*pvDataln\_, uint16\_t u16Sizeln\_, void \*pvDataOut\_

 , uint16\_t u16SizeOut\_)

Control.

### **Additional Inherited Members**

# 19.3.1 Detailed Description

This class implements the "default" driver (/dev/null)

Definition at line 46 of file driver.cpp.

#### 19.3.2 Member Function Documentation

```
19.3.2.1 virtual uint8_t DevNull::Close( ) [inline], [virtual]
```

Close.

Close a previously-opened device driver.

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 51 of file driver.cpp.

```
19.3.2.2 virtual uint16_t DevNull::Control ( uint16_t u16Event_, void * pvDataln_, uint16_t u16Sizeln_, void * pvDataOut_, uint16_t u16SizeOut_ ) [inline], [virtual]
```

#### Control.

This is the main entry-point for device-specific io and control operations. This is used for implementing all "side-channel" communications with a device, and any device-specific IO operations that do not conform to the typical POSIX read/write paradigm. use of this funciton is analagous to the non-POSIX (yet still common) devctl() or ioctl().

#### **Parameters**

u16Event_	Code defining the io event (driver-specific)
pvDataIn_	Pointer to the intput data
u16SizeIn⊷	Size of the input data (in bytes)
_	
pvData⊷	Pointer to the output data
Out_	
u16Size⇔	Size of the output data (in bytes)
Out_	

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 55 of file driver.cpp.

19.3.2.3 virtual void DevNull::Init() [inline], [virtual]

Init.

Initialize a driver, must be called prior to use

Implements Driver.

Definition at line 49 of file driver.cpp.

19.3.2.4 virtual uint8\_t DevNull::Open() [inline], [virtual]

Open.

Open a device driver prior to use.

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 50 of file driver.cpp.

```
19.3.2.5 virtual uint16_t DevNull::Read ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [inline], [virtual]
```

Read.

Read a specified number of bytes from the device into a specific buffer. Depending on the driver-specific implementation, this may be a number less than the requested number of bytes read, indicating that there there was less input than desired, or that as a result of buffering, the data may not be available.

#### **Parameters**

u16 <b></b>	Number of bytes to read (<= size of the buffer)
Bytes_	
pu8⇔	Pointer to a data buffer receiving the read data
Data_	

#### Returns

Number of bytes actually read

Implements Driver.

Definition at line 52 of file driver.cpp.

```
19.3.2.6 virtual uint16_t DevNull::Write ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [inline], [virtual]
```

Write.

Write a payload of data of a given length to the device. Depending on the implementation of the driver, the amount of data written to the device may be less than the requested number of bytes. A result less than the requested size may indicate that the device buffer is full, indicating that the user must retry the write at a later point with the remaining data.

#### **Parameters**

u16⇔	Number of bytes to write (<= size of the buffer)
Bytes_	
pu8⇔	Pointer to a data buffer containing the data to write
Data	

Generated by Doxygen

Returns

Number of bytes actually written

Implements Driver.

Definition at line 53 of file driver.cpp.

The documentation for this class was generated from the following file:


/home/moslevin/projects/mark3-source/kernel/driver.cpp

# 19.4 DoubleLinkList Class Reference

Doubly-linked-list data type, inherited from the base LinkList type.

```
#include <11.h>
```

Inheritance diagram for DoubleLinkList:



# **Public Member Functions**

• DoubleLinkList ()

DoubleLinkList.

void Add (LinkListNode \*node\_)

Ada

• void Remove (LinkListNode \*node\_)

Remove.

# **Additional Inherited Members**

# 19.4.1 Detailed Description

Doubly-linked-list data type, inherited from the base LinkList type.

Definition at line 149 of file II.h.

19.5 Driver Class Reference 103

#### 19.4.2 Constructor & Destructor Documentation

19.4.2.1 DoubleLinkList::DoubleLinkList( ) [inline]

#### DoubleLinkList.

Default constructor - initializes the head/tail nodes to NULL

Definition at line 158 of file II.h.

#### 19.4.3 Member Function Documentation

19.4.3.1 void DoubleLinkList::Add ( LinkListNode \* node\_ )

Add.

Add the linked list node to this linked list

#### **Parameters**

node←	Pointer to the node to add

Definition at line 47 of file II.cpp.

19.4.3.2 void DoubleLinkList::Remove ( LinkListNode \* node\_ )

Remove.

Add the linked list node to this linked list

# **Parameters**

node⊷	Pointer to the node to remove

Definition at line 68 of file II.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/II.h
- /home/moslevin/projects/mark3-source/kernel/ll.cpp

# 19.5 Driver Class Reference

Base device-driver class used in hardware abstraction.

```
#include <driver.h>
```

#### Inheritance diagram for Driver:



#### **Public Member Functions**

```
• virtual void Init ()=0
```

Init.

• virtual uint8\_t Open ()=0

Open.

• virtual uint8\_t Close ()=0

Close

• virtual uint16\_t Read (uint16\_t u16Bytes\_, uint8\_t \*pu8Data\_)=0

Read

virtual uint16\_t Write (uint16\_t u16Bytes\_, uint8\_t \*pu8Data\_)=0

Write

Control.

void SetName (const char \*pcName\_)

SetName

• const char \* GetPath ()

GetPath.

### **Private Attributes**

• const char \* m\_pcPath string pointer that holds the driver path (name)

# **Additional Inherited Members**

# 19.5.1 Detailed Description

Base device-driver class used in hardware abstraction.

All other device drivers inherit from this class

Definition at line 121 of file driver.h.

19.5 Driver Class Reference 105

#### 19.5.2 Member Function Documentation

```
19.5.2.1 virtual uint8_t Driver::Close( ) [pure virtual]
```

Close.

Close a previously-opened device driver.

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

```
19.5.2.2 virtual uint16_t Driver::Control ( uint16_t u16Event_, void * pvDataln_, uint16_t u16Sizeln_, void * pvDataOut_, uint16_t u16SizeOut_ ) [pure virtual]
```

Control.

This is the main entry-point for device-specific io and control operations. This is used for implementing all "side-channel" communications with a device, and any device-specific IO operations that do not conform to the typical POSIX read/write paradigm. use of this funciton is analagous to the non-POSIX (yet still common) devctl() or ioctl().

#### **Parameters**

u16Event_	Code defining the io event (driver-specific)
pvDataIn_	Pointer to the intput data
u16SizeIn⇔	Size of the input data (in bytes)
_	
pvData⊷	Pointer to the output data
Out_	
u16Size⇔	Size of the output data (in bytes)
Out_	

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

19.5.2.3 const char\* Driver::GetPath() [inline]

GetPath.

Returns a string containing the device path.

#### Returns

pcName\_ Return the string constant representing the device path

Definition at line 221 of file driver.h.

```
19.5.2.4 virtual void Driver::Init( ) [pure virtual]
```

Init.

Initialize a driver, must be called prior to use

Implemented in DevNull.

```
19.5.2.5 virtual uint8_t Driver::Open() [pure virtual]
```

Open.

Open a device driver prior to use.

#### Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

```
19.5.2.6 virtual uint16_t Driver::Read ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [pure virtual]
```

#### Read.

Read a specified number of bytes from the device into a specific buffer. Depending on the driver-specific implementation, this may be a number less than the requested number of bytes read, indicating that there there was less input than desired, or that as a result of buffering, the data may not be available.

#### **Parameters**

u16⇔	Number of bytes to read (<= size of the buffer)
Bytes_	
pu8⇔	Pointer to a data buffer receiving the read data
Data	

#### Returns

Number of bytes actually read

Implemented in DevNull.

```
19.5.2.7 void Driver::SetName (const char * pcName_) [inline]
```

SetName.

Set the path for the driver. Name must be set prior to access (since driver access is name-based).

#### **Parameters**

pc⇔	String constant containing the device path
Name_	

Definition at line 213 of file driver.h.

```
19.5.2.8 virtual uint16_t Driver::Write ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [pure virtual]
```

Write.

Write a payload of data of a given length to the device. Depending on the implementation of the driver, the amount of data written to the device may be less than the requested number of bytes. A result less than the requested size may indicate that the device buffer is full, indicating that the user must retry the write at a later point with the remaining data.

#### **Parameters**

u16← Bytes_	Number of bytes to write (<= size of the buffer)
pu8← Data_	Pointer to a data buffer containing the data to write

#### Returns

Number of bytes actually written

Implemented in DevNull.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/mark3-source/kernel/public/driver.h

# 19.6 DriverList Class Reference

List of Driver objects used to keep track of all device drivers in the system.

```
#include <driver.h>
```

#### **Static Public Member Functions**

```
• static void Init ()
```

Init.

• static void Add (Driver \*pclDriver\_)

Add

• static void Remove (Driver \*pclDriver\_)

Remove.

• static Driver \* FindByPath (const char \*m\_pcPath)

FindByPath.

#### **Static Private Attributes**

static DoubleLinkList m\_clDriverList

LinkedList object used to implementing the driver object management.

#### 19.6.1 Detailed Description

List of Driver objects used to keep track of all device drivers in the system.

By default, the list contains a single entity, "/dev/null".

Definition at line 232 of file driver.h.

#### 19.6.2 Member Function Documentation

```
19.6.2.1 static void DriverList::Add ( Driver * pclDriver_ ) [inline], [static]
```

Add.

Add a Driver object to the managed global driver-list.

#### **Parameters**

pcl⇔	pointer to the driver object to add to the global driver list.
Driver_	

#### **Examples:**

buffalogger/main.cpp.

Definition at line 252 of file driver.h.

```
19.6.2.2 Driver * DriverList::FindByPath ( const char * m_pcPath ) [static]
```

#### FindByPath.

Look-up a driver in the global driver-list based on its path. In the event that the driver is not found in the list, a pointer to the default "/dev/null" object is returned. In this way, unimplemented drivers are automatically stubbed out.

Definition at line 104 of file driver.cpp.

```
19.6.2.3 void DriverList::Init( ) [static]
```

Init.

Initialize the list of drivers. Must be called prior to using the device driver library.

Definition at line 95 of file driver.cpp.

```
19.6.2.4 static void DriverList::Remove ( Driver * pclDriver_ ) [inline], [static]
```

Remove.

Remove a driver from the global driver list.

#### **Parameters**

pcl⇔	Pointer to the driver object to remove from the global table
Driver_	

Definition at line 261 of file driver.h.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/driver.h
- /home/moslevin/projects/mark3-source/kernel/driver.cpp

# 19.7 EventFlag Class Reference

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

```
#include <eventflag.h>
```

Inheritance diagram for EventFlag:



### **Public Member Functions**

• void Init ()

Init Initializes the EventFlag object prior to use.

uint16\_t Wait (uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_)

Wait - Block a thread on the specific flags in this event flag group.

• uint16\_t Wait (uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_, uint32\_t u32TimeMS\_)

Wait - Block a thread on the specific flags in this event flag group.

• void WakeMe (Thread \*pclOwner\_)

WakeMe.

void Set (uint16\_t u16Mask\_)

Set - Set additional flags in this object (logical OR).

void Clear (uint16\_t u16Mask\_)

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

• uint16\_t GetMask ()

GetMask Returns the state of the 16-bit bitmask within this object.

#### **Private Member Functions**

uint16\_t Wait\_i (uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_, uint32\_t u32TimeMS\_)
 Wait\_i.

#### **Private Attributes**

uint16\_t m\_u16SetMask

Event flags currently set in this object.

#### **Additional Inherited Members**

#### 19.7.1 Detailed Description

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

Each EventFlag object contains a 16-bit bitmask, which is used to trigger events on associated threads. Threads wishing to block, waiting for a specific event to occur can wait on any pattern within this 16-bit bitmask to be set. Here, we provide the ability for a thread to block, waiting for ANY bits in a specified mask to be set, or for ALL bits within a specific mask to be set. Depending on how the object is configured, the bits that triggered the wakeup can be automatically cleared once a match has occurred.

#### **Examples:**

lab7\_events/main.cpp.

Definition at line 46 of file eventflag.h.

#### 19.7.2 Member Function Documentation

```
19.7.2.1 void EventFlag::Clear ( uint16_t u16Mask_ )
```

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

#### **Parameters**

u16⇔	- Bitmask of flags to clear
Mask_	

#### **Examples:**

lab7\_events/main.cpp.

Definition at line 317 of file eventflag.cpp.

19.7.2.2 uint16\_t EventFlag::GetMask()

GetMask Returns the state of the 16-bit bitmask within this object.

#### Returns

The state of the 16-bit bitmask

Definition at line 330 of file eventflag.cpp.

19.7.2.3 void EventFlag::Set ( uint16\_t u16Mask\_ )

Set - Set additional flags in this object (logical OR).

This API can potentially result in threads blocked on Wait() to be unblocked.

#### **Parameters**

u16 <b></b>	- Bitmask of flags to set.
Mask	

#### **Examples:**

lab7\_events/main.cpp.

Definition at line 207 of file eventflag.cpp.

19.7.2.4 uint16\_t EventFlag::Wait ( uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_ )

Wait - Block a thread on the specific flags in this event flag group.

#### **Parameters**

u16⇔	- 16-bit bitmask to block on
Mask_	
eMode_	- EVENT_FLAG_ANY: Thread will block on any of the bits in the mask
	EVENT_FLAG_ALL: Thread will block on all of the bits in the mask

#### Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

# **Examples:**

lab7\_events/main.cpp.

Definition at line 189 of file eventflag.cpp.

19.7.2.5 uint16\_t EventFlag::Wait ( uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_, uint32\_t u32TimeMS\_ )

Wait - Block a thread on the specific flags in this event flag group.

### **Parameters**

6-bit bitmask to block on
VENT_FLAG_ANY: Thread will block on any of the bits in the mask
• EVENT_FLAG_ALL: Thread will block on all of the bits in the mask
me to block (in ms)

#### Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

Definition at line 200 of file eventflag.cpp.

```
19.7.2.6 uint16_t EventFlag::Wait_i ( uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS_ ) [private]
```

#### Wait\_i.

Interal abstraction used to manage both timed and untimed wait operations

#### **Parameters**

u16Mask_	- 16-bit bitmask to block on
eMode_	- EVENT_FLAG_ANY: Thread will block on any of the bits in the mask
	EVENT_FLAG_ALL: Thread will block on all of the bits in the mask
u32TimeM⇔	- Time to block (in ms)
<i>S</i> _	

#### Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

! If the Yield operation causes a new thread to be chosen, there will! Be a context switch at the above CS\_EXIT(). The original calling! thread will not return back until a matching SetFlags call is made! or a timeout occurs.

Definition at line 101 of file eventflag.cpp.

```
19.7.2.7 void EventFlag::WakeMe ( Thread * pclOwner_ )
```

WakeMe.

Wake the given thread, currently blocking on this object

#### **Parameters**

pcl←	Pointer to the owner thread to unblock.
Owner_	

Definition at line 89 of file eventflag.cpp.

The documentation for this class was generated from the following files:

- · /home/moslevin/projects/mark3-source/kernel/public/eventflag.h
- /home/moslevin/projects/mark3-source/kernel/eventflag.cpp

## 19.8 FakeThread t Struct Reference

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

```
#include <thread.h>
```

#### **Public Attributes**

K\_WORD \* m\_pwStackTop

Pointer to the top of the thread's stack.

K\_WORD \* m\_pwStack

Pointer to the thread's stack.

• uint8 t m u8ThreadID

Thread ID.

PORT\_PRIO\_TYPE m\_uXPriority

Default priority of the thread.

PORT PRIO TYPE m uXCurPriority

Current priority of the thread (priority inheritence)

• ThreadState t m eState

Enum indicating the thread's current state.

void \* m\_pvExtendedContext

Pointer provided to a Thread to implement thread-local storage.

# 19.8.1 Detailed Description

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

When cast to a Thread, this data structure will still result in GetPriority() calls being valid, which is all that is needed to support the tick-based/tickless times – while saving a fairly decent chunk of RAM on a small micro.

Note that this struct must have the same memory layout as the Thread class up to the last item.

Definition at line 533 of file thread.h.

The documentation for this struct was generated from the following file:

/home/moslevin/projects/mark3-source/kernel/public/thread.h

# 19.9 GlobalMessagePool Class Reference

Implements a list of message objects shared between all threads.

```
#include <message.h>
```

# **Static Public Member Functions**

```
    static void Init ()
        Init.
    static void Push (Message *pclMessage_)
        Push.
    static Message * Pop ()
        Pop.
    static Message * GetHead ()
        GetHead.
    static MessagePool * GetPool ()
```

#### **Static Private Attributes**

GetPool.

static Message m\_aclMessagePool [GLOBAL\_MESSAGE\_POOL\_SIZE]
 Array of message objects that make up the message pool.

#### 19.9.1 Detailed Description

Implements a list of message objects shared between all threads.

Definition at line 208 of file message.h.

#### 19.9.2 Member Function Documentation

```
19.9.2.1 Message * GlobalMessagePool::GetHead( ) [static]
```

GetHead.

Return a pointer to the first element in the message list

Returns

Pointer to head message element, or NULL if empty

Definition at line 112 of file message.cpp.

```
19.9.2.2 MessagePool * GlobalMessagePool::GetPool( ) [static]
```

GetPool.

Get the pointer to the underlying message pool object

Returns

Pointer to message pool.

Definition at line 118 of file message.cpp.

19.9.2.3 void GlobalMessagePool::Init(void) [static]

Init.

Initialize the message queue prior to use

Definition at line 89 of file message.cpp.

```
19.9.2.4 Message * GlobalMessagePool::Pop( ) [static]
```

Pop.

Pop a message from the global queue, returning it to the user to be popu32ated before sending by a transmitter.

#### Returns

Pointer to a Message object

### **Examples:**

lab8\_messages/main.cpp.

Definition at line 106 of file message.cpp.

```
19.9.2.5 void GlobalMessagePool::Push ( Message * pclMessage_ ) [static]
```

Push.

Return a previously-claimed message object back to the global queue. used once the message has been processed by a receiver.

### **Parameters**

pcl←	Pointer to the Message object to return back to the global queue
Message_	

### **Examples:**

lab8\_messages/main.cpp.

Definition at line 100 of file message.cpp.

The documentation for this class was generated from the following files:

- · /home/moslevin/projects/mark3-source/kernel/public/message.h
- /home/moslevin/projects/mark3-source/kernel/message.cpp

## 19.10 Kernel Class Reference

Class that encapsulates all of the kernel startup functions.

```
#include <kernel.h>
```

#### Static Public Member Functions

· static void Init (void)

Kernel Initialization Function, call before any other OS function.

static void Start (void)

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

static bool IsStarted ()

IsStarted.

• static void SetPanic (PanicFunc\_t pfPanic\_)

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

• static bool IsPanic ()

IsPanic Returns whether or not the kernel is in a panic state.

static void Panic (uint16\_t u16Cause\_)

Panic Cause the kernel to enter its panic state.

static void SetIdleFunc (IdleFunc\_t pfIdle\_)

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

static void IdleFunc (void)

IdleFunc Call the low-priority idle function when no active threads are available to be scheduled.

static Thread \* GetIdleThread (void)

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

static void SetThreadCreateCallout (ThreadCreateCallout\_t pfCreate\_)

SetThreadCreateCallout.

static void SetThreadExitCallout (ThreadExitCallout t pfExit )

SetThreadExitCallout.

static void SetThreadContextSwitchCallout (ThreadContextCallout\_t pfContext\_)

SetThreadContextSwitchCallout.

static ThreadCreateCallout\_t GetThreadCreateCallout (void)

GetThreadCreateCallout.

static ThreadExitCallout\_t GetThreadExitCallout (void)

GetThreadExitCallout.

• static ThreadContextCallout\_t GetThreadContextSwitchCallout (void)

GetThreadContextSwitchCallout.

# **Static Private Attributes**

static bool m blsStarted

true if kernel is running, false otherwise

• static bool m\_blsPanic

true if kernel is in panic state, false otherwise

static PanicFunc t m pfPanic

set panic function

static ldleFunc\_t m\_pfldle

set idle function

static FakeThread\_t m\_clldle

Idle thread object (note: not a real thread)

• static ThreadCreateCallout\_t m\_pfThreadCreateCallout

Function to call on thread creation.

static ThreadExitCallout\_t m\_pfThreadExitCallout

Function to call on thread exit.

static ThreadContextCallout\_t m\_pfThreadContextCallout

Function to call on context switch.

#### 19.10.1 Detailed Description

Class that encapsulates all of the kernel startup functions.

Definition at line 44 of file kernel.h.

## 19.10.2 Member Function Documentation

```
19.10.2.1 static Thread* Kernel::GetIdleThread(void) [inline], [static]
```

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

Note that the Thread object involved is to be used for comparisons only – the thread itself is "virtual", and doesn't represent a unique execution context with its own stack.

## Returns

Pointer to the Kernel's idle thread object

Definition at line 122 of file kernel.h.

19.10.2.2 static ThreadContextCallout\_t Kernel::GetThreadContextSwitchCallout(void) [inline], [static]

GetThreadContextSwitchCallout.

Return the current function called on every Thread::ContextSwitchSWI()

### Returns

Pointer to the currently-installed callout function, or NULL if not set.

Definition at line 190 of file kernel.h.

```
19.10.2.3 static ThreadCreateCallout_t Kernel::GetThreadCreateCallout ( void ) [inline], [static]
GetThreadCreateCallout.
Return the current function called on every <a href="https://www.thread::Init()">Thread::Init()</a>;
Returns
     Pointer to the currently-installed callout function, or NULL if not set.
Definition at line 172 of file kernel.h.
19.10.2.4 static ThreadExitCallout_t Kernel::GetThreadExitCallout(void) [inline], [static]
GetThreadExitCallout.
Return the current function called on every Thread::Exit();
Returns
     Pointer to the currently-installed callout function, or NULL if not set.
Definition at line 181 of file kernel.h.
19.10.2.5 void Kernel::Init(void) [static]
Kernel Initialization Function, call before any other OS function.
Initializes all global resources used by the operating system. This must be called before any other kernel function is
invoked.
Examples:
     buffalogger/main.cpp, lab10 notifications/main.cpp, lab11 mailboxes/main.cpp, lab1 kernel setup/main.←
     cpp, lab2_idle_function/main.cpp, lab3_round_robin/main.cpp, lab4_semaphores/main.cpp, lab5_←
     mutexes/main.cpp, lab6_timers/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_←
     dynamic_threads/main.cpp.
Definition at line 67 of file kernel.cpp.
19.10.2.6 static bool Kernel::IsPanic() [inline], [static]
IsPanic Returns whether or not the kernel is in a panic state.
Returns
     Whether or not the kernel is in a panic state
Definition at line 90 of file kernel.h.
19.10.2.7 static bool Kernel::IsStarted() [inline], [static]
IsStarted.
Returns
     Whether or not the kernel has started - true = running, false = not started
Definition at line 77 of file kernel.h.
19.10.2.8 void Kernel::Panic ( uint16_t u16Cause_ ) [static]
```

Panic Cause the kernel to enter its panic state.

#### **Parameters**

u16 <b></b>	Reason for the kernel panic
Cause_	

Definition at line 110 of file kernel.cpp.

```
19.10.2.9 static void Kernel::SetIdleFunc(IdleFunc_t pfIdle_) [inline], [static]
```

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

#### **Parameters**

pf←	Pointer to the idle function
ldle⊷	
_	

## **Examples:**

lab2\_idle\_function/main.cpp.

Definition at line 103 of file kernel.h.

```
19.10.2.10 static void Kernel::SetPanic ( PanicFunc_t pfPanic_ ) [inline], [static]
```

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

## **Parameters**

pf← Panic←	Panic function pointer
_	

Definition at line 85 of file kernel.h.

```
19.10.2.11 static void Kernel::SetThreadContextSwitchCallout ( ThreadContextCallout_t pfContext_ ) [inline], [static]
```

SetThreadContextSwitchCallout.

Set a function to be called on each context switch.

A callout is only executed if this method has been called to set a valid handler function.

#### **Parameters**

pf⊷	Pointer to a function to call on context switch
Context←	

#### **Examples:**

lab9\_dynamic\_threads/main.cpp.

Definition at line 159 of file kernel.h.

19.10.2.12 static void Kernel::SetThreadCreateCallout( ThreadCreateCallout\_t pfCreate\_) [inline], [static]

SetThreadCreateCallout.

Set a function to be called on creation of a new thread. This callout is executed on the successful completion of a Thread::Init() call. A callout is only executed if this method has been called to set a valid handler function.

#### **Parameters**

pf⇔	Pointer to a function to call on thread creation
Create←	

## **Examples:**

lab9\_dynamic\_threads/main.cpp.

Definition at line 136 of file kernel.h.

19.10.2.13 static void Kernel::SetThreadExitCallout( ThreadExitCallout\_t pfExit\_) [inline], [static]

SetThreadExitCallout.

Set a function to be called on thread exit. This callout is executed from the beginning of Thread::Exit().

A callout is only executed if this method has been called to set a valid handler function.

### **Parameters**

pf⇔	Pointer to a function to call on thread exit
Create←	

# **Examples:**

lab9\_dynamic\_threads/main.cpp.

Definition at line 148 of file kernel.h.

```
19.10.2.14 void Kernel::Start (void ) [static]
```

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

You must have at least one thread added to the kernel before calling this function, otherwise the behavior is undefined. The exception to this is if the system is configured to use the threadless idle hook, in which case the kernel is allowed to run without any ready threads.

#### **Examples:**

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main.cpp, lab2\_idle\_function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_cuttexes/main.cpp, lab6\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_cutering-dynamic\_threads/main.cpp.

Definition at line 101 of file kernel.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/kernel.h
- /home/moslevin/projects/mark3-source/kernel/kernel.cpp

#### 19.11 KernelAware Class Reference

```
The KernelAware class.
```

```
#include <kernelaware.h>
```

#### **Static Public Member Functions**

```
    static void ProfileInit (const char *szStr_)
```

ProfileInit.

static void ProfileStart (void)

ProfileStart.

• static void ProfileStop (void)

ProfileStop.

static void ProfileReport (void)

 ${\it Profile Report.}$ 

static void ExitSimulator (void)

ExitSimulator.

static void Print (const char \*szStr\_)

Print.

static void Trace (uint16\_t u16File\_, uint16\_t u16Line\_)

Trace.

• static void Trace (uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_)

Trace.

static void Trace (uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_, uint16\_t u16Arg2\_)

Trace.

· static bool IsSimulatorAware (void)

IsSimulatorAware.

#### **Static Private Member Functions**

```
    static void Trace_i (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_, Kernel
        — AwareCommand_t eCmd_)
        Trace_i.
```

## 19.11.1 Detailed Description

The KernelAware class.

This class contains functions that are used to trigger kernel-aware functionality within a supported simulation environment (i.e. flAVR).

These static methods operate on a singleton set of global variables, which are monitored for changes from within the simulator. The simulator hooks into these variables by looking for the correctly-named symbols in an elf-formatted binary being run and registering callbacks that are called whenever the variables are changed. On each change of the command variable, the kernel-aware data is analyzed and interpreted appropriately.

If these methods are run in an unsupported simulator or on actual hardware the commands generally have no effect (except for the exit-on-reset command, which will result in a jump-to-0 reset).

Definition at line 64 of file kernelaware.h.

## 19.11.2 Member Function Documentation

```
19.11.2.1 void KernelAware::ExitSimulator( void ) [static]
```

ExitSimulator.

Instruct the kernel-aware simulator to terminate (destroying the virtual CPU).

Definition at line 109 of file kernelaware.cpp.

```
19.11.2.2 bool KernelAware::lsSimulatorAware(void) [static]
```

IsSimulatorAware.

use this function to determine whether or not the code is running on a simulator that is aware of the kernel.

Returns

true - the application is being run in a kernel-aware simulator. false - otherwise.

Definition at line 154 of file kernelaware.cpp.

```
19.11.2.3 void KernelAware::Print ( const char * szStr_ ) [static]
```

Print.

Instruct the kernel-aware simulator to print a char string

#### **Parameters**



#### **Examples:**

lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main.cpp, lab2\_idle\_← function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_mutexes/main.cpp, lab6← \_\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_dynamic\_threads/main.cpp.

Definition at line 145 of file kernelaware.cpp.

```
19.11.2.4 void KernelAware::ProfileInit (const char * szStr_) [static]
```

#### ProfileInit.

Initializes the kernel-aware profiler. This function instructs the kernel-aware simulator to reset its accounting variables, and prepare to start counting profiling data tagged to the given string. How this is handled is the responsibility of the simulator.

#### **Parameters**

SZ←	String to use as a tag for the profilng session.
Str_	

Definition at line 82 of file kernelaware.cpp.

```
19.11.2.5 void KernelAware::ProfileReport( void ) [static]
```

### ProfileReport.

Instruct the kernel-aware simulator to print a report for its current profiling data.

Definition at line 103 of file kernelaware.cpp.

```
19.11.2.6 void KernelAware::ProfileStart(void) [static]
```

#### ProfileStart.

Instruct the kernel-aware simulator to begin counting cycles towards the current profiling counter.

Definition at line 91 of file kernelaware.cpp.

```
19.11.2.7 void KernelAware::ProfileStop (void ) [static]
```

## ProfileStop.

Instruct the kernel-aware simulator to end counting cycles relative to the current profiling counter's iteration.

Definition at line 97 of file kernelaware.cpp.

```
19.11.2.8 void KernelAware::Trace ( uint16_t u16File_, uint16_t u16Line_ ) [static]
```

#### Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

### **Parameters**

<i>u</i> 16⇔	16-bit code representing the file
File_	
<i>u</i> 16⇔	16-bit code representing the line in the file
Line_	

## **Examples:**

lab11\_mailboxes/main.cpp, lab8\_messages/main.cpp, and lab9\_dynamic\_threads/main.cpp.

Definition at line 115 of file kernelaware.cpp.

```
19.11.2.9 void KernelAware::Trace ( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_ ) [static]
```

#### Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

## **Parameters**

u16File⊷	16-bit code representing the file
_	
u16⇔	16-bit code representing the line in the file
Line_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg1_	

Definition at line 121 of file kernelaware.cpp.

```
19.11.2.10 void KernelAware::Trace ( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_ ) [static]
```

## Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

#### **Parameters**

u16File←	16-bit code representing the file
_	
u16⇔	16-bit code representing the line in the file
Line_	

#### **Parameters**

u16 <b></b>	16-bit argument to the format string.
Arg1_	
u16⇔	16-bit argument to the format string.
Arg2_	

Definition at line 126 of file kernelaware.cpp.

```
19.11.2.11 void KernelAware::Trace_i ( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_, KernelAwareCommand_t eCmd_ ) [static], [private]
```

#### Trace\_i.

Private function by which the class's Trace() methods are reflected, which allows u16 to realize a modest code saving.

#### **Parameters**

u16File⊷	16-bit code representing the file
u16↔ Line_	16-bit code representing the line in the file
u16⇔ Arg1_	16-bit argument to the format string.
u16← Arg2_	16-bit argument to the format string.
eCmd_	Code indicating the number of arguments to emit.

Definition at line 132 of file kernelaware.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/kernelaware.h
- /home/moslevin/projects/mark3-source/kernel/kernelaware.cpp

# 19.12 KernelAwareData\_t Union Reference

This structure is used to communicate between the kernel and a kernel- aware host.

## **Public Attributes**

```
    volatile uint16_t au16Buffer [5]
    Raw binary contents of the struct.
```

```
    struct {
        volatile const char * szName
        Name of the profiling data to report.
    } Profiler
```

The Profiler struct contains data related to the code-execution profiling functionality provided by a kernel-aware host simluator.

```
    struct {
        volatile uint16_t u16File
            File index.
        volatile uint16_t u16Line
            Line number.
        volatile uint16_t u16Arg1
            (optional) argument code
        volatile uint16_t u16Arg2
            (optional) argument code
    } Trace
    Trace
    The Trace struct contains data related to the display and output of kernel-trace strings on a kernel-aware host.
    struct {
        volatile const char * szString
```

The Print struct contains data related to the display of arbitrary null-terminated ASCII strings on the kernel-aware host.

### 19.12.1 Detailed Description

} Print

This structure is used to communicate between the kernel and a kernel- aware host.

Its data contents is interpreted differently depending on the command executed (by means of setting the g\_u8KA $\leftarrow$  Command variable, as is done in the command handlers in this module). As a result, any changes to this struct by way of modifying or adding data must be mirrored in the kernel-aware simulator.

Definition at line 48 of file kernelaware.cpp.

Pointer ot a string (in RAM) to print.

The documentation for this union was generated from the following file:

/home/moslevin/projects/mark3-source/kernel/kernelaware.cpp

## 19.13 KernelSWI Class Reference

Class providing the software-interrupt required for context-switching in the kernel.

```
#include <kernelswi.h>
```

## **Static Public Member Functions**

## 19.13.1 Detailed Description

Class providing the software-interrupt required for context-switching in the kernel.

Definition at line 31 of file kernelswi.h.

## 19.13.2 Member Function Documentation

```
19.13.2.1 void KernelSWI::Clear (void ) [static]
```

Clear.

Clear the software interrupt

Definition at line 68 of file kernelswi.cpp.

```
19.13.2.2 void KernelSWI::Config(void) [static]
```

Config.

Configure the software interrupt - must be called before any other software interrupt functions are called.

Definition at line 29 of file kernelswi.cpp.

```
19.13.2.3 uint8_t KernelSWI::DI( ) [static]
```

DI.

Disable the SWI flag itself

Returns

previous status of the SWI, prior to the DI call

Definition at line 50 of file kernelswi.cpp.

```
19.13.2.4 void KernelSWI::RI ( bool bEnable_ ) [static]
```

RI.

Restore the state of the SWI to the value specified

**Parameters** 

b⇔	true - enable the SWI, false - disable SWI
Enable⊷	

Definition at line 58 of file kernelswi.cpp.

```
19.13.2.5 void KernelSWI::Start (void ) [static]
```

Start.

Enable ("Start") the software interrupt functionality

Definition at line 37 of file kernelswi.cpp.

```
19.13.2.6 void KernelSWI::Stop(void) [static]
```

Stop.

Disable the software interrupt functionality

Definition at line 44 of file kernelswi.cpp.

```
19.13.2.7 void KernelSWI::Trigger( void ) [static]
```

Trigger.

Call the software interrupt

Definition at line 74 of file kernelswi.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h
- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp

# 19.14 KernelTimer Class Reference

Hardware timer interface, used by all scheduling/timer subsystems.

```
#include <kerneltimer.h>
```

## **Static Public Member Functions**

```
    static void Config (void)

          Config.
    • static void Start (void)
         Start.

    static void Stop (void)

         Stop.
    • static uint8_t DI (void)

    static void RI (bool bEnable_)

    • static void EI (void)

    static PORT_TIMER_COUNT_TYPE SubtractExpiry (PORT_TIMER_COUNT_TYPE uInterval_)

         SubtractExpiry.

    static PORT_TIMER_COUNT_TYPE TimeToExpiry (void)

          TimeToExpiry.

    static PORT_TIMER_COUNT_TYPE SetExpiry (uint32_t u32Interval_)

    static PORT_TIMER_COUNT_TYPE GetOvertime (void)

          GetOvertime.

    static void ClearExpiry (void)

         ClearExpiry.

    static PORT_TIMER_COUNT_TYPE Read (void)

         Read.
19.14.1 Detailed Description
Hardware timer interface, used by all scheduling/timer subsystems.
Definition at line 31 of file kerneltimer.h.
19.14.2 Member Function Documentation
19.14.2.1 void KernelTimer::ClearExpiry (void ) [static]
ClearExpiry.
Clear the hardware timer expiry register
Definition at line 136 of file kerneltimer.cpp.
19.14.2.2 void KernelTimer::Config (void ) [static]
Config.
```

Generated by Doxygen

Initializes the kernel timer before use

Definition at line 33 of file kerneltimer.cpp.

```
19.14.2.3 uint8_t KernelTimer::DI(void) [static]
DI.
Disable the kernel timer's expiry interrupt
Definition at line 144 of file kerneltimer.cpp.
19.14.2.4 void KernelTimer::El ( void ) [static]
EI.
Enable the kernel timer's expiry interrupt
Definition at line 157 of file kerneltimer.cpp.
19.14.2.5 PORT_TIMER_COUNT_TYPE KernelTimer::GetOvertime(void) [static]
GetOvertime.
Return the number of ticks that have elapsed since the last expiry.
Returns
     Number of ticks that have elapsed after last timer expiration
Definition at line 112 of file kerneltimer.cpp.
19.14.2.6 PORT_TIMER_COUNT_TYPE KernelTimer::Read(void) [static]
Read.
Safely read the current value in the timer register
Returns
     Value held in the timer register
Examples:
     lab9 dynamic threads/main.cpp.
Definition at line 66 of file kerneltimer.cpp.
19.14.2.7 void KernelTimer::RI ( bool bEnable_ ) [static]
RI.
Retstore the state of the kernel timer's expiry interrupt.
```

#### **Parameters**

b⇔	1 enable, 0 disable
Enable←	
_	

Definition at line 163 of file kerneltimer.cpp.

```
19.14.2.8 PORT_TIMER_COUNT_TYPE KernelTimer::SetExpiry ( uint32_t u32Interval_ ) [static]
```

SetExpiry.

Resets the kernel timer's expiry interval to the specified value

#### **Parameters**

<i>u32</i> ⇔	Desired interval in ticks to set the timer for
Interval_	

#### Returns

Actual number of ticks set (may be less than desired)

Definition at line 118 of file kerneltimer.cpp.

```
19.14.2.9 void KernelTimer::Start(void) [static]
```

Start.

Starts the kernel time (must be configured first)

Definition at line 39 of file kerneltimer.cpp.

```
19.14.2.10 void KernelTimer::Stop (void ) [static]
```

Stop.

Shut down the kernel timer, used when no timers are scheduled

Definition at line 54 of file kerneltimer.cpp.

```
19.14.2.11 PORT_TIMER_COUNT_TYPE KernelTimer::SubtractExpiry ( PORT_TIMER_COUNT_TYPE uInterval_ ) [static]
```

SubtractExpiry.

Subtract the specified number of ticks from the timer's expiry count register. Returns the new expiry value stored in the register.

#### **Parameters**

<i>u32</i> ←	Time (in HW-specific) ticks to subtract
Interval_	

#### Returns

Value in ticks stored in the timer's expiry register

Definition at line 84 of file kerneltimer.cpp.

19.14.2.12 PORT\_TIMER\_COUNT\_TYPE KernelTimer::TimeToExpiry(void) [static]

TimeToExpiry.

Returns the number of ticks remaining before the next timer expiry.

#### Returns

Time before next expiry in platform-specific ticks

Definition at line 95 of file kerneltimer.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h
- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp

## 19.15 LinkList Class Reference

Abstract-data-type from which all other linked-lists are derived.

#include <ll.h>

Inheritance diagram for LinkList:



## **Public Member Functions**

```
• void Init ()
```

Init.

LinkListNode \* GetHead ()

GetHead.

LinkListNode \* GetTail ()

GetTail.

## **Protected Attributes**

• LinkListNode \* m pstHead

Pointer to the head node in the list.

LinkListNode \* m\_pstTail

Pointer to the tail node in the list.

## 19.15.1 Detailed Description

Abstract-data-type from which all other linked-lists are derived.

Definition at line 109 of file II.h.

## 19.15.2 Member Function Documentation

```
19.15.2.1 LinkListNode* LinkList::GetHead( ) [inline]
```

GetHead.

Get the head node in the linked list

Returns

Pointer to the head node in the list

Definition at line 134 of file II.h.

19.15.2.2 LinkListNode\* LinkList::GetTail( ) [inline]

GetTail.

Get the tail node of the linked list

Returns

Pointer to the tail node in the list

Definition at line 142 of file II.h.

```
19.15.2.3 void LinkList::Init(void) [inline]
```

Init.

Clear the linked list.

Definition at line 121 of file II.h.

The documentation for this class was generated from the following file:


• /home/moslevin/projects/mark3-source/kernel/public/ll.h

## 19.16 LinkListNode Class Reference

Basic linked-list node data structure.

```
#include <11.h>
```

Inheritance diagram for LinkListNode:



## **Public Member Functions**

LinkListNode \* GetNext (void)

GetNext.

LinkListNode \* GetPrev (void)

GetPrev.

## **Protected Member Functions**

void ClearNode ()
 ClearNode.

#### **Protected Attributes**

LinkListNode \* next

Pointer to the next node in the list.

LinkListNode \* prev

Pointer to the previous node in the list.

#### **Friends**

- class LinkList
- · class DoubleLinkList
- class CircularLinkList
- class ThreadList

## 19.16.1 Detailed Description

Basic linked-list node data structure.

This data is managed by the linked-list class types, and can be used transparently between them.

Definition at line 68 of file II.h.

#### 19.16.2 Member Function Documentation

```
19.16.2.1 void LinkListNode::ClearNode( ) [protected]
```

ClearNode.

Initialize the linked list node, clearing its next and previous node.

Definition at line 40 of file II.cpp.

```
19.16.2.2 LinkListNode* LinkListNode::GetNext(void) [inline]
```

GetNext.

Returns a pointer to the next node in the list.

Returns

a pointer to the next node in the list.

Definition at line 90 of file II.h.

```
19.16.2.3 LinkListNode* LinkListNode::GetPrev(void) [inline]
```

GetPrev.

Returns a pointer to the previous node in the list.

Returns

a pointer to the previous node in the list.

Definition at line 98 of file II.h.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/II.h
- /home/moslevin/projects/mark3-source/kernel/II.cpp

## 19.17 Mailbox Class Reference

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

```
#include <mailbox.h>
```

#### **Public Member Functions**

bool ReceiveTail (void \*pvData\_, uint32\_t u32TimeoutMS\_)

# **Private Member Functions**

Receive\_i.

ReceiveTail.

```
    void * GetHeadPointer (void)

     GetHeadPointer.

    void * GetTailPointer (void)

     GetTailPointer.

    void CopyData (const void *src_, const void *dst_, uint16_t len_)

     CopyData.

    void MoveTailForward (void)

     MoveTailForward.

    void MoveHeadForward (void)

     MoveHeadForward.

    void MoveTailBackward (void)

     MoveTailBackward.

    void MoveHeadBackward (void)

     MoveHeadBackward.

    bool Send_i (const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_)

• bool Receive_i (const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_)
```

## **Private Attributes**

uint16\_t m\_u16Head

Current head index.

• uint16\_t m\_u16Tail

Current tail index.

• uint16\_t m\_u16Count

Count of items in the mailbox.

• volatile uint16\_t m\_u16Free

Current number of free slots in the mailbox.

• uint16\_t m\_u16ElementSize

Size of the objects tracked in this mailbox.

const void \* m\_pvBuffer

Pointer to the data-buffer managed by this mailbox.

• Semaphore m\_clRecvSem

Counting semaphore used to synchronize threads on the object.

• Semaphore m\_clSendSem

Binary semaphore for send-blocked threads.

## 19.17.1 Detailed Description

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

### **Examples:**

lab11\_mailboxes/main.cpp.

Definition at line 35 of file mailbox.h.

## 19.17.2 Member Function Documentation

19.17.2.1 void Mailbox::CopyData (const void \* src\_, const void \* dst\_, uint16\_t len\_) [inline], [private]

CopyData.

Perform a direct byte-copy from a source to a destination object.

### **Parameters**

Pointer to an object to read from
Pointer to an object to write to
Length to copy (in bytes)
0 17 ( ) /

Definition at line 238 of file mailbox.h.

```
19.17.2.2 void* Mailbox::GetHeadPointer(void) [inline], [private]
```

GetHeadPointer.

Return a pointer to the current head of the mailbox's internal circular buffer.

Returns

pointer to the head element in the mailbox

Definition at line 207 of file mailbox.h.

```
19.17.2.3 void* Mailbox::GetTailPointer(void) [inline], [private]
```

GetTailPointer.

Return a pointer to the current tail of the mailbox's internal circular buffer.

Returns

pointer to the tail element in the mailbox

Definition at line 222 of file mailbox.h.

```
19.17.2.4 void Mailbox::Init ( void * pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_ )
```

Init.

Initialize the mailbox object prior to its use. This must be called before any calls can be made to the object.

## **Parameters**

pvBuffer_	Pointer to the static buffer to use for the mailbox
u16BufferSize_	Size of the mailbox buffer, in bytes
u16Element⊷	Size of each envelope, in bytes
Size_	

## **Examples:**

lab11\_mailboxes/main.cpp.

Definition at line 51 of file mailbox.cpp.

```
19.17.2.5 void Mailbox::MoveHeadBackward (void ) [inline], [private]
```

MoveHeadBackward.

Move the head index backward one element

Definition at line 291 of file mailbox.h.

```
19.17.2.6 void Mailbox::MoveHeadForward (void ) [inline], [private]
```

MoveHeadForward.

Move the head index forward one element

Definition at line 265 of file mailbox.h.

```
19.17.2.7 void Mailbox::MoveTailBackward (void ) [inline], [private]
```

MoveTailBackward.

Move the tail index backward one element

Definition at line 278 of file mailbox.h.

```
19.17.2.8 void Mailbox::MoveTailForward (void ) [inline], [private]
```

MoveTailForward.

Move the tail index forward one element

Definition at line 252 of file mailbox.h.

```
19.17.2.9 void Mailbox::Receive (void * pvData_)
```

Receive.

Read one envelope from the head of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered.

#### **Parameters**

pv⊷	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
Data	

#### **Examples:**

lab11\_mailboxes/main.cpp.

Definition at line 89 of file mailbox.cpp.

```
19.17.2.10 bool Mailbox::Receive ( void * pvData_, uint32_t u32TimeoutMS_ )
```

Receive.

Read one envelope from the head of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered, or the specified time has elapsed without delivery.

#### **Parameters**

pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⊷	Maximum time to wait for delivery.
<i>S</i> _	

#### Returns

true - envelope was delivered, false - delivery timed out.

Definition at line 102 of file mailbox.cpp.

19.17.2.11 bool Mailbox::Receive\_i ( const void \* pvData\_, bool bTail\_, uint32\_t u32WaitTimeMS\_ ) [private]

## Receive\_i.

Internal method which implements all Read() methods in the class.

#### **Parameters**

pvData_	Pointer to the envelope data
bTail_	true - read from tail, false - read from head
u32WaitTimeM⊷ S_	Time to wait before timeout (in ms).

### Returns

true - read successfully, false - timeout.

Definition at line 244 of file mailbox.cpp.

19.17.2.12 void Mailbox::ReceiveTail ( void \* pvData\_ )

# ReceiveTail.

Read one envelope from the tail of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered.

#### **Parameters**

pv⊷	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
Data_	

Definition at line 110 of file mailbox.cpp.

19.17.2.13 bool Mailbox::ReceiveTail ( void \* pvData\_, uint32\_t u32TimeoutMS\_ )

ReceiveTail.

Read one envelope from the tail of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered, or the specified time has elapsed without delivery.

#### **Parameters**

pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⊷	Maximum time to wait for delivery.
<i>S_</i>	

#### Returns

true - envelope was delivered, false - delivery timed out.

Definition at line 123 of file mailbox.cpp.

```
19.17.2.14 bool Mailbox::Send (void * pvData_)
```

#### Send.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the head of the mailbox.

### **Parameters**

pv⊷	Pointer to the data object to send to the mailbox.
Data_	

#### Returns

true - envelope was delivered, false - mailbox is full.

### **Examples:**

lab11\_mailboxes/main.cpp.

Definition at line 131 of file mailbox.cpp.

```
19.17.2.15 bool Mailbox::Send ( void * pvData_, uint32_t u32TimeoutMS_ )
```

## Send.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the head of the mailbox.

## **Parameters**

pvData_	Pointer to the data object to send to the mailbox.
u32TimeoutM⇔	Maximum time to wait for a free transmit slot
S_	

#### Returns

true - envelope was delivered, false - mailbox is full.

Definition at line 156 of file mailbox.cpp.

19.17.2.16 bool Mailbox::Send\_i ( const void \* pvData\_, bool bTail\_, uint32\_t u32WaitTimeMS\_ ) [private]

## Send\_i.

Internal method which implements all Send() methods in the class.

#### **Parameters**

pvData_	Pointer to the envelope data
bTail_	true - write to tail, false - write to head
u32WaitTimeM← S_	Time to wait before timeout (in ms).

### Returns

true - data successfully written, false - buffer full

Definition at line 174 of file mailbox.cpp.

19.17.2.17 bool Mailbox::SendTail ( void \* pvData\_ )

# SendTail.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the tail of the mailbox.

#### **Parameters**

pv⊷	Pointer to the data object to send to the mailbox.
Data	

#### Returns

true - envelope was delivered, false - mailbox is full.

Definition at line 143 of file mailbox.cpp.

19.17.2.18 bool Mailbox::SendTail (void \* pvData\_, uint32\_t u32TimeoutMS\_)

SendTail.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the tail of the mailbox.

#### **Parameters**

pvData_	Pointer to the data object to send to the mailbox.
u32TimeoutM⊷	Maximum time to wait for a free transmit slot
S_	

#### Returns

true - envelope was delivered, false - mailbox is full.

Definition at line 164 of file mailbox.cpp.

## 19.17.3 Member Data Documentation

19.17.3.1 Semaphore Mailbox::m\_clSendSem [private]

Binary semaphore for send-blocked threads.

Definition at line 360 of file mailbox.h.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/mailbox.h
- /home/moslevin/projects/mark3-source/kernel/mailbox.cpp

# 19.18 Message Class Reference

Class to provide message-based IPC services in the kernel.

#include <message.h>

Inheritance diagram for Message:



## **Public Member Functions**

```
    void Init ()
        Init.

    void SetData (void *pvData_)
        SetData.

    void * GetData ()
        GetData.

    void SetCode (uint16_t u16Code_)
        SetCode.

    uint16_t GetCode ()
        GetCode.
```

## **Private Attributes**

```
    void * m_pvData
    Pointer to the message data.
```

• uint16\_t m\_u16Code

Message code, providing context for the message.

## **Additional Inherited Members**

## 19.18.1 Detailed Description

Class to provide message-based IPC services in the kernel.

### **Examples:**

```
lab8_messages/main.cpp.
```

Definition at line 99 of file message.h.

#### 19.18.2 Member Function Documentation

```
19.18.2.1 uint16_t Message::GetCode( ) [inline]
```

GetCode.

Return the code set in the message upon receipt

Returns

user code set in the object

## **Examples:**

lab8\_messages/main.cpp.

Definition at line 146 of file message.h.

```
19.18.2.2 void* Message::GetData() [inline]
```

GetData.

Get the data pointer stored in the message upon receipt

Returns

Pointer to the data set in the message object

## Examples:

lab8\_messages/main.cpp.

Definition at line 130 of file message.h.

```
19.18.2.3 void Message::Init (void ) [inline]
```

Init.

Initialize the data and code in the message.

Definition at line 108 of file message.h.

```
19.18.2.4 void Message::SetCode ( uint16_t u16Code_ ) [inline]
```

SetCode.

Set the code in the message before transmission

## **Parameters**

u16 <b></b>	Data code to set in the object
Code_	

## **Examples:**

lab8\_messages/main.cpp.

Definition at line 138 of file message.h.

```
19.18.2.5 void Message::SetData (void * pvData_) [inline]
```

SetData.

Set the data pointer for the message before transmission.

#### **Parameters**

pv⊷	Pointer to the data object to send in the message
Data_	

## **Examples:**

lab8\_messages/main.cpp.

Definition at line 122 of file message.h.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/mark3-source/kernel/public/message.h

# 19.19 MessagePool Class Reference

Implements a list of message objects.

```
#include <message.h>
```

## **Public Member Functions**

```
• void Init ()
```

Init.

void Push (Message \*pclMessage\_)

Push.

• Message \* Pop ()

Рор.

Message \* GetHead ()

GetHead.

## **Private Attributes**

• DoubleLinkList m\_clList

Linked list used to manage the Message objects.

# 19.19.1 Detailed Description

Implements a list of message objects.

Definition at line 159 of file message.h.

19.19.2 Member Function Documentation

19.19.2.1 Message \* MessagePool::GetHead ( )

GetHead.

Return a pointer to the first element in the message list

Returns

Definition at line 83 of file message.cpp.

19.19.2.2 void MessagePool::Init ( void )

Init.

Initialize the message queue prior to use

Definition at line 50 of file message.cpp.

19.19.2.3 Message \* MessagePool::Pop()

Pop.

Pop a message from the queue, returning it to the user to be popu32ated before sending by a transmitter.

Returns

Pointer to a Message object

Definition at line 68 of file message.cpp.

19.19.2.4 void MessagePool::Push ( Message \* pclMessage\_ )

Push.

Return a previously-claimed message object back to the queue. used once the message has been processed by a receiver.

**Parameters** 

pcl⇔	Pointer to the Message object to return back to the queue
Message_	

Definition at line 56 of file message.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/message.h
- /home/moslevin/projects/mark3-source/kernel/message.cpp

# 19.20 MessageQueue Class Reference

List of messages, used as the channel for sending and receiving messages between threads.

```
#include <message.h>
```

#### **Public Member Functions**

### **Private Member Functions**

```
    Message * Receive_i (uint32_t u32TimeWaitMS_)
    Receive_i.
```

### **Private Attributes**

• Semaphore m\_clSemaphore

Counting semaphore used to manage thread blocking.

• DoubleLinkList m\_clLinkList

List object used to store messages.

## 19.20.1 Detailed Description

List of messages, used as the channel for sending and receiving messages between threads.

## **Examples:**

```
lab8_messages/main.cpp.
```

Definition at line 269 of file message.h.

```
19.20.2 Member Function Documentation
19.20.2.1 uint16_t MessageQueue::GetCount ( )
GetCount.
Return the number of messages pending in the "receive" queue.
Returns
     Count of pending messages in the queue.
Definition at line 193 of file message.cpp.
19.20.2.2 void MessageQueue::Init (void)
Init.
Initialize the message queue prior to use.
Examples:
     lab8_messages/main.cpp.
Definition at line 124 of file message.cpp.
19.20.2.3 Message * MessageQueue::Receive ( )
Receive.
Receive a message from the message queue. If the message queue is empty, the thread will block until a message
is available.
Returns
     Pointer to a message object at the head of the queue
Examples:
     lab8_messages/main.cpp.
Definition at line 130 of file message.cpp.
19.20.2.4 Message * MessageQueue::Receive ( uint32_t u32TimeWaitMS_ )
Receive.
```

Receive a message from the message queue. If the message queue is empty, the thread will block until a message is available for the duration specified. If no message arrives within that duration, the call will return with NULL.

Generated by Doxygen

#### **Parameters**

u32TimeWaitM⊷	The amount of time in ms to wait for a message before timing out and unblocking the
S_	waiting thread.

#### Returns

Pointer to a message object at the head of the queue or NULL on timeout.

Definition at line 141 of file message.cpp.

```
19.20.2.5 Message * MessageQueue::Receive_i(uint32_t u32TimeWaitMS_) [private]
```

Receive\_i.

Internal function used to abstract timed and un-timed Receive calls.

#### Parameters 4 8 1

u32TimeWaitM⊷	Time (in ms) to block, 0 for un-timed call.	
S_		

#### Returns

Pointer to a message, or 0 on timeout.

Definition at line 149 of file message.cpp.

```
19.20.2.6 void MessageQueue::Send ( Message * pclSrc_ )
```

Send.

Send a message object into this message queue. Will un-block the first waiting thread blocked on this queue if that occurs.

#### **Parameters**

pcl←	Pointer to the message object to add to the queue
Src	

# **Examples:**

lab8\_messages/main.cpp.

Definition at line 177 of file message.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/message.h
- /home/moslevin/projects/mark3-source/kernel/message.cpp

### 19.21 Mutex Class Reference

Mutual-exclusion locks, based on BlockingObject.

```
#include <mutex.h>
```

Inheritance diagram for Mutex:



### **Public Member Functions**

```
• void Init ()
```

Init.

• void Claim ()

Claim.

• bool Claim (uint32\_t u32WaitTimeMS\_)

Claim.

void WakeMe (Thread \*pclOwner\_)

WakeMe.

• void Release ()

Release.

### **Private Member Functions**

```
• uint8_t WakeNext ()
```

WakeNext.

bool Claim\_i (uint32\_t u32WaitTimeMS\_)

Claim\_i.

# **Private Attributes**

• uint8\_t m\_u8Recurse

The recursive lock-count when a mutex is claimed multiple times by the same owner.

bool m\_bReady

State of the mutex - true = ready, false = claimed.

uint8\_t m\_u8MaxPri

Maximum priority of thread in queue, used for priority inheritence.

• Thread \* m\_pclOwner

Pointer to the thread that owns the mutex (when claimed)

# **Additional Inherited Members**

# 19.21.1 Detailed Description

Mutual-exclusion locks, based on BlockingObject.

**Examples:** 

lab5\_mutexes/main.cpp.

Definition at line 68 of file mutex.h.

#### 19.21.2 Member Function Documentation

19.21.2.1 void Mutex::Claim (void)

Claim.

Claim the mutex. When the mutex is claimed, no other thread can claim a region protected by the object. If another Thread currently holds the Mutex when the Claim method is called, that Thread will block until the current owner of the mutex releases the Mutex.

If the calling Thread's priority is lower than that of a Thread that currently owns the Mutex object, then the priority of that Thread will be elevated to that of the highest-priority calling object until the Mutex is released. This property is known as "Priority Inheritence"

Note: A single thread can recursively claim a mutex up to a count of

1. Attempting to claim a mutex beyond that will cause a kernel panic.

### **Examples:**

lab5\_mutexes/main.cpp.

Definition at line 228 of file mutex.cpp.

19.21.2.2 bool Mutex::Claim ( uint32\_t u32WaitTimeMS\_ )

Claim.

Claim a mutex, with timeout.

# **Parameters**

u32WaitTimeM⊷ S\_

#### Returns

true - mutex was claimed within the time period specified false - mutex operation timed-out before the claim operation.

Definition at line 239 of file mutex.cpp.

```
19.21.2.3 bool Mutex::Claim_i ( uint32_t u32WaitTimeMS_ ) [private]
```

Claim\_i.

Abstracts out timed/non-timed mutex claim operations.

#### **Parameters**

u32WaitTimeM⊷	Time in MS to wait, 0 for infinite
S_	

#### Returns

true on successful claim, false otherwise

Definition at line 129 of file mutex.cpp.

```
19.21.2.4 void Mutex::Init ( void )
```

Init.

Initialize a mutex object for use - must call this function before using the object.

#### **Examples:**

lab5\_mutexes/main.cpp.

Definition at line 109 of file mutex.cpp.

```
19.21.2.5 void Mutex::Release ( )
```

Release.

Release the mutex. When the mutex is released, another object can enter the mutex-protected region.

If there are Threads waiting for the Mutex to become available, then the highest priority Thread will be unblocked at this time and will claim the Mutex lock immediately - this may result in an immediate context switch, depending on relative priorities.

If the calling Thread's priority was boosted as a result of priority inheritence, the Thread's previous priority will also be restored at this time.

Note that if a Mutex is held recursively, it must be Release'd the same number of times that it was Claim'd before it will be availabel for use by another Thread.

#### **Examples:**

lab5\_mutexes/main.cpp.

Definition at line 246 of file mutex.cpp.

```
19.21.2.6 void Mutex::WakeMe ( Thread * pclOwner_ )
```

WakeMe.

Wake a thread blocked on the mutex. This is an internal function used for implementing timed mutexes relying on timer callbacks. Since these do not have access to the private data of the mutex and its base classes, we have to wrap this as a public method - do not use this for any other purposes.

#### **Parameters**

pcl←	Thread to unblock from this object.
Owner_	

Definition at line 79 of file mutex.cpp.

```
19.21.2.7 uint8_t Mutex::WakeNext( ) [private]
```

WakeNext.

Wake the next thread waiting on the Mutex.

Definition at line 88 of file mutex.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/mutex.h
- /home/moslevin/projects/mark3-source/kernel/mutex.cpp

# 19.22 Notify Class Reference

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

```
#include <notify.h>
```

Inheritance diagram for Notify:



### **Public Member Functions**

```
    void Init (void)
```

Init.

• void Signal (void)

Signal.

void Wait (bool \*pbFlag\_)

Wait

bool Wait (uint32\_t u32WaitTimeMS\_, bool \*pbFlag\_)

Wait

void WakeMe (Thread \*pclChosenOne\_)

WakeMe.

### **Additional Inherited Members**

# 19.22.1 Detailed Description

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

#### **Examples:**

```
lab10_notifications/main.cpp.
```

Definition at line 33 of file notify.h.

# 19.22.2 Member Function Documentation

```
19.22.2.1 void Notify::Init (void)
```

Init.

Initialze the Notification object prior to use.

### **Examples:**

lab10\_notifications/main.cpp.

Definition at line 68 of file notify.cpp.

```
19.22.2.2 void Notify::Signal (void)
```

Signal.

Signal the notification object. This will cause the highest priority thread currently blocking on the object to wake. If no threads are currently blocked on the object, the call has no effect.

# **Examples:**

```
lab10_notifications/main.cpp.
```

Definition at line 77 of file notify.cpp.

```
19.22.2.3 void Notify::Wait ( bool * pbFlag_ )
```

Wait.

Block the current thread, waiting for a signal on the object.

#### **Parameters**

pb⇔	Flag set to false on block, and true upon wakeup.
Flag_	

### **Examples:**

lab10\_notifications/main.cpp.

Definition at line 102 of file notify.cpp.

19.22.2.4 bool Notify::Wait ( uint32\_t u32WaitTimeMS\_, bool \* pbFlag\_ )

Wait.

Block the current thread, waiting for a signal on the object.

### **Parameters**

u32WaitTimeM⇔ S_	Time to wait for the notification event.
pbFlag_	Flag set to false on block, and true upon wakeup.

### Returns

true on notification, false on timeout

Definition at line 123 of file notify.cpp.

19.22.2.5 void Notify::WakeMe ( Thread \* pclChosenOne\_ )

WakeMe.

Wake the specified thread from its current blocking queue. Note that this is only public in order to be accessible from a timer callack.

### **Parameters**

pclChosen⇔	Thread to wake up
One_	

Definition at line 162 of file notify.cpp.

The documentation for this class was generated from the following files:

- · /home/moslevin/projects/mark3-source/kernel/public/notify.h
- /home/moslevin/projects/mark3-source/kernel/notify.cpp

# 19.23 PriorityMap Class Reference

The PriorityMap class.

```
#include <priomap.h>
```

#### **Public Member Functions**

• PriorityMap ()

PriorityMap.

• void Set (PORT\_PRIO\_TYPE uXPrio\_)

Set Set the priority map bitmap data, at all levels, for the given priority.

void Clear (PORT\_PRIO\_TYPE uXPrio\_)

Clear Clear the priority map bitmap data, at all levels, for the given priority.

• PORT\_PRIO\_TYPE HighestPriority (void)

HighestPriority.

### 19.23.1 Detailed Description

The PriorityMap class.

Definition at line 70 of file priomap.h.

### 19.23.2 Constructor & Destructor Documentation

```
19.23.2.1 PriorityMap::PriorityMap()
```

## PriorityMap.

Initialize the priority map object, clearing the bitamp data to all 0's.

Definition at line 51 of file priomap.cpp.

### 19.23.3 Member Function Documentation

```
19.23.3.1 void PriorityMap::Clear ( PORT_PRIO_TYPE uXPrio_ )
```

Clear Clear the priority map bitmap data, at all levels, for the given priority.

# **Parameters**

uX⊷	Priority level to clear the bitmap data for.
Prio_	

Definition at line 78 of file priomap.cpp.

```
19.23.3.2 PORT_PRIO_TYPE PriorityMap::HighestPriority (void)
```

HighestPriority.

Computes the numeric priority of the highest-priority thread represented in the priority map.

#### Returns

Highest priority ready-thread's number.

Definition at line 94 of file priomap.cpp.

```
19.23.3.3 void PriorityMap::Set ( PORT_PRIO_TYPE uXPrio_ )
```

Set Set the priority map bitmap data, at all levels, for the given priority.

#### **Parameters**

uX⊷	Priority level to set the bitmap data for.
Prio_	

Definition at line 64 of file priomap.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/priomap.h
- /home/moslevin/projects/mark3-source/kernel/priomap.cpp

## 19.24 Profiler Class Reference

System profiling timer interface.

```
#include <kernelprofile.h>
```

#### **Static Public Member Functions**

```
• static void Init ()
```

Init.

• static void Start ()

Start.

· static void Stop ()

Stop.

• static PORT\_TIMER\_COUNT\_TYPE Read ()

Read.

• static void Process ()

Process

• static uint32\_t GetEpoch ()

GetEpoch.

# 19.24.1 Detailed Description

System profiling timer interface.

Definition at line 37 of file kernelprofile.h.

#### 19.24.2 Member Function Documentation

```
19.24.2.1 static uint32_t Profiler::GetEpoch() [inline],[static]
```

GetEpoch.

Return the current timer epoch

Definition at line 81 of file kernelprofile.h.

```
19.24.2.2 void Profiler::Init( void ) [static]
```

Init.

Initialize the global system profiler. Must be called prior to use.

Definition at line 32 of file kernelprofile.cpp.

```
19.24.2.3 void Profiler::Process (void ) [static]
```

Process.

Process the profiling counters from ISR.

Definition at line 70 of file kernelprofile.cpp.

```
19.24.2.4 PORT_TIMER_COUNT_TYPE Profiler::Read() [static]
```

Read.

Read the current tick count in the timer.

Definition at line 58 of file kernelprofile.cpp.

```
19.24.2.5 void Profiler::Start (void ) [static]
```

Start.

Start the global profiling timer service.

Definition at line 42 of file kernelprofile.cpp.

```
19.24.2.6 void Profiler::Stop ( ) [static]
```

Stop.

Stop the global profiling timer service

Definition at line 51 of file kernelprofile.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h
- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp

# 19.25 ProfileTimer Class Reference

```
Profiling timer.
```

```
#include <profile.h>
```

### **Public Member Functions**

```
· void Init ()
```

Init.

• void Start ()

Start.

void Stop ()

Stop.

• uint32\_t GetAverage ()

GetAverage.

• uint32\_t GetCurrent ()

GetCurrent.

# **Private Member Functions**

uint32\_t ComputeCurrentTicks (uint16\_t u16Count\_, uint32\_t u32Epoch\_)
 ComputeCurrentTicks.

### **Private Attributes**

• uint32\_t m\_u32Cumulative

Cumulative tick-count for this timer.

• uint32 t m u32CurrentIteration

Tick-count for the current iteration.

• uint16\_t m\_u16Initial

Initial count.

• uint32\_t m\_u32InitialEpoch

Initial Epoch.

• uint16\_t m\_u16Iterations

Number of iterations executed for this profiling timer.

bool m\_bActive

Wheter or not the timer is active or stopped.

# 19.25.1 Detailed Description

Profiling timer.

This class is used to perform high-performance profiling of code to see how int32\_t certain operations take. useful in instrumenting the performance of key algorithms and time-critical operations to ensure real-timer behavior.

Definition at line 69 of file profile.h.

### 19.25.2 Member Function Documentation

```
19.25.2.1 uint32_t ProfileTimer::ComputeCurrentTicks ( uint16_t u16Count_, uint32_t u32Epoch_ ) [private]
```

ComputeCurrentTicks.

Figure out how many ticks have elapsed in this iteration

#### **Parameters**

u16⇔	Current timer count
Count_	
<i>u32</i> ⇔	Current timer epoch
Epoch_	

### Returns

Current tick count

Definition at line 107 of file profile.cpp.

```
19.25.2.2 uint32_t ProfileTimer::GetAverage ( )
```

GetAverage.

Get the average time associated with this operation.

Returns

Average tick count normalized over all iterations

Definition at line 83 of file profile.cpp.

```
19.25.2.3 uint32_t ProfileTimer::GetCurrent ( )
```

GetCurrent.

Return the current tick count held by the profiler. Valid for both active and stopped timers.

Returns

The currently held tick count.

Definition at line 92 of file profile.cpp.

```
19.25.2.4 void ProfileTimer::Init ( void )

Init.

Initialize the profiling timer prior to use. Can also be used to reset a timer that's been used previously.

Definition at line 43 of file profile.cpp.

19.25.2.5 void ProfileTimer::Start ( void )

Start.

Start a profiling session, if the timer is not already active. Has no effect if the timer is already active.
```

Definition at line 52 of file profile.cpp.

```
19.25.2.6 void ProfileTimer::Stop ( )
```

Stop.

Stop the current profiling session, adding to the cumulative time for this timer, and the total iteration count.

Definition at line 65 of file profile.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/profile.h
- /home/moslevin/projects/mark3-source/kernel/profile.cpp

#### 19.26 Quantum Class Reference

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

```
#include <quantum.h>
```

# **Static Public Member Functions**

```
    static void UpdateTimer ()
```

UpdateTimer.

• static void AddThread (Thread \*pclThread\_)

AddThread.

• static void RemoveThread ()

RemoveThread.

• static void SetInTimer (void)

SetInTimer.

• static void ClearInTimer (void)

ClearInTimer.

#### **Static Private Member Functions**

static void SetTimer (Thread \*pclThread\_)
 SetTimer.

### 19.26.1 Detailed Description

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

Definition at line 41 of file quantum.h.

#### 19.26.2 Member Function Documentation

```
19.26.2.1 void Quantum::AddThread ( Thread * pclThread_ ) [static]
```

AddThread.

Add the thread to the quantum timer. Only one thread can own the quantum, since only one thread can be running on a core at a time.

Definition at line 86 of file quantum.cpp.

```
19.26.2.2 static void Quantum::ClearInTimer (void ) [inline], [static]
```

ClearInTimer.

Clear the flag once the timer callback function has been completed.

Definition at line 83 of file quantum.h.

```
19.26.2.3 void Quantum::RemoveThread (void ) [static]
```

RemoveThread.

Remove the thread from the quantum timer. This will cancel the timer.

Definition at line 114 of file quantum.cpp.

```
19.26.2.4 static void Quantum::SetInTimer(void) [inline], [static]
```

SetInTimer.

Set a flag to indicate that the CPU is currently running within the timer-callback routine. This prevents the Quantum timer from being updated in the middle of a callback cycle, potentially resulting in the kernel timer becoming disabled.

Definition at line 77 of file quantum.h.

```
19.26.2.5 void Quantum::SetTimer(Thread * pclThread_) [static], [private]
```

SetTimer.

Set up the quantum timer in the timer scheduler. This creates a one-shot timer, which calls a static callback in quantum.cpp that on expiry will pivot the head of the threadlist for the thread's priority. This is the mechanism that provides round-robin scheduling in the system.

#### **Parameters**

pcl⇔	Pointer to the thread to set the Quantum timer on
Thread_	

Definition at line 76 of file quantum.cpp.

```
19.26.2.6 void Quantum::UpdateTimer(void) [static]
```

UpdateTimer.

This function is called to update the thread quantum timer whenever something in the scheduler has changed. This can result in the timer being re-loaded or started. The timer is never stopped, but if may be ignored on expiry.

Definition at line 126 of file quantum.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/quantum.h
- /home/moslevin/projects/mark3-source/kernel/quantum.cpp

### 19.27 Scheduler Class Reference

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

```
#include <scheduler.h>
```

#### **Static Public Member Functions**

```
• static void Init ()
```

Init.

• static void Schedule ()

Schedule.

static void Add (Thread \*pclThread\_)

Add.

• static void Remove (Thread \*pclThread )

Remove.

static bool SetScheduler (bool bEnable\_)

SetScheduler.

static Thread \* GetCurrentThread ()

Get Current Thread.

static volatile Thread \* GetNextThread ()

Get Next Thread.

• static ThreadList \* GetThreadList (PORT\_PRIO\_TYPE uXPriority\_)

GetThreadList.

• static ThreadList \* GetStopList ()

GetStopList.

static bool IsEnabled ()

IsEnabled.

• static void QueueScheduler ()

QueueScheduler.

### **Static Private Attributes**

static bool m\_bEnabled

Scheduler's state - enabled or disabled.

• static bool m\_bQueuedSchedule

Variable representing whether or not there's a queued scheduler operation.

• static ThreadList m\_clStopList

ThreadList for all stopped threads.

• static ThreadList m\_aclPriorities [KERNEL\_NUM\_PRIORITIES]

ThreadLists for all threads at all priorities.

• static PriorityMap m\_clPrioMap

Priority bitmap lookup structure, 1-bit per thread priority.

# 19.27.1 Detailed Description

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

Definition at line 62 of file scheduler.h.

### 19.27.2 Member Function Documentation

```
19.27.2.1 void Scheduler::Add ( Thread * pclThread_ ) [static]
```

Add.

Add a thread to the scheduler at its current priority level.

#### **Parameters**

pcl⊷	Pointer to the thread to add to the scheduler
Thread_	

Definition at line 89 of file scheduler.cpp.

```
19.27.2.2 static Thread* Scheduler::GetCurrentThread() [inline], [static]
```

GetCurrentThread.

Return the pointer to the currently-running thread.

Returns

Pointer to the currently-running thread

#### **Examples:**

lab9\_dynamic\_threads/main.cpp.

Definition at line 121 of file scheduler.h.

```
19.27.2.3 static volatile Thread* Scheduler::GetNextThread() [inline], [static]
```

GetNextThread.

Return the pointer to the thread that should run next, according to the last run of the scheduler.

Returns

Pointer to the next-running thread

Definition at line 130 of file scheduler.h.

```
19.27.2.4 static ThreadList* Scheduler::GetStopList() [inline], [static]
```

GetStopList.

Return the pointer to the list of threads that are in the scheduler's stopped state.

Returns

Pointer to the ThreadList containing the stopped threads

Definition at line 150 of file scheduler.h.

```
19.27.2.5 static ThreadList* Scheduler::GetThreadList( PORT_PRIO_TYPE uXPriority_ ) [inline], [static]
```

GetThreadList.

Return the pointer to the active list of threads that are at the given priority level in the scheduler.

### **Parameters**

uX⊷	Priority level of the threadlist
Priority	

Returns

Pointer to the ThreadList for the given priority level

Definition at line 141 of file scheduler.h.

```
19.27.2.6 void Scheduler::Init (void ) [static]
```

Init.

Intiailize the scheduler, must be called before use.

Definition at line 54 of file scheduler.cpp.

19.27.2.7 static bool Scheduler::IsEnabled ( ) [inline], [static]

IsEnabled.

Return the current state of the scheduler - whether or not scheduling is enabled or disabled.

Returns

true - scheduler enabled, false - disabled

Definition at line 159 of file scheduler.h.

```
19.27.2.8 static void Scheduler::QueueScheduler( ) [inline], [static]
```

QueueScheduler.

Tell the kernel to perform a scheduling operation as soon as the scheduler is re-enabled.

Definition at line 166 of file scheduler.h.

```
19.27.2.9 void Scheduler::Remove ( Thread * pclThread_ ) [static]
```

Remove.

Remove a thread from the scheduler at its current priority level.

#### **Parameters**

pcl⊷	Pointer to the thread to be removed from the scheduler
Thread_	

Definition at line 95 of file scheduler.cpp.

```
19.27.2.10 void Scheduler::Schedule() [static]
```

Schedule.

Run the scheduler, determines the next thread to run based on the current state of the threads. Note that the next-thread chosen from this function is only valid while in a critical section.

Definition at line 63 of file scheduler.cpp.

```
19.27.2.11 bool Scheduler::SetScheduler(bool bEnable_) [static]
```

SetScheduler.

Set the active state of the scheduler. When the scheduler is disabled, the *next thread* is never set; the currently running thread will run forever until the scheduler is enabled again. Care must be taken to ensure that we don't end up trying to block while the scheduler is disabled, otherwise the system ends up in an unusable state.

#### **Parameters**

b⇔	true to enable, false to disable the scheduler	
Enable⊷		
_		

Definition at line 101 of file scheduler.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/scheduler.h
- /home/moslevin/projects/mark3-source/kernel/scheduler.cpp

# 19.28 Semaphore Class Reference

Binary & Counting semaphores, based on BlockingObject base class.

```
#include <ksemaphore.h>
```

Inheritance diagram for Semaphore:



## **Public Member Functions**

- void Init (uint16\_t u16InitVal\_, uint16\_t u16MaxVal\_)
   Initialize a semaphore before use.
- bool Post ()

Increment the semaphore count.

• void Pend ()

Decrement the semaphore count.

• uint16\_t GetCount ()

Return the current semaphore counter.

bool Pend (uint32\_t u32WaitTimeMS\_)

Decrement the semaphore count.

• void WakeMe (Thread \*pclChosenOne\_)

Wake a thread blocked on the semaphore.

# **Private Member Functions**

• uint8\_t WakeNext ()

Wake the next thread waiting on the semaphore.

bool Pend\_i (uint32\_t u32WaitTimeMS\_)

Pend\_i.

#### **Private Attributes**

• uint16\_t m\_u16Value

Current count held by the semaphore.

• uint16 t m u16MaxValue

Maximum count that can be held by this semaphore.

#### **Additional Inherited Members**

#### 19.28.1 Detailed Description

Binary & Counting semaphores, based on BlockingObject base class.

#### **Examples:**

buffalogger/main.cpp, lab4\_semaphores/main.cpp, lab6\_timers/main.cpp, and lab9\_dynamic\_threads/main. ← cpp.

Definition at line 37 of file ksemaphore.h.

### 19.28.2 Member Function Documentation

```
19.28.2.1 uint16_t Semaphore::GetCount()
```

Return the current semaphore counter.

This can be usedd by a thread to bypass blocking on a semaphore - allowing it to do other things until a non-zero count is returned, instead of blocking until the semaphore is posted.

### Returns

The current semaphore counter value.

Definition at line 253 of file ksemaphore.cpp.

```
19.28.2.2 void Semaphore::Init ( uint16_t u16InitVal_, uint16_t u16MaxVal_ )
```

Initialize a semaphore before use.

Must be called before attempting post/pend operations on the object.

This initialization is required to configure the behavior of the semaphore with regards to the initial and maximum values held by the semaphore. By providing access to the raw initial and maximum count elements of the semaphore, these objects are able to be used as either counting or binary semaphores.

To configure a semaphore object for use as a binary semaphore, set values of 0 and 1 respectively for the initial/maximum value parameters.

Any other combination of values can be used to implement a counting semaphore.

#### **Parameters**

u16InitVal↔	Initial value held by the semaphore
_	
u16Max⊷	Maximum value for the semaphore. Must be nonzero.
Val_	

#### **Examples:**

buffalogger/main.cpp, lab4\_semaphores/main.cpp, lab6\_timers/main.cpp, and lab9\_dynamic\_threads/main. ← cpp.

Definition at line 112 of file ksemaphore.cpp.

19.28.2.3 void Semaphore::Pend ( )

Decrement the semaphore count.

If the count is zero, the calling Thread will block until the semaphore is posted, and the Thread's priority is higher than that of any other Thread blocked on the object.

#### **Examples:**

 $buffalogger/main.cpp, lab4\_semaphores/main.cpp, lab6\_timers/main.cpp, and lab9\_dynamic\_threads/main. \\ \hookleftarrow cpp.$ 

Definition at line 235 of file ksemaphore.cpp.

19.28.2.4 bool Semaphore::Pend ( uint32\_t u32WaitTimeMS\_ )

Decrement the semaphore count.

If the count is zero, the thread will block until the semaphore is pended. If the specified interval expires before the thread is unblocked, then the status is returned back to the user.

### Returns

true - semaphore was acquired before the timeout false - timeout occurred before the semaphore was claimed.

Definition at line 246 of file ksemaphore.cpp.

19.28.2.5 bool Semaphore::Pend\_i ( uint32\_t u32WaitTimeMS\_ ) [private]

Pend\_i.

Internal function used to abstract timed and untimed semaphore pend operations.

#### **Parameters**

u32WaitTimeM⊷	Time in MS to wait
<i>S</i> _	

#### Returns

true on success, false on failure.

Definition at line 180 of file ksemaphore.cpp.

```
19.28.2.6 bool Semaphore::Post ( )
```

Increment the semaphore count.

If the semaphore count is zero at the time this is called, and there are threads blocked on the object, this will immediately unblock the highest-priority blocked Thread.

Note that if the priority of that Thread is higher than the current thread's priority, a context switch will occur and control will be relinquished to that Thread.

#### Returns

true if the semaphore was posted, false if the count is already maxed out.

#### **Examples:**

buffalogger/main.cpp, lab4\_semaphores/main.cpp, lab6\_timers/main.cpp, and lab9\_dynamic\_threads/main. ← cpp

Definition at line 131 of file ksemaphore.cpp.

```
19.28.2.7 void Semaphore::WakeMe ( Thread * pclChosenOne_ )
```

Wake a thread blocked on the semaphore.

This is an internal function used for implementing timed semaphores relying on timer callbacks. Since these do not have access to the private data of the semaphore and its base classes, we have to wrap this as a public method - do not used this for any other purposes.

Definition at line 82 of file ksemaphore.cpp.

```
19.28.2.8 uint8_t Semaphore::WakeNext() [private]
```

Wake the next thread waiting on the semaphore.

Used internally.

Definition at line 95 of file ksemaphore.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/ksemaphore.h
- /home/moslevin/projects/mark3-source/kernel/ksemaphore.cpp

# 19.29 Thread Class Reference

Object providing fundamental multitasking support in the kernel.

```
#include <thread.h>
```

Inheritance diagram for Thread:



### **Public Member Functions**

```
• void Init (K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, ThreadEntry_
 t pfEntryPoint_, void *pvArg_)
     Init.
• void Start ()
     Start.

    void Stop ()

     Stop.

    ThreadList * GetOwner (void)

     GetOwner.

    ThreadList * GetCurrent (void)

     GetCurrent.
• PORT_PRIO_TYPE GetPriority (void)
     GetPriority.
• PORT_PRIO_TYPE GetCurPriority (void)
     GetCurPriority.
• void SetQuantum (uint16_t u16Quantum_)
     SetQuantum.
• uint16_t GetQuantum (void)
     GetQuantum.

    void SetCurrent (ThreadList *pclNewList_)

     SetCurrent.

    void SetOwner (ThreadList *pclNewList_)

     SetOwner.

    void SetPriority (PORT_PRIO_TYPE uXPriority_)

     SetPriority.

    void InheritPriority (PORT_PRIO_TYPE uXPriority_)

     InheritPriority.
• void Exit ()
     Exit.

    void SetID (uint8_t u8ID_)

     SetID.
• uint8_t GetID ()
     GetID.

    uint16_t GetStackSlack ()
```

GetStackSlack.

uint16\_t GetEventFlagMask ()

GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag blocking object type.

void SetEventFlagMask (uint16\_t u16Mask\_)

SetEventFlagMask Sets the active event flag bitfield mask.

void SetEventFlagMode (EventFlagOperation\_t eMode\_)

SetEventFlagMode Sets the active event flag operation mode.

EventFlagOperation\_t GetEventFlagMode ()

GetEventFlagMode Returns the thread's event flag's operating mode.

• Timer \* GetTimer ()

Return a pointer to the thread's timer object.

void SetExpired (bool bExpired\_)

SetExpired.

· bool GetExpired ()

GetExpired.

· void InitIdle ()

InitIdle Initialize this Thread object as the Kernel's idle thread.

void \* GetExtendedContext ()

GetExtendedContext.

void SetExtendedContext (void \*pvData\_)

SetExtendedContext.

• ThreadState\_t GetState ()

GetState Returns the current state of the thread to the caller.

void SetState (ThreadState\_t eState\_)

SetState Set the thread's state to a new value.

K WORD \* GetStack ()

GetStack.

uint16\_t GetStackSize ()

GetStackSize.

# **Static Public Member Functions**

static void Sleep (uint32\_t u32TimeMs\_)

Sleep.

• static void USleep (uint32\_t u32TimeUs\_)

USleep.

• static void Yield (void)

Yield.

### **Private Member Functions**

void SetPriorityBase (PORT\_PRIO\_TYPE uXPriority\_)
 SetPriorityBase.

### **Static Private Member Functions**

· static void ContextSwitchSWI (void)

ContextSwitchSWI.

#### **Private Attributes**

K\_WORD \* m\_pwStackTop

Pointer to the top of the thread's stack.

K\_WORD \* m\_pwStack

Pointer to the thread's stack.

uint8\_t m\_u8ThreadID

Thread ID.

• PORT\_PRIO\_TYPE m\_uXPriority

Default priority of the thread.

PORT\_PRIO\_TYPE m\_uXCurPriority

Current priority of the thread (priority inheritence)

• ThreadState t m eState

Enum indicating the thread's current state.

void \* m\_pvExtendedContext

Pointer provided to a Thread to implement thread-local storage.

uint16 t m u16StackSize

Size of the stack (in bytes)

• ThreadList \* m pclCurrent

Pointer to the thread-list where the thread currently resides.

• ThreadList \* m\_pclOwner

Pointer to the thread-list where the thread resides when active.

ThreadEntry t m pfEntryPoint

The entry-point function called when the thread starts.

void \* m\_pvArg

Pointer to the argument passed into the thread's entrypoint.

• uint16 t m u16Quantum

Thread quantum (in milliseconds)

uint16\_t m\_u16FlagMask

Event-flag mask.

• EventFlagOperation\_t m\_eFlagMode

Event-flag mode.

· Timer m clTimer

Timer used for blocking-object timeouts.

bool m\_bExpired

Indicate whether or not a blocking-object timeout has occurred.

### **Friends**

· class ThreadPort

# **Additional Inherited Members**

# 19.29.1 Detailed Description

Object providing fundamental multitasking support in the kernel.

### **Examples:**

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main.cpc, cpp, lab2\_idle\_function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_comutexes/main.cpp, lab6\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_comutexes/main.cpp.

Definition at line 60 of file thread.h.

# 19.29.2 Member Function Documentation

```
19.29.2.1 void Thread::ContextSwitchSWI(void) [static], [private]
```

ContextSwitchSWI.

This code is used to trigger the context switch interrupt. Called whenever the kernel decides that it is necessary to swap out the current thread for the "next" thread.

Definition at line 475 of file thread.cpp.

```
19.29.2.2 void Thread::Exit ( )
```

Exit.

Remove the thread from being scheduled again. The thread is effectively destroyed when this occurs. This is extremely useful for cases where a thread encounters an unrecoverable error and needs to be restarted, or in the context of systems where threads need to be created and destroyed dynamically.

This must not be called on the idle thread.

#### **Examples:**

```
lab9_dynamic_threads/main.cpp.
```

Definition at line 229 of file thread.cpp.

```
19.29.2.3 PORT_PRIO_TYPE Thread::GetCurPriority ( void ) [inline]
```

GetCurPriority.

Return the priority of the current thread

Returns

Priority of the current thread

Definition at line 182 of file thread.h.

```
19.29.2.4 ThreadList* Thread::GetCurrent ( void ) [inline]
```

GetCurrent.

Return the ThreadList where the thread is currently located

Returns

Pointer to the thread's current list

Definition at line 165 of file thread.h.

```
19.29.2.5 uint16_t Thread::GetEventFlagMask( ) [inline]
```

GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag blocking object type.

Returns

A copy of the thread's event flag mask

Definition at line 327 of file thread.h.

```
19.29.2.6 EventFlagOperation_t Thread::GetEventFlagMode( ) [inline]
```

GetEventFlagMode Returns the thread's event flag's operating mode.

Returns

The thread's event flag mode.

Definition at line 343 of file thread.h.

```
19.29.2.7 bool Thread::GetExpired ( )
```

GetExpired.

Return the status of the most-recent blocking call on the thread.

Returns

```
true - call expired, false - call did not expire
```

Definition at line 527 of file thread.cpp.

```
19.29.2.8 void* Thread::GetExtendedContext() [inline]
```

GetExtendedContext.

Return the Thread object's extended-context data pointer. Used by code implementing a user-defined thread-local storage model. Pointer exists only for the lifespan of the Thread.

Returns

Thread's extended context data pointer.

Definition at line 391 of file thread.h.

```
19.29.2.9 uint8_t Thread::GetID() [inline]
GetID.
Return the 8-bit ID corresponding to this thread.
Returns
      Thread's 8-bit ID, set by the user
Definition at line 304 of file thread.h.
19.29.2.10 ThreadList* Thread::GetOwner(void) [inline]
GetOwner.
Return the ThreadList where the thread belongs when it's in the active/ready state in the scheduler.
Returns
      Pointer to the Thread's owner list
Definition at line 157 of file thread.h.
19.29.2.11 PORT_PRIO_TYPE Thread::GetPriority ( void ) [inline]
GetPriority.
Return the priority of the current thread
Returns
      Priority of the current thread
Definition at line 174 of file thread.h.
19.29.2.12 uint16_t Thread::GetQuantum ( void ) [inline]
GetQuantum.
Get the thread's round-robin execution quantum.
Returns
      The thread's quantum
```

Definition at line 199 of file thread.h.

```
19.29.2.13 K_WORD* Thread::GetStack( ) [inline]
```

GetStack.

Returns

Pointer to the blob of memory used as the thread's stack

Definition at line 427 of file thread.h.

```
19.29.2.14 uint16_t Thread::GetStackSize() [inline]
```

GetStackSize.

Returns

Size of the thread's stack in bytes

Definition at line 433 of file thread.h.

```
19.29.2.15 uint16_t Thread::GetStackSlack( )
```

GetStackSlack.

Performs a (somewhat lengthy) check on the thread stack to check the amount of stack margin (or "slack") remaining on the stack. If you're having problems with blowing your stack, you can run this function at points in your code during development to see what operations cause problems. Also useful during development as a tool to optimally size thread stacks.

Returns

The amount of slack (unused bytes) on the stack

ToDo: Reverse the logic for MCUs where stack grows UP instead of down

**Examples:** 

```
lab9_dynamic_threads/main.cpp.
```

Definition at line 346 of file thread.cpp.

```
19.29.2.16 ThreadState_t Thread::GetState() [inline]
```

GetState Returns the current state of the thread to the caller.

Can be used to determine whether or not a thread is ready (or running), stopped, or terminated/exit'd.

Returns

ThreadState\_t representing the thread's current state

**Examples:** 

```
lab9_dynamic_threads/main.cpp.
```

Definition at line 413 of file thread.h.

```
19.29.2.17 void Thread::InheritPriority ( PORT_PRIO_TYPE uXPriority_ )
```

InheritPriority.

Allow the thread to run at a different priority level (temporarily) for the purpose of avoiding priority inversions. This should only be called from within the implementation of blocking-objects.

#### **Parameters**

uX⇔	New Priority to boost to.
Priority_	

Definition at line 464 of file thread.cpp.

```
19.29.2.18 void Thread::Init ( K_WORD * pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, ThreadEntry_t pfEntryPoint_, void * pvArg_ )
```

Init.

Initialize a thread prior to its use. Initialized threads are placed in the stopped state, and are not scheduled until the thread's start method has been invoked first.

#### **Parameters**

pwStack_	Pointer to the stack to use for the thread
u16Stack⇔	Size of the stack (in bytes)
Size_	
uXPriority_	Priority of the thread (0 = idle, 7 = max)
pfEntryPoint⇔	This is the function that gets called when the thread is started
_	
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

#### **Examples:**

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main.cpp, cpp, lab2\_idle\_function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_comutexes/main.cpp, lab6\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_comutexes/main.cpp.

Definition at line 70 of file thread.cpp.

```
19.29.2.19 void Thread::InitIdle ( void )
```

InitIdle Initialize this Thread object as the Kernel's idle thread.

There should only be one of these, maximum, in a given system.

Definition at line 539 of file thread.cpp.

```
19.29.2.20 void Thread::SetCurrent ( ThreadList * pclNewList_ ) [inline]
```

SetCurrent.

Set the thread's current to the specified thread list

#### **Parameters**

pclNew←	Pointer to the threadlist to apply thread ownership
List_	

Definition at line 209 of file thread.h.

19.29.2.21 void Thread::SetEventFlagMask ( uint16\_t u16Mask\_ ) [inline]

SetEventFlagMask Sets the active event flag bitfield mask.

#### **Parameters**



Definition at line 332 of file thread.h.

19.29.2.22 void Thread::SetEventFlagMode ( EventFlagOperation\_t eMode\_ ) [inline]

SetEventFlagMode Sets the active event flag operation mode.

### **Parameters**

e⊷	Event flag operation mode, defines the logical operator to apply to the event flag.
Mode⊷	
_	

Definition at line 338 of file thread.h.

19.29.2.23 void Thread::SetExpired ( bool bExpired\_ )

SetExpired.

Set the status of the current blocking call on the thread.

#### **Parameters**

b⇔	true - call expired, false - call did not expire
Expired←	

Definition at line 517 of file thread.cpp.

19.29.2.24 void Thread::SetExtendedContext(void \* pvData\_) [inline]

SetExtendedContext.

Assign the Thread object's extended-context data pointer. Used by code implementing a user-defined thread-local storage model.

Object assigned to the context pointer should persist for the duration of the Thread.

#### **Parameters**

pv⊷	Object to assign to the extended data pointer.+
Data_	

Definition at line 404 of file thread.h.

```
19.29.2.25 void Thread::SetID ( uint8_t u8ID_ ) [inline]
```

SetID.

Set an 8-bit ID to uniquely identify this thread.

#### **Parameters**

u8l⊷	8-bit Thread ID, set by the user
D_	

Definition at line 296 of file thread.h.

```
19.29.2.26 void Thread::SetOwner ( ThreadList * pclNewList_ ) [inline]
```

SetOwner.

Set the thread's owner to the specified thread list

#### **Parameters**

14.1	British at the second of the second
pclNew←	Pointer to the threadlist to apply thread ownership
List	
LISI	

Definition at line 217 of file thread.h.

```
19.29.2.27 void Thread::SetPriority ( PORT_PRIO_TYPE uXPriority_ )
```

SetPriority.

Set the priority of the Thread (running or otherwise) to a different level. This activity involves re-scheduling, and must be done so with due caution, as it may effect the determinism of the system.

This should *always* be called from within a critical section to prevent system issues.

#### **Parameters**

uX⊷	New priority of the thread
Priority_	

Definition at line 421 of file thread.cpp.

19.29.2.28 void Thread::SetPriorityBase( PORT\_PRIO\_TYPE uXPriority\_) [private]

SetPriorityBase.

#### **Parameters**



Definition at line 407 of file thread.cpp.

19.29.2.29 void Thread::SetQuantum ( uint16\_t u16Quantum\_ ) [inline]

SetQuantum.

Set the thread's round-robin execution quantum.

### **Parameters**

<i>u</i> 16⇔	Thread's execution quantum (in milliseconds)
Quantum_	

### Examples:

lab3\_round\_robin/main.cpp.

Definition at line 191 of file thread.h.

19.29.2.30 void Thread::SetState ( ThreadState\_t eState\_ ) [inline]

SetState Set the thread's state to a new value.

This is only to be used by code within the kernel, and is not indended for use by an end-user.

#### **Parameters**

e⊷	New thread state to set.
State←	
_	

Definition at line 421 of file thread.h.

```
19.29.2.31 void Thread::Sleep ( uint32_t u32TimeMs_ ) [static]
```

Sleep.

Put the thread to sleep for the specified time (in milliseconds). Actual time slept may be longer (but not less than) the interval specified.

#### **Parameters**

u32Time⊷	Time to sleep (in ms)
Ms_	

#### **Examples:**

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main. $\leftarrow$  cpp, lab2\_idle\_function/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_dynamic\_ $\leftarrow$  threads/main.cpp.

Definition at line 301 of file thread.cpp.

```
19.29.2.32 void Thread::Start (void)
```

Start.

Start the thread - remove it from the stopped list, add it to the scheduler's list of threads (at the thread's set priority), and continue along.

### Examples:

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main. $\leftarrow$  cpp, lab2\_idle\_function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_ $\leftarrow$  mutexes/main.cpp, lab6\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_ $\leftarrow$  dynamic\_threads/main.cpp.

Definition at line 146 of file thread.cpp.

```
19.29.2.33 void Thread::Stop ( )
```

Stop.

Stop a thread that's actively scheduled without destroying its stacks. Stopped threads can be restarted using the Start() API.

Definition at line 182 of file thread.cpp.

```
19.29.2.34 void Thread::USleep ( uint32_t u32TimeUs_ ) [static]
```

USleep.

Put the thread to sleep for the specified time (in microseconds). Actual time slept may be longer (but not less than) the interval specified.

#### **Parameters**

u32Time <i>⊷</i>	Time to sleep (in microseconds)	1
Us_		

Definition at line 323 of file thread.cpp.

```
19.29.2.35 void Thread::Yield (void ) [static]
```

Yield.

Yield the thread - this forces the system to call the scheduler and determine what thread should run next. This is typically used when threads are moved in and out of the scheduler.

Definition at line 381 of file thread.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/thread.h
- /home/moslevin/projects/mark3-source/kernel/thread.cpp

# 19.30 ThreadList Class Reference

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

```
#include <threadlist.h>
```

Inheritance diagram for ThreadList:



### **Public Member Functions**

• ThreadList ()

ThreadList.

void SetPriority (PORT\_PRIO\_TYPE uXPriority\_)

SetPriority.

void SetMapPointer (PriorityMap \*pclMap\_)

SetMapPointer.

void Add (LinkListNode \*node\_)

Add

void Add (LinkListNode \*node\_, PriorityMap \*pclMap\_, PORT\_PRIO\_TYPE uXPriority\_)

Add

void AddPriority (LinkListNode \*node\_)

AddPriority.

• void Remove (LinkListNode \*node\_)

Remove.

• Thread \* HighestWaiter ()

HighestWaiter.

#### **Private Attributes**

PORT\_PRIO\_TYPE m\_uXPriority

Priority of the threadlist.

PriorityMap \* m\_pclMap

Pointer to the bitmap/flag to set when used for scheduling.

#### **Additional Inherited Members**

#### 19.30.1 Detailed Description

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

Definition at line 35 of file threadlist.h.

#### 19.30.2 Constructor & Destructor Documentation

```
19.30.2.1 ThreadList::ThreadList( ) [inline]
```

#### ThreadList.

Default constructor - zero-initializes the data.

Definition at line 44 of file threadlist.h.

#### 19.30.3 Member Function Documentation

```
19.30.3.1 void ThreadList::Add ( LinkListNode * node_ )
```

Add.

Add a thread to the threadlist.

#### Parameters

node←	Pointer to the thread (link list node) to add to the list
_	

Definition at line 52 of file threadlist.cpp.

```
19.30.3.2 void ThreadList::Add ( LinkListNode * node_, PriorityMap * pclMap_, PORT_PRIO_TYPE uXPriority_ )
```

Add.

Add a thread to the threadlist, specifying the flag and priority at the same time.

186 Class Documentation

#### **Parameters**

node_	Pointer to the thread to add (link list node)	
pclMap_	Pointer to the bitmap flag to set (if used in a scheduler context), or NULL for non-scheduler.	
uX⇔	Priority of the threadlist	
Priority_		

Definition at line 101 of file threadlist.cpp.

19.30.3.3 void ThreadList::AddPriority ( LinkListNode \* node\_ )

AddPriority.

Add a thread to the list such that threads are ordered from highest to lowest priority from the head of the list.

#### **Parameters**

node⊷	Pointer to a thread to add to the list.	

Definition at line 65 of file threadlist.cpp.

19.30.3.4 Thread \* ThreadList::HighestWaiter ( )

HighestWaiter.

Return a pointer to the highest-priority thread in the thread-list.

Returns

Pointer to the highest-priority thread

Definition at line 124 of file threadlist.cpp.

19.30.3.5 void ThreadList::Remove ( LinkListNode \* node\_ )

Remove.

Remove the specified thread from the threadlist

#### **Parameters**

node⊷	Pointer to the thread to remove

Definition at line 111 of file threadlist.cpp.

19.30.3.6 void ThreadList::SetMapPointer ( PriorityMap \* pclMap\_ )

SetMapPointer.

Set the pointer to a bitmap to use for this threadlist. Once again, only needed when the threadlist is being used for scheduling purposes.

#### **Parameters**

pcl←	Pointer to the priority map object used to track this thread.
Мар_	

Definition at line 46 of file threadlist.cpp.

19.30.3.7 void ThreadList::SetPriority ( PORT\_PRIO\_TYPE uXPriority\_ )

SetPriority.

Set the priority of this threadlist (if used for a scheduler).

#### **Parameters**

uX⇔	Priority level of the thread list
Priority_	

Definition at line 40 of file threadlist.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/threadlist.h
- /home/moslevin/projects/mark3-source/kernel/threadlist.cpp

#### 19.31 ThreadPort Class Reference

Class defining the architecture specific functions required by the kernel.

```
#include <threadport.h>
```

#### **Static Public Member Functions**

static void StartThreads ()
 StartThreads.

#### **Static Private Member Functions**

static void InitStack (Thread \*pstThread\_)
 InitStack.

188 Class Documentation

#### **Friends**

· class Thread

#### 19.31.1 Detailed Description

Class defining the architecture specific functions required by the kernel.

This is limited (at this point) to a function to start the scheduler, and a function to initialize the default stack-frame for a thread.

Definition at line 275 of file threadport.h.

#### 19.31.2 Member Function Documentation

```
19.31.2.1 void ThreadPort::InitStack ( Thread * pstThread_ ) [static], [private]
```

InitStack.

Initialize the thread's stack.

#### **Parameters**

pst⇔	Pointer to the thread to initialize
Thread_	

Definition at line 39 of file threadport.cpp.

```
19.31.2.2 void ThreadPort::StartThreads( ) [static]
```

StartThreads.

Function to start the scheduler, initial threads, etc.

Definition at line 130 of file threadport.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/threadport.h
- /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/threadport.cpp

#### 19.32 Timer Class Reference

Kernel-managed software timers.

```
#include <timer.h>
```

Inheritance diagram for Timer:



#### **Public Member Functions**

```
• Timer ()
      Timer.
• void Init ()
     Init.

    void Start (bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_, void *pvData_)

    void Start (bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_, TimerCallback_t pf

 Callback, void *pvData)
     Start.
• void Start ()
     Start.

    void Stop ()

     Stop.

    void SetFlags (uint8_t u8Flags_)

     SetFlags.

    void SetCallback (TimerCallback_t pfCallback_)

     SetCallback.

    void SetData (void *pvData_)

     SetData.
void SetOwner (Thread *pclOwner_)
     SetOwner.

    void SetIntervalTicks (uint32 t u32Ticks )

     SetIntervalTicks.

    void SetIntervalSeconds (uint32_t u32Seconds_)

     SetIntervalSeconds.
• uint32_t GetInterval ()
     GetInterval.

    void SetIntervalMSeconds (uint32 t u32MSeconds )

     SetIntervalMSeconds.

    void SetIntervalUSeconds (uint32_t u32USeconds_)

     SetIntervalUSeconds.

    void SetTolerance (uint32_t u32Ticks_)

     SetTolerance.
```

#### **Private Attributes**

• uint8 t m u8Flags

Flags for the timer, defining if the timer is one-shot or repeated.

TimerCallback\_t m\_pfCallback

Pointer to the callback function.

uint32 t m u32Interval

Interval of the timer in timer ticks.

uint32\_t m\_u32TimeLeft

Time remaining on the timer.

uint32\_t m\_u32TimerTolerance

Maximum tolerance (usedd for timer harmonization)

• Thread \* m\_pclOwner

Pointer to the owner thread.

void \* m\_pvData

Pointer to the callback data.

190 Class Documentation

#### **Friends**

· class TimerList

#### **Additional Inherited Members**

#### 19.32.1 Detailed Description

Kernel-managed software timers.

Kernel-managed timers, used to provide high-precision high-resolution delays. Functionality is useful to both usercode, and is used extensively within the kernel and its blocking objects to implement round-robin scheduling, thread sleep, and timeouts. Relies on a single hardware timer, which is multiplexed through the kernel.

#### **Examples:**

```
lab6_timers/main.cpp.
```

Definition at line 112 of file timer.h.

#### 19.32.2 Constructor & Destructor Documentation

```
19.32.2.1 Timer::Timer ( )
```

#### Timer.

Default Constructor - Do nothing. Allow the init call to perform the necessary object initialization prior to use.

Definition at line 48 of file timer.cpp.

#### 19.32.3 Member Function Documentation

```
19.32.3.1 uint32_t Timer::GetInterval( ) [inline]
```

GetInterval.

Return the timer's configured interval in ticks

Returns

Timer interval in ticks.

Definition at line 238 of file timer.h.

```
19.32.3.2 void Timer::Init (void)
```

Init.

Re-initialize the Timer to default values.

Definition at line 57 of file timer.cpp.

```
19.32.3.3 void Timer::SetCallback ( TimerCallback_t pfCallback_ ) [inline]
```

SetCallback.

Define the callback function to be executed on expiry of the timer

#### **Parameters**

pf⇔	Pointer to the callback function to call
Callback⊷	

Definition at line 195 of file timer.h.

19.32.3.4 void Timer::SetData (void \* pvData\_) [inline]

SetData.

Define a pointer to be sent to the timer callbcak on timer expiry

#### **Parameters**

pv⇔	Pointer to data to pass as argument into the callback	1
Data_		

Definition at line 203 of file timer.h.

19.32.3.5 void Timer::SetFlags ( uint8\_t u8Flags\_ ) [inline]

SetFlags.

Set the timer's flags based on the bits in the u8Flags\_ argument

#### **Parameters**

и8⇔	Flags to assign to the timer object. TIMERLIST_FLAG_ONE_SHOT for a one-shot timer, 0 for a
Flags_	continuous timer.

Definition at line 187 of file timer.h.

19.32.3.6 void Timer::SetIntervalMSeconds ( uint32\_t u32MSeconds\_ )

SetIntervalMSeconds.

Set the timer expiry interval in milliseconds (platform agnostic)

#### **Parameters**

<i>u32M</i> ↔	Time in milliseconds
Seconds_	

Definition at line 168 of file timer.cpp.

192 Class Documentation

19.32.3.7 void Timer::SetIntervalSeconds ( uint32\_t u32Seconds\_ )

SetIntervalSeconds.

! The next three cost u16 330 bytes of flash on AVR...

Set the timer expiry interval in seconds (platform agnostic)

#### **Parameters**

<i>u32</i> ⇔	Time in seconds
Seconds_	

Definition at line 158 of file timer.cpp.

19.32.3.8 void Timer::SetIntervalTicks ( uint32\_t u32Ticks\_ )

SetIntervalTicks.

Set the timer expiry in system-ticks (platform specific!)

#### **Parameters**

<i>u32</i> ⇔	Time in ticks
Ticks_	

Definition at line 146 of file timer.cpp.

19.32.3.9 void Timer::SetIntervalUSeconds ( uint32\_t u32USeconds\_ )

SetIntervalUSeconds.

Set the timer expiry interval in microseconds (platform agnostic)

#### **Parameters**

u32U⇔	Time in microseconds
Seconds_	

Definition at line 178 of file timer.cpp.

19.32.3.10 void Timer::SetOwner ( Thread \* pclOwner\_ ) [inline]

SetOwner.

Set the owner-thread of this timer object (all timers must be owned by a thread).

#### **Parameters**

pcl⇔	Owner thread of this timer object
Owner_	

Definition at line 212 of file timer.h.

19.32.3.11 void Timer::SetTolerance ( uint32\_t u32Ticks\_ )

SetTolerance.

Set the timer's maximum tolerance in order to synchronize timer processing with other timers in the system.

#### **Parameters**

<i>u32</i> ⇔	Maximum tolerance in ticks
Ticks_	

Definition at line 194 of file timer.cpp.

19.32.3.12 void Timer::Start ( bool bRepeat\_, uint32\_t u32IntervalMs\_, TimerCallback\_t pfCallback\_, void \* pvData\_ )

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

#### **Parameters**

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32Interval⊷	- Interval of the timer in miliseconds
Ms_	
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

#### **Examples:**

lab6\_timers/main.cpp.

Definition at line 77 of file timer.cpp.

19.32.3.13 void Timer::Start ( bool bRepeat\_, uint32\_t u32IntervalMs\_, uint32\_t u32ToleranceMs\_, TimerCallback\_t pfCallback\_, void \* pvData\_ )

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

194 Class Documentation

#### **Parameters**

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32IntervalMs_	- Interval of the timer in miliseconds
u32Tolerance⊷ Ms_	- Allow the timer expiry to be delayed by an additional maximum time, in order to have as many timers expire at the same time as possible.
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

Definition at line 102 of file timer.cpp.

```
19.32.3.14 void Timer::Start ( void )
```

Start.

Start or restart a timer using parameters previously configured via calls to Start(<with args>), or via the a-la-carte parameter setter methods. This is especially useful for retriggering one-shot timers that have previously expired, using the timer's previous configuration.

Definition at line 118 of file timer.cpp.

```
19.32.3.15 void Timer::Stop ( )
```

Stop.

Stop a timer already in progress. Has no effect on timers that have already been stopped.

Definition at line 133 of file timer.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/mark3-source/kernel/public/timer.h
- /home/moslevin/projects/mark3-source/kernel/timer.cpp

#### 19.33 TimerList Class Reference

TimerList class - a doubly-linked-list of timer objects.

```
#include <timerlist.h>
```

Inheritance diagram for TimerList:



#### **Public Member Functions**

• void Init ()

Init.

void Add (Timer \*pclListNode\_)

Add

void Remove (Timer \*pclListNode\_)

Remove.

· void Process ()

Process.

#### **Private Attributes**

• uint32\_t m\_u32NextWakeup

The time (in system clock ticks) of the next wakeup event.

• bool m\_bTimerActive

Whether or not the timer is active.

#### **Additional Inherited Members**

#### 19.33.1 Detailed Description

TimerList class - a doubly-linked-list of timer objects.

Definition at line 37 of file timerlist.h.

#### 19.33.2 Member Function Documentation

```
19.33.2.1 void TimerList::Add ( Timer * pclListNode_ )
```

Add.

Add a timer to the TimerList.

#### **Parameters**

pclList←	Pointer to the Timer to Add
Node_	

Definition at line 56 of file timerlist.cpp.

```
19.33.2.2 void TimerList::Init (void)
```

Init.

Initialize the TimerList object. Must be called before using the object.

Definition at line 49 of file timerlist.cpp.

196 Class Documentation

```
19.33.2.3 void TimerList::Process (void)
```

Process.

Process all timers in the timerlist as a result of the timer expiring. This will select a new timer epoch based on the next timer to expire. ToDo - figure out if we need to deal with any overtime here.

Definition at line 119 of file timerlist.cpp.

```
19.33.2.4 void TimerList::Remove ( Timer * pclListNode_ )
```

Remove.

Remove a timer from the TimerList, cancelling its expiry.

#### **Parameters**

pclList←	Pointer to the Timer to remove
Node_	

Definition at line 102 of file timerlist.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/mark3-source/kernel/public/timerlist.h
- /home/moslevin/projects/mark3-source/kernel/timerlist.cpp

#### 19.34 TimerScheduler Class Reference

"Static" Class used to interface a global TimerList with the rest of the kernel.

```
#include <timerscheduler.h>
```

#### **Static Public Member Functions**

```
• static void Init ()
```

Init.

static void Add (Timer \*pclListNode\_)

Add.

static void Remove (Timer \*pclListNode\_)

Remove.

• static void Process ()

Process.

#### **Static Private Attributes**

static TimerList m\_clTimerList

TimerList object manipu32ated by the Timer Scheduler.

#### 19.34.1 Detailed Description

"Static" Class used to interface a global TimerList with the rest of the kernel.

Definition at line 38 of file timerscheduler.h.

#### 19.34.2 Member Function Documentation

```
19.34.2.1 static void TimerScheduler::Add ( Timer * pclListNode_ ) [inline], [static]
```

Add.

Add a timer to the timer scheduler. Adding a timer implicitly starts the timer as well.

#### **Parameters**

pclList←	Pointer to the timer list node to add	
Node_		

Definition at line 56 of file timerscheduler.h.

```
19.34.2.2 static void TimerScheduler::Init (void ) [inline], [static]
```

Init.

Initialize the timer scheduler. Must be called before any timer, or timer-derived functions are used.

Definition at line 47 of file timerscheduler.h.

```
19.34.2.3 static void TimerScheduler::Process (void ) [inline], [static]
```

Process.

This function must be called on timer expiry (from the timer's ISR context). This will result in all timers being updated based on the epoch that just elapsed. The next timer epoch is set based on the next Timer object to expire.

Definition at line 74 of file timerscheduler.h.

```
19.34.2.4 static void TimerScheduler::Remove ( Timer * pclListNode_ ) [inline], [static]
```

Remove.

Remove a timer from the timer scheduler. May implicitly stop the timer if this is the only active timer scheduled.

#### **Parameters**

pclList←	Pointer to the timer list node to remove
Node_	

198 Class Documentation

Definition at line 65 of file timerscheduler.h.

The documentation for this class was generated from the following files:

• /home/moslevin/projects/mark3-source/kernel/public/timerscheduler.h

• /home/moslevin/projects/mark3-source/kernel/timerlist.cpp

## **Chapter 20**

## **File Documentation**

## 20.1 /home/moslevin/projects/mark3-source/kernel/atomic.cpp File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "atomic.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

#### 20.1.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.cpp.

### 20.2 atomic.cpp

```
00001 /*=======
00002
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h'
00023 #include "atomic.h"
00024 #include "threadport.h"
00025
00026 #define _CAN_HAS_DEBUG

00027 //--[Autogenerated - Do Not Modify]-------

00028 #include "dbg_file_list.h"

00029 #include "buffalogger.h"
```

```
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_ATOMIC_CPP
00034 #endif
00035 //--[End Autogenerated content]------
00037 #if KERNEL_USE_ATOMIC
00038
00039 //----
00040 uint8_t Atomic::Set(uint8_t* pu8Source_, uint8_t u8Val_)
00041 {
00042
         uint8_t u8Ret;
         CS_ENTER();
u8Ret = *pu8Source_;
00043
00044
         *pu8Source_ = u8Val_;
00045
00046
         CS EXIT();
00047
         return u8Ret;
00048 }
00049 //--
00050 uint16_t Atomic::Set(uint16_t* pu16Source_, uint16_t u16Val_)
00051 {
         uint16_t u16Ret;
00052
00053
         CS_ENTER();
00054
         u16Ret
                     = *pu16Source_;
00055
         *pul6Source_ = ul6Val_;
00056
         CS_EXIT();
00057
         return u16Ret;
00058 }
00059 //-----
00060 uint32_t Atomic::Set(uint32_t* pu32Source_, uint32_t u32Val_)
00061 {
00062
         uint32_t u32Ret;
         uints2_c
CS_ENTER();
= *pu32Source_;
00063
00064
         *pu32Source_ = u32Val_;
00065
00066
         CS EXIT();
00067
         return u32Ret;
00068 }
00069
00070 //----
00071 uint8_t Atomic::Add(uint8_t* pu8Source_, uint8_t u8Val_)
00072 {
00073
         uint8_t u8Ret;
00074
         CS_ENTER();
00075
         u8Ret = *pu8Source_;
00076
         *pu8Source_ += u8Val_;
00077
         CS EXIT();
00078
         return u8Ret:
00079 }
08000
00081 //----
00082 uint16_t Atomic::Add(uint16_t* pu16Source_, uint16_t u16Val_)
00083 {
00084
         uint16_t u16Ret;
00085
         CS_ENTER();
00086
         u16Ret = *pu16Source_;
00087
         *pu16Source_ += u16Val_;
00088
         CS_EXIT();
00089
         return u16Ret;
00090 }
00091
00092 //-
00093 uint32_t Atomic::Add(uint32_t* pu32Source_, uint32_t u32Val_)
00094 {
00095
         uint32_t u32Ret;
00096
         CS_ENTER();
        u32Ret = *pu32Source_;
*pu32Source_ += u32Val_;
00097
00098
00099
         CS_EXIT();
00100
         return u32Ret;
00101 }
00102
00103 //----
00104 uint8_t Atomic::Sub(uint8_t* pu8Source_, uint8_t u8Val_)
00105 {
00106
         uint8_t u8Ret;
00107
         CS_ENTER();
         u8Ret = *pu8Source_;
00108
         *pu8Source_ -= u8Val_;
00109
00110
         CS EXIT();
00111
         return u8Ret;
00112 }
00113
00114 //---
00115 uint16_t Atomic::Sub(uint16_t* pu16Source_, uint16_t u16Val_)
00116 {
```

```
00117
          uint16_t u16Ret;
00118
          CS_ENTER();
00119
          u16Ret = *pu16Source_;
00120
          *pu16Source_ -= u16Val_;
00121
          CS EXIT();
          return u16Ret;
00122
00123 }
00124
00125 //---
00126 uint32_t Atomic::Sub(uint32_t* pu32Source_, uint32_t u32Val_)
00127 {
00128
          uint32 t u32Ret:
00129
          CS_ENTER();
00130
         u32Ret = *pu32Source_;
00131
          *pu32Source_ -= u32Val_;
00132
          CS_EXIT();
00133
         return u32Ret:
00134 }
00135
00136 //--
00137 bool Atomic::TestAndSet(bool* pbLock_)
00138 {
00139
          uint8_t u8Ret;
00140
         CS_ENTER();
u8Ret = *pbLock_;
00141
00142
         if (!u8Ret) {
00143
              *pbLock_ = 1;
00144
         CS_EXIT();
00145
00146
          return u8Ret;
00147 }
00148
00149 #endif // KERNEL_USE_ATOMIC
```

## 20.3 /home/moslevin/projects/mark3-source/kernel/autoalloc.cpp File Reference

Automatic memory allocation for kernel objects.

```
#include "mark3cfg.h"
#include "mark3.h"
#include "autoalloc.h"
#include "threadport.h"
#include "kernel.h"
```

#### 20.3.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.cpp.

## 20.4 autoalloc.cpp

```
00020 #include "mark3cfg.h"
00021 #include "mark3.h"
00022 #include "autoalloc.h"
00023 #include "threadport.h"
00024 #include "kernel.h"
00025
00026 #if KERNEL_USE_AUTO_ALLOC
00027
00028 // Align to nearest word boundary
00029 \#define ALLOC_ALIGN(x) (((x) + (sizeof(K_ADDR) - 1)) & (sizeof(K_ADDR) - 1))
00030
00031 //
00032 uint8_t AutoAlloc::m_au8AutoHeap[AUTO_ALLOC_SIZE];
00033 K_ADDR AutoAlloc::m_aHeapTop;
00034
00035 //---
00036 void AutoAlloc::Init(void)
00037 {
00038
          m_aHeapTop = (K_ADDR) (m_au8AutoHeap);
00039 }
00040
00041 //--
00042 void* AutoAlloc::Allocate(uint16_t u16Size_)
00043 {
00044
          void* pvRet = 0;
00045
00046
          CS_ENTER();
00047
          uint16_t u16AllocSize = ALLOC_ALIGN(u16Size_);
          if ((((K_ADDR)m_aHeapTop - (K_ADDR)&m_au8AutoHeap[0]) + u16AllocSize) < AUTO_ALLOC_SIZE) {</pre>
00048
              pvRet = (void*)m_aHeapTop;
00049
00050
              m_aHeapTop += u16AllocSize;
00051
00052
          CS_EXIT();
00053
00054
          if (!pvRet) {
00055
              Kernel::Panic(PANIC_AUTO_HEAP_EXHAUSTED);
00056
00057
00058
          return pvRet;
00059 }
00060
00061 #if KERNEL_USE_SEMAPHORE
00062 //---
00063 Semaphore* AutoAlloc::NewSemaphore(void)
00064 {
00065
          void* pvObj = Allocate(sizeof(Semaphore));
00066
          if (pvObj) {
00067
            return new (pvObj) Semaphore();
          }
00068
00069
          return 0:
00070 }
00071 #endif
00072
00073 #if KERNEL_USE_MUTEX
00074 //----
00075 Mutex* AutoAlloc::NewMutex(void)
00076 {
00077
          void* pvObj = Allocate(sizeof(Mutex));
00078
         if (pvObj) {
         return new (pvObj) Mutex();
}
00079
00080
00081
         return 0;
00082 }
00083 #endif
00084
00085 #if KERNEL_USE_EVENTFLAG
00086 //--
00087 EventFlag* AutoAlloc::NewEventFlag(void)
00088 {
00089
          void* pvObj = Allocate(sizeof(EventFlag));
00090
          if (pvObj) {
00091
             return new (pvObj) EventFlag();
00092
00093
          return 0:
00094 }
00095 #endif
00096
00097 #if KERNEL_USE_MESSAGE
00098 //---
00099 Message* AutoAlloc::NewMessage(void)
00100 {
00101
          void* pvObj = Allocate(sizeof(Message));
00102
         return new (pvObj) Message();
}
          if (pvObj) {
00103
00104
          return 0;
00105
00106 }
```

```
00108 MessageQueue* AutoAlloc::NewMessageQueue(void)
00109 {
00110
         void* pvObj = Allocate(sizeof(MessageQueue));
00111
       return new (pvObj) MessageQueue();
00112
00113
00114
         return 0;
00115 }
00116
00117 #endif
00118
00119 #if KERNEL_USE_NOTIFY
00120 //--
00121 Notify* AutoAlloc::NewNotify(void)
00122 {
         void* pvObj = Allocate(sizeof(Notify));
00123
00124
        if (pvObj) {
       return new (pvObj) Notify();
}
return 0;
00126
00127
00128 }
00129 #endif
00130
00131 #if KERNEL_USE_MAILBOX
00133 Mailbox* AutoAlloc::NewMailbox(void)
00134 {
00135
         void* pvObj = Allocate(sizeof(Mailbox));
00136
        return new (pvObj) Mailbox();
}
00137
00138
00139
00140 }
00141 #endif
00142
00143 //---
00144 Thread* AutoAlloc::NewThread(void)
00145 {
00146
         void* pvObj = Allocate(sizeof(Thread));
        return new (pvObj) Thread();
00147
00148
00149
00150
         return 0;
00151 }
00152
00153 #if KERNEL_USE_TIMERS
00154 //----
00155 Timer* AutoAlloc::NewTimer(void)
00156 {
         void* pvObj = Allocate(sizeof(Timer));
00157
00158
        if (pvObj) {
       return new (pvObj) Timer();
}
return 0;
00159
00160
00161
00162 }
00163 #endif
00164
00165 #endif
```

### 20.5 /home/moslevin/projects/mark3-source/kernel/blocking.cpp File Reference

Implementation of base class for blocking objects.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### 20.5.1 Detailed Description

Implementation of base class for blocking objects.

Definition in file blocking.cpp.

### 20.6 blocking.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009
      --[Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 #include "blocking.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]--
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_BLOCKING_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037 #include "kerneldebug.h'
00038
00039 #if KERNEL_USE_SEMAPHORE || KERNEL_USE_MUTEX
00040 //-
00041 void BlockingObject::Block(Thread* pclThread_)
00042 {
          KERNEL_ASSERT(pclThread_);
KERNEL_TRACE_1("Blocking Thread %d", (uint16_t)pclThread_->
00043
00044
     GetID());
00045
00046
          // Remove the thread from its current thread list (the "owner" list)
00047
           // ... And add the thread to this object's block list
00048
          Scheduler::Remove(pclThread_);
00049
          m_clBlockList.Add(pclThread_);
00050
00051
          // Set the "current" list location to the blocklist for this thread
00052
          pclThread_->SetCurrent(&m_clBlockList);
00053
          pclThread_->SetState(THREAD_STATE_BLOCKED);
00054 }
00055
00056 //--
00057 void BlockingObject::BlockPriority(Thread* pclThread_)
00058 {
00059
          KERNEL_ASSERT (pclThread_);
00060
          KERNEL_TRACE_1("Blocking Thread %d", (uint16_t)pclThread_->
00061
00062
          // Remove the thread from its current thread list (the "owner" list)
00063
          // ... And add the thread to this object's block list
00064
          Scheduler::Remove(pclThread_);
00065
          m_clBlockList.AddPriority(pclThread_);
00066
00067
          // Set the "current" list location to the blocklist for this thread
          pclThread_->SetCurrent(&m_clBlockList);
00068
          pclThread_->SetState(THREAD_STATE_BLOCKED);
00069
00070 }
00071
00072 //--
00073 void BlockingObject::UnBlock(Thread* pclThread_)
00074 {
00075
          KERNEL_ASSERT (pclThread_);
00076
          KERNEL_TRACE_1("Unblocking Thread %d", (uint16_t)pclThread_->
```

```
GetID());
00077
00078
           // Remove the thread from its current thread list (the "owner" list)
00079
           pclThread_->GetCurrent()->Remove(pclThread_);
08000
00081
           // Put the thread back in its active owner's list. This is usually
           // the ready-queue at the thread's original priority.
00082
00083
           Scheduler::Add(pclThread_);
00084
          // Tag the thread's current list location to its owner
pclThread_->SetCurrent(pclThread_->GetOwner());
00085
00086
00087
           pclThread_->SetState(THREAD_STATE_READY);
00088 }
00089
00090 #endif
```

## 20.7 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp File Reference

ATMega328p Profiling timer implementation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

#### 20.7.1 Detailed Description

ATMega328p Profiling timer implementation.

Definition in file kernelprofile.cpp.

### 20.8 kernelprofile.cpp

```
00001 /*
00002
00003
00004
00005 1
                  1.11
00006
00008
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ==
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022 #include "profile.h"
00022 "Include "kernelprofile.h"
00024 #include "threadport.h"
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 #if KERNEL USE PROFILER
00029 uint32_t Profiler::m_u32Epoch;
00030
00031 //---
00032 void Profiler::Init()
```

```
00033 {
00034
          TCCR0A
                  = 0;
= 0;
= 0;
00035
          TCCR0B
00036
          TIFR0
          TIMSK0
00037
00038
         m_u32Epoch = 0;
00040
00041 //--
00042 void Profiler::Start() 00043 {
          TIFR0 = 0;
00044
          TCNT0 = 0;
00045
         TCCROB |= (1 << CSO1);
TIMSKO |= (1 << TOIEO);
00046
00047
00048 }
00049
00050 //---
00051 void Profiler::Stop()
00052 {
          TIFR0 = 0;
00053
         TCCROB &= ~(1 << CSO1);
TIMSKO &= ~(1 << TOIEO);
00054
00055
00056 }
00057 //--
00058 PORT_TIMER_COUNT_TYPE Profiler::Read()
00059 {
00060
          uint16_t u16Ret;
00067 }
00068
00069 //--
00070 void Profiler::Process()
00070 .
00072
         CS_ENTER();
00073
         m_u32Epoch++;
00074
         CS_EXIT();
00075 }
00076
00078 ISR(TIMERO_OVF_vect)
00079 {
08000
          Profiler::Process();
00081 }
00082
00083 #endif
```

## 20.9 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp File Reference

Kernel Software interrupt implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kernelswi.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

#### 20.9.1 Detailed Description

Kernel Software interrupt implementation for ATMega328p.

Definition in file kernelswi.cpp.

20.10 kernelswi.cpp 207

### 20.10 kernelswi.cpp

```
00001 /*=======
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00022 #include "kerneltypes.h"
00023 #include "kernelswi.h"
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 //---
00029 void KernelSWI::Config(void)
00030 {
00031
          PORTD &= \sim 0 \times 04;
00032
          DDRD |= 0x04;
                                                     // Set PortD, bit 2 (INTO) As Output
00033
          EICRA \mid = (1 << ISC00) \mid (1 << ISC01); // Rising edge on INT0
00034 }
00035
00036 //-
00037 void KernelSWI::Start(void)
00038 {
          EIFR &= \sim(1 << INTF0); // Clear any pending interrupts on INT0 EIMSK |= (1 << INT0); // Enable INT0 interrupt (as int32_t as I-bit is set)
00039
00040
00041 }
00042
00043 //---
00044 void KernelSWI::Stop(void)
00045 {
          EIMSK &= \sim(1 << INT0); // Disable INT0 interrupts
00046
00047 }
00048
00049 //--
00050 uint8_t KernelSWI::DI()
00051 {
00052
           bool bEnabled = ((EIMSK & (1 << INT0)) != 0);
          EIMSK &= ~(1 << INTO);
00053
          return bEnabled;
00054
00055 }
00056
00057 //----
00058 void KernelSWI::RI(bool bEnable_)
00059 {
00060
           if (bEnable_) {
00061
               EIMSK |= (1 << INTO);
00062
          } else
00063
               EIMSK &= \sim (1 << INT0);
00064
          }
00065 }
00066
00067 //-
00068 void KernelSWI::Clear(void)
00069 {
00070
          EIFR &= \sim (1 << INTF0); // Clear the interrupt flag for INT0
00071 }
00072
00073 //-
00074 void KernelSWI::Trigger(void)
00075 {
00076
           // if(Thread_IsSchedulerEnabled())
00077
00078
               PORTD &= \sim 0 \times 0.4:
00079
               PORTD |= 0x04;
08000
          }
00081 }
```

## 20.11 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp File Reference

Kernel Timer Implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kerneltimer.h"
#include "mark3cfg.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

#### 20.11.1 Detailed Description

Kernel Timer Implementation for ATMega328p.

Definition in file kerneltimer.cpp.

## 20.12 kerneltimer.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "kerneltimer.h"
00023 #include "mark3cfg.h"
00024
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00028 #define TCCR1B_INIT ((1 << WGM12) | (1 << CS12))
00029 \#define TIMER_IMSK (1 << OCIE1A)
00030 #define TIMER_IFR (1 << OCF1A)
00031
00032 //-
00033 void KernelTimer::Config(void)
00034 {
00035
           TCCR1B = TCCR1B_INIT;
00036 }
00037
00038 //----
00039 void KernelTimer::Start(void)
00040 {
00041 #if !KERNEL_TIMERS_TICKLESS
          TCCR1B = ((1 << WGM12) | (1 << CS11) | (1 << CS10));
OCR1A = ((PORT_SYSTEM_FREQ / 1000) / 64);
00042
00043
00044 #else
00045
         TCCR1B |= (1 << CS12);
00046 #endif
00047
           TCNT1 = 0;
00048
          TIFR1 &= ~TIMER_IFR;
TIMSK1 |= TIMER_IMSK;
00049
00050
00051 }
00052
00053 //--
00054 void KernelTimer::Stop(void)
00055 {
00056 #if KERNEL TIMERS TICKLESS
         TIFR1 &= ~TIMER_IFR;
00057
           TIMSK1 &= ~TIMER_IMSK;
00058
00059
           TCCR1B &= ~(1 << CS12); // Disable count...
          TCNT1 = 0;
OCR1A = 0;
00060
00061
00062 #endif
00063 }
00064
00065 //---
```

20.12 kerneltimer.cpp 209

```
00066 PORT_TIMER_COUNT_TYPE KernelTimer::Read(void)
00067 {
00068 #if KERNEL_TIMERS_TICKLESS
00069
         volatile uint16_t u16Read1;
00070
          volatile uint16_t u16Read2;
00071
         u16Read1 = TCNT1;
u16Read2 = TCNT1;
00073
00074
00075
         } while (u16Read1 != u16Read2);
00076
00077
          return u16Read1;
00078 #else
00079
00080 #endif
00081 }
00082
00083 //---
00084 PORT_TIMER_COUNT_TYPE KernelTimer::SubtractExpiry(
      PORT_TIMER_COUNT_TYPE uInterval)
00085 {
00086 #if KERNEL_TIMERS_TICKLESS
       OCR1A -= uInterval;
00087
          return OCR1A:
00088
00089 #else
       return 0;
00091 #endif
00092 }
00093
00094 //----
00095 PORT_TIMER_COUNT_TYPE KernelTimer::TimeToExpiry(void)
00097 #if KERNEL_TIMERS_TICKLESS
00098
         uint16_t u16Read = KernelTimer::Read();
         uint16_t u160CR1A = OCR1A;
00099
00100
00101
        if (u16Read >= u160CR1A) {
00102
             return 0;
00103
        } else {
00104
            return (u160CR1A - u16Read);
00105
00106 #else
00107
       return 0:
00108 #endif
00109 }
00110
00111 //---
00112 PORT_TIMER_COUNT_TYPE KernelTimer::GetOvertime(void)
00113 {
00114
          return KernelTimer::Read();
00115 }
00116
00117 //---
00118 PORT_TIMER_COUNT_TYPE KernelTimer::SetExpiry(uint32_t
     u32Interval_)
00119 {
00120 #if KERNEL_TIMERS_TICKLESS
       uint16_t u16SetInterval;
00121
00122
         if (u32Interval_ > 65535)
              ul6SetInterval = 65535;
00123
         } else {
00124
             ul6SetInterval = (uint16_t)u32Interval_;
00125
        }
00126
00127
00128
         OCR1A = u16SetInterval;
00129
         return u16SetInterval;
00130 #else
00131
         return 0;
00132 #endif
00133 }
00134
00135 //----
00136 void KernelTimer::ClearExpiry(void)
00137 {
00138 #if KERNEL_TIMERS_TICKLESS
00139 OCR1A = 65535; // Clear the compare value
00140 #endif
00141 }
00142
00143 //----
00144 uint8_t KernelTimer::DI(void)
00146 #if KERNEL_TIMERS_TICKLESS
00147
         bool bEnabled = ((TIMSK1 & (TIMER_IMSK)) != 0);
         TIFR1 &= ~TIMER_IFR; // Clear interrupt flags
TIMSK1 &= ~TIMER_IMSK; // Disable interrupt
00148
00149
00150
         return bEnabled;
```

```
00151 #else
00152
          return 0;
00153 #endif
00154 }
00155
00156 //---
00157 void KernelTimer::EI(void)
00158 {
00159
          KernelTimer::RI(0);
00160 }
00161
00162 //--
00163 void KernelTimer::RI(bool bEnable_)
00164 {
00165 #if KERNEL_TIMERS_TICKLESS
       if (bEnable_) {
    TIMSK1 |= (1 << OCIE1A); // Enable interrupt</pre>
00166
00167
          } else {
00168
              TIMSK1 &= ~(1 << OCIE1A);
00169
00171 #endif
00172 }
```

## 20.13 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h File Reference

Profiling timer hardware interface.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

#### Classes

class Profiler

System profiling timer interface.

#### 20.13.1 Detailed Description

Profiling timer hardware interface.

Definition in file kernelprofile.h.

## 20.14 kernelprofile.h

```
00022 #include "11.h"
00024 #ifndef __KPROFILE_H__
00025 #define __KPROFILE_H_
00026
00027 #if KERNEL_USE_PROFILER
00029 //----
00030 #define TICKS_PER_OVERFLOW (256)
00031 #define CLOCK_DIVIDE (8)
00032
00033 //----
00037 class Profiler
00038 {
00039 public:
00046 static void Init();
00047
00053
        static void Start();
00054
00060
        static void Stop();
00061
       static PORT_TIMER_COUNT_TYPE Read();
00067
00068
00074
        static void Process();
00075
        static uint32_t GetEpoch() { return m_u32Epoch; }
00082 private:
00083 static uint32_t m_u32Epoch;
00084 };
00085
00086 #endif // KERNEL_USE_PROFILER
00087
00088 #endif
```

# 20.15 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h File Reference

Kernel Software interrupt declarations.

```
#include "kerneltypes.h"
```

#### Classes

· class KernelSWI

Class providing the software-interrupt required for context-switching in the kernel.

### 20.15.1 Detailed Description

Kernel Software interrupt declarations.

Definition in file kernelswi.h.

#### 20.16 kernelswi.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #ifndef __KERNELSWI_H_
00024 #define __KERNELSWI_H_
00025
00026 //---
00031 class KernelSWI
00032 {
00033 public:
00040
          static void Config(void);
00041
00047
          static void Start (void);
00048
00054
          static void Stop(void);
00055
00061
          static void Clear (void);
00062
00069
          static void Trigger (void);
00070
00078
          static uint8_t DI();
00079
00087
          static void RI(bool bEnable_);
00088 };
00089
00090 #endif // __KERNELSIW_H_
```

# 20.17 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h File Reference

Kernel Timer Class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

#### Classes

class KernelTimer

Hardware timer interface, used by all scheduling/timer subsystems.

#### 20.17.1 Detailed Description

Kernel Timer Class declaration.

Definition in file kerneltimer.h.

20.18 kerneltimer.h 213

#### 20.18 kerneltimer.h

```
00001 /
00002
00004
00005
00006
00007
00008
00009
       -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00024 #ifndef ___KERNELTIMER_H_
00025 #define ___KERNELTIMER_H_
00026
00027 //-
00031 class KernelTimer
00032 {
00033 public:
00039
          static void Config(void);
00040
00046
          static void Start (void);
00047
00053
          static void Stop(void);
00054
00060
          static uint8_t DI(void);
00061
00069
          static void RI (bool bEnable_);
00070
00076
          static void EI(void);
00077
00088
          static PORT_TIMER_COUNT_TYPE SubtractExpiry(
     PORT_TIMER_COUNT_TYPE uInterval_);
00089
00098
          static PORT_TIMER_COUNT_TYPE TimeToExpiry(void);
00099
00108
          static PORT_TIMER_COUNT_TYPE SetExpiry(uint32_t u32Interval_);
00109
00118
          static PORT_TIMER_COUNT_TYPE GetOvertime(void);
00119
00125
          static void ClearExpiry(void);
00126
00134
          static PORT_TIMER_COUNT_TYPE Read(void);
00135 };
00136
00137 #endif //__KERNELTIMER_H_
```

## 20.19 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/portcfg.h File Reference

Mark3 Port Configuration.

#### **Macros**

• #define AVR (1)

Define a macro indicating the CPU architecture for which this port belongs.

#define K\_WORD uint8\_t

Define types that map to the CPU Architecture's default data-word and address size.

#define K\_ADDR uint16\_t

Size of an address (pointer size)

#define PORT\_PRIO\_TYPE uint8\_t

Set a base datatype used to represent each element of the scheduler's priority bitmap.

• #define PORT\_PRIO\_MAP\_WORD\_SIZE (1)

size of PORT\_PRIO\_TYPE in bytes

• #define PORT\_SYSTEM\_FREQ ((uint32\_t)16000000)

Define the running CPU frequency.

#define PORT\_TIMER\_FREQ ((uint32\_t)(PORT\_SYSTEM\_FREQ / 1000))

Set the timer frequency.

#define PORT\_TIMER\_COUNT\_TYPE uint16\_t

Define the native type corresponding to the kernel timer hardware's counter register.

• #define PORT\_MIN\_TIMER\_TICKS (0)

Minimum number of timer ticks for any delay or sleep, required to ensure that a timer cannot be initialized to a negative value.

#### 20.19.1 Detailed Description

Mark3 Port Configuration.

This file is used to configure the kernel for your specific target CPU in order to provide the optimal set of features for a given use case.

!! NOTE: This file must ONLY be included from mark3cfg.h

Definition in file portcfg.h.

#### 20.19.2 Macro Definition Documentation

20.19.2.1 #define AVR (1)

Define a macro indicating the CPU architecture for which this port belongs.

This may also be set by the toolchain, but that's not guaranteed.

Definition at line 34 of file portcfg.h.

20.19.2.2 #define K\_WORD uint8\_t

Define types that map to the CPU Architecture's default data-word and address size.

Size of a data word

#### **Examples:**

buffalogger/main.cpp, lab10\_notifications/main.cpp, lab11\_mailboxes/main.cpp, lab1\_kernel\_setup/main.cpp, lab2\_idle\_function/main.cpp, lab3\_round\_robin/main.cpp, lab4\_semaphores/main.cpp, lab5\_cuttexes/main.cpp, lab6\_timers/main.cpp, lab7\_events/main.cpp, lab8\_messages/main.cpp, and lab9\_cutering-dynamic\_threads/main.cpp.

Definition at line 41 of file portcfg.h.

20.19.2.3 #define PORT\_PRIO\_TYPE uint8\_t

Set a base datatype used to represent each element of the scheduler's priority bitmap.

PORT\_PRIO\_MAP\_WORD\_SIZE should map to the *size* of an element of type PORT\_PROI\_TYPE.Type used for bitmap in the PriorityMap class

Definition at line 51 of file portcfg.h.

20.19.2.4 #define PORT\_SYSTEM\_FREQ ((uint32\_t)16000000)

Define the running CPU frequency.

This may be an integer constant, or an alias for another variable which holds the CPU's current running frequency.  $\leftarrow$  CPU Frequency in Hz

Definition at line 59 of file portcfg.h.

20.19.2.5 #define PORT\_TIMER\_COUNT\_TYPE uint16\_t

Define the native type corresponding to the kernel timer hardware's counter register.

Timer counter type

Definition at line 78 of file portcfg.h.

20.19.2.6 #define PORT\_TIMER\_FREQ ((uint32\_t)(PORT\_SYSTEM\_FREQ / 1000))

Set the timer frequency.

If running in tickless mode, this is simply the frequency at which the free-running kernel timer increments.

In tick-based mode, this is the frequency at which the fixed-frequency kernel tick interrupt occurs. Fixed timer interrupt frequency

Definition at line 72 of file portcfg.h.

### 20.20 portcfg.h

```
00001 /*========
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00025 #ifndef __PORTCFG_H_
00026 #define __PORTCFG_H_
00027
00033 #ifndef AVR
00034 # define AVR
                                            (1)
00035 #endif
00036
00041 #define K WORD
                                            uint8 t
00042 #define K_ADDR
                                            uint16_t
00043
00044
00051 #define PORT_PRIO_TYPE
00052 #define PORT_PRIO_MAP_WORD_SIZE
                                            uint8_t
00053
00054
00058 #if !defined(PORT_SYSTEM_FREQ)
00059 #define PORT_SYSTEM_FREQ
                                            ((uint32_t)16000000)
00060 #endif
00061
00069 #if KERNEL_TIMERS_TICKLESS
00070 #define PORT_TIMER_FREQ
                                            ((uint32_t)(PORT_SYSTEM_FREQ / 256))
00071 #else
00072 #define PORT_TIMER_FREQ
                                            ((uint32_t)(PORT_SYSTEM_FREQ / 1000))
00073 #endif
00074
00078 #define PORT_TIMER_COUNT_TYPE
                                            uint16 t
00079
00084 #define PORT_MIN_TIMER_TICKS
00085
00086 #endif // ___PORTCFG_H__
```

## 20.21 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/public/threadport.h File Reference

#### ATMega328p Multithreading support.

```
#include "kerneltypes.h"
#include "thread.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

#### **Classes**

· class ThreadPort

Class defining the architecture specific functions required by the kernel.

#### **Macros**

```
    #define ASM(x) asm volatile(x);

          ASM Macro - simplify the use of ASM directive in C.

    #define SR 0x3F

          Status register define - map to 0x003F.
    • #define SPH_ 0x3E
          Stack pointer define.

    #define TOP_OF_STACK(x, y) (uint8_t*)(((uint16_t)x) + (y - 1))

          Macro to find the top of a stack given its size and top address.

    #define PUSH_TO_STACK(x, y)

          Push a value y to the stack pointer x and decrement the stack pointer.

    #define Thread SaveContext()

          Save the context of the Thread.

    #define Thread_RestoreContext()

          Restore the context of the Thread.
    • #define CS ENTER()
          These macros must be used in pairs!

    #define CS_EXIT()

          Exit critical section (restore status register)
    • #define ENABLE INTS() ASM("sei");
          Initiate a contex switch without using the SWI.
Functions
    uint8_t __mark3_clz8 (uint8_t in_)
20.21.1 Detailed Description
ATMega328p Multithreading support.
Definition in file threadport.h.
20.21.2 Macro Definition Documentation
20.21.2.1 #define CS_ENTER( )
Value:
uint8_t \underline{\ \ \ }x = _SFR_IO8(SR_);
ASM("cli");
These macros must be used in pairs!
Enter critical section (copy status register, disable interrupts)
Examples:
```

buffalogger/main.cpp, and lab9 dynamic threads/main.cpp.

Definition at line 245 of file threadport.h.

#### 20.21.3 Function Documentation

```
20.21.3.1 uint8_t __mark3_clz8 ( uint8_t in_ ) [inline]
```

Lookup table based count-leading zeros implementation, used by scheduler by way of PriorityMap

Definition at line 51 of file threadport.h.

### 20.22 threadport.h

```
00002
00003
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #ifndef ___THREADPORT_H_
00022 #define __THREADPORT_H_
00023
00024 #include "kerneltypes.h"
00025 #include "thread.h"
00026
00027 #include <avr/io.h>
00028 #include <avr/interrupt.h>
00029
00032 #define ASM(x) asm volatile(x);
00033 #define SR_ 0x3F
00035 #define SPH_ 0x3E
00037 #define SPL_ 0x3D
00038
00041 #define TOP_OF_STACK(x, y) (uint8_t*)(((uint16_t)x) + (y - 1))
00042 #define PUSH_TO_STACK(x, y)
00044
00046 #define STACK_GROWS_DOWN (1)
00047
00048 //----
00051 inline uint8_t __mark3_clz8(uint8_t in_)
00052 {
00053
          static const uint8_t u8Lookup[] = {4, 3, 2, 2, 1, 1, 1, 1, 0, 0, 0, 0, 0, 0, 0};
00054
          uint8_t hi = __builtin_avr_swap(in_) & 0x0F;
00055
00056
              return u8Lookup[hi];
00057
          return 4 + u8Lookup[in_];
00058
00059 }
00060
00061 //---
00062 #define HW_CLZ (1)
00063 #define CLZ(x) __mark3_clz8(x)
00064
00065 //---
00067 #define Thread_SaveContext()
00068
00069 ASM("push r0");
00070
00071 ASM("in r0, __SREG__");
00072
00073 ASM("cli");
00074
00075 ASM("push r0");
```

20.22 threadport.h

```
00077 ASM("push r1");
00078
00079 ASM("clr r1");
08000
00081 ASM("push r2");
00082
00083 ASM("push r3");
00084
00085 ASM("push r4");
00086
00087 ASM("push r5");
00088
00089 ASM("push r6");
00090
00091 ASM("push r7");
00092
00093 ASM("push r8");
00094
00095 ASM("push r9");
00096
00097 ASM("push r10");
00098
00099 ASM("push r11");
00100
00101 ASM("push r12");
00102
00103 ASM("push r13");
00104
00105 ASM("push r14");
00106
00107 ASM("push r15");
00108
00109 ASM("push r16");
00110
00111 ASM("push r17");
00112
00113 ASM("push r18");
00114
00115 ASM("push r19");
00116 \
00117 ASM("push r20");
00118
00119 ASM("push r21");
00120
00121 ASM("push r22");
00123 ASM("push r23");
00124
00125 ASM("push r24");
00126
00127 ASM("push r25");
00128
00129 ASM("push r26");
00130
00131 ASM("push r27");
00132
00133 ASM("push r28");
```

```
00134
00135 ASM("push r29");
00136
00137 ASM("push r30");
00138
00139 ASM("push r31");
00140
00141 ASM("lds r26, g_pclCurrent");
00143 ASM("lds r27, g_pclCurrent + 1");
00144
00145 ASM("adiw r26, 4");
00146
00147 ASM("in
              r0, 0x3D");
00148
00149 ASM("st
              x+, r0");
00150
00151 ASM("in
              r0, 0x3E");
00152
00153 ASM("st
              x+, r0");
00154
00155 //----
00157 #define Thread_RestoreContext()
00158
00159 ASM("lds r26, g_pclCurrent");
00160
00161 ASM("lds r27, g_pclCurrent + 1");
00162
00163 ASM("adiw r26, 4");
00164
00165 ASM("ld
                 r28, x+");
00166
00167 ASM("out 0x3D, r28");
00168
00169 ASM("ld
              r29, x+");
00170
00171 ASM("out 0x3E, r29");
00172
00173 ASM("pop r31");
00174
00175 ASM("pop r30");
00176
00177 ASM("pop r29");
00178
00179 ASM("pop r28");
00180
00181 ASM("pop r27");
00183 ASM("pop r26");
00184
00185 ASM("pop r25");
00186
00187 ASM("pop r24");
00188
00189 ASM("pop r23");
00190
00191 ASM("pop r22");
00192
00193 ASM("pop r21");
```

20.22 threadport.h 221

```
00194
00195 ASM("pop r20");
00196
00197 ASM("pop r19");
00198
00199 ASM("pop r18");
00200
00201 ASM("pop r17");
00202
00203 ASM("pop r16");
00204
00205 ASM("pop r15");
00206
00207 ASM("pop r14");
00208
00209 ASM("pop r13");
00210
00211 ASM("pop r12");
00212
00213 ASM("pop r11");
00214
00215 ASM("pop r10");
00216
00217 ASM("pop r9");
00218
00219 ASM("pop r8");
00220
00221 ASM("pop r7");
00222
00223 ASM("pop r6");
00224
00225 ASM("pop r5");
00226
00227 ASM("pop r4");
00228
00229 ASM("pop r3");
00230
00231 ASM("pop r2");
00232
00233 ASM("pop r1");
00234
00235 ASM("pop r0");
00236
00237 ASM("out __SREG__, r0");
00238
00239 ASM("pop r0");
00240
00241 //---
00243 //----
00245 #define CS_ENTER()
00246
00247 {
00248
00249 uint8_t __x = _SFR_IO8(SR_);
00250
00251 ASM("cli");
00252 //----
00254 #define CS_EXIT()
00255
00256 _SFR_IO8(SR_)
```

```
00258
00259 }
00260
00261 //----
00263 #define ENABLE_INTS() ASM("sei");
00264 #define DISABLE_INTS() ASM("cli");
00265
00266 //----
00267 class Thread;
00275 class ThreadPort
00276 {
00277 public:
00283
       static void StartThreads();
00284
         friend class Thread;
00285
00286 private:
        static void InitStack(Thread* pstThread_);
00295 };
00296
00297 #endif //__ThreadPORT_H_
```

# 20.23 /home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gcc/threadport.cpp File Reference

## ATMega328p Multithreading.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "threadport.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernel.h"
#include "kernelaware.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

## **Functions**

ISR (TIMER1\_COMPA\_vect)

ISR(TIMER1\_COMPA\_vect) Timer interrupt ISR - causes a tick, which may cause a context switch.

## 20.23.1 Detailed Description

ATMega328p Multithreading.

Definition in file threadport.cpp.

20.24 threadport.cpp 223

# 20.24 threadport.cpp

```
00001 /*=======
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ========
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00025 #Include "thread.h"
00025 #include "threadport.h"
00026 #include "kernelswi.h"
00027 #include "kerneltimer.h"
00028 #include "timerlist.h"
00029 #include "quantum.h"
00030 #include "kernel.h"
00031 #include "kernelaware.h"
00032 #include <avr/io.h>
00033 #include <avr/interrupt.h>
00034
00035 //-
00036 Thread* g_pclCurrentThread;
00037
00038 //--
00039 void ThreadPort::InitStack(Thread* pclThread_)
00040 {
           // Initialize the stack for a Thread
00041
00042
           uint16_t u16Addr;
00043
           uint8_t* pu8Stack;
00044
           uint16_t i;
00045
00046
           // Get the address of the thread's entry function
00047
           u16Addr = (uint16_t) (pclThread_->m_pfEntryPoint);
00048
00049
           // Start by finding the bottom of the stack
00050
           pu8Stack = (uint8_t*)pclThread_->m_pwStackTop;
00051
00052
           // clear the stack, and initialize it to a known-default value (easier
           // clear class stack, and initialize it to a known default value (ea
// to debug when things go sour with stack corruption or overflow)
for (i = 0; i < pclThread_->m_ul6StackSize; i++) {
00053
00054
00055
               pclThread_->m_pwStack[i] = 0xFF;
00056
00057
00058
           // Our context starts with the entry function
           PUSH_TO_STACK(pu8Stack, (uint8_t)(u16Addr & 0x00FF));
PUSH_TO_STACK(pu8Stack, (uint8_t)((u16Addr >> 8) & 0x00FF));
00059
00060
00061
00062
00063
           PUSH_TO_STACK(pu8Stack, 0x00); // R0
00064
00065
           // Push status register and R1 (which is used as a constant zero)
00066
           PUSH_TO_STACK(pu8Stack, 0x80); // SR
00067
           PUSH_TO_STACK(pu8Stack, 0x00); // R1
00068
00069
           // Push other registers
00070
           for (i = 2; i \leq 23; i++) // R2-R23
00071
00072
               PUSH_TO_STACK(pu8Stack, i);
00073
00074
00075
           // Assume that the argument is the only stack variable
00076
           PUSH_TO_STACK(pu8Stack, (uint8_t)(((uint16_t)(pclThread_->
      m_pvArg)) & 0x00FF));
                                       // R24
           PUSH_TO_STACK(pu8Stack, (uint8_t)((((uint16_t)(pclThread_->
00077
      m_pvArg)) >> 8) & 0x00FF)); // R25
00078
           // Push the rest of the registers in the context for (i = 26; i <= 31; i++) (
00079
00080
               PUSH_TO_STACK(pu8Stack, i);
00081
00082
00083
00084
           // Set the top o' the stack.
00085
           pclThread_->m_pwStackTop = (uint8_t*)pu8Stack;
00086
00087
           // That's it! the thread is ready to run now.
00088 }
00089
```

```
00091 static void Thread_Switch(void)
00093 #if KERNEL_USE_IDLE_FUNC
00094
         // If there's no next-thread-to-run...
00095
          if (g pclNext == Kernel::GetIdleThread()) {
00096
              g pclCurrent = Kernel::GetIdleThread();
00098
              // Disable the SWI, and re-enable interrupts -- enter nested interrupt
00099
              // mode.
00100
              KernelSWI::DI();
00101
00102
              uint8 t u8SR = SFR IO8(SR);
00103
00104
              // So long as there's no "next-to-run" thread, keep executing the Idle
00105
              // function to conclusion...
00106
              while (g_pclNext == Kernel::GetIdleThread()) {
00107
00108
                 // Ensure that we run this block in an interrupt enabled context (but
                  // with the rest of the checks being performed in an interrupt disabled
00109
00110
                  // context).
00111
                  ASM("sei");
00112
                  Kernel::IdleFunc();
                 ASM("cli");
00113
00114
             }
00115
             // Progress has been achieved -- an interrupt-triggered event has caused
00116
              // the scheduler to run, and choose a new thread. Since we've already // saved the context of the thread we've hijacked to run idle, we can
00117
00118
00119
              \ensuremath{//} proceed to disable the nested interrupt context and switch to the
              // new thread.
00120
00121
00122
              _SFR_IO8(SR_) = u8SR;
00123
              KernelSWI::RI(true);
00124
00125 #endif
         g_pclCurrent = (Thread*)g_pclNext;
00126
00127 }
00129 //-
00130 void ThreadPort::StartThreads()
00131 {
         KernelSWI::Config(); // configure the task switch SWI
KernelTimer::Config(); // configure the kernel timer
00132
00133
00134
00135
          Scheduler::SetScheduler(1); // enable the scheduler
00136
          Scheduler::Schedule();
                                      // run the scheduler - determine the first thread to run
00137
00138
          Thread_Switch(); // Set the next scheduled thread to the current thread
00139
          KernelTimer::Start(); // enable the kernel timer
00140
00141
          KernelSWI::Start(); // enable the task switch SWI
00142
00143 #if KERNEL_USE_QUANTUM
       // Restart the thread quantum timer, as any value held prior to starting
// the kernel will be invalid. This fixes a bug where multiple threads
00144
00145
         // started with the highest priority before starting the kernel causes problems // until the running thread voluntarily blocks.
00146
00148
          Quantum::RemoveThread();
00149
         Quantum::AddThread(g_pclCurrent);
00150 #endif
00151
00152
          // Restore the context...
          Thread_RestoreContext(); // restore the context of the first running thread
00153
00154
                                  // return from interrupt - will return to the first scheduled thread
00155 }
00156
00157 //--
00162 //----
00163 ISR(INTO_vect) __attribute__((signal, naked));
00164 ISR(INTO_vect)
00165 {
         00166
00167
         Thread_Switch();
00168
00169
00170 }
00171
00172 //-----
00177 //-----
00178 ISR(TIMER1_COMPA_vect)
00179 {
00180 #if KERNEL_USE_TIMERS
00181
       TimerScheduler::Process();
00182 #endif
00183 #if KERNEL_USE_QUANTUM
00184
       Quantum::UpdateTimer();
00185 #endif
```

00186 }

# 20.25 /home/moslevin/projects/mark3-source/kernel/driver.cpp File Reference

Device driver/hardware abstraction layer.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "driver.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### Classes

class DevNull

This class implements the "default" driver (/dev/null)

## **Functions**

static uint8\_t DrvCmp (const char \*szStr1\_, const char \*szStr2\_)
 DrvCmp.

## **Variables**

• static DevNull clDevNull

Default driver included to allow for run-time "stubbing".

## 20.25.1 Detailed Description

Device driver/hardware abstraction layer.

Definition in file driver.cpp.

#### 20.25.2 Function Documentation

```
20.25.2.1 static uint8_t DrvCmp ( const char * szStr1_, const char * szStr2_ ) [static]
```

#### DrvCmp.

String comparison function used to compare input driver name against a known driver name in the existing driver list

#### **Parameters**

SZ←	user-specified driver name
Str1_	
SZ⊷	name of a driver, provided from the driver table
Str2_	

#### Returns

1 on match, 0 on no-match

Definition at line 75 of file driver.cpp.

# 20.26 driver.cpp

```
00001 /
00002
00003
00004
00005 I
00006 |
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "driver.h"
00024
00025 #define CAN HAS DEBUG
00026 //--[Autogenerated - Do Not Modify]-----
00027 #include "dbg_file_list.h"
00028 #include "buffalogger.h"
00029 #if defined(DBG_FILE)
00030 #error "Debug logging file token already defined! Bailing."
00031 #else
00032 #define DBG_FILE _DBG___KERNEL_DRIVER_CPP
00033 #endif
00034 //--[End Autogenerated content]-----
00035
00036 #include "kerneldebug.h"
00037
00038 //
00039 #if KERNEL_USE_DRIVER
00040
00041 DoubleLinkList DriverList::m_clDriverList;
00042
00046 class DevNull : public Driver
00047 {
00048 public:
00049
          virtual void
                              Init() { SetName("/dev/null"); };
          virtual uint8_t Open() { return 0; }
virtual uint8_t Close() { return 0; }
00050
00051
          virtual uint16_t Read(uint16_t u16Bytes_, uint8_t* pu8Data_) { return 0; }
virtual uint16_t Write(uint16_t u16Bytes_, uint8_t* pu8Data_) { return 0; }
00052
00053
00054
          virtual uint16 t
           Control (uint16_t u16Event_, void* pvDataIn_, uint16_t u16SizeIn_, void* pvDataOut_, uint16_t
00055
      u16SizeOut_)
00056
         {
00057
               return 0:
00058
           }
00059 };
00060
00061 //----
00062 static DevNull clDevNull;
00063
00064 //-
00075 static uint8_t DrvCmp(const char* szStr1_, const char* szStr2_)
00076 {
           char* szTmp1 = (char*)szStr1_;
```

```
00078
         char* szTmp2 = (char*)szStr2_;
00079
08000
         while (*szTmp1 && *szTmp2) {
          if (*szTmp1++ != *szTmp2++) {
00081
00082
                 return 0;
00083
00084
00085
00086
         // Both terminate at the same length
00087
         if (!(*szTmp1) && !(*szTmp2)) {
            return 1;
00088
00089
00090
00091
00092 }
00093
00094 //---
00095 void DriverList::Init()
          // Ensure we always have at least one entry - a default in case no match
00098
         // is found (/dev/null)
00099
         clDevNull.Init();
00100
        Add(&clDevNull);
00101 }
00102
00103 //--
00104 Driver* DriverList::FindByPath(const char* m_pcPath)
00105 {
00106
         KERNEL_ASSERT (m_pcPath);
         Driver* pclTemp = static_cast<Driver*>(m_clDriverList.GetHead());
00107
00108
00109
         // Iterate through the list of drivers until we find a match, or we
00110 // exhaust our list of installed drivers
00111 while (pclTemp) {
          if (DrvCmp(m_pcPath, pclTemp->GetPath())) {
00112
00113
                  return pclTemp;
          }
pclTemp = static_cast<Driver*>(pclTemp->GetNext());
00114
00115
00116
00117
         // No matching driver found - return a pointer to our /dev/null driver
00118
         return &clDevNull;
00119 }
00120
00121 #endif
```

# 20.27 /home/moslevin/projects/mark3-source/kernel/eventflag.cpp File Reference

Event Flag Blocking Object/IPC-Object implementation.

```
#include "mark3cfg.h"
#include "blocking.h"
#include "kernel.h"
#include "thread.h"
#include "eventflag.h"
#include "kernelaware.h"
#include "kerneldebug.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "timerlist.h"
```

## **Functions**

void TimedEventFlag Callback (Thread \*pclOwner , void \*pvData )

TimedEventFlag\_Callback.

# 20.27.1 Detailed Description

Event Flag Blocking Object/IPC-Object implementation.

Definition in file eventflag.cpp.

#### 20.27.2 Function Documentation

```
20.27.2.1 void TimedEventFlag_Callback ( Thread * pclOwner_, void * pvData_ )
```

TimedEventFlag\_Callback.

This function is called whenever a timed event flag wait operation fails in the time provided. This function wakes the thread for which the timeout was requested on the blocking call, sets the thread's expiry flags, and reschedules if necessary.

#### **Parameters**

pcl←	Thread to wake
Owner_	
pvData_	Pointer to the event-flag object

Definition at line 54 of file eventflag.cpp.

# 20.28 eventflag.cpp

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013
00019 #include "mark3cfg.h"
00020 #include "blocking.h"
00021 #include "kernel.h"
00022 #include "thread.h"
00022 #Include "eventflag.h"
00024 #include "kernelaware.h"
00025 #include "kerneldebug.h"
00026
00027 #define CAN HAS DEBUG
00028 //--[Autogenerated - Do Not Modify]-----
00029 #include "dbg_file_list.h
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 \#error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_EVENTFLAG_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037
00038 #if KERNEL_USE_EVENTFLAG
00039
00040 #if KERNEL_USE_TIMEOUTS
00041 #include "timerlist.h"
00042 //-
```

20.28 eventflag.cpp 229

```
00054 void TimedEventFlag_Callback(Thread* pclOwner_, void* pvData_)
00055 {
00056
          EventFlag* pclEventFlag = static_cast<EventFlag*>(pvData_);
00057
00058
          pclEventFlag->WakeMe(pclOwner_);
00059
          pclOwner_->SetExpired(true);
          pclOwner_->SetEventFlagMask(0);
00060
00061
00062
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      ()->GetCurPriority()) {
00063
              Thread::Yield():
00064
00065 }
00066 //----
00067 EventFlag::~EventFlag()
00068 {
          // If there are any threads waiting on this object when it goes out
// of scope, set a kernel panic.
if (m_clBlockList.HighestWaiter()) {
00069
00070
00072
              Kernel::Panic(PANIC_ACTIVE_EVENTFLAG_DESCOPED);
00073
00074 }
00075
00076 //--
00077 void EventFlag::Init()
00078 {
00079 #if KERNEL_EXTRA_CHECKS
00080
         KERNEL_ASSERT(!m_clBlockList.GetHead());
00081 #endif
         m_u16SetMask = 0;
00082
00083 #if KERNEL_EXTRA_CHECKS
00084
         SetInitialized();
00085 #endif
00086 }
00087
00088 //--
00089 void EventFlag::WakeMe(Thread* pclChosenOne_)
00090 {
00091 #if KERNEL_EXTRA_CHECKS
00092
         KERNEL_ASSERT(IsInitialized());
00093 #endif
00094
00095
          UnBlock(pclChosenOne );
00096 }
00097 #endif
00098
00099 //--
00100 #if KERNEL USE TIMEOUTS
00101 uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
      EventFlagOperation_t eMode_, uint32_t u32TimeMS_)
00103 uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
      EventFlagOperation_t eMode_)
00104 #endif
00105 {
00106 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(IsInitialized());
00108 #endif
00109
00110
          bool bThreadYield = false;
00111
          bool bMatch
                             = false:
00112
00113 #if KERNEL_USE_TIMEOUTS
      Timer clEventTimer;
00114
00115
         bool bUseTimer = false;
00116 #endif
00117
00118
          // Ensure we're operating in a critical section while we determine
00119
          // whether or not we need to block the current thread on this object.
          CS_ENTER();
00120
00121
00122
          // Check to see whether or not the current mask matches any of the
          // desired bits.
00123
          g_pclCurrent->SetEventFlagMask(u16Mask_);
00124
00125
          if ((eMode_ == EVENT_FLAG_ALL) || (eMode_ ==
     EVENT_FLAG_ALL_CLEAR)) {
00127
              // Check to see if the flags in their current state match all of
00128
               \ensuremath{//} the set flags in the event flag group, with this mask.
              if ((m_u16SetMask & u16Mask_) == u16Mask_) {
00129
00130
                  bMatch = true;
00131
                  g_pclCurrent->SetEventFlagMask(u16Mask_);
00132
00133
          } else if ((eMode_ == EVENT_FLAG_ANY) || (eMode_ ==
     EVENT_FLAG_ANY_CLEAR)) {
              // Check to see if the existing flags match any of the set flags in // the event flag group with this mask
00134
00135
```

```
00136
            if (m_u16SetMask & u16Mask_) {
                 bMatch = true;
00137
00138
                 g_pclCurrent->SetEventFlagMask(
     m_u16SetMask & u16Mask_);
00139
            }
00140
         }
00141
00142
         // We're unable to match this pattern as-is, so we must block.
         if (!bMatch) {
00143
00144
              // Reset the current thread's event flag mask & mode
00145
             q_pclCurrent->SetEventFlagMask(u16Mask_);
             g_pclCurrent->SetEventFlagMode(eMode_);
00146
00147
00148 #if KERNEL_USE_TIMEOUTS
00149
             if (u32TimeMS_) {
00150
                 g_pclCurrent->SetExpired(false);
00151
                 clEventTimer.Init();
                 clEventTimer.Start(0, u32TimeMS_, TimedEventFlag_Callback, (void*)
00152
     this);
00153
                 bUseTimer = true;
00154
00155 #endif
00156
              // Add the thread to the object's block-list.
00157
00158
             BlockPriority(g_pclCurrent);
00159
00160
              // Trigger that
00161
             bThreadYield = true;
00162
        }
00163
00164
         // If bThreadYield is set, it means that we've blocked the current thread,
00165
         // and must therefore rerun the scheduler to determine what thread to
00166
         // switch to.
00167
         if (bThreadYield) {
00168
             // Switch threads immediately
             Thread::Yield();
00169
00170
         }
00171
00172
          // Exit the critical section and return back to normal execution
00173
         CS_EXIT();
00174
00179 #if KERNEL USE TIMEOUTS
       if (bUseTimer && bThreadYield) {
00180
00181
             clEventTimer.Stop();
00182
00183 #endif
00184
00185
         return g_pclCurrent->GetEventFlagMask();
00186 }
00187
00188 //----
00189 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_)
00190 {
00191 #if KERNEL_USE_TIMEOUTS
00192
         return Wait_i(u16Mask_, eMode_, 0);
00193 #else
       return Wait_i(u16Mask_, eMode_);
00195 #endif
00196 }
00197
00198 #if KERNEL_USE_TIMEOUTS
00199 //--
00200 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_,
      uint32_t u32TimeMS_)
00201 {
00202
          return Wait_i(u16Mask_, eMode_, u32TimeMS_);
00203 }
00204 #endif
00205
00207 void EventFlag::Set(uint16_t u16Mask_)
00208 {
00209 #if KERNEL_EXTRA_CHECKS
00210
         KERNEL_ASSERT(IsInitialized());
00211 #endif
00212
00213
          Thread* pclPrev;
         Thread* pclCurrent;
bool bReschedule = false;
00214
00215
00216
         uint16_t u16NewMask;
00217
00218
         CS_ENTER();
00219
00220
          // Walk through the whole block list, checking to see whether or not
00221
          // the current flag set now matches any/all of the masks and modes of
          // the threads involved.
00222
00223
```

20.28 eventflag.cpp 231

```
m_u16SetMask |= u16Mask_;
          u16NewMask = m_u16SetMask;
00225
00226
          // Start at the head of the list, and iterate through until we hit the // "head" element in the list again. Ensure that we handle the case where
00227
00228
00229
          // we remove the first or last elements in the list, or if there's only
           // one element in the list.
00231
          pclCurrent = static_cast<Thread*>(m_clBlockList.GetHead());
00232
00233
          \ensuremath{//} Do nothing when there are no objects blocking.
00234
          if (pclCurrent) {
00235
               // First loop - process every thread in the block-list and check to
00236
               // see whether or not the current flags match the event-flag conditions
00237
               // on the thread.
00238
               do {
                   pclPrev
00239
                              = pclCurrent;
                   pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00240
00241
                   // Read the thread's event mask/mode
00243
                                         u16ThreadMask = pclPrev->GetEventFlagMask();
                   EventFlagOperation_t eThreadMode = pclPrev->
      GetEventFlagMode();
00245
                   // For the "any" mode - unblock the blocked threads if one or more bits
00246
00247
                   // in the thread's bitmask match the object's bitmask
                    f ((EVENT_FLAG_ANY == eThreadMode) || (
00248
      EVENT_FLAG_ANY_CLEAR == eThreadMode)) {
00249
                      if (u16ThreadMask & m_u16SetMask) {
00250
                            pclPrev->SetEventFlagMode(
      EVENT_FLAG_PENDING_UNBLOCK);
                            pclPrev->SetEventFlagMask(m_u16SetMask & u16ThreadMask);
00251
00252
                            bReschedule = true;
00253
00254
                            // If the "clear" variant is set, then clear the bits in the mask
00255
                            \ensuremath{//} that caused the thread to unblock.
00256
                            if (EVENT_FLAG_ANY_CLEAR == eThreadMode) {
00257
                                u16NewMask &= ~(u16ThreadMask & u16Mask);
00259
00260
                   // For the "all" mode, every set bit in the thread's requested bitmask must // match the object's flag mask.
00261
00262
                   else if ((EVENT_FLAG_ALL == eThreadMode) || (
00263
      EVENT_FLAG_ALL_CLEAR == eThreadMode)) {
00264
                      if ((u16ThreadMask & m_u16SetMask) == u16ThreadMask) {
00265
                            pclPrev->SetEventFlagMode(
      EVENT_FLAG_PENDING_UNBLOCK);
00266
                            pclPrev->SetEventFlagMask(u16ThreadMask);
00267
                            bReschedule = true;
00268
                            // If the "clear" variant is set, then clear the bits in the mask
00270
                            // that caused the thread to unblock.
00271
                            if (EVENT_FLAG_ALL_CLEAR == eThreadMode) {
00272
                                u16NewMask &= ~(u16ThreadMask & u16Mask_);
00273
00274
                       }
                  }
00276
00277
               // To keep looping, ensure that there's something in the list, and
               // that the next item isn't the head of the list.
while (pclPrev != m_clBlockList.GetTail());
00278
00279
00280
00281
               // Second loop - go through and unblock all of the threads that
               // were tagged for unblocking.
00282
               pclCurrent
00283
                            = static_cast<Thread*>(m_clBlockList.
     GetHead());
00284
              bool bIsTail = false;
00285
               do {
                   pclPrev
00286
                             = pclCurrent;
                  pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00288
00289
                   \ensuremath{//} Check to see if this is the condition to terminate the loop
00290
                   if (pclPrev == m_clBlockList.GetTail()) {
                       bIsTail = true;
00291
00292
00293
00294
                   // If the first pass indicated that this thread should be
                   // unblocked, then unblock the thread
if (pclPrev->GetEventFlagMode() ==
00295
00296
     EVENT_FLAG_PENDING_UNBLOCK) {
00297
                       UnBlock (pclPrev);
00298
00299
               } while (!bIsTail);
00300
          }
00301
          \ensuremath{//} If we awoke any threads, re-run the scheduler
00302
00303
          if (bReschedule) {
```

```
Thread::Yield();
00305
00306
         // Update the bitmask based on any "clear" operations performed along
00307
00308
00309
         m u16SetMask = u16NewMask;
00310
00311
         // Restore interrupts - will potentially cause a context switch if a
00312
          // thread is unblocked.
00313
          CS EXIT();
00314 }
00315
00316 //--
00317 void EventFlag::Clear(uint16_t u16Mask_)
00318 {
00319 #if KERNEL_EXTRA_CHECKS
00320
         KERNEL_ASSERT(IsInitialized());
00321 #endif
          // Just clear the bitfields in the local object.
00324
         CS_ENTER();
00325
         m_u16SetMask &= ~u16Mask_;
00326
         CS_EXIT();
00327 }
00328
00330 uint16_t EventFlag::GetMask()
00331 {
00332 #if KERNEL_EXTRA_CHECKS
00333
         KERNEL_ASSERT(IsInitialized());
00334 #endif
00335
00336
          \ensuremath{//} Return the presently held event flag values in this object. Ensure
00337
         // we get this within a critical section to guarantee atomicity.
00338
         uint16_t u16Return;
00339
         CS_ENTER();
00340
         u16Return = m_u16SetMask;
00341
         CS_EXIT();
00342
          return u16Return;
00343 }
00344
00345 #endif // KERNEL USE EVENTFLAG
```

# 20.29 /home/moslevin/projects/mark3-source/kernel/kernel.cpp File Reference

Kernel initialization and startup code.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernel.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "timerlist.h"
#include "message.h"
#include "driver.h"
#include "profile.h"
#include "kernelprofile.h"
#include "autoalloc.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "tracebuffer.h"
```

## 20.29.1 Detailed Description

Kernel initialization and startup code.

Definition in file kernel.cpp.

20.30 kernel.cpp 233

# 20.30 kernel.cpp

```
00001 /*========
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 #include "kernel.h"
00025 #include "scheduler.h'
00026 #include "thread.h"
00027 #include "threadport.h"
00028 #include "timerlist.h"
00029 #include "message.h"
00030 #include "driver.h"
00031 #include "profile.h"
00032 #include "kernelprofile.h"
00033 #include "autoalloc.h'
00034
00035 #define _CAN_HAS_DEBUG
00036 //--[Autogenerated - Do Not Modify]-----
00037 #include "dbg_file_list.h"
00038 #include "buffalogger.h"
00039 #if defined(DBG FILE)
00040 #error "Debug logging file token already defined! Bailing."
00041 #else
00042 #define DBG_FILE _DBG___KERNEL_KERNEL_CPP
00043 #endif
00044 //--[End Autogenerated content]------
00045 #include "kerneldebug.h"
00046 #include "tracebuffer.h"
00047
00048 bool
                     Kernel::m_bIsStarted;
00049 bool
                     Kernel::m_bIsPanic;
00050 PanicFunc_t Kernel::m_pfPanic;
00051
00052 #if KERNEL_USE_STACK_GUARD
00053 uint16_t Kernel::m_u16GuardThreshold;
00054 #endif
00055
00056 #if KERNEL_USE_IDLE_FUNC
00057 IdleFunc_t Kernel::m_pfIdle;
00058 FakeThread_t Kernel::m_clIdle;
00059 #endif
00060
00061 #if KERNEL_USE_THREAD_CALLOUTS
00062 ThreadCreateCallout_t Kernel::m_pfThreadCreateCallout;
00063 ThreadExitCallout_t Kernel::m_pfThreadExitCallout;
00064 ThreadContextCallout_t Kernel::m_pfThreadContextCallout;
00065 #endif
00066 //---
00067 void Kernel::Init(void)
00068 {
00069 #if KERNEL_USE_AUTO_ALLOC
00070
          AutoAlloc::Init();
00071 #endif
00072 #if KERNEL_USE_IDLE_FUNC
00073
           ((Thread*)&m_clIdle)->InitIdle();
00074 #endif
00075 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00076
           TraceBuffer::Init();
00077 #endif
00078
          KERNEL_TRACE("Initializing Mark3 Kernel");
00079
08000
           \ensuremath{//} Initialize the global kernel data - scheduler, timer-scheduler, and
           \ensuremath{//} the global message pool.
00081
           Scheduler::Init();
00082
00083 #if KERNEL_USE_DRIVER
00084
          DriverList::Init();
00085 #endif
00086 #if KERNEL_USE_TIMERS
00087
           TimerScheduler::Init();
00088 #endif
00089 #if KERNEL_USE_MESSAGE
00090
          GlobalMessagePool::Init();
00091 #endif
```

```
00092 #if KERNEL_USE_PROFILER
          Profiler::Init();
00094 #endif
00095 #if KERNEL_USE_STACK_GUARD
00096
          m_u16GuardThreshold = KERNEL_STACK_GUARD_DEFAULT;
00097 #endif
00098 }
00099
00100 //--
00101 void Kernel::Start(void)
00102 {
          KERNEL_TRACE("Starting Mark3 Scheduler");
00103
00104
          m bIsStarted = true;
00105
          ThreadPort::StartThreads();
00106
          KERNEL_TRACE("Error starting Mark3 Scheduler");
00107 }
00108
00109 //--
00110 void Kernel::Panic(uint16_t u16Cause_)
00111 {
00112
          m_bIsPanic = true;
00113     if (m_pfPanic) {
00114          m_pfPanic(u16Cause_);
00115     } else {
00116 #if KERNEL_AWARE_SIMULATION
00117 KernelAware::Print("Panic\n");
00118 KernelAware::Trace(0, 0, u16Cause_, g_pclCurrent->
00119 KernelAware::ExitSimulator();
00120 #endif
00121
              while (1)
00122
                ;
00123
        }
00124 }
```

# 20.31 /home/moslevin/projects/mark3-source/kernel/kernelaware.cpp File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernelaware.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

#### **Classes**

union KernelAwareData\_t

This structure is used to communicate between the kernel and a kernel- aware host.

#### **Variables**

• volatile bool g\_blsKernelAware

Will be set to true by a kernel-aware host.

volatile uint8\_t g\_u8KACommand

Kernel-aware simulator command to execute.

KernelAwareData\_t g\_stKAData

Data structure used to communicate with host.

20.32 kernelaware.cpp 235

## 20.31.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.cpp.

#### 20.31.2 Variable Documentation

20.31.2.1 volatile bool g\_blsKernelAware

Will be set to true by a kernel-aware host.

Definition at line 77 of file kernelaware.cpp.

#### 20.31.2.2 KernelAwareData\_t g\_stKAData

Data structure used to communicate with host.

Definition at line 79 of file kernelaware.cpp.

# 20.32 kernelaware.cpp

```
00001
00002
00003
00004 |
00005 1
00006
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "kernelaware.h"
00024 #include "threadport.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG FILE)
00031 #error "Debug logging file token already defined! Bailing."
00033 #define DBG_FILE _DBG___KERNEL_KERNELAWARE_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL_AWARE_SIMULATION
00038
00039 //---
00048 typedef union {
00049
          volatile uint16_t au16Buffer[5];
00050
00054
          struct {
               volatile const char* szName;
          } Profiler;
00056
00061
          struct {
           volatile uint16_t u16File;
00062
00063
              volatile uint16_t u16Line;
volatile uint16_t u16Arg1;
00064
00065
               volatile uint16_t u16Arg2;
00066
          } Trace;
```

```
00071
        struct {
00072
             volatile const char* szString;
         } Print;
00073
00074 } KernelAwareData_t;
00075
00076 //---
00077 volatile bool g_bIsKernelAware; 00078 volatile uint8_t g_u8KACommand;
00079 KernelAwareData_t g_stKAData;
08000
00081 //----
00082 void KernelAware::ProfileInit(const char* szStr_)
00083 {
00084
         CS_ENTER();
00085
         g_stKAData.Profiler.szName = szStr_;
          g_u8KACommand
00086
                                    = KA_COMMAND_PROFILE_INIT;
00087
         CS_EXIT();
00088 }
00089
00090 //-
00091 void KernelAware::ProfileStart(void)
00092 {
00093
         g_u8KACommand = KA_COMMAND_PROFILE_START;
00094 }
00095
00097 void KernelAware::ProfileStop(void)
00098 {
00099
          g_u8KACommand = KA_COMMAND_PROFILE_STOP;
00100 }
00101
00102 //-
00103 void KernelAware::ProfileReport(void)
00104 {
00105
          g_u8KACommand = KA_COMMAND_PROFILE_REPORT;
00106 }
00107
00109 void KernelAware::ExitSimulator(void)
00110 {
00111
          g_u8KACommand = KA_COMMAND_EXIT_SIMULATOR;
00112 }
00113
00114 //---
00115 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_)
00116 {
00117
         Trace_i(u16File_, u16Line_, 0, 0, KA_COMMAND_TRACE_0);
00118 }
00119
00120 //-
00121 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)
00122 {
00123
          Trace_i(u16File_, u16Line_, u16Argl_, 0, KA_COMMAND_TRACE_1);
00124 }
00125 //---
00126 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t
      u16Arg2_)
00127 {
00128
          Trace_i(u16File_, u16Line_, u16Arg1_, u16Arg2_, KA_COMMAND_TRACE_2);
00129 }
00130
00131 //-
00132 void KernelAware::Trace_i(
         uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_,
     KernelAwareCommand_t eCmd_)
00134 {
         CS_ENTER();
00135
         g_stKAData.Trace.u16File = u16File_;
00136
00137
         g_stKAData.Trace.ul6Line = ul6Line_;
         g_stKAData.Trace.ul6Arg1 = ul6Arg1_;
00138
00139
         g_stKAData.Trace.u16Arg2 = u16Arg2_;
00140
          g_u8KACommand
                                   = eCmd ;
00141
         CS_EXIT();
00142 }
00143
00145 void KernelAware::Print(const char* szStr_)
00146 {
         CS_ENTER();
00147
         g_stKAData.Print.szString = szStr_;
00148
                                   = KA_COMMAND_PRINT;
00149
          g u8KACommand
00150
         CS_EXIT();
00151 }
00152
00153 //---
00154 bool KernelAware::IsSimulatorAware(void)
00155 {
```

```
00156     return g_bIsKernelAware;
00157 }
00158
00159 #endif
```

# 20.33 /home/moslevin/projects/mark3-source/kernel/ksemaphore.cpp File Reference

Semaphore Blocking-Object Implemenation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ksemaphore.h"
#include "blocking.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "timerlist.h"
```

#### **Functions**

void TimedSemaphore\_Callback (Thread \*pclOwner\_, void \*pvData\_)
 TimedSemaphore\_Callback.

## 20.33.1 Detailed Description

Semaphore Blocking-Object Implemenation.

Definition in file ksemaphore.cpp.

#### 20.33.2 Function Documentation

```
20.33.2.1 void TimedSemaphore_Callback ( Thread * pclOwner_, void * pvData_ )
```

TimedSemaphore\_Callback.

This function is called from the timer-expired context to trigger a timeout on this semphore. This results in the waking of the thread that generated the semaphore pend call that was not completed in time.

## **Parameters**

pcl⊷ Owner_	Pointer to the thread to wake
pvData_	Pointer to the semaphore object that the thread is blocked on

Definition at line 56 of file ksemaphore.cpp.

# 20.34 ksemaphore.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "ksemaphore.h"
00026 #include "blocking.h"
00027
00028 #define _CAN_HAS_DEBUG
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG_FILE)
00033 #error "Debug logging file token already defined! Bailing."
00034 #else
00035 #define DBG_FILE _DBG___KERNEL_KSEMAPHORE_CPP
00036 #endif
00037 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL_USE_SEMAPHORE
00041
00042 #if KERNEL_USE_TIMEOUTS
00043 #include "timerlist.h"
00044
00045 //-
00056 void TimedSemaphore_Callback(Thread* pclOwner_, void* pvData_)
00057 {
00058
          Semaphore* pclSemaphore = static_cast<Semaphore*>(pvData_);
00059
00060
          // Indicate that the semaphore has expired on the thread
00061
          pclOwner_->SetExpired(true);
00062
00063
          // Wake up the thread that was blocked on this semaphore.
00064
          pclSemaphore->WakeMe (pclOwner_);
00065
00066
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      ()->GetCurPriority()) {
00067
              Thread::Yield();
00068
00069 }
00070
00071 //-----
00072 Semaphore::~Semaphore()
00073 {
00074
          \ensuremath{//} If there are any threads waiting on this object when it goes out
00075
          // of scope, set a kernel panic.
00076
          if (m_clBlockList.GetHead()) {
00077
              Kernel::Panic(PANIC_ACTIVE_SEMAPHORE_DESCOPED);
00078
00079 }
00080
00081 //
00082 void Semaphore::WakeMe(Thread* pclChosenOne_)
00083 4
00084 #if KERNEL EXTRA CHECKS
00085
         KERNEL_ASSERT(IsInitialized());
00086 #endif
00087
00088
          // Remove from the semaphore waitlist and back to its ready list.
00089
          UnBlock (pclChosenOne_);
00090 }
00091
00092 #endif // KERNEL USE TIMEOUTS
00093
00094 //--
00095 uint8_t Semaphore::WakeNext()
00096 {
00097
          Thread* pclChosenOne;
00098
00099
          pclChosenOne = m clBlockList.HighestWaiter();
00100
00101
          // Remove from the semaphore waitlist and back to its ready list.
```

```
00102
          UnBlock (pclChosenOne);
00103
00104
          // Call a task switch if higher or equal priority thread
00105
          if (pclChosenOne->GetCurPriority() >=
     Scheduler::GetCurrentThread()->GetCurPriority()) {
            return 1;
00106
00107
00108
          return 0;
00109 }
00110
00111 //----
00112 void Semaphore::Init(uint16_t u16InitVal_, uint16_t u16MaxVal_)
00113 {
00114 #if KERNEL_EXTRA_CHECKS
00115
         KERNEL_ASSERT(!m_clBlockList.GetHead());
00116 #endif
00117
00118
           // Copy the paramters into the object - set the maximum value for this
          // semaphore to implement either binary or counting semaphores, and set
          // the initial count. Clear the wait list for this object.
00120
00121
          m_u16Value = u16InitVal_;
          m_u16MaxValue = u16MaxVal_;
00122
00123
00124 #if KERNEL_EXTRA_CHECKS
00125
         SetInitialized();
00126 #endif
00127
00128 }
00129
00130 //-----
00131 bool Semaphore::Post()
00132 {
00133 #if KERNEL_EXTRA_CHECKS
00134
        KERNEL_ASSERT(IsInitialized());
00135 #endif
00136
          KERNEL_TRACE_1("Posting semaphore, Thread %d", (uint16_t)
00137
     g_pclCurrent->GetID());
00138
00139
          bool bThreadWake = 0;
                            = false;
00140
          bool bBail
          \ensuremath{//} Increment the semaphore count - we can mess with threads so ensure this
00141
          // increment the semaphore count — we can mess with threads so ensure this // is in a critical section. We don't just disable the scheudler since // we want to be able to do this from within an interrupt context as well.
00142
00143
00144
          CS_ENTER();
00145
00146
          // If nothing is waiting for the semaphore
00147
          if (m_clBlockList.GetHead() == NULL) {
               // Check so see if we've reached the maximum value in the semaphore
00148
               if (m_u16Value < m_u16MaxValue) {</pre>
00149
                   // Increment the count value
00150
00151
                   m_u16Value++;
              } else {
    // Maximum value has been reached, bail out.
00152
00153
00154
                   bBail = true;
00155
00156
          } else {
00157
              // Otherwise, there are threads waiting for the semaphore to be
00158
               // posted, so wake the next one (highest priority goes first).
00159
              bThreadWake = WakeNext();
00160
          }
00161
00162
          CS_EXIT();
00163
00164
          // If we weren't able to increment the semaphore count, fail out.
00165
          if (bBail) {
00166
               return false;
00167
00168
00169
          \ensuremath{//} if bThreadWake was set, it means that a higher-priority thread was
00170
          // woken. Trigger a context switch to ensure that this thread gets
00171
          // to execute next.
00172
          if (bThreadWake) {
00173
              Thread::Yield();
00174
00175
          return true;
00176 }
00177
00178 //---
00179 #if KERNEL USE TIMEOUTS
00180 bool Semaphore::Pend_i(uint32_t u32WaitTimeMS_)
00181 #else
00182 void Semaphore::Pend_i(void)
00183 #endif
00184 (
00185 #if KERNEL_EXTRA_CHECKS
00186
          KERNEL_ASSERT(IsInitialized());
```

```
00187 #endif
00188
         KERNEL_TRACE_1("Pending semaphore, Thread %d", (uint16_t)
00189
     g_pclCurrent->GetID());
00190
00191 #if KERNEL_USE_TIMEOUTS
          Timer clSemTimer;
00192
00193
         bool bUseTimer = false;
00194 #endif
00195
         \ensuremath{//} Once again, messing with thread data - ensure
00196
         // we're doing all of these operations from within a thread-safe context.
00197
00198
         CS_ENTER();
00199
00200
          // Check to see if we need to take any action based on the semaphore count
00201
         if (m_u16Value != 0) {
              // The semaphore count is non-zero, we can just decrement the count
00202
00203
              // and go along our merry way.
              m_u16Value--;
00205
          } else {
00206 // The semaphore count is zero - we need to block the current thread
00207 // and wait until the semaphore is posted from elsewhere.
00208 #if KERNEL_USE_TIMEOUTS
00209
             if (u32WaitTimeMS ) {
00210
                 q_pclCurrent->SetExpired(false);
00211
                 clSemTimer.Init();
00212
                 clSemTimer.Start(0, u32WaitTimeMS_, TimedSemaphore_Callback, (void*)this
00213
                 bUseTimer = true;
00214
             }
00215 #endif
00216
             BlockPriority(g_pclCurrent);
00217
00218
             // Switch Threads immediately
00219
             Thread::Yield();
        }
00220
00221
        CS_EXIT();
00223
00224 #if KERNEL_USE_TIMEOUTS
00225 if (bUseTimer) {
00226
             clSemTimer.Stop();
             return (g_pclCurrent->GetExpired() == 0);
00227
        }
return true;
00228
00229
00230 #endif
00231 }
00232
00233 //----
00234 // Redirect the untimed pend API to the timed pend, with a null timeout.
00235 void Semaphore::Pend()
00236 {
00237 #if KERNEL_USE_TIMEOUTS
00238
         Pend_i(0);
00239 #else
00240
        Pend i();
00241 #endif
00242 }
00243
00244 #if KERNEL_USE_TIMEOUTS
00245 //---
00246 bool Semaphore::Pend(uint32_t u32WaitTimeMS_)
00247 {
00248
         return Pend_i (u32WaitTimeMS_);
00249 }
00250 #endif
00251
00252 //---
00253 uint16_t Semaphore::GetCount()
00255 #if KERNEL_EXTRA_CHECKS
00256
        KERNEL_ASSERT(IsInitialized());
00257 #endif
00258 uint16_t u16Ret;
00259
         CS_ENTER();
00260
         u16Ret = m_u16Value;
00261
         CS_EXIT();
00262
         return u16Ret;
00263 }
00264
00265 #endif
```

# 20.35 /home/moslevin/projects/mark3-source/kernel/II.cpp File Reference

Core Linked-List implementation, from which all kernel objects are derived.

```
#include "kerneltypes.h"
#include "kernel.h"
#include "ll.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

## 20.35.1 Detailed Description

Core Linked-List implementation, from which all kernel objects are derived.

Definition in file II.cpp.

# 20.36 II.cpp

```
00001
00002
00003
00004
00005
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #include "kernel.h"
00024 #include "11.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_LL_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 //--
00040 void LinkListNode::ClearNode()
00041 {
         next = NULL;
prev = NULL;
00042
00043
00044 }
00045
00046 //--
00047 void DoubleLinkList::Add(LinkListNode* node_)
00048 {
00049
          KERNEL_ASSERT (node_);
00050
00051
          node_->prev = m_pstTail;
00052
          node_->next = NULL;
00053
00054
          \ensuremath{//} If the list is empty, initilize the head
00055
          if (!m_pstHead) {
00056
              m_pstHead = node ;
00057
00058
          // Otherwise, adjust the tail's next pointer
```

```
else {
            m_pstTail->next = node_;
00060
00061
00062
          \ensuremath{//} Move the tail node, and assign it to the new node just passed in
00063
00064
          m pstTail = node ;
00066
00067 //-
00068 void DoubleLinkList::Remove(LinkListNode* node)
00069 {
00070
          KERNEL_ASSERT (node_);
00071
          if (node_->prev) {
00072
00073 #if SAFE_UNLINK
00074
          if (node_->prev->next != node_) {
   Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00075
00076
              }
00077 #endif
00078
              node_->prev->next = node_->next;
00079
          if (node_->next) {
00080
00081 #if SAFE_UNLINK
              if (node_->next->prev != node_) {
   Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00082
00083
00084
00085 #endif
00086
              node_->next->prev = node_->prev;
00087
          if (node_ == m_pstHead) {
00088
00089
              m_pstHead = node_->next;
00090
00091
          if (node_ == m_pstTail) {
00092
             m_pstTail = node_->prev;
00093
00094
          node_->ClearNode();
00095 }
00097 //--
00098 void CircularLinkList::Add(LinkListNode* node_)
00099 {
00100
          KERNEL ASSERT (node );
00101
00102
          if (!m_pstHead) {
00103
              // If the list is empty, initilize the nodes
00104
              m_pstHead = node_;
00105
              m_pstTail = node_;
          } else {
    // Move the tail node, and assign it to the new node just passed in
00106
00107
              m_pstTail->next = node_;
00108
00109
          }
00110
00111
         // Add a node to the end of the linked list.
00112
         node_->prev = m_pstTail;
          node_->next = m_pstHead;
00113
00114
00115
          m_pstTail
                           = node_;
00116
          m_pstHead->prev = node_;
00117 }
00118
00119 //--
00120 void CircularLinkList::Remove(LinkListNode* node )
00121 {
00122
          KERNEL_ASSERT (node_);
00123
00124
          // Check to see if this is the head of the list...
00125
          if ((node_ == m_pstHead) && (m_pstHead == m_pstTail)) {
              // Clear the head and tail pointers - nothing else left.
00126
00127
              m_pstHead = NULL;
00128
              m_pstTail = NULL;
00129
00130
          }
00131
00132 #if SAFE UNLINK
       // Verify that all nodes are properly connected
if ((node_->prev->next != node_) || (node_->next->prev != node_)) {
00133
00134
00135
              Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00136
00137 #endif
00138
00139
          // This is a circularly linked list - no need to check for connection,
          // just remove the node.
00141
          node_->next->prev = node_->prev;
00142
          node_->prev->next = node_->next;
00143
          if (node_ == m_pstHead) {
00144
00145
              m_pstHead = m_pstHead->next;
```

```
00146
00147
          if (node_ == m_pstTail) {
00148
             m_pstTail = m_pstTail->prev;
00149
          node_->ClearNode();
00150
00151 }
00152
00153 //---
00154 void CircularLinkList::PivotForward()
00155 {
00156
         if (m_pstHead) {
         m_pstHead = m_pstHead->next;
00157
             m_pstTail = m_pstTail->next;
00158
00159
00160 }
00161
00162 //---
00163 void CircularLinkList::PivotBackward()
00164 {
00165
          if (m_pstHead) {
             m_pstHead = m_pstHead->prev;
m_pstTail = m_pstTail->prev;
00166
00167
       }
00168
00169 }
00170
00171 //---
00172 void CircularLinkList::InsertNodeBefore(
     LinkListNode* node_, LinkListNode* insert_)
00173 {
          KERNEL_ASSERT (node_);
00174
00175
         node_->next = insert_;
node_->prev = insert_->prev;
00176
00177
00178
00179
         insert_->prev->next = node_;
}
          if (insert_->prev) {
00180
00181
00182
         insert_->prev = node_;
00183 }
```

# 20.37 /home/moslevin/projects/mark3-source/kernel/mailbox.cpp File Reference

# Mailbox + Envelope IPC mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "ksemaphore.h"
#include "mailbox.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

## 20.37.1 Detailed Description

Mailbox + Envelope IPC mechanism.

Definition in file mailbox.cpp.

# 20.38 mailbox.cpp

```
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #include "mark3cfg.h"
00022 #include "kerneltypes.h"
00023 #include "ksemaphore.h"
00024 #include "mailbox.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]------
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_MAILBOX_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MAILBOX
00040
00041 //----
00042 Mailbox::~Mailbox()
00043 {
00044
          // If the mailbox isn't empty on destruction, kernel panic.
00045
         if (m_u16Free != m_u16Count)
00046
              Kernel::Panic(PANIC_ACTIVE_MAILBOX_DESCOPED);
00047
00048 }
00050 //--
00051 void Mailbox::Init(void* pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_)
00052 {
00053
          KERNEL ASSERT (u16BufferSize );
00054
          KERNEL_ASSERT (u16ElementSize_);
00055
         KERNEL_ASSERT (pvBuffer_);
00056
          m_pvBuffer
00057
                          = pvBuffer_;
00058
         m_u16ElementSize = u16ElementSize_;
00059
         m_u16Count = (u16BufferSize_ / u16ElementSize_);
00060
         m_u16Free = m_u16Count;
00061
00062
00063
          m_u16Head = 0;
00064
         m_u16Tail = 0;
00065
00066
          // We use the counting semaphore to implement blocking - with one element
00067
          // in the mailbox corresponding to a post/pend operation in the semaphore.
         m_clRecvSem.Init(0, m_ul6Free);
00068
00069
00070 #if KERNEL_USE_TIMEOUTS
         // Binary semaphore is used to track any threads that are blocked on a // "send" due to lack of free slots.
00071
00072
         m_clSendSem.Init(0, 1);
00073
00074 #endif
00075 }
00076
00077 //----
00078 #if KERNEL_USE_AUTO_ALLOC
00079 Mailbox* Mailbox::Init(uint16_t u16BufferSize_, uint16_t u16ElementSize_)
00080 {
00081
          Mailbox* pclNew = (Mailbox*)AutoAlloc::Allocate(sizeof(
     Mailbox));
00082
         woid+
                   pvBuffer = AutoAlloc::Allocate(u16BufferSize_);
         pclNew->Init(pvBuffer, u16BufferSize_, u16ElementSize_);
00083
00084
         return pclNew;
00085 }
00086 #endif
00087
00088 //---
00089 void Mailbox::Receive(void* pvData_)
00090 {
         KERNEL_ASSERT (pvData_);
00091
00092
00093 #if KERNEL_USE_TIMEOUTS
00094
         Receive_i (pvData_, false, 0);
00095 #else
00096
       Receive_i(pvData_, false);
00097 #endif
```

20.38 mailbox.cpp 245

```
00098 }
00099
00100 #if KERNEL_USE_TIMEOUTS
00101 //--
00102 bool Mailbox::Receive(void* pvData_, uint32_t u32TimeoutMS_)
00103 {
         KERNEL_ASSERT (pvData_);
00105
         return Receive_i(pvData_, false, u32TimeoutMS_);
00106 }
00107 #endif
00108
00109 //-
00110 void Mailbox::ReceiveTail(void* pvData)
00111 {
00112
         KERNEL_ASSERT (pvData_);
00113
00114 #if KERNEL_USE_TIMEOUTS
00115
         Receive_i (pvData_, true, 0);
00116 #else
        Receive_i(pvData_, true);
00117
00118 #endif
00119 }
00120
00121 #if KERNEL_USE_TIMEOUTS
00122 //--
00123 bool Mailbox::ReceiveTail(void* pvData_, uint32_t u32TimeoutMS_)
00124 {
00125
         KERNEL_ASSERT (pvData_);
00126
         return Receive_i (pvData_, true, u32TimeoutMS_);
00127 }
00128 #endif
00129
00130 //----
00131 bool Mailbox::Send(void* pvData_)
00132 {
         KERNEL_ASSERT (pvData_);
00133
00134
00135 #if KERNEL_USE_TIMEOUTS
00136
         return Send_i(pvData_, false, 0);
00137 #else
00138
        return Send_i(pvData_, false);
00139 #endif
00140 }
00141
00142 //-
00143 bool Mailbox::SendTail(void* pvData_)
00144 {
00145
         KERNEL_ASSERT (pvData_);
00146
00147 #if KERNEL_USE_TIMEOUTS
00148
         return Send_i (pvData_, true, 0);
00149 #else
00150
         return Send_i(pvData_, true);
00151 #endif
00152 }
00153
00154 #if KERNEL_USE_TIMEOUTS
00155 //--
00156 bool Mailbox::Send(void* pvData_, uint32_t u32TimeoutMS_)
00157 {
00158
         KERNEL_ASSERT (pvData_);
00159
00160
         return Send_i(pvData_, false, u32TimeoutMS_);
00161 }
00162
00163 //---
00164 bool Mailbox::SendTail(void* pvData_, uint32_t u32TimeoutMS_)
00165 {
00166
         KERNEL ASSERT (pvData );
00167
00168
        return Send_i (pvData_, true, u32TimeoutMS_);
00169 }
00170 #endif
00171
00172 //-
00173 #if KERNEL_USE_TIMEOUTS
00174 bool Mailbox::Send_i(const void* pvData_, bool bTail_, uint32_t u32TimeoutMS_)
00175 #else
00176 bool Mailbox::Send_i(const void* pvData_, bool bTail_)
00177 #endif
00178 {
00179
         const void* pvDst;
00180
00181
         bool bRet
                          = false;
00182
         bool bSchedState = Scheduler::SetScheduler(false);
00183
00184 #if KERNEL_USE_TIMEOUTS
```

```
00185
         bool bBlock = false;
00186
         bool bDone = false;
00187
          while (!bDone) {
             // Try to claim a slot first before resorting to blocking.
00188
00189
              if (bBlock) {
00190
                  bDone = true;
00191
                  Scheduler::SetScheduler(bSchedState);
00192
                  m_clSendSem.Pend(u32TimeoutMS_);
00193
                  Scheduler::SetScheduler(false);
00194
00195 #endif
00196
00197
              CS_ENTER();
00198
              // Ensure we have a free slot before we attempt to write data
00199
              if (m_u16Free) {
00200
                  m_u16Free--;
00201
00202
                  if (bTail_) {
                      pvDst = GetTailPointer();
00203
00204
                      MoveTailBackward();
00205
                  } else {
00206
                     MoveHeadForward();
                      pvDst = GetHeadPointer();
00207
00208
00209
                  bRet = true;
00210 #if KERNEL_USE_TIMEOUTS
00211
                  bDone = true;
00212 #endif
00213
00214 #if KERNEL_USE_TIMEOUTS
00215
             else if (u32TimeoutMS_) {
00216
                 bBlock = true;
00217
00218
                  bDone = true;
00219
00220 #endif
00221
              CS_EXIT();
00223
00224 #if KERNEL_USE_TIMEOUTS
00225
00226 #endif
00227
00228
          // Copy data to the claimed slot, and post the counting semaphore
00229
         if (bRet) {
00230
              CopyData(pvData_, pvDst, m_u16ElementSize);
00231
00232
00233
         Scheduler::SetScheduler(bSchedState);
00234
00235
         if (bRet) {
00236
             m_clRecvSem.Post();
00237
         }
00238
00239
          return bRet;
00240 }
00241
00242 //---
00243 #if KERNEL_USE_TIMEOUTS
00244 bool Mailbox::Receive_i(const void* pvData_, bool bTail_, uint32_t u32WaitTimeMS_)
00245 #else
00246 void Mailbox::Receive_i(const void* pvData_, bool bTail_)
00247 #endif
00248 {
00249
          const void* pvSrc;
00250
00251 #if KERNEL_USE_TIMEOUTS
        if (!m_clRecvSem.Pend(u32WaitTimeMS_)) {
00252
00253
              // Failed to get the notification from the counting semaphore in the
00254
              // time allotted. Bail.
00255
              return false;
00256
00257 #else
        m clRecvSem.Pend():
00258
00259 #endif
00260
00261
          // Disable the scheduler while we do this -- this ensures we don't have
00262
          \ensuremath{//} multiple concurrent readers off the same queue, which could be problematic
00263
          // if multiple writes occur during reads, etc.
00264
         bool bSchedState = Scheduler::SetScheduler(false);
00265
00266
          // Update the head/tail indexes, and get the associated data pointer for
00267
          // the read operation.
00268
         CS_ENTER();
00269
         m_u16Free++;
if (bTail_) {
00270
00271
```

```
00272
              MoveTailForward();
00273
              pvSrc = GetTailPointer();
00274
00275
              pvSrc = GetHeadPointer();
00276
              MoveHeadBackward();
00277
          }
00278
00279
          CS_EXIT();
00280
00281
         CopyData(pvSrc, pvData_, m_u16ElementSize);
00282
00283
          Scheduler::SetScheduler(bSchedState);
00284
00285 #if KERNEL_USE_TIMEOUTS
00286
          // Unblock a thread waiting for a free slot to send to
00287
         m_clSendSem.Post();
00288
00289
          return true;
00290 #endif
00291 }
00292
00293 #endif
```

# 20.39 /home/moslevin/projects/mark3-source/kernel/message.cpp File Reference

Inter-thread communications via message passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "message.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "timerlist.h"
```

## 20.39.1 Detailed Description

Inter-thread communications via message passing.

Definition in file message.cpp.

# 20.40 message.cpp

```
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "message.h"
00026 #include "threadport.h"
00027
00028 #define _CAN_HAS_DEBUG
```

```
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG_FILE)
00033 #error "Debug logging file token already defined! Bailing."
00034 #else
00035 #define DBG_FILE _DBG___KERNEL_MESSAGE_CPP
00036 #endif
00037 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL_USE_MESSAGE
00041
00042 #if KERNEL_USE_TIMEOUTS
00043 #include "timerlist.h"
00044 #endif
00045
                  GlobalMessagePool::m_aclMessagePool[
00046 Message
      GLOBAL_MESSAGE_POOL_SIZE];
00047 MessagePool GlobalMessagePool::m_clPool;
00048
00049 //--
00050 void MessagePool::Init()
00051 {
00052
          m_clList.Init();
00053 }
00054
00055 //--
00056 void MessagePool::Push(Message* pclMessage_)
00057 {
00058
          KERNEL ASSERT (pclMessage );
00059
00060
          CS_ENTER();
00061
00062
         m_clList.Add(pclMessage_);
00063
00064
          CS EXIT();
00065 }
00066
00067 //---
00068 Message* MessagePool::Pop()
00069 {
00070
          Message* pclRet:
00071
          CS_ENTER();
00072
00073
          pclRet = static_cast<Message*>(m_clList.GetHead());
00074
          if (0 != pclRet) {
00075
              m_clList.Remove(static_cast<LinkListNode*>(pclRet));
00076
          }
00077
00078
          CS_EXIT();
00079
          return pclRet;
00080 }
00081
00082 //----
00083 Message* MessagePool::GetHead()
00084 {
00085
          return static_cast<Message*>(m_clList.GetHead());
00086 }
00087
00088 //----
00089 void GlobalMessagePool::Init()
00090 {
00091
          uint8_t i;
00092
          GlobalMessagePool::m_clPool.Init();
          for (i = 0; i < GLOBAL_MESSAGE_POOL_SIZE; i++) {</pre>
00093
00094
              GlobalMessagePool::m_aclMessagePool[i].Init();
              \label{lem:clPool.Push} Global Message Pool:: m\_clPool.Push (\& (Global Message Pool:: m\_acl Message Pool[i])); \\
00095
00096
          }
00097 }
00098
00099 //--
00100 void GlobalMessagePool::Push(Message* pclMessage_)
00101 {
00102
          m clPool.Push(pclMessage);
00103 }
00104
00105 //---
00106 Message* GlobalMessagePool::Pop()
00107 {
00108
          return m_clPool.Pop();
00109 }
00110
00111 //-
00112 Message* GlobalMessagePool::GetHead()
00113 {
00114
          return m clPool.GetHead();
```

20.40 message.cpp 249

```
00115 }
00116
00117 //--
00118 MessagePool* GlobalMessagePool::GetPool()
00119 {
00120
         return &m clPool:
00121 }
00122
00123 //--
00124 void MessageQueue::Init()
00125 {
00126
         m clSemaphore.Init(0, GLOBAL MESSAGE POOL SIZE);
00127 }
00128
00129 //----
00130 Message* MessageQueue::Receive()
00131 {
00132 #if KERNEL_USE_TIMEOUTS
         return Receive_i(0);
00133
00134 #else
00135
        return Receive_i();
00136 #endif
00137 }
00138
00139 //-
00140 #if KERNEL_USE_TIMEOUTS
00141 Message* MessageQueue::Receive(uint32_t u32TimeWaitMS_)
00142 {
00143
         return Receive_i(u32TimeWaitMS_);
00144 }
00145 #endif
00146
00147 //----
00148 #if KERNEL_USE_TIMEOUTS
00149 Message* MessageQueue::Receive_i(uint32_t u32TimeWaitMS_)
00150 #else
00151 Message* MessageOueue::Receive i(void)
00152 #endif
00153 {
00154
         Message* pclRet;
00155
00156 // Block the current thread on the counting semaphore
00157 #if KERNEL_USE_TIMEOUTS
       if (!m_clSemaphore.Pend(u32TimeWaitMS_)) {
00158
00159
             return NULL;
00160
00161 #else
00162
       m_clSemaphore.Pend();
00163 #endif
00164
00165
         CS_ENTER();
00166
00167
         // Pop the head of the message queue and return it
00168
         pclRet = static_cast<Message*>(m_clLinkList.GetHead());
         m_clLinkList.Remove(static_cast<Message*>(pclRet));
00169
00170
00171
         CS_EXIT();
00172
00173
         return pclRet;
00174 }
00175
00176 //-
00177 void MessageQueue::Send(Message* pclSrc_)
00178 {
00179
         KERNEL_ASSERT (pclSrc_);
00180
00181
         CS ENTER();
00182
00183
         // Add the message to the head of the linked list
00184
         m_clLinkList.Add(pclSrc_);
00185
00186
         // Post the semaphore, waking the blocking thread for the queue.
00187
         m_clSemaphore.Post();
00188
00189
         CS EXIT();
00190 }
00191
00192 //---
00193 uint16_t MessageQueue::GetCount()
00194 {
00195
         return m_clSemaphore.GetCount();
00196 }
00197 #endif // KERNEL_USE_MESSAGE
```

# 20.41 /home/moslevin/projects/mark3-source/kernel/mutex.cpp File Reference

## Mutual-exclusion object.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "mutex.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### **Functions**

void TimedMutex\_Calback (Thread \*pclOwner\_, void \*pvData\_)
 TimedMutex Calback.

## 20.41.1 Detailed Description

Mutual-exclusion object.

Definition in file mutex.cpp.

## 20.41.2 Function Documentation

```
20.41.2.1 void TimedMutex_Calback ( Thread * pclOwner_, void * pvData_ )
```

TimedMutex\_Calback.

This function is called from the timer-expired context to trigger a timeout on this mutex. This results in the waking of the thread that generated the mutex claim call that was not completed in time.

# **Parameters**

pcl←	Pointer to the thread to wake
Owner_	
pvData_	Pointer to the mutex object that the thread is blocked on

Definition at line 54 of file mutex.cpp.

# 20.42 mutex.cpp



20.42 mutex.cpp 251

```
00006 |_/\_/|_||||\_\ _|||_|\\_ |||_|
80000
00009 -- [Mark3 Realtime Platform] -----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022
00023 #include "blocking.h"
00024 #include "mutex.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]------00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_MUTEX_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MUTEX
00040
00041 #if KERNEL USE TIMEOUTS
00042
00043 //-
00054 void TimedMutex_Calback(Thread* pclOwner_, void* pvData_)
00055 {
00056
          Mutex* pclMutex = static_cast<Mutex*>(pvData_);
00057
          // Indicate that the semaphore has expired on the thread
00058
00059
         pclOwner_->SetExpired(true);
00060
00061
          // Wake up the thread that was blocked on this semaphore.
00062
         pclMutex->WakeMe(pclOwner_);
00063
          if (pclOwner ->GetCurPriority() >= Scheduler::GetCurrentThread
00064
      ()->GetCurPriority()) {
00065
            Thread::Yield();
00066
00067 }
00068 //----
00069 Mutex::~Mutex()
00070 {
          // If there are any threads waiting on this object when it goes out
00072
          // of scope, set a kernel panic.
00073
          if (m_clBlockList.GetHead()) {
00074
              Kernel::Panic(PANIC_ACTIVE_MUTEX_DESCOPED);
00075
00076 }
00077
00078 //--
00079 void Mutex::WakeMe(Thread* pclOwner_)
00080 {
00081
          // Remove from the semaphore waitlist and back to its ready list.
00082
          UnBlock (pclOwner_);
00083 }
00084
00085 #endif
00086
00087 //--
00088 uint8_t Mutex::WakeNext()
00089 {
00090
          Thread* pclChosenOne = NULL;
00091
00092
          // Get the highest priority waiter thread
00093
          pclChosenOne = m_clBlockList.HighestWaiter();
00094
00095
          // Unblock the thread
00096
          UnBlock (pclChosenOne);
00097
00098
          \ensuremath{//} The chosen one now owns the mutex
00099
          m_pclOwner = pclChosenOne;
00100
          // Signal a context switch if it's a greater than or equal to the current priority
00101
00102
          if (pclChosenOne->GetCurPriority() >=
      Scheduler::GetCurrentThread()->GetCurPriority()) {
00103
             return 1;
00104
00105
          return 0;
00106 }
```

```
00108 //---
00109 void Mutex::Init()
00110 {
           // Cannot re-init a mutex which has threads blocked on it
00111
00112 #if KERNEL_EXTRA_CHECKS
        KERNEL_ASSERT(!m_clBlockList.GetHead());
00113
00114 #endif
00115
00116
          \ensuremath{//} Reset the data in the mutex
          m_bReady = 1; // The mutex is free.
m_u8MaxPri = 0; // Set the maximum priority inheritence state
00117
          m_bReady
00118
          m_pclOwner = NULL; // Clear the mutex owner
00119
00120
         m_u8Recurse = 0;
                               // Reset recurse count
00121
00122 #if KERNEL_EXTRA_CHECKS
00123
        SetInitialized():
00124 #endif
00125 }
00126
00127 //----
00128 #if KERNEL_USE_TIMEOUTS
00129 bool Mutex::Claim_i (uint32_t u32WaitTimeMS_)
00130 #else
00131 void Mutex::Claim_i(void)
00132 #endif
00133 {
00134 #if KERNEL_EXTRA_CHECKS
00135
        KERNEL_ASSERT(IsInitialized());
00136 #endif
00137
00138
          KERNEL_TRACE_1("Claiming Mutex, Thread %d", (uint16_t)
     g_pclCurrent->GetID());
00139
00140 #if KERNEL_USE_TIMEOUTS
         Timer clTimer;
00141
          bool bUseTimer = false;
00142
00143 #endif
00144
00145
           // Disable the scheduler while claiming the mutex - we're dealing with all
         // sorts of private thread data, can't have a thread switch while messing // with internal data structures.
00146
00147
00148
          Scheduler::SetScheduler(0);
00149
00150
          // Check to see if the mutex is claimed or not
00151
          if (m_bReady != 0) {
00152
              // Mutex isn't claimed, claim it.
00153
              m_bReady = 0;
              m_u8Recurse = 0;
00154
              m_u8MaxPri = g_pclCurrent->GetPriority();
m_pclOwner = g_pclCurrent;
00155
00156
00157
00158
              Scheduler::SetScheduler(1);
00159
00160 #if KERNEL_USE_TIMEOUTS
00161
              return true;
00163
              return:
00164 #endif
00165
00166
00167
         // If the mutex is already claimed, check to see if this is the owner thread,
00168
          // since we allow the mutex to be claimed recursively.
00169
         if (g_pclCurrent == m_pclOwner) {
00170
               // Ensure that we haven't exceeded the maximum recursive-lock count
00171
              KERNEL_ASSERT((m_u8Recurse < 255));</pre>
00172
              m_u8Recurse++;
00173
00174
              // Increment the lock count and bail
              Scheduler::SetScheduler(1);
00176 #if KERNEL_USE_TIMEOUTS
00177
              return true;
00178 #else
00179
              return;
00180 #endif
00181
00182
00183 \/\/ The mutex is claimed already - we have to block now. Move the
00184 // current thread to the list of threads waiting on the mutex. 00185 \#if KERNEL USE TIMEOUTS
00186 if (u32WaitTimeMS_) {
00187
              g_pclCurrent->SetExpired(false);
              clTimer.Init();
00188
00189
              clTimer.Start(0, u32WaitTimeMS_, (TimerCallback_t)
     TimedMutex_Calback, (void*)this);
bUseTimer = true;
00190
00191
          }
```

20.42 mutex.cpp 253

```
00192 #endif
00193
          BlockPriority(g_pclCurrent);
00194
          // Check if priority inheritence is necessary. We do this in order
// to ensure that we don't end up with priority inversions in case
// multiple threads are waiting on the same resource.
if (m_u8MaxPri <= g_pclCurrent->GetPriority()) {
00195
00196
00197
00198
00199
               m_u8MaxPri = g_pclCurrent->GetPriority();
00200
00201
               Thread* pclTemp = static_cast<Thread*>(m_clBlockList.
      GetHead());
00202
              while (pclTemp) {
00203
                   pclTemp->InheritPriority(m_u8MaxPri);
                    if (pclTemp == static_cast<Thread*>(m_clBlockList.
      GetTail())) {
00205
00206
00207
                   pclTemp = static_cast<Thread*>(pclTemp->GetNext());
00208
               }
00209
               m_pclOwner->InheritPriority(m_u8MaxPri);
00210
00211
           \ensuremath{//} Done with thread data -reenable the scheduler
00212
00213
          Scheduler::SetScheduler(1);
00214
00215
           // Switch threads if this thread acquired the mutex
00216
          Thread::Yield();
00217
00218 #if KERNEL_USE_TIMEOUTS
         if (bUseTimer) {
00219
00220
               clTimer.Stop();
00221
               return (g_pclCurrent->GetExpired() == 0);
00222
00223
          return true;
00224 #endif
00225 }
00226
00228 void Mutex::Claim(void)
00229 {
00230 #if KERNEL_USE_TIMEOUTS
00231
          Claim_i(0);
00232 #else
         Claim_i();
00233
00234 #endif
00235 }
00236
00237 //---
00238 #if KERNEL_USE_TIMEOUTS
00239 bool Mutex::Claim(uint32_t u32WaitTimeMS_)
00241
           return Claim_i(u32WaitTimeMS_);
00242 }
00243 #endif
00244
00245 //
00246 void Mutex::Release()
00247 {
00248 #if KERNEL_EXTRA_CHECKS
00249
          KERNEL_ASSERT(IsInitialized());
00250 #endif
00251
00252
          KERNEL_TRACE_1("Releasing Mutex, Thread %d", (uint16_t)
      g_pclCurrent->GetID());
00253
00254
          bool bSchedule = 0;
00255
00256
           // Disable the scheduler while we deal with internal data structures.
00257
          Scheduler::SetScheduler(0);
00258
00259
           // This thread had better be the one that owns the mutex currently...
00260
          KERNEL_ASSERT((g_pclCurrent == m_pclOwner));
00261
00262
           // If the owner had claimed the lock multiple times, decrease the lock
00263
           // count and return immediately.
00264
           if (m_u8Recurse) {
00265
               m_u8Recurse--;
00266
               Scheduler::SetScheduler(1);
00267
               return;
00268
          }
00269
00270
           // Restore the thread's original priority
           if (g_pclCurrent->GetCurPriority() != g_pclCurrent->
      GetPriority()) {
00272
              g_pclCurrent->SetPriority(g_pclCurrent->
      GetPriority());
00273
```

```
// In this case, we want to reschedule
00275
               bSchedule = 1;
00276
00277
          // No threads are waiting on this semaphore?
if (m_clBlockList.GetHead() == NULL) {
00278
00279
               // Re-initialize the mutex to its default values
00281
               m_bReady
               m_u8MaxPri = 0;
00282
00283
              m_pclOwner = NULL;
          } else {
    // Wake the highest priority Thread pending on the mutex
00284
00285
00286
00287
                   // Switch threads if it's higher or equal priority than the current thread
00288
                   bSchedule = 1;
00289
00290
00291
00292
          // Must enable the scheduler again in order to switch threads.
00293
          Scheduler::SetScheduler(1);
00294
          if (bSchedule) {
00295
               // Switch threads if a higher-priority thread was woken
00296
               Thread::Yield();
00297
00298 }
00299
00300 #endif // KERNEL_USE_MUTEX
```

# 20.43 /home/moslevin/projects/mark3-source/kernel/notify.cpp File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "notify.h"
#include "mark3.h"
#include "kerneldebug.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

#### 20.43.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.cpp.

# 20.44 notify.cpp

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =====
00022 #include "mark3cfg.h"
00023 #include "notify.h"
00024 #include "mark3.h"
00025 #include "kerneldebug.h"
00026
```

20.44 notify.cpp 255

```
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]------
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_NOTIFY_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037
00038 #if KERNEL USE NOTIFY
00039
00040 #if KERNEL_USE_TIMEOUTS
00041 //-
00042 void TimedNotify_Callback(Thread* pclOwner_, void* pvData_)
00043 {
00044
          Notify* pclNotify = static cast<Notify*>(pvData );
00045
00046
          // Indicate that the semaphore has expired on the thread
00047
          pclOwner_->SetExpired(true);
00048
          \ensuremath{//} Wake up the thread that was blocked on this semaphore.
00049
          pclNotify->WakeMe(pclOwner_);
00050
00051
00052
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      ()->GetCurPriority())
00053
             Thread::Yield();
00054
00055 }
00056 #endif
00057 //
00058 Notify::~Notify()
00059 {
00060
          // If there are any threads waiting on this object when it goes out
         // of scope, set a kernel panic.
if (m_clBlockList.GetHead()) {
00061
00062
              Kernel::Panic(PANIC_ACTIVE_NOTIFY_DESCOPED);
00063
00064
          }
00065 }
00066
00067 //----
00068 void Notify::Init(void)
00069 {
00070 #if KERNEL_EXTRA_CHECKS
00071
          KERNEL_ASSERT(!m_clBlockList.GetHead());
00072
          SetInitialized();
00073 #endif
00074 }
00075
00077 void Notify::Signal(void)
00078 {
00079 #if KERNEL EXTRA CHECKS
08000
         KERNEL_ASSERT(IsInitialized());
00081 #endif
00082
00083
          bool bReschedule = false;
00084
00085
          CS_ENTER();
          Thread* pclCurrent = (Thread*)m_clBlockList.GetHead();
00086
          while (pclCurrent != NULL) {
00087
           UnBlock (pclCurrent);
00088
              if (!bReschedule && (pclCurrent->GetCurPriority() >=
     Scheduler::GetCurrentThread()->GetCurPriority())) {
00090
                  bReschedule = true;
00091
00092
              pclCurrent = (Thread*)m_clBlockList.GetHead();
00093
00094
          CS_EXIT();
00095
00096
          if (bReschedule) {
00097
              Thread::Yield();
00098
00099 }
00100
00101 //--
00102 void Notify::Wait (bool* pbFlag_)
00103 (
00104 #if KERNEL EXTRA CHECKS
          KERNEL_ASSERT(IsInitialized());
00105
00106 #endif
00107
00108
          CS_ENTER();
00109
          Block(g_pclCurrent);
00110
          if (pbFlag_) {
00111
              *pbFlag_ = false;
```

```
00113
          CS_EXIT();
00114
00115
          Thread::Yield();
00116
          if (pbFlag_) {
             *pbFlag_ = true;
00117
00118
00119 }
00120
00121 //---
00122 #if KERNEL_USE_TIMEOUTS
00123 bool Notify::Wait(uint32_t u32WaitTimeMS_, bool* pbFlag_)
00124 {
00125 #if KERNEL_EXTRA_CHECKS
00126
         KERNEL_ASSERT(IsInitialized());
00127 #endif
         bool bUseTimer = false:
00128
00129
         Timer clNotifyTimer;
00130
00131
         CS_ENTER();
00132
         if (u32WaitTimeMS_) {
00133
              bUseTimer = true;
              g_pclCurrent->SetExpired(false);
00134
00135
00136
              clNotifyTimer.Init();
00137
             clNotifyTimer.Start(0, u32WaitTimeMS_, TimedNotify_Callback, (void*)this);
00138
00139
00140
          Block(g_pclCurrent);
00141
00142
          if (pbFlag_) {
             *pbFlag_ = false;
00143
00144
00145
          CS_EXIT();
00146
          Thread::Yield();
00147
00148
          if (bUseTimer) {
00150
             clNotifyTimer.Stop();
00151
              return (g_pclCurrent->GetExpired() == 0);
00152
00153
         if (pbFlag_) {
00154
00155
              *pbFlag_ = true;
00156
00157
00158
          return true;
00159 }
00160 #endif
00161 //---
00162 void Notify::WakeMe(Thread* pclChosenOne_)
00163 {
00164 #if KERNEL_EXTRA_CHECKS
00165
         KERNEL_ASSERT(IsInitialized());
00166 #endif
00167
         UnBlock (pclChosenOne );
00168 }
00169
00170 #endif
```

# 20.45 /home/moslevin/projects/mark3-source/kernel/priomap.cpp File Reference

Priority map data structure.

```
#include "mark3.h"
#include "priomap.h"
#include "threadport.h"
#include <stdint.h>
#include <stdbool.h>
```

#### 20.45.1 Detailed Description

Priority map data structure.

Definition in file priomap.cpp.

20.46 priomap.cpp 257

## 20.46 priomap.cpp

```
00001 /*========
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ========
00019 #include "mark3.h"
00020 #include "priomap.h"
00021 #include "threadport.h"
00022
00023 #include <stdint.h>
00024 #include <stdbool.h>
00025
00026 //----
00027 static inline uint8_t priority_from_bitmap(PORT_PRIO_TYPE uXPrio_)
00028 (
00029 #if HW CLZ
00030
          // Support hardware-accelerated Count-leading-zeros instruction
00031
          uint8_t rc = PRIO_MAP_BITS - CLZ(uXPrio_);
00032
          return rc;
00033 #else
00034
          // Default un-optimized count-leading zeros operation
00035
          PORT_PRIO_TYPE uXMask = (1 << (PRIO_MAP_BITS - 1));</pre>
00036
                    u8Zeros = 0;
          uint8_t
00037
00038
          while (uXMask) {
00039
             if (uXMask & uXPrio_) {
00040
                  return (PRIO_MAP_BITS - u8Zeros);
00041
00042
              uXMask >>= 1:
00043
00044
              u8Zeros++;
00045
00046
          return 0;
00047 #endif
00048 }
00049
00050 //
00051 PriorityMap::PriorityMap()
00052 {
00053 #if PRIO_MAP_MULTI_LEVEL
         m_uXPriorityMapL2 = 0;
for (int i = 0; i < PRIO_MAP_NUM_WORDS; i++) {</pre>
00054
00055
00056
             m_auXPriorityMap[i] = 0;
00057
00058 #else
00059
         m_uXPriorityMap = 0;
00060 #endif
00061 }
00062
00063 //
00064 void PriorityMap::Set(PORT_PRIO_TYPE uXPrio_)
00065 {
00066
          PORT_PRIO_TYPE uXPrioBit = PRIO_BIT(uXPrio_);
00067 #if PRIO MAP MULTI LEVEI
          PORT_PRIO_TYPE uXWordIdx = PRIO_MAP_WORD_INDEX(uXPrio_);
00068
00069
00070
          m_auXPriorityMap[uXWordIdx] |= (1 << uXPrioBit);</pre>
00071
          m_uXPriorityMapL2 |= (1 << uXWordIdx);</pre>
00072 #else
00073
         m_uXPriorityMap |= (1 << uXPrioBit);</pre>
00074 #endif
00075 }
00076
00077 //-
00078 void PriorityMap::Clear(PORT_PRIO_TYPE uXPrio_)
00079 {
00080
          PORT_PRIO_TYPE uXPrioBit = PRIO_BIT(uXPrio_);
00081 #if PRIO MAP MULTI LEVEL
00082
          PORT_PRIO_TYPE uXWordIdx = PRIO_MAP_WORD_INDEX(uXPrio_);
00083
00084
          m_auXPriorityMap[uXWordIdx] &= ~(1 << uXPrioBit);</pre>
00085
          if (!m_auXPriorityMap[uXWordIdx]) {
00086
              m_uXPriorityMapL2 &= ~(1 << uXWordIdx);
00087
00088 #else
00089
          m_uXPriorityMap &= ~(1 << uXPrioBit);</pre>
```

```
00090 #endif
00091 }
00092
00093 //---
00094 PORT_PRIO_TYPE PriorityMap::HighestPriority(void)
00095 {
00096 #if PRIO_MAP_MULTI_LEVEL
00097
          PORT_PRIO_TYPE uXMapIdx = priority_from_bitmap(m_uXPriorityMapL2);
00098
          if (!uXMapIdx) {
              return 0;
00099
00100
          uXMapIdx--;
00101
00102
          PORT_PRIO_TYPE uXPrio = priority_from_bitmap(m_auXPriorityMap[uXMapIdx]);
00103
          uXPrio += (uXMapIdx * PRIO_MAP_BITS);
00104 #else
00105
          PORT_PRIO_TYPE uXPrio = priority_from_bitmap(m_uXPriorityMap);
00106 #endif
00107
          return uXPrio;
00108 }
```

# 20.47 /home/moslevin/projects/mark3-source/kernel/profile.cpp File Reference

Code profiling utilities.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

### 20.47.1 Detailed Description

Code profiling utilities.

Definition in file profile.cpp.

# 20.48 profile.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00022 #include "profile.h"
00024 #include "kernelprofile.h"
00025 #include "threadport.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]--
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
```

20.48 profile.cpp 259

```
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_PROFILE_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL USE PROFILER
00041
00042 //--
00043 void ProfileTimer::Init()
00044 {
00045
         m\_u32Cumulative
00046
         m_u32CurrentIteration = 0;
         m_u16Iterations = 0;
m_bActive = 0;
00047
00048
00049 }
00050
00051 //---
00052 void ProfileTimer::Start()
00053 {
00054
          if (!m_bActive) {
00055
             CS_ENTER();
00056
             m_u32CurrentIteration = 0;
             00057
00058
             m_u16Initial
00059
             CS_EXIT();
             m_bActive = 1;
00060
00061
         }
00062 }
00063
00064 //---
00065 void ProfileTimer::Stop()
00066 {
00067
         if (m bActive) {
             uint16_t u16Final;
00069
             uint32_t u32Epoch;
00070
              CS_ENTER();
             u16Final = Profiler::Read();
u32Epoch = Profiler::GetEpoch();
00071
00072
00073
             // Compute total for current iteration...
00074
             m_u32CurrentIteration = ComputeCurrentTicks(u16Final,
     u32Epoch);
       m_u32Cumulative += m_u32CurrentIteration;
00075
00076
             m_u16Iterations++;
00077
             CS_EXIT();
00078
             m_bActive = 0;
00079
         }
00080 }
00081
00082 //----
00083 uint32_t ProfileTimer::GetAverage()
00084 {
00085
         return m_u32Cumulative / (uint32_t)m_u16Iterations;
}
00086
00087
00088
         return 0;
00089 }
00090
00091 //-
00092 uint32_t ProfileTimer::GetCurrent()
00093 {
00094
          if (m_bActive) {
00095
             uint16_t u16Current;
00096
             uint32_t u32Epoch;
CS_ENTER();
00097
00098
             u16Current = Profiler::Read();
             u32Epoch = Profiler::GetEpoch();
00099
00100
             CS_EXIT();
00101
             return ComputeCurrentTicks(u16Current, u32Epoch);
00102
         return m_u32CurrentIteration;
00103
00104 }
00105
00106 //---
00107 uint32_t ProfileTimer::ComputeCurrentTicks(uint16_t u16Current_, uint32_t
     u32Epoch_)
00108 {
00109
          uint32 t u32Total;
00110
         uint32_t u320verflows;
00111
00112
         u32Overflows = u32Epoch_ - m_u32InitialEpoch;
00113
         // More than one overflow...
00114
00115
         if (u320verflows > 1) {
```

```
u32Total = ((uint32_t)(u32Overflows - 1) * TICKS_PER_OVERFLOW) + (uint32_t)(TICKS_PER_OVERFLOW -
00117
                            + (uint32_t)u16Current_;
00118
           // Only one overflow, or one overflow that has yet to be processed else if (u320verflows || (u16Current_ < m_u16Initial)) {
00119
00120
00121
               u32Total = (uint32_t)(TICKS_PER_OVERFLOW - m_u16Initial) + (uint32_t)u16Current_;
00122
00123
           // No overflows, none pending.
00124
           else {
               u32Total = (uint32_t) (u16Current_ - m_u16Initial);
00125
00126
00127
00128
           return u32Total;
00129 }
00130
00131 #endif
```

## 20.49 /home/moslevin/projects/mark3-source/kernel/public/atomic.h File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "threadport.h"
```

### 20.49.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.h.

### 20.50 atomic.h

```
00002
00003
00004
                  1 - 11
00005
                  1.11
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ------
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #ifndef __ATOMIC_H_
00022 #define __ATOMIC_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026 #include "threadport.h"
00027
00028 #if KERNEL_USE_ATOMIC
00029
00039 class Atomic
00040 {
00041 public:
00048
          static uint8_t Set(uint8_t* pu8Source_, uint8_t u8Val_);
          static uint16_t Set(uint16_t* pu16Source_, uint16_t u16Val_);
static uint32_t Set(uint32_t* pu32Source_, uint32_t u32Val_);
00049
00050
00051
00058
          static uint8_t Add(uint8_t* pu8Source_, uint8_t u8Val_);
00059
          static uint16_t Add(uint16_t* pu16Source_, uint16_t u16Val_);
00060
          static uint32_t Add(uint32_t* pu32Source_, uint32_t u32Val_);
```

# 20.51 /home/moslevin/projects/mark3-source/kernel/public/autoalloc.h File Reference

Automatic memory allocation for kernel objects.

```
#include <stdint.h>
#include <stdbool.h>
#include "mark3cfg.h"
```

## 20.51.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.h.

#### 20.52 autoalloc.h

```
00002
00003
00004 |
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00020 #ifndef __AUTO_ALLOC_H_
00021 #define __AUTO_ALLOC_H_
00022
00023 #include <stdint.h>
00024 #include <stdbool.h>
00025 #include "mark3cfg.h"
00026
00027 #if KERNEL_USE_AUTO_ALLOC
00028 // Forward declaration of kernel objects that can be auotomatically allocated.
00029
00030 #if KERNEL_USE_EVENTFLAG
00031 class EventFlag;
00032 #endif
00033
00034 #if KERNEL USE MAILBOX
00035 class Mailbox;
00036 #endif
00038 #if KERNEL_USE_MESSAGE
00039 class Message;
00040 class MessageQueue;
00041 #endif
00042
00043 #if KERNEL_USE_MUTEX
00044 class Mutex;
```

```
00045 #endif
00046
00047 #if KERNEL_USE_NOTIFY
00048 class Notify;
00049 #endif
00050
00051 #if KERNEL_USE_SEMAPHORE
00052 class Semaphore;
00053 #endif
00054
00055 class Thread:
00056
00057 #if KERNEL_USE_TIMERS
00058 class Timer;
00059 #endif
00060
00061 class AutoAlloc
00062 {
00063 public:
00070
          static void Init(void);
00071
00082
          static void* Allocate(uint16_t u16Size_);
00083
00084 #if KERNEL_USE_SEMAPHORE
00085
         static Semaphore* NewSemaphore(void);
00087
00088 #if KERNEL_USE_MUTEX
00089
         static Mutex* NewMutex(void);
00090 #endif
00091
00092 #if KERNEL_USE_EVENTFLAG
00093
          static EventFlag* NewEventFlag(void);
00094 #endif
00095
00096 #if KERNEL_USE_MESSAGE
00097 static Message* NewMessage(void);
00098 static MessageQueue* NewMessageQueue(void);
00099 #endif
00100
00101 #if KERNEL_USE_NOTIFY
        static Notify* NewNotify(void);
00102
00103 #endif
00104
00105 #if KERNEL_USE_MAILBOX
00106
          static Mailbox* NewMailbox(void);
00107 #endif
00108
00109
          static Thread* NewThread(void);
00110
00111 #if KERNEL_USE_TIMERS
00112
          static Timer* NewTimer(void);
00113 #endif
00114
00115 private:
00116 static uint8_t m_au8AutoHeap[AUTO_ALLOC_SIZE]; // Heap memory 00117 static K_ADDR m_aHeapTop; // Top of the
          static K_ADDR m_aHeapTop;
                                                             // Top of the heap
00118 };
00119 #endif
00120
00121 #endif
```

## 20.53 /home/moslevin/projects/mark3-source/kernel/public/blocking.h File Reference

Blocking object base class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
#include "thread.h"
```

### Classes

class BlockingObject

Class implementing thread-blocking primatives.

20.54 blocking.h 263

#### 20.53.1 Detailed Description

Blocking object base class declarations.

A Blocking object in Mark3 is essentially a thread list. Any blocking object implementation (being a semaphore, mutex, event flag, etc.) can be built on top of this class, utilizing the provided functions to manipu32ate thread location within the Kernel.

Blocking a thread results in that thread becoming de-scheduled, placed in the blocking object's own private list of threads which are waiting on the object.

Unblocking a thread results in the reverse: The thread is moved back to its original location from the blocking list.

The only difference between a blocking object based on this class is the logic used to determine what consitutes a Block or Unblock condition.

For instance, a semaphore Pend operation may result in a call to the Block() method with the currently-executing thread in order to make that thread wait for a semaphore Post. That operation would then invoke the UnBlock() method, removing the blocking thread from the semaphore's list, and back into the the appropriate thread inside the scheduler.

Care must be taken when implementing blocking objects to ensure that critical sections are used judiciously, otherwise asynchronous events like timers and interrupts could result in non-deterministic and often catastrophic behavior.

Definition in file blocking.h.

# 20.54 blocking.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009
       -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00047 #ifndef __BLOCKING_H_
00048 #define __BLOCKING_H_
00049
00050 #include "kerneltypes.h"
00051 #include "mark3cfg.h"
00052
00053 #include "11.h"
00054 #include "threadlist.h"
00055 #include "thread.h"
00056
00057 #if KERNEL_USE_MUTEX || KERNEL_USE_SEMAPHORE || KERNEL_USE_EVENTFLAG
00058
00059 //
00060 // Cookies used to determine whether or not an object has been initialized
00061 #define BLOCKING_INVALID_COOKIE
00062 #define BLOCKING_INIT_COOKIE
00063
00064 //--
00070 class BlockingObject
00071 {
00072 public:
00073 #if KERNEL_EXTRA_CHECKS
00074
          BlockingObject() { m_u8Initialized = BLOCKING_INVALID_COOKIE; }
00075
          ~BlockingObject() { m_u8Initialized = BLOCKING_INVALID_COOKIE; }
00076 #endif
00077
00078 protected:
```

```
void Block(Thread* pclThread_);
00100
00109
          void BlockPriority(Thread* pclThread_);
00110
00122
          void UnBlock(Thread* pclThread_);
00123
          ThreadList m_clBlockList;
00129
00130 #if KERNEL_EXTRA_CHECKS
00131
00135
          uint8_t m_u8Initialized;
00136
00140
          void SetInitialized(void) { m_u8Initialized = BLOCKING_INIT_COOKIE; }
00141
00146
          bool IsInitialized(void) { return (m_u8Initialized == BLOCKING_INIT_COOKIE); }
00147
00148 #endif
00149
00150 };
00151
00152 #endif
00153
00154 #endif
```

# 20.55 /home/moslevin/projects/mark3-source/kernel/public/buffalogger.h File Reference

Super-efficient, super-secure logging routines.

```
#include <stdint.h>
```

### 20.55.1 Detailed Description

Super-efficient, super-secure logging routines.

Uses offline processing to ensure performance.

Definition in file buffalogger.h.

# 20.56 buffalogger.h

```
00001 /
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ==========
00020 #pragma once
00021 #include <stdint.h>
00022
00023 //----
00024 #define STR1(s) #s
00025 #define STR(s) STR1(s)
00026
00027 /
00028 #define EMIT_DBG_STRING(str)
00029
00030
              const static volatile char
                                            log_str[] __attribute__((section(".logger")))
        _attribute__((unused)) = str;
00031
              const static volatile uint16_t line_id __attribute__((section(".logger"))) __attribute__((unused))
00032
              const static volatile uint16_t file_id __attribute__((section(".logger"))) __attribute__((unused))
        = DBG_FILE;
00033
              const static volatile uint16_t sync __attribute__((section(".logger"))) __attribute__((unused))
        = 0xCAFE;
00034
         } while (0);
```

## 20.57 /home/moslevin/projects/mark3-source/kernel/public/driver.h File Reference

Driver abstraction framework.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

#### Classes

class Driver

Base device-driver class used in hardware abstraction.

class DriverList

List of Driver objects used to keep track of all device drivers in the system.

#### 20.57.1 Detailed Description

Driver abstraction framework.

Driver abstraction framework for Mark3C.

#### 20.57.2 Intro

This is the basis of the driver framework. In the context of Mark3, drivers don't necessarily have to be based on physical hardware peripherals. They can be used to represent algorithms (such as random number generators), files, or protocol stacks. Unlike FunkOS, where driver IO is protected automatically by a mutex, we do not use this kind of protection - we leave it up to the driver implementor to do what's right in its own context. This also frees up the driver to implement all sorts of other neat stuff, like sending messages to threads associated with the driver. Drivers are implemented as character devices, with the standard array of posix-style accessor methods for reading, writing, and general driver control.

A global driver list is provided as a convenient and minimal "filesystem" structure, in which devices can be accessed by name.

#### 20.57.3 Driver Design

A device driver needs to be able to perform the following operations: -Initialize a peripheral -Start/stop a peripheral -Handle I/O control operations -Perform various read/write operations

At the end of the day, that's pretty much all a device driver has to do, and all of the functionality that needs to be presented to the developer.

We abstract all device drivers using a base-class which implements the following methods: -Start/Open -Stop/Close -Control -Read -Write

A basic driver framework and API can thus be implemented in five function calls - that's it! You could even reduce that further by handling the initialize, start, and stop operations inside the "control" operation.

#### 20.57.4 Driver API

In C++, we can implement this as a class to abstract these event handlers, with virtual void functions in the base class overridden by the inherited objects.

To add and remove device drivers from the global table, we use the following methods:

```
void DriverList::Add( Driver *pclDriver_ );
void DriverList::Remove( Driver *pclDriver_ );
```

DriverList::Add()/Remove() takes a single arguments the pointer to he object to operate on.

Once a driver has been added to the table, drivers are opened by NAME using DriverList::FindBy Name("/dev/name"). This function returns a pointer to the specified driver if successful, or to a built in /dev/null device if the path name is invalid. After a driver is open, that pointer is used for all other driver access functions.

This abstraction is incredibly useful any peripheral or service can be accessed through a consistent set of APIs, that make it easy to substitute implementations from one platform to another. Portability is ensured, the overhead is negligible, and it emphasizes the reuse of both driver and application code as separate entities.

Consider a system with drivers for I2C, SPI, and UART peripherals - under our driver framework, an application can initialize these peripherals and write a greeting to each using the same simple API functions for all drivers:

```
pclI2C = DriverList::FindByName("/dev/i2c");
pclUART = DriverList::FindByName("/dev/tty0");
pclSPI = DriverList::FindByName("/dev/spi");
pclI2C->Write(12, "Hello World!");
pclUART->Write(12, "Hello World!");
pclSPI->Write(12, "Hello World!");
```

Definition in file driver.h.

## 20.58 driver.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00105 #include "kerneltypes.h"
00106 #include "mark3cfg.h"
00107
00108 #include "11.h"
00109
00110 #ifndef __DRIVER_H_
00111 #define __DRIVER_H_
00112
00113 #if KERNEL USE DRIVER
00114
00115 class DriverList;
00116 //-
00121 class Driver : public LinkListNode
00122 {
00123 public:
00124
          void* operator new(size t sz, void* pv) { return (Driver*)pv; };
00130
          virtual void Init() = 0;
00131
```

```
00139
          virtual uint8_t Open() = 0;
00148
          virtual uint8_t Close() = 0;
00149
00164
          virtual uint16_t Read(uint16_t u16Bytes_, uint8_t* pu8Data_) = 0;
00165
00181
          virtual uint16_t Write(uint16_t u16Bytes_, uint8_t* pu8Data_) = 0;
00182
00201
          virtual uint16_t
00202
          Control (uint16_t u16Event_, void* pvDataIn_, uint16_t u16SizeIn_, void* pvDataOut_, uint16_t
ul6SizeOut_)
00203 - ^
00204
        void SetName(const char* pcName_) { m_pcPath = pcName_; }
          const char* GetPath() { return m_pcPath; }
00222 private:
00224
         const char* m_pcPath;
00225 };
00232 class DriverList
00233 {
00234 public:
00242
        static void Init();
00243
       static void Add(Driver* pclDriver_) { m_clDriverList.Add(pclDriver_); }
static void Remove(Driver* pclDriver_) { m_clDriverList.Remove(pclDriver_); }
static Driver* FindByPath(const char* m_pcPath);
00261
00270
00271
00276
00277 #endif // KERNEL_USE_DRIVER
00278
00279 #endif
```

# 20.59 /home/moslevin/projects/mark3-source/kernel/public/eventflag.h File Reference

Event Flag Blocking Object/IPC-Object definition.

```
#include "mark3cfg.h"
#include "kernel.h"
#include "kerneltypes.h"
#include "blocking.h"
#include "thread.h"
```

#### **Classes**

· class EventFlag

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

#### 20.59.1 Detailed Description

Event Flag Blocking Object/IPC-Object definition.

Definition in file eventflag.h.

# 20.60 eventflag.h

```
00001 /*=
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00019 #ifndef __EVENTFLAG_H__
00020 #define __EVENTFLAG_H_
00021
00022 #include "mark3cfg.h'
00022 #include "kernel.h"
00024 #include "kerneltypes.h"
00025 #include "blocking.h"
00026 #include "thread.h"
00027
00028 #if KERNEL_USE_EVENTFLAG
00030 //----
00046 class EventFlag : public BlockingObject
00047 (
00048 public:
00049
          void* operator new(size_t sz, void* pv) { return (EventFlag*)pv; };
           ~EventFlag();
00051
00055
          void Init();
00056
00064
          uint16_t Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_);
00065
00066 #if KERNEL_USE_TIMEOUTS
00075
           uint16_t Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t
      u32TimeMS_);
00076
00084
           void WakeMe(Thread* pclOwner_);
00085
00086 #endif
00087
00093
           void Set(uint16_t u16Mask_);
00094
00099
          void Clear(uint16_t u16Mask_);
00100
          uint16_t GetMask();
00106
00107 private:
00108 #if KERNEL USE TIMEOUTS
00109
00121
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t
      u32TimeMS_);
00122 #else
00123
00133
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation_t eMode_);
00134 #endif
00135
00136
          uint16_t m_u16SetMask;
00137 };
00138
00139 #endif // KERNEL_USE_EVENTFLAG
00140 #endif //__EVENTFLAG_H_
```

## 20.61 /home/moslevin/projects/mark3-source/kernel/public/kernel.h File Reference

### Kernel initialization and startup class.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "paniccodes.h"
#include "thread.h"
```

20.62 kernel.h 269

#### **Classes**

· class Kernel

Class that encapsulates all of the kernel startup functions.

#### 20.61.1 Detailed Description

Kernel initialization and startup class.

The Kernel namespace provides functions related to initializing and starting up the kernel.

The Kernel::Init() function must be called before any of the other functions in the kernel can be used.

Once the initial kernel configuration has been completed (i.e. first threads have been added to the scheduler), the Kernel::Start() function can then be called, which will transition code execution from the "main()" context to the threads in the scheduler.

Definition in file kernel.h.

### 20.62 kernel.h

```
00001
00002
00003
00004
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00032 #ifndef ___KERNEL_H
00033 #define ___KERNEL_H_
00034
00035 #include "mark3cfg.h"
00036 #include "kerneltypes.h"
00037 #include "paniccodes.h"
00038 #include "thread.h"
00039
00040 //---
00044 class Kernel
00045 {
00046 public:
00055
          static void Init(void);
00056
00069
          static void Start (void):
00070
          static bool IsStarted() { return m_bIsStarted; }
00085
          static void SetPanic(PanicFunc_t pfPanic_) { m_pfPanic = pfPanic_; }
00090
          static bool IsPanic() { return m_bIsPanic; }
00095
          static void Panic(uint16_t u16Cause_);
00096
00097 #if KERNEL_USE_IDLE_FUNC
00098
00103
          static void SetIdleFunc(IdleFunc_t pfIdle_) { m_pfIdle = pfIdle_; }
00108
          static void IdleFunc(void)
00109
00110
               if (m_pfIdle != 0) {
00111
                  m_pfIdle();
00112
00113
00114
00122
          static Thread* GetIdleThread(void) { return (Thread*)&
      m_clIdle; }
00123 #endif
00124
00125 #if KERNEL_USE_THREAD_CALLOUTS
```

```
static void SetThreadCreateCallout(ThreadCreateCallout_t pfCreate_) {
      m_pfThreadCreateCallout = pfCreate_; }
00148
          static void SetThreadExitCallout(ThreadExitCallout_t pfExit_) {
m_pfThreadExitCallout = pfExit_; }
00159     static_void_Set_m
          static void SetThreadContextSwitchCallout(ThreadContextCallout_t
     pfContext_)
00160
00161
               m_pfThreadContextCallout = pfContext_;
00162
00163
          static ThreadCreateCallout_t GetThreadCreateCallout(void) { return
00172
      m_pfThreadCreateCallout; }
          static ThreadExitCallout_t GetThreadExitCallout(void) { return
      m_pfThreadExitCallout; }
00190
          static ThreadContextCallout_t GetThreadContextSwitchCallout(void) { return
       m_pfThreadContextCallout; }
00191 #endif
00192
00193 #if KERNEL_USE_STACK_GUARD
00194
          static void SetStackGuardThreshold(uint16_t u16Threshold_) { m_u16GuardThreshold = u16Threshold_; }
00195
          static uint16_t
                                                           GetStackGuardThreshold(void) { return m_u16GuardThreshold;
00196 #endif
00197
00198 private:
00199 static bool
00200 static bool
                              m_bIsPanic;
          static PanicFunc_t m_pfPanic;
00201
00202 #if KERNEL_USE_IDLE_FUNC
00203 static IdleFunc_t m_pfIdle;
00204 static FakeThread_t m_clIdle;
00205 #endif
00206
00207 #if KERNEL_USE_THREAD_CALLOUTS
00208 static ThreadCreateCallout_t m_pfThreadCreateCallout;
00209 static ThreadExitCallout_t m_pfThreadExitCallout;
         static ThreadContextCallout_t m_pfThreadContextCallout;
00211 #endif
00212
00213 #if KERNEL_USE_STACK_GUARD
        static uint16_t m_u16GuardThreshold;
00214
00215 #endif
00216 };
00217
00218 #endif
```

## 20.63 /home/moslevin/projects/mark3-source/kernel/public/kernelaware.h File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

#### **Classes**

class KernelAware

The KernelAware class.

#### **Enumerations**

### 20.63.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.h.

20.64 kernelaware.h 271

### 20.63.2 Enumeration Type Documentation

### 20.63.2.1 enum KernelAwareCommand\_t

This enumeration contains a list of supported commands that can be executed to invoke a response from a kernel aware host.

#### **Enumerator**

```
KA_COMMAND_IDLE Null command, does nothing.
```

 $\textit{KA\_COMMAND\_PROFILE\_INIT} \quad \text{Initialize a new profiling session}.$ 

**KA\_COMMAND\_PROFILE\_START** Begin a profiling sample.

**KA\_COMMAND\_PROFILE\_STOP** End a profiling sample.

KA\_COMMAND\_PROFILE\_REPORT Report current profiling session.

KA\_COMMAND\_EXIT\_SIMULATOR Terminate the host simulator.

KA\_COMMAND\_TRACE\_0 0-argument kernel trace

KA\_COMMAND\_TRACE\_1 1-argument kernel trace

KA\_COMMAND\_TRACE\_2 2-argument kernel trace

KA\_COMMAND\_PRINT Print an arbitrary string of data.

Definition at line 33 of file kernelaware.h.

### 20.64 kernelaware.h

```
00001 /
00002
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ========
00021 #ifndef ___KERNEL_AWARE_H_
00022 #define __KERNEL_AWARE_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #if KERNEL AWARE SIMULATION
00028 //---
00033 typedef enum {
       KA_COMMAND_IDLE = 0,
00034
00035
          KA_COMMAND_PROFILE_INIT,
00036
         KA_COMMAND_PROFILE_START,
00037
          KA_COMMAND_PROFILE_STOP,
00038
          KA_COMMAND_PROFILE_REPORT,
00039
          KA_COMMAND_EXIT_SIMULATOR,
00040
          KA_COMMAND_TRACE_0,
00041
          KA_COMMAND_TRACE_1,
00042
          KA_COMMAND_TRACE_2
          KA COMMAND_PRINT
00043
00044 } KernelAwareCommand_t;
00045
00046 //-
00064 class KernelAware
00065 {
00066 public:
00067
00078
          static void ProfileInit(const char* szStr_);
00079
```

```
static void ProfileStart(void);
00089
00090
          static void ProfileStop(void);
00097
00098
00099
00107
          static void ProfileReport(void);
00108
00109
          static void ExitSimulator(void);
00117
00118
00119
00127
          static void Print (const char* szStr_);
00128
00129
00139
          static void Trace(uint16_t u16File_, uint16_t u16Line_);
00140
00152
          static void Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_);
00153
00154
00166
          static void Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_);
00167
00168
00178
          static bool IsSimulatorAware(void);
00179
00180 private:
00181
00194
          static void
          Trace_i (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_,
00195
      KernelAwareCommand_t eCmd_);
00196 };
00197
00198 #endif
00199
00200 #endif
```

## 20.65 /home/moslevin/projects/mark3-source/kernel/public/kerneldebug.h File Reference

Macros and functions used for assertions, kernel traces, etc.

```
#include "mark3cfg.h"
#include "tracebuffer.h"
#include "kernelaware.h"
#include "paniccodes.h"
#include "kernel.h"
#include "buffalogger.h"
#include "dbg_file_list.h"
```

## **Macros**

```
#define KERNEL_TRACE(x)

Null Kernel Trace Macro.
#define KERNEL_TRACE_1(x, arg1)

Null Kernel Trace Macro.
#define KERNEL_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.
#define USER_TRACE(x)

Null Kernel Trace Macro.
#define USER_TRACE_1(x, arg1)

Null Kernel Trace Macro.
#define USER_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.
#define USER_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.
#define USER_ASSERT(x)
```

Null Kernel Assert Macro.

20.66 kerneldebug.h

### 20.65.1 Detailed Description

Macros and functions used for assertions, kernel traces, etc.

Definition in file kerneldebug.h.

## 20.66 kerneldebug.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009
      --[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #ifndef __KERNEL_DEBUG_H_
00021 #define __KERNEL_DEBUG_H_
00022
00023 #include "mark3cfg.h" 00024 #include "tracebuffer.h"
00025 #include "kernelaware.h
00026 #include "paniccodes.h"
00027 #include "kernel.h"
00028 #include "buffalogger.h"
00029 #include "dbg_file_list.h"
00030
00031 //--
00032 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
00033
00035 #define KERNEL_TRACE(x)
00036
00037 {
00038
                EMIT_DBG_STRING(x);
00039
                uint16_t au16Msg__[4];
00040
                au16Msg_{[0]} = 0xACDC;
00041
                au16Msg__[1] = DBG_FILE;
00042
                au16Msg__[2] = __LINE__;
00043
                au16Msg__[3] = TraceBuffer::Increment();
00044
                TraceBuffer::Write(au16Msg___, 4);
00045
00046 };
00047
00048 //
00049 #define KERNEL_TRACE_1(x, arg1)
00050
00051 {
00052
               EMIT_DBG_STRING(x);
00053
                uint16_t au16Msg__[5];
                au16Msg_{[0]} = 0xACDC;
00054
00055
                au16Msg__[1] = DBG_FILE;
00056
                au16Msg__[2] = __LINE__;
00057
                au16Msg__[3] = TraceBuffer::Increment();
00058
                au16Msg_{[4]} = arg1;
                TraceBuffer::Write(au16Msg___, 5);
```

```
00060
00061 }
00062
00063 //-
00064 #define KERNEL_TRACE_2(x, arg1, arg2)
00065
00066 {
00067
              EMIT_DBG_STRING(x);
00068
              uint16_t au16Msg__[6];
00069
              au16Msg_{[0]} = 0xACDC;
00070
              au16Msg__[1] = DBG_FILE;
00071
              au16Msg__[2] = __LINE__;
00072
              au16Msg__[3] = TraceBuffer::Increment();
00073
              au16Msg__[4] = arg1;
00074
              au16Msq_{5} = arg2;
00075
              TraceBuffer::Write(au16Msg___, 6);
00076
00077
00078
00079 /
00080 #define KERNEL_ASSERT(x)
00081
00082
00083
              if ((x) == false) {
00084
                   EMIT_DBG_STRING("ASSERT FAILED");
00085
                   uint16_t au16Msg__[4];
00086
                   au16Msg_{[0]} = 0xACDC;
00087
                   au16Msg__[1] = DBG_FILE;
00088
                   au16Msg__[2] = __LINE__;
00089
                   au16Msg__[3] = TraceBuffer::Increment();
00090
                   TraceBuffer::Write(au16Msg___, 4);
00091
                   Kernel::Panic(PANIC_ASSERT_FAILED);
00092
00093
00094
00095 #elif (KERNEL_USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
00096
00097 /
00098 #define KERNEL_TRACE(x)
00099
00100 {
00101
              EMIT DBG STRING(x):
00102
              KernelAware::Trace(DBG_FILE, __LINE__);
00103
00104 };
00105
00106 //
00107 #define KERNEL_TRACE_1(x, arg1)
00108
00109 {
00110
              EMIT DBG STRING(x);
00111
              KernelAware::Trace(DBG_FILE, __LINE__, arg1);
00112
00113 }
00114
```

20.66 kerneldebug.h

```
00115 //-
00116 #define KERNEL_TRACE_2(x, arg1, arg2)
00117
00118 {
00119
              EMIT_DBG_STRING(x);
00120
              KernelAware::Trace(DBG_FILE, __LINE__, arg1, arg2);
00121
00122
00123
00124 //--
00125 #define KERNEL_ASSERT(x)
00126
00127 {
00128
              if ((x) == false) {
00129
                  EMIT_DBG_STRING("ASSERT FAILED");
00130
                  KernelAware::Trace(DBG FILE, LINE );
00131
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00132
00133
00134
00135 #elif KERNEL_USE_DEBUG
00136 // If running KERNEL_USE_DEBUG without any logging, ensure that we provide
00137 // at least a basic KERNEL_ASSERT().
00138 //--
00139 #define KERNEL_TRACE(x)
00140 /
00141 #define KERNEL_TRACE_1(x, arg1)
00142 /
00143 #define KERNEL_TRACE_2(x, arg1, arg2)
00144 //-
00145 #define KERNEL ASSERT(x) \
00146 {
00147
          if ((x) == false) {
00148
              Kernel::Panic(PANIC_ASSERT_FAILED);
00149
00150 }
00151 #else
00152 //--
00153 // Note -- when kernel-debugging is disabled, we still have to define the
00154 // macros to ensure that the expressions compile (albeit, by elimination
00155 // during pre-processing).
00157 #define KERNEL_TRACE(x)
00158 //
00159 #define KERNEL_TRACE_1(x, arg1)
00160 //
00161 #define KERNEL_TRACE_2(x, arg1, arg2)
00162 /
00163 #define KERNEL_ASSERT(x)
00164
00165 #endif // KERNEL_USE_DEBUG
00166
00167 //--
00168 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
00169
00170 //--
00171 #define USER_TRACE(x)
00172
00173 {
00174
              EMIT_DBG_STRING(x);
00175
              uint16_t au16Msg__[4];
00176
              au16Msg_{[0]} = 0xACDC;
00177
              au16Msg__[1] = DBG_FILE;
00178
              au16Msg__[2] = __LINE__;
00179
              au16Msg [3] = TraceBuffer::Increment();
```

```
00180
              TraceBuffer::Write(au16Msg___, 4);
00181
00182 };
00183
00184 /
00185 #define USER_TRACE_1(x, arg1)
00186
00187 {
00188
              EMIT_DBG_STRING(x);
00189
              uint16_t au16Msg__[5];
              au16Msg_{[0]} = 0xACDC;
00190
00191
              au16Msg__[1] = DBG_FILE;
00192
              au16Msg__[2] = __LINE__;
00193
              au16Msg__[3] = TraceBuffer::Increment();
00194
              au16Msq_{4} = arg1;
00195
              TraceBuffer::Write(au16Msg___, 5);
00196
00197
00198
00199 /
00200 #define USER_TRACE_2(x, arg1, arg2)
00201
00202 {
00203
              EMIT_DBG_STRING(x);
00204
              uint16_t au16Msg__[6];
00205
              au16Msg_{[0]} = 0xACDC;
00206
              au16Msg__[1] = DBG_FILE;
00207
              au16Msg__[2] = __LINE__;
00208
              au16Msg__[3] = TraceBuffer::Increment();
00209
              au16Msg_{[4]} = arg1;
00210
              au16Msg__[5] = arg2;
00211
              TraceBuffer::Write(au16Msg___, 6);
00212
00213 }
00214
00215 //-
00216 #define USER_ASSERT(x)
00217
00218
00219
              if ((x) == false) {
                   EMIT_DBG_STRING("ASSERT FAILED");
00220
00221
                   uint16_t au16Msq__[4];
00222
                   au16Msg_{[0]} = 0xACDC;
00223
                   au16Msg__[1] = DBG_FILE;
00224
                   au16Msg__[2] = __LINE__;
00225
                   au16Msg__[3] = TraceBuffer::Increment();
00226
                   TraceBuffer::Write(au16Msg___, 4);
                   Kernel::Panic(PANIC_ASSERT_FAILED);
00227
00228
00229
00230
00231 #elif (KERNEL_USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
```

```
00232
00233
00234 #define USER_TRACE(x)
00235
00236 {
00237
              EMIT_DBG_STRING(x);
00238
              KernelAware::Trace(DBG_FILE, __LINE__);
00239
00240 };
00242 //--
00243 #define USER_TRACE_1(x, arg1)
00244
00245 {
00246
              EMIT_DBG_STRING(x);
00247
              KernelAware::Trace(DBG_FILE, __LINE__, arg1);
00248
00249 }
00250
00251 //---
00252 #define USER_TRACE_2(x, arg1, arg2)
00253
00254 {
00255
              {\tt EMIT\_DBG\_STRING(x);}
00256
              KernelAware::Trace(DBG_FILE, __LINE__, arg1, arg2);
00259
00260 //----
00261 #define USER_ASSERT(x)
00262
00263 {
00264
              if ((x) == false) {
00265
                  EMIT_DBG_STRING("ASSERT FAILED");
00266
                  KernelAware::Trace(DBG_FILE, __LINE__);
00267
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00268
00269
00270 }
00271
00272 #else
00273 //---
00274 // Note -- when kernel-debugging is disabled, we still have to define the
00275 // macros to ensure that the expressions compile (albeit, by elimination
00276 // during pre-processing).
00277 //--
00278 #define USER_TRACE(x)
00279 //-
00280 #define USER_TRACE_1(x, arg1)
00281 //--
00282 #define USER_TRACE_2(x, arg1, arg2)
00283 /
00284 #define USER_ASSERT(x)
00285
00286 #endif // KERNEL_USE_DEBUG
00287
00288 #endif
```

## 20.67 /home/moslevin/projects/mark3-source/kernel/public/kerneltypes.h File Reference

Basic data type primatives used throughout the OS.

```
#include <stdint.h>
#include <stdbool.h>
#include <stddef.h>
```

## **Typedefs**

typedef void(\* PanicFunc\_t) (uint16\_t u16PanicCode\_)
 Function pointer type used to implement kernel-panic handlers.

typedef void(\* IdleFunc t) (void)

Function pointer type used to implement the idle function, where support for an idle function (as opposed to an idle thread) exists.

typedef void(\* ThreadEntry\_t) (void \*pvArg\_)

Function pointer type used for thread entrypoint functions.

#### **Enumerations**

#### 20.67.1 Detailed Description

Basic data type primatives used throughout the OS.

Definition in file kerneltypes.h.

## 20.67.2 Enumeration Type Documentation

20.67.2.1 enum EventFlagOperation\_t

This enumeration describes the different operations supported by the event flag blocking object.

#### **Enumerator**

**EVENT\_FLAG\_ALL** Block until all bits in the specified bitmask are set.

EVENT\_FLAG\_ANY Block until any bits in the specified bitmask are set.

**EVENT\_FLAG\_ALL\_CLEAR** Block until all bits in the specified bitmask are cleared.

EVENT\_FLAG\_ANY\_CLEAR Block until any bits in the specified bitmask are cleared.

EVENT\_FLAG\_MODES Count of event-flag modes. Not used by user

EVENT\_FLAG\_PENDING\_UNBLOCK Special code. Not used by user

Definition at line 50 of file kerneltypes.h.

20.68 kerneltypes.h 279

## 20.68 kerneltypes.h

```
00003
00004 |
00005 1
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00019 #include <stdint.h>
00020 #include <stdbool.h>
00021 #include <stddef.h>
00022
00023 #ifndef __KERNELTYPES_H_
00024 #define ___KERNELTYPES_H_
00030 typedef void (*PanicFunc_t) (uint16_t u16PanicCode_);
00031
00032 //----
00037 typedef void (*IdleFunc_t)(void);
00043 typedef void (*ThreadEntry_t)(void* pvArg_);
00044
00045 //-----
00050 typedef enum {
00051 EVENT_FLAG_ALL,
00052
         EVENT_FLAG_ANY,
00053
         EVENT_FLAG_ALL_CLEAR,
       EVENT_FLAG_ANY_CLEAR,
00054
                                    //---
00055
       EVENT_FLAG_MODES,
EVENT_FLAG_PENDING_UNBLOCK
00056
00057
00058 } EventFlagOperation_t;
00059
00060 //----
00064 typedef enum {
00065 THREAD_STATE_EXIT = 0,
00066
         THREAD_STATE_READY,
         THREAD_STATE_BLOCKED,
        THREAD_STATE_STOP,
00068
00069
        //--
THREAD_STATES,
00070
00071
         THREAD_STATE_INVALID
00072 } ThreadState_t;
00074 #endif
```

# 20.69 /home/moslevin/projects/mark3-source/kernel/public/ksemaphore.h File Reference

Semaphore Blocking Object class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "threadlist.h"
```

#### Classes

· class Semaphore

Binary & Counting semaphores, based on BlockingObject base class.

## 20.69.1 Detailed Description

Semaphore Blocking Object class declarations.

Definition in file ksemaphore.h.

## 20.70 ksemaphore.h

```
00002
00003
00004
00005 1
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00022 #ifndef __KSEMAPHORE_H_
00023 #define __KSEMAPHORE_H_
00024
00025 #include "kerneltypes.h"
00026 #include "mark3cfg.h"
00027
00028 #include "blocking.h"
00029 #include "threadlist.h"
00030
00031 #if KERNEL_USE_SEMAPHORE
00032
00033 //-
00037 class Semaphore : public BlockingObject
00038 {
00039 public:
00040
          void* operator new(size_t sz, void* pv) { return (Semaphore*)pv; };
00041
          ~Semaphore();
00042
00064
          void Init(uint16_t u16InitVal_, uint16_t u16MaxVal_);
00065
08000
          bool Post();
00081
00089
          void Pend();
00090
00102
          uint16_t GetCount();
00103
00104 #if KERNEL_USE_TIMEOUTS
00105
00116
          bool Pend(uint32_t u32WaitTimeMS_);
00117
          void WakeMe(Thread* pclChosenOne_);
00128
00129 #endif
00130
00131 private:
00137
          uint8_t WakeNext();
00138
00139 #if KERNEL_USE_TIMEOUTS
00140
00148
          bool Pend_i (uint32_t u32WaitTimeMS_);
00149 #else
00150
00156
          void Pend_i (void);
00157 #endif
00158
00159
          uint16_t m_u16Value;
00160
          uint16_t m_u16MaxValue;
00161 };
00162
00163 #endif // KERNEL_USE_SEMAPHORE
00164
00165 #endif
```

## 20.71 /home/moslevin/projects/mark3-source/kernel/public/II.h File Reference

Core linked-list declarations, used by all kernel list types.

```
#include "kerneltypes.h"
```

#### **Classes**

· class LinkListNode

Basic linked-list node data structure.

· class LinkList

Abstract-data-type from which all other linked-lists are derived.

· class DoubleLinkList

Doubly-linked-list data type, inherited from the base LinkList type.

· class CircularLinkList

Circular-linked-list data type, inherited from the base LinkList type.

#### 20.71.1 Detailed Description

Core linked-list declarations, used by all kernel list types.

At the heart of RTOS data structures are linked lists. Having a robust and efficient set of linked-list types that we can use as a foundation for building the rest of our kernel types allows u16 to keep our RTOS code efficient and logically-separated.

So what data types rely on these linked-list classes?

-Threads -ThreadLists -The Scheduler -Timers, -The Timer Scheduler -Blocking objects (Semaphores, Mutexes, etc...)

Pretty much everything in the kernel uses these linked lists. By having objects inherit from the base linked-list node type, we're able to leverage the double and circular linked-list classes to manager virtually every object type in the system without duplicating code. These functions are very efficient as well, allowing for very deterministic behavior in our code.

Definition in file II.h.

### 20.72 II.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ==
00043 #ifndef __LL_H_
00044 #define __LL_H_
00045
```

```
00046 #include "kerneltypes.h"
00047
00048 //---
00049 #ifndef NULL
00050 #define NULL (0)
00051 #endif
00052
00053 //---
00059 class LinkList;
00060 class DoubleLinkList;
00061 class CircularLinkList:
00062
00063 //----
00068 class LinkListNode
00069 {
00070 protected:
          LinkListNode* next;
00071
00072
          LinkListNode* prev;
00074
         LinkListNode() {}
00080
         void ClearNode();
00081
00082 public:
        LinkListNode* GetNext(void) { return next; }
LinkListNode* GetPrev(void) { return prev; }
00090
00098
00099
         friend class LinkList;
00100
         friend class DoubleLinkList;
        friend class CircularLinkList;
00101
00102
         friend class ThreadList;
00103 };
00104
00105 //--
00109 class LinkList
00110 {
00111 protected:
         LinkListNode* m_pstHead;
00112
00113
          LinkListNode* m_pstTail;
00115 public:
00121
       void Init()
00122
          {
              m_pstHead = NULL;
m_pstTail = NULL;
00123
00124
00125
          }
00126
00134
          LinkListNode* GetHead() { return m_pstHead; }
00142
         LinkListNode* GetTail() { return m_pstTail; }
00143 };
00144
00145 //-
00149 class DoubleLinkList : public LinkList
00150 {
00151 public:
00152
          void* operator new(size_t sz, void* pv) { return (DoubleLinkList*)pv; };
00158
          DoubleLinkList()
00159
          {
00160
              m_pstHead = NULL;
00161
              m_pstTail = NULL;
00162
00163
         void Add(LinkListNode* node_);
00171
00172
00180
          void Remove(LinkListNode* node_);
00181 };
00182
00183 //----
00187 class CircularLinkList : public LinkList
00188 {
00189 public:
          void* operator new(size_t sz, void* pv) { return (CircularLinkList*)pv; };
00190
00191
          CircularLinkList()
00192
              m_pstHead = NULL;
m_pstTail = NULL;
00193
00194
00195
          }
00196
00204
          void Add(LinkListNode* node_);
00205
00213
          void Remove(LinkListNode* node );
00214
00221
          void PivotForward();
00222
00229
          void PivotBackward();
00230
00240
          void InsertNodeBefore(LinkListNode* node_, LinkListNode* insert_);
00241 };
00242
```

00243 #endif

# 20.73 /home/moslevin/projects/mark3-source/kernel/public/mailbox.h File Reference

Mailbox + Envelope IPC Mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "ksemaphore.h"
```

#### **Classes**

· class Mailbox

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

### 20.73.1 Detailed Description

Mailbox + Envelope IPC Mechanism.

Definition in file mailbox.h.

### 20.74 mailbox.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00021 #ifndef __MAILBOX_H__
00022 #define __MAILBOX_H_
00023
00024 #include "mark3cfg.h"
00025 #include "kerneltypes.h"
00026 #include "ksemaphore.h"
00027
00028 #if KERNEL_USE_MAILBOX
00029
00035 class Mailbox
00036 {
00037 public:
00038
          void* operator new(size_t sz, void* pv) { return (Mailbox*)pv; };
00039
00040
00051
          void Init(void* pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_);
00052
00053 #if KERNEL_USE_AUTO_ALLOC
00054
          static Mailbox* Init(uint16_t u16BufferSize_, uint16_t u16ElementSize_);
00067
00068
00069 #endif
00070
00084
          bool Send(void* pvData_);
```

```
00085
00099
          bool SendTail(void* pvData_);
00100
00101 #if KERNEL USE TIMEOUTS
00102
00116
          bool Send(void* pvData_, uint32_t u32TimeoutMS_);
00117
00132
          bool SendTail(void* pvData_, uint32_t u32TimeoutMS_);
00133 #endif
00134
00144
          void Receive(void* pvData_);
00145
00155
          void ReceiveTail(void* pvData_);
00156
00157 #if KERNEL_USE_TIMEOUTS
00158
          bool Receive (void* pvData , uint32 t u32TimeoutMS );
00170
00171
00184
          bool ReceiveTail(void* pvData_, uint32_t u32TimeoutMS_);
00185 #endif
00186
00187
          uint16_t GetFreeSlots(void)
00188
00189
              uint16 t rc:
00190
              CS_ENTER();
00191
              rc = m_u16Free;
00192
              CS_EXIT();
00193
              return rc;
00194
         }
00195
          bool IsFull(void) { return (GetFreeSlots() == 0); }
bool IsEmpty(void) { return (GetFreeSlots() == m_ul6Count); }
00196
00197
00198 private:
00207
          void* GetHeadPointer(void)
00208
              K ADDR uAddr = (K_ADDR)m_pvBuffer;
00209
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (
00210
     m_u16Head);
00211
              return (void*)uAddr;
00212
00213
          void* GetTailPointer(void)
00222
00223
00224
              K_ADDR uAddr = (K_ADDR)m_pvBuffer;
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (
     m_u16Tail);
00226
             return (void*)uAddr;
00227
00228
00238
          void CopyData(const void* src_, const void* dst_, uint16_t len_)
00239
00240
              uint8_t* u8Src = (uint8_t*)src_;
00241
              uint8_t* u8Dst = (uint8_t*)dst_;
00242
              while (len_--) {
  *u8Dst++ = *u8Src++;
00243
00244
              }
00245
          }
00246
00252
          void MoveTailForward(void)
00253
00254
              m u16Tail++:
00255
              if (m_u16Tail == m_u16Count) {
00256
                  m_u16Tail = 0;
00257
00258
          }
00259
00265
          void MoveHeadForward(void)
00266
00267
              m_u16Head++;
00268
              if (m_u16Head == m_u16Count) {
00269
                  m_u16Head = 0;
00270
00271
          }
00272
00278
          void MoveTailBackward(void)
00279
00280
              if (m_u16Tail == 0) {
00281
                  m_u16Tail = m_u16Count;
00282
              m_u16Tail--;
00283
00284
          }
00285
00291
          void MoveHeadBackward(void)
00292
00293
               if (m_u16Head == 0) {
                   m_u16Head = m_u16Count;
00294
00295
              }
```

```
00296
             m_u16Head--;
00297
00298
00299 #if KERNEL USE TIMEOUTS
00300
         bool Send_i(const void* pvData_, bool bTail_, uint32_t u32WaitTimeMS_);
00310
00311 #else
00312
00321
          bool Send_i(const void* pvData_, bool bTail_);
00322 #endif
00323
00324 #if KERNEL USE TIMEOUTS
00325
00335
         bool Receive_i(const void* pvData_, bool bTail_, uint32_t u32WaitTimeMS_);
00336 #else
00337
00345
          void Receive_i(const void* pvData_, bool bTail_);
00346 #endif
00347
00348
          uint16_t m_u16Head;
00349
         uint16_t m_u16Tail;
00350
00351
         uint16 t
                           m_u16Count;
00352
         volatile uint16_t m_u16Free;
00353
00354
                      m_u16ElementSize;
00355
         const void* m_pvBuffer;
00356
00357
         Semaphore m_clRecvSem;
00358
00359 #if KERNEL_USE_TIMEOUTS
00360
         Semaphore m_clSendSem;
00361 #endif
00362 };
00363
00364 #endif
00365
00366 #endif
```

# 20.75 /home/moslevin/projects/mark3-source/kernel/public/manual.h File Reference

/brief Ascii-format documentation, used by doxygen to create various printable and viewable forms.

### 20.75.1 Detailed Description

/brief Ascii-format documentation, used by doxygen to create various printable and viewable forms.

Definition in file manual.h.

### 20.76 manual.h

## 20.77 /home/moslevin/projects/mark3-source/kernel/public/mark3.h File Reference

Single include file given to users of the Mark3 Kernel API.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "threadport.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "kernelprofile.h"
#include "kernel.h"
#include "thread.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "mutex.h"
#include "eventflag.h"
#include "message.h"
#include "notify.h"
#include "mailbox.h"
#include "atomic.h"
#include "driver.h"
#include "kernelaware.h"
#include "profile.h"
#include "autoalloc.h"
#include "priomap.h"
```

### 20.77.1 Detailed Description

Single include file given to users of the Mark3 Kernel API.

Definition in file mark3.h.

## 20.78 mark3.h

```
00004
00005
00006 1
00007
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00021 #ifndef ___MARK3_H__
00022 #define __MARK3_H_
00023
00024 #include "mark3cfg.h"
00025 #include "kerneltypes.h"
00026
00027 #include "threadport.h"
00028 #include "kernelswi.h"
00029 #include "kerneltimer.h"
00030 #include "kernelprofile.h"
00031
00032 #include "kernel.h"
00033 #include "thread.h"
00034 #include "timerlist.h"
```

```
00035
00036 #include "ksemaphore.h"
00037 #include "mutex.h"
00038 #include "eventflag.h"
00039 #include "message.h"
00040 #include "notify.h"
00041 #include "mailbox.h"
00042
00043 #include "atomic.h"
00044 #include "driver.h"
00045
00046 #include "kernelaware.h"
00047
00048 #include "profile.h"
00049 #include "autoalloc.h"
00050 #include "priomap.h"
00051
00051
```

## 20.79 /home/moslevin/projects/mark3-source/kernel/public/mark3cfg.h File Reference

Mark3 Kernel Configuration.

```
#include "portcfg.h"
```

#### **Macros**

#define KERNEL\_NUM\_PRIORITIES (8)

Define the number of thread priorities that the kernel's scheduler will support.

• #define KERNEL USE TIMERS (1)

The following options is related to all kernel time-tracking.

• #define KERNEL\_TIMERS\_TICKLESS (1)

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

• #define KERNEL TIMERS MINIMUM DELAY US (25)

When using tickless timers, it is useful to define a minimum sleep value.

#define KERNEL\_USE\_TIMEOUTS (1)

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it.

• #define KERNEL USE QUANTUM (1)

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

• #define THREAD\_QUANTUM\_DEFAULT (4)

This value defines the default thread quantum when KERNEL\_USE\_QUANTUM is enabled.

#define KERNEL\_USE\_NOTIFY (1)

This is a simple blocking object, where a thread (or threads) are guaranteed to block until an asynchronous event signals the object.

• #define KERNEL USE SEMAPHORE (1)

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

• #define KERNEL USE MUTEX (1)

Do you want the ability to use mutual exclusion semaphores (mutex) for resource/block protection? Enabling this feature provides mutexes, with priority inheritence, as declared in mutex.h.

• #define KERNEL USE EVENTFLAG (1)

Provides additional event-flag based blocking.

#define KERNEL\_USE\_MESSAGE (1)

Enable inter-thread messaging using message queues.

• #define GLOBAL\_MESSAGE\_POOL\_SIZE (8)

If Messages are enabled, define the size of the default kernel message pool.

#define KERNEL\_USE\_MAILBOX (1)

Enable inter-thread messaging using mailboxes.

#define KERNEL\_USE\_SLEEP (1)

Do you want to be able to set threads to sleep for a specified time? This enables the Thread::Sleep() API.

• #define KERNEL\_USE\_DRIVER (1)

Enabling device drivers provides a posix-like filesystem interface for peripheral device drivers.

• #define KERNEL\_USE\_THREADNAME (0)

Provide Thread method to allow the user to set a name for each thread in the system.

• #define KERNEL\_USE\_EXTENDED\_CONTEXT (1)

Allocate an extra pointer's worth of storage within a Thread object (and corresponding accessor methods) to provide the user with a means to implement arbitrary Thread-local storage.

• #define KERNEL\_USE\_DYNAMIC\_THREADS (1)

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime.

#define KERNEL\_USE\_PROFILER (1)

Provides extra classes for profiling the performance of code.

• #define KERNEL USE DEBUG (1)

Provides extra logic for kernel debugging, and instruments the kernel with extra asserts, and kernel trace functionality.

• #define KERNEL ENABLE LOGGING (0)

Set this to 1 to enable very chatty kernel logging.

• #define KERNEL\_ENABLE\_USER\_LOGGING (0)

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently.

#define KERNEL\_USE\_ATOMIC (0)

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

• #define SAFE\_UNLINK (0)

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

• #define KERNEL AWARE SIMULATION (1)

Include support for kernel-aware simulation.

#define KERNEL\_USE\_IDLE\_FUNC (1)

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

• #define KERNEL USE AUTO ALLOC (0)

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

• #define KERNEL USE THREAD CALLOUTS (1)

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited

#define KERNEL\_USE\_STACK\_GUARD (0)

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch.

• #define KERNEL EXTRA CHECKS (0)

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations.

## 20.79.1 Detailed Description

Mark3 Kernel Configuration.

This file is used to configure the kernel for your specific application in order to provide the optimal set of features for a given use case.

Since you only pay the price (code space/RAM) for the features you use, you can usually find a sweet spot between features and resource usage by picking and choosing features a-la-carte. This config file is written in an "interactive" way, in order to minimize confusion about what each option provides, and to make dependencies obvious.

Definition in file mark3cfg.h.

#### 20.79.2 Macro Definition Documentation

20.79.2.1 #define GLOBAL\_MESSAGE\_POOL\_SIZE (8)

If Messages are enabled, define the size of the default kernel message pool.

Messages can be manually added to the message pool, but this mechansims is more convenient and automatic. All message queues share their message objects from this global pool to maximize efficiency and simplify data management.

Definition at line 174 of file mark3cfg.h.

20.79.2.2 #define KERNEL\_AWARE\_SIMULATION (1)

Include support for kernel-aware simulation.

Enabling this feature adds advanced profiling, trace, and environment-aware debugging and diagnostic functionality when Mark3-based applications are run on the flavr AVR simulator.

Definition at line 284 of file mark3cfg.h.

20.79.2.3 #define KERNEL\_ENABLE\_LOGGING (0)

Set this to 1 to enable very chatty kernel logging.

Since most important things in the kernel emit logs, a large log-buffer and fast output are required in order to keep up. This is a pretty advanced power-user type feature, so it's disabled by default.

Definition at line 249 of file mark3cfg.h.

20.79.2.4 #define KERNEL\_ENABLE\_USER\_LOGGING (0)

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently.

This allows for user-code to benefit from the built-in kernel logging macros without having to account for the superhigh-volume of logs generated by kernel code.1 to enable logging outside of kernel code

Definition at line 258 of file mark3cfg.h.

20.79.2.5 #define KERNEL\_EXTRA\_CHECKS (0)

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations.

This is especially helpful during development, and can help catch problems at development time, instead of in the field.include CPU/Port specific configuration options

Definition at line 339 of file mark3cfg.h.

20.79.2.6 #define KERNEL\_NUM\_PRIORITIES (8)

Define the number of thread priorities that the kernel's scheduler will support.

The number of thread priorities is limited only by the memory of the host CPU, as a ThreadList object is statically-allocated for each thread priority.

In practice, systems rarely need more than 32 priority levels, with the most complex having the capacity for 256.

Definition at line 41 of file mark3cfg.h.

20.79.2.7 #define KERNEL TIMERS MINIMUM DELAY US (25)

When using tickless timers, it is useful to define a minimum sleep value.

In the event that a delay/sleep/timeout value lower than this is provided to a timer-based API, the minimum value will be substituted.

Definition at line 86 of file mark3cfg.h.

20.79.2.8 #define KERNEL\_TIMERS\_TICKLESS (1)

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

Tick-based timers provide a "traditional" RTOS timer implementation based on a fixed-frequency timer interrupt. While this provides very accurate, reliable timing, it also means that the CPU is being interrupted far more often than may be necessary (as not all timer ticks result in "real work" being done).

Tick-less timers still rely on a hardware timer interrupt, but uses a dynamic expiry interval to ensure that the interrupt is only called when the next timer expires. This increases the complexity of the timer interrupt handler, but reduces the number and frequency.

Note that the CPU port (kerneltimer.cpp) must be implemented for the particular timer variant desired.

Definition at line 77 of file mark3cfg.h.

20.79.2.9 #define KERNEL\_USE\_ATOMIC (0)

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

Add/Sub/Set contain 8, 16, and 32-bit variants.

Definition at line 268 of file mark3cfg.h.

20.79.2.10 #define KERNEL\_USE\_AUTO\_ALLOC (0)

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

Note that auto-alloc memory cannot be reclaimed.

Definition at line 305 of file mark3cfg.h.

20.79.2.11 #define KERNEL\_USE\_DYNAMIC\_THREADS (1)

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime.

useful for designs implementing worker threads, or threads that can be restarted after encountering error conditions.

Definition at line 228 of file mark3cfg.h.

20.79.2.12 #define KERNEL\_USE\_EVENTFLAG (1)

Provides additional event-flag based blocking.

This relies on an additional per-thread flag-mask to be allocated, which adds 2 bytes to the size of each thread object.

Definition at line 153 of file mark3cfg.h.

20.79.2.13 #define KERNEL\_USE\_IDLE\_FUNC (1)

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

This saves a full thread stack, but also requires a bit extra static data. This also adds a slight overhead to the context switch and scheduler, as a special case has to be taken into account.

Definition at line 294 of file mark3cfg.h.

20.79.2.14 #define KERNEL\_USE\_MAILBOX (1)

Enable inter-thread messaging using mailboxes.

A mailbox manages a blob of data provided by the user, that is partitioned into fixed-size blocks called envelopes. The size of an envelope is set by the user when the mailbox is initialized. Any number of threads can read-from and write-to the mailbox. Envelopes can be sent-to or received-from the mailbox at the head or tail. In this way, mailboxes essentially act as a circular buffer that can be used as a blocking FIFO or LIFO gueue.

Definition at line 187 of file mark3cfg.h.

20.79.2.15 #define KERNEL\_USE\_MESSAGE (1)

Enable inter-thread messaging using message queues.

This is the preferred mechanism for IPC for serious multi-threaded communications; generally anywhere a semaphore or event-flag is insufficient.

Definition at line 161 of file mark3cfg.h.

20.79.2.16 #define KERNEL\_USE\_PROFILER (1)

Provides extra classes for profiling the performance of code.

useful for debugging and development, but uses an additional hardware timer.

Definition at line 234 of file mark3cfg.h.

20.79.2.17 #define KERNEL\_USE\_QUANTUM (1)

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

This allows equal tasks to use unequal amounts of the CPU, which is a great way to set up CPU budgets per thread in a round-robin scheduling system. If enabled, you can specify a number of ticks that serves as the default time period (quantum). Unless otherwise specified, every thread in a priority will get the default quantum.

Definition at line 116 of file mark3cfg.h.

20.79.2.18 #define KERNEL\_USE\_SEMAPHORE (1)

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

If you have to pick one blocking mechanism, this is the one to choose.

Definition at line 139 of file mark3cfg.h.

20.79.2.19 #define KERNEL\_USE\_STACK\_GUARD (0)

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch.

Enabling this is the most effective means to guard against stack corruption and stack overflow in the kernel, at the cost of increased context switch latency.

Definition at line 327 of file mark3cfg.h.

20.79.2.20 #define KERNEL\_USE\_THREAD\_CALLOUTS (1)

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited.

This is useful for implementing low-level instrumentation based on information held in the threads.

Definition at line 317 of file mark3cfg.h.

20.79.2.21 #define KERNEL\_USE\_THREADNAME (0)

Provide Thread method to allow the user to set a name for each thread in the system.

Adds a const char\* pointer to the size of the thread object.

Definition at line 213 of file mark3cfg.h.

20.79.2.22 #define KERNEL\_USE\_TIMEOUTS (1)

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it.

This support comes at a small cost to code size, but a slightly larger cost to realtime performance - as checking for the use of timers in the underlying internal code costs some cycles.

As a result, the option is given to the user here to manually disable these timeout-based APIs if desired by the user for performance and code-size reasons.

Definition at line 101 of file mark3cfg.h.

20.79.2.23 #define KERNEL\_USE\_TIMERS (1)

The following options is related to all kernel time-tracking.

- -timers provide a way for events to be periodically triggered in a lightweight manner. These can be periodic, or one-shot.
- -Thread Quantum (usedd for round-robin scheduling) is dependent on this module, as is Thread Sleep functionality.

Definition at line 56 of file mark3cfg.h.

20.79.2.24 #define SAFE\_UNLINK (0)

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

This goes beyond pointer checks, adding a layer of structural and metadata validation to help detect system corruption early.

Definition at line 276 of file mark3cfg.h.

#### 20.79.2.25 #define THREAD\_QUANTUM\_DEFAULT (4)

This value defines the default thread quantum when KERNEL\_USE\_QUANTUM is enabled.

The thread quantum value is in milliseconds

Definition at line 125 of file mark3cfg.h.

## 20.80 mark3cfg.h

```
00001 /*----
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00029 #ifndef __MARK3CFG_H_
00030 #define ___MARK3CFG_H_
00031
00041 #define KERNEL_NUM_PRIORITIES (8)
00042
00043 #if KERNEL_NUM_PRIORITIES > 1024
00044 #error "Mark3 supports a maximum of 1024 priorities"
00045 #endif
00046
00056 #define KERNEL_USE_TIMERS (1)
00057
00076 #if KERNEL_USE_TIMERS
00077 #define KERNEL_TIMERS_TICKLESS (1)
00078 #endif
00079
00080 #if KERNEL_TIMERS_TICKLESS
00081
00086 #define KERNEL_TIMERS_MINIMUM_DELAY_US (25)
00087 #endif
00088
00100 #if KERNEL_USE_TIMERS
00101 #define KERNEL USE TIMEOUTS (1)
00102 #else
00103 #define KERNEL_USE_TIMEOUTS (0)
00104 #endif
00105
00115 #if KERNEL_USE_TIMERS
00116 #define KERNEL_USE_QUANTUM (1)
00117 #else
00118 #define KERNEL_USE_QUANTUM (0)
00119 #endif
00120
00125 #define THREAD QUANTUM DEFAULT (4)
00126
00131 #define KERNEL_USE_NOTIFY (1)
00132
00139 #define KERNEL_USE_SEMAPHORE (1)
00140
00146 #define KERNEL_USE_MUTEX (1)
00147
00153 #define KERNEL_USE_EVENTFLAG (1)
00154
00160 #if KERNEL_USE_SEMAPHORE
00161 #define KERNEL_USE_MESSAGE (1)
00162 #else
00163 #define KERNEL_USE_MESSAGE (0)
00164 #endif
00165
00173 #if KERNEL_USE_MESSAGE
00174 #define GLOBAL_MESSAGE_POOL_SIZE (8)
00175 #endif
00176
00186 #if KERNEL_USE_SEMAPHORE
00187 #define KERNEL_USE_MAILBOX (1)
00188 #else
```

```
00189 #define KERNEL_USE_MAILBOX (0)
00190 #endif
00191
00196 #if KERNEL_USE_TIMERS && KERNEL_USE_SEMAPHORE
00197 #define KERNEL_USE_SLEEP (1)
00198 #else
00199 #define KERNEL_USE_SLEEP (0)
00200 #endif
00201
00206 #define KERNEL USE DRIVER (1)
00207
00213 #define KERNEL USE THREADNAME (0)
00214
00220 #define KERNEL_USE_EXTENDED_CONTEXT
00221
00228 #define KERNEL_USE_DYNAMIC_THREADS (1)
00229
00234 #define KERNEL USE PROFILER (1)
00240 #define KERNEL_USE_DEBUG (1)
00241
00242 #if KERNEL_USE_DEBUG
00243
00249 #define KERNEL ENABLE LOGGING (0)
00250
00258 #define KERNEL_ENABLE_USER_LOGGING (0)
00259 #else
00260 #define KERNEL_ENABLE_LOGGING (0)
00261 #define KERNEL_ENABLE_USER_LOGGING (0)
00262 #endif
00263
00268 #define KERNEL_USE_ATOMIC (0)
00269
00276 #define SAFE_UNLINK (0)
00277
00284 #define KERNEL_AWARE_SIMULATION (1)
00285
00293 #if !defined(ARM)
00294 #define KERNEL_USE_IDLE_FUNC (1) // Supported everywhere but ARM
00295 #else
00296 #define KERNEL_USE_IDLE_FUNC (0) // Not currently supported on ARM
00297 #endif
00298
00305 #define KERNEL_USE_AUTO_ALLOC (0)
00306
00307 #if KERNEL_USE_AUTO_ALLOC
00308 #define AUTO_ALLOC_SIZE (512)
00309 #endif
00310
00317 #define KERNEL_USE_THREAD_CALLOUTS (1)
00318
00327 #define KERNEL_USE_STACK_GUARD (0)
00328
00329 #if KERNEL_USE_STACK_GUARD
00330 #define KERNEL_STACK_GUARD_DEFAULT (32) // words
00331 #endif
00332
00339 #define KERNEL_EXTRA_CHECKS (0)
00340
00341 #include "portcfg.h"
00342
00343 #endif
```

# 20.81 /home/moslevin/projects/mark3-source/kernel/public/message.h File Reference

Inter-thread communication via message-passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "ksemaphore.h"
#include "timerlist.h"
```

#### Classes

· class Message

Class to provide message-based IPC services in the kernel.

class MessagePool

Implements a list of message objects.

class GlobalMessagePool

Implements a list of message objects shared between all threads.

• class MessageQueue

List of messages, used as the channel for sending and receiving messages between threads.

## 20.81.1 Detailed Description

Inter-thread communication via message-passing.

Embedded systems guru Jack Ganssle once said that without a robust form of interprocess communications (IPC), an RTOS is just a toy. Mark3 implements a form of IPC to provide safe and flexible messaging between threads.

using kernel-managed IPC offers significant benefits over other forms of data sharing (i.e. Global variables) in that it avoids synchronization issues and race conditions common to the practice. using IPC also enforces a more disciplined coding style that keeps threads decoupled from one another and minimizes global data, preventing careless and hard-to-debug errors.

## 20.81.2 using Messages, Queues, and the Global Message Pool

```
// Declare a message queue shared between two threads
MessageQueue my_queue;
int main()
    // Initialize the message gueue
    my_queue.init();
void Thread1()
    // Example TX thread - sends a message every 10ms
    while(1)
        // Grab a message from the global message pool
        Message *tx_message = GlobalMessagePool::Pop();
        // Set the message data/parameters
        tx_message->SetCode( 1234 );
        tx_message->SetData( NULL );
        \ensuremath{//} Send the message on the queue.
        my\_queue.Send(tx\_message);
        Thread::Sleep(10);
void Thread2()
    while()
         // Blocking receive - wait until we have messages to process
        Message *rx_message = my_queue.Recv();
        // Do something with the message data...
        // Return back into the pool when done
        GlobalMessagePool::Push(rx_message);
```

Definition in file message.h.

20.82 message.h 297

# 20.82 message.h

```
00001 /*========
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00080 #ifndef __MESSAGE_H_
00081 #define __MESSAGE_H_
00082
00083 #include "kerneltypes.h"
00084 #include "mark3cfg.h"
00085
00086 #include "ll.h"
00087 #include "ksemaphore.h"
00088
00089 #if KERNEL_USE_MESSAGE
00090
00091 #if KERNEL USE TIMEOUTS
00092 #include "timerlist.h"
00093 #endif
00094
00095 //---
00099 class Message : public LinkListNode
00100 {
00101 public:
00102
          void* operator new(size_t sz, void* pv) { return (Message*)pv; };
00108
           void Init()
00109
00110
               ClearNode();
              m_pvData = NULL;
m_u16Code = 0;
00111
00112
00113
          }
00114
00122
          void SetData(void* pvData_) { m_pvData = pvData_; }
          void* GetData() { return m_pvData; }
void SetCode(uint16_t u16Code_) { m_u16Code = u16Code_; }
00130
00138
          uint16_t GetCode() { return m_u16Code; }
00146
00147 private:
          void* m_pvData;
00150
00152
          uint16_t m_u16Code;
00153 };
00154
00155 //-
00159 class MessagePool
00160 {
00161 public:
00167
          void Init();
00168
00178
          void Push (Message* pclMessage_);
00179
00188
          Message* Pop();
00189
00197
          Message* GetHead();
00198
00199 private:
00201
          DoubleLinkList m_clList;
00202 };
00203
00204 //
00208 class GlobalMessagePool
00209 {
00210 public:
00216
          static void Init();
00217
00227
          static void Push(Message* pclMessage_);
00228
00237
          static Message* Pop();
00238
00246
          static Message* GetHead();
00247
00255
          static MessagePool* GetPool();
00256
00257 private:
00259
          static Message m_aclMessagePool[GLOBAL_MESSAGE_POOL_SIZE];
00260
00261
          static MessagePool m_clPool;
```

```
00262 };
00264 //--
00269 class MessageQueue
00270 {
00271 public:
         void* operator new(size_t sz, void* pv) { return (MessageQueue*)pv; };
00278
00279
00288
         Message* Receive();
00289
00290 #if KERNEL_USE_TIMEOUTS
00291
00305
         Message* Receive(uint32_t u32TimeWaitMS_);
00306 #endif
00307
00316
          void Send(Message* pclSrc_);
00317
00325
         uint16_t GetCount();
00327 private:
00328 #if KERNEL_USE_TIMEOUTS
00329
         Message* Receive_i(uint32_t u32TimeWaitMS_);
00338
00339 #else
          Message* Receive_i(void);
00347
00348 #endif
00349
00351
         Semaphore m_clSemaphore;
00352
         DoubleLinkList m_clLinkList;
00355 };
00356
00357 #endif // KERNEL_USE_MESSAGE
00358
00359 #endif
```

# 20.83 /home/moslevin/projects/mark3-source/kernel/public/mutex.h File Reference

Mutual exclusion class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "timerlist.h"
```

## **Classes**

class Mutex

Mutual-exclusion locks, based on BlockingObject.

## 20.83.1 Detailed Description

Mutual exclusion class declaration.

Resource locks are implemented using mutual exclusion semaphores (Mutex\_t). Protected blocks can be placed around any resource that may only be accessed by one thread at a time. If additional threads attempt to access the protected resource, they will be placed in a wait queue until the resource becomes available. When the resource becomes available, the thread with the highest original priority claims the resource and is activated. Priority inheritance is included in the implementation to prevent priority inversion. Always ensure that you claim and release your mutex objects consistently, otherwise you may end up with a deadlock scenario that's hard to debug.

20.84 mutex.h 299

## 20.83.2 Initializing

Initializing a mutex object by calling:

```
clMutex.Init();
```

## 20.83.3 Resource protection example

```
clMutex.Claim();
...
<resource protected block>
...
clMutex.Release();
```

Definition in file mutex.h.

## 20.84 mutex.h

```
00001 /*=
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00050 #ifndef __MUTEX_H_
00051 #define __MUTEX_H_
00052
00053 #include "kerneltypes.h"
00054 #include "mark3cfg.h"
00055
00056 #include "blocking.h"
00057
00058 #if KERNEL_USE_MUTEX
00060 #if KERNEL_USE_TIMEOUTS
00061 #include "timerlist.h"
00062 #endif
00063
00064 //
00068 class Mutex : public BlockingObject
00069 {
00070 public:
00071
           void* operator new(size_t sz, void* pv) { return (Mutex*)pv; };
00072
           ~Mutex();
00073
00080
           void Init();
00081
00099
           void Claim();
00100
00101 #if KERNEL_USE_TIMEOUTS
00102
00113
           bool Claim(uint32_t u32WaitTimeMS_);
00114
00127
           void WakeMe(Thread* pclOwner_);
00128
00129 #endif
00130
00151
           void Release();
00152
00153 private:
00159
           uint8_t WakeNext();
00160
00161 #if KERNEL_USE_TIMEOUTS
00162
00170
           bool Claim_i(uint32_t u32WaitTimeMS_);
```

```
00171 #else
00172
00178
          void Claim_i(void);
00179 #endif
00180
          uint8_t m_u8Recurse;
00181
00182
                 m_bReady;
          bool
00183
          uint8_t m_u8MaxPri;
00184
         Thread* m_pclOwner;
00185 };
00186
00187 #endif // KERNEL_USE_MUTEX
00188
00189 #endif //__MUTEX_H_
```

# 20.85 /home/moslevin/projects/mark3-source/kernel/public/notify.h File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "blocking.h"
```

#### Classes

· class Notify

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

## 20.85.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.h.

# 20.86 notify.h

```
00001 /*
00002
00003
00004
00005
00006
00008
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00021 #ifndef __NOTIFY_H_
00022 #define __NOTIFY_H_
00023
00024 #include "mark3cfg.h"
00025 #include "blocking.h"
00026
00027 #if KERNEL_USE_NOTIFY
00028
00033 class Notify : public BlockingObject
00034 {
00035 public:
00036
          void* operator new(size_t sz, void* pv) { return (Notify*)pv; };
00037
          ~Notify();
```

```
00038
00044
          void Init(void);
00045
00055
          void Signal(void);
00056
00066
          void Wait (bool* pbFlag_);
00067
00068 #if KERNEL_USE_TIMEOUTS
00069
00081
          bool Wait(uint32_t u32WaitTimeMS_, bool* pbFlag_);
00082 #endif
00083
00093
          void WakeMe(Thread* pclChosenOne_);
00094 };
00095
00096 #endif
00097
00098 #endif
```

# 20.87 /home/moslevin/projects/mark3-source/kernel/public/paniccodes.h File Reference

Defines the reason codes thrown when a kernel panic occurs.

#### 20.87.1 Detailed Description

Defines the reason codes thrown when a kernel panic occurs.

Definition in file paniccodes.h.

# 20.88 paniccodes.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00020 #ifndef ___PANIC_CODES_H
00021 #define ___PANIC_CODES_H
00022
00023 #define PANIC_ASSERT_FAILED (1)
00024 #define PANIC_LIST_UNLINK_FAILED (2)
00025 #define PANIC_STACK_SLACK_VIOLATED (3)
00026 #define PANIC_AUTO_HEAP_EXHAUSTED (4)
00027 #define PANIC_POWERMAN_EXHAUSTED (5)
00028 #define PANIC_NO_READY_THREADS (6)
00029 #define PANIC_RUNNING_THREAD_DESCOPED (7)
00030 #define PANIC_ACTIVE_SEMAPHORE_DESCOPED (8)
00031 #define PANIC_ACTIVE_MUTEX_DESCOPED (9)
00032 #define PANIC_ACTIVE_EVENTFLAG_DESCOPED (10)
00033 #define PANIC_ACTIVE_NOTIFY_DESCOPED (11)
00034 #define PANIC_ACTIVE_MAILBOX_DESCOPED (12) 00035 #define PANIC_ACTIVE_TIMER_DESCOPED (13)
00036
00037 #endif // __PANIC_CODES_H
```

# 20.89 /home/moslevin/projects/mark3-source/kernel/public/priomap.h File Reference

Priority map data structure.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

#### **Classes**

class PriorityMap
 The PriorityMap class.

## 20.89.1 Detailed Description

Priority map data structure.

Definition in file priomap.h.

# 20.90 priomap.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00019 #ifndef ___PRIOMAP_H_
00020 #define __PRIOMAP_H_
00021
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00026 // Define the type used to store the priority map based on the word size of
00027 // the underlying host architecture.
00028 #if !defined(PORT_PRIO_MAP_WORD_SIZE)
00029 #error "undefined PORT_PRIO_MAP_WORD_SIZE"
00030 #endif
00031
00032 #define PRIO_MAP_WORD_TYPE K_WORD
00033
00034 // Size of the map index type in bits \,
00035 #define PRIO_MAP_BITS (8 * PORT_PRIO_MAP_WORD_SIZE)
00036
00037 // # of bits in an integer used to represent the number of bits in the map.
00038 // Used for bitshifting the bit index away from the map index. 00039 // i.e. 3 == 8 bits, 4 == 16 bits, 5 == 32 bits, etc...
00040 #define PRIO_MAP_WORD_SHIFT (2 + PORT_PRIO_MAP_WORD_SIZE)
00041
00042 // Bitmask used to separate out the priorities first-level bitmap from its
00043 // second-level map index for a given priority 00044 #define PRIO_MAP_BIT_MASK ((1 << PRIO_MAP_WORD_SHIFT) - 1)
00045
00046 // Get the priority bit for a given thread
00047 #define PRIO_BIT(x) ((x)&PRIO_MAP_BIT_MASK)
00048
00049 \ensuremath{//} Macro used to get the map index for a given priroity
00050 #define PRIO_MAP_WORD_INDEX(prio) ((prio) >> PRIO_MAP_WORD_SHIFT)
00051
```

```
00052 // Required size of the bitmap array in words
00053 #define PRIO_MAP_NUM_WORDS ((KERNEL_NUM_PRIORITIES + (PRIO_MAP_BITS - 1)) / (PRIO_MAP_BITS))
00054
00055 //---
00056 #if (PRIO_MAP_NUM_WORDS == 1)
00057 // If there is only 1 word required to store the priority information, we don't
00058 // need an array, or a secondary bitmap. 00059 #define PRIO_MAP_MULTI_LEVEL (0)
00060 #else
00061 // An array of bitmaps are required, and a secondary index is required to
00062 // efficiently track which priority levels are active. 00063 #define PRIO_MAP_MULTI_LEVEL (1)
00064 #endif
00066 //---
00070 class PriorityMap 00071 {
00072 public:
          PriorityMap();
00079
00085
          void Set(PORT_PRIO_TYPE uXPrio_);
00086
          void Clear(PORT_PRIO_TYPE uXPrio_);
00092
00093
00102
          PORT_PRIO_TYPE HighestPriority(void);
00103
00104 private:
00105 #if PRIO_MAP_MULTI_LEVEL
00106 PRIO_MAP_WORD_TYPE m_auXPriorityMap[PRIO_MAP_NUM_WORDS];
          PRIO_MAP_WORD_TYPE m_uXPriorityMapL2;
00107
00108 #else
00109
          PRIO_MAP_WORD_TYPE m_uXPriorityMap;
00110 #endif
00111 };
00112
00113 #endif
```

# 20.91 /home/moslevin/projects/mark3-source/kernel/public/profile.h File Reference

High-precision profiling timers.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

### Classes

class ProfileTimer

Profiling timer.

## 20.91.1 Detailed Description

High-precision profiling timers.

Enables the profiling and instrumentation of performance-critical code. Multiple timers can be used simultaneously to enable system-wide performance metrics to be computed in a lightweight manner.

Usage:

```
ProfileTimer clMyTimer;
int i;

clMyTimer.Init();

// Profile the same block of code ten times
for (i = 0; i < 10; i++)
{
    clMyTimer.Start();
    ...
    //Block of code to profile
    ...
    clMyTimer.Stop();
}

// Get the average execution time of all iterations
u32AverageTimer = clMyTimer.GetAverage();

// Get the execution time from the last iteration
u32LastTimer = clMyTimer.GetCurrent();</pre>
```

Definition in file profile.h.

# 20.92 profile.h

```
00001 /*===
                                                   _____
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00052 #ifndef ___PROFILE_H__
00053 #define ___PROFILE_H_
00054
00055 #include "kerneltypes.h"
00055 #Include kernercypes
00056 #include "mark3cfg.h"
00057 #include "ll.h"
00058
00059 #if KERNEL USE PROFILER
00060
00069 class ProfileTimer
00070 {
00071 public:
00078
          void Init();
00079
00086
          void Start();
00087
00094
          void Stop();
00095
00103
          uint32_t GetAverage();
00104
          uint32_t GetCurrent();
00113
00114
00115 private:
00126
          uint32_t ComputeCurrentTicks(uint16_t u16Count_, uint32_t u32Epoch_);
00127
          uint32_t m_u32Cumulative;
00128
          uint32_t m_u32CurrentIteration;
uint16_t m_u16Initial;
00129
00130
00131
          uint32_t m_u32InitialEpoch;
00132
          uint16_t m_u16Iterations;
00133
          bool
                   m_bActive;
00134 };
00135
00136 #endif // KERNEL_USE_PROFILE
00137
00138 #endif
```

# 20.93 /home/moslevin/projects/mark3-source/kernel/public/quantum.h File Reference

Thread Quantum declarations for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
```

#### Classes

· class Quantum

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

## 20.93.1 Detailed Description

Thread Quantum declarations for Round-Robin Scheduling.

Definition in file quantum.h.

# 20.94 quantum.h

```
00001 /*===
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00022 #ifndef __KQUANTUM_H_
00023 #define __KQUANTUM_H_
00024
00025 #include "kerneltypes.h"
00026 #include "mark3cfg.h"
00027
00028 #include "thread.h"
00029 #include "timer.h"
00030 #include "timerlist.h"
00031 #include "timerscheduler.h"
00032
00033 #if KERNEL USE OUANTUM
00034 class Timer;
00035
00041 class Quantum
00042 {
00043 public:
00052
          static void UpdateTimer();
00053
00060
          static void AddThread(Thread* pclThread_);
00061
00067
          static void RemoveThread();
00068
           static void SetInTimer(void) { m_bInTimer = true; }
           static void ClearInTimer(void) { m_bInTimer = false; }
00083
00084 private:
00096
           static void SetTimer(Thread* pclThread_);
```

```
00097
00098 static Timer m_clQuantumTimer;
00099 static bool m_bActive;
00100 static bool m_bInTimer;
00101 };
00102
00103 #endif // KERNEL_USE_QUANTUM
00104
00105 #endif
```

# 20.95 /home/moslevin/projects/mark3-source/kernel/public/scheduler.h File Reference

Thread scheduler function declarations.

```
#include "kerneltypes.h"
#include "thread.h"
#include "threadport.h"
#include "priomap.h"
```

#### Classes

· class Scheduler

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

#### **Variables**

volatile Thread \* g\_pclNext

Pointer to the currently-chosen next-running thread.

Thread \* g\_pclCurrent

Pointer to the currently-running thread.

## 20.95.1 Detailed Description

Thread scheduler function declarations.

This scheduler implements a very flexible type of scheduling, which has become the defacto industry standard when it comes to real-time operating systems. This scheduling mechanism is referred to as priority round- robin.

From the name, there are two concepts involved here:

1) Priority scheduling:

Threads are each assigned a priority, and the thread with the highest priority which is ready to run gets to execute.

2) Round-robin scheduling:

Where there are multiple ready threads at the highest-priority level, each thread in that group gets to share time, ensuring that progress is made.

The scheduler uses an array of ThreadList objects to provide the necessary housekeeping required to keep track of threads at the various priorities. As s result, the scheduler contains one ThreadList per priority, with an additional list to manage the storage of threads which are in the "stopped" state (either have been stopped, or have not been started yet).

Definition in file scheduler.h.

20.96 scheduler.h 307

## 20.96 scheduler.h

```
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00046 #ifndef __SCHEDULER_H_
00047 #define ___SCHEDULER_H_
00048
00049 #include "kerneltypes.h"
00050 #include "thread.h"
00051 #include "threadport.h"
00052 #include "priomap.h"
00053
00054 extern volatile Thread* g_pclNext;
00055 extern Thread*
                              g_pclCurrent;
00056
00057 //
00062 class Scheduler
00063 {
00064 public:
00070
          static void Init();
00071
00079
          static void Schedule();
08000
00088
          static void Add(Thread* pclThread_);
00089
00098
          static void Remove(Thread* pclThread_);
00099
00112
          static bool SetScheduler (bool bEnable_);
00113
00121
          static Thread* GetCurrentThread() { return
00130
          static volatile Thread* GetNextThread() { return
      g_pclNext; }
00141
          static ThreadList * GetThreadList (PORT PRIO TYPE uXPriority ) {
      return &m_aclPriorities[uXPriority_]; }
00150
          static ThreadList* GetStopList() { return &m_clStopList; }
00159
          static bool IsEnabled() { return m_bEnabled; }
00166
          static void QueueScheduler() { m_bQueuedSchedule = true; }
00167 private:
00169
          static bool m bEnabled;
00172
          static bool m_bQueuedSchedule;
00173
00175
          static ThreadList m_clStopList;
00176
          static ThreadList m_aclPriorities[
00178
      KERNEL_NUM_PRIORITIES];
00179
00181
          static PriorityMap m_clPrioMap;
00182 };
00183 #endif
```

## 20.97 /home/moslevin/projects/mark3-source/kernel/public/thread.h File Reference

Platform independent thread class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
#include "scheduler.h"
#include "threadport.h"
#include "quantum.h"
#include "autoalloc.h"
#include "priomap.h"
```

#### Classes

· class Thread

Object providing fundamental multitasking support in the kernel.

struct FakeThread t

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

#### 20.97.1 Detailed Description

Platform independent thread class declarations.

Threads are an atomic unit of execution, and each instance of the thread class represents an instance of a program running of the processor. The Thread is the fundmanetal user-facing object in the kernel - it is what makes multiprocessing possible from application code.

In Mark3, threads each have their own context - consisting of a stack, and all of the registers required to multiplex a processor between multiple threads.

The Thread class inherits directly from the LinkListNode class to facilitate efficient thread management using Double, or Double-Circular linked lists.

Definition in file thread.h.

## 20.98 thread.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===========
00035 #ifndef ___THREAD_H_
00036 #define __THREAD_H_
00037
00038 #include "kerneltypes.h"
00039 #include "mark3cfg.h"
00040
00041 #include "ll.h"
00042 #include "threadlist.h"
00043 #include "scheduler.h
00044 #include "threadport.h"
00045 #include "quantum.h"
00046 #include "autoalloc.h"
00047 #include "priomap.h'
00048
00049 class Thread;
00050
00051 //----
00052 typedef void (*ThreadCreateCallout_t)(Thread* pclThread_);
00053 typedef void (*ThreadExitCallout_t)(Thread* pclThread_);
00054 typedef void (*ThreadContextCallout_t)(Thread* pclThread_);
00056 //-
00060 class Thread : public LinkListNode
00061 {
00062 public:
00063
          void* operator new(size t sz, void* pv) { return (Thread*)pv; };
00064
          ~Thread();
00065
```

20.98 thread.h 309

```
00066 #if KERNEL_EXTRA_CHECKS
         Thread() { m_eState = THREAD_STATE_INVALID; }
00067
00068
00069
          bool IsInitialized() { return (m_eState != THREAD_STATE_INVALID); }
00070 #endif
00071
88000
          Init(K_WORD* pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_,
     ThreadEntry_t pfEntryPoint_, void* pvArg_);
00089
00090 #if KERNEL USE AUTO ALLOC
00091
          static Thread* Init (uint16_t u16StackSize_, uint8_t uXPriority_,
00109
     ThreadEntry_t pfEntryPoint_, void* pvArg_);
00110 #endif
00111
00119
          void Start ():
00120
00127
          void Stop();
00128
00129 #if KERNEL_USE_THREADNAME
00130
00139
          void SetName(const char* szName_) { m_szName = szName_; }
          const char* GetName() { return m_szName; }
00146
00147 #endif
00148
00157
          ThreadList* GetOwner(void) { return m_pclOwner; }
00165
          ThreadList* GetCurrent(void) { return m_pclCurrent; }
          PORT_PRIO_TYPE GetPriority(void) { return
00174
     m_uXPriority; }
00182
         PORT_PRIO_TYPE GetCurPriority(void) { return
      m_uXCurPriority; }
00183 #if KERNEL_USE_QUANTUM
00184
00191
          void SetQuantum(uint16_t u16Quantum_) { m_u16Quantum = u16Quantum_; }
00199
          uint16_t GetQuantum(void) { return m_u16Quantum; }
00200 #endif
00201
00209
          void SetCurrent(ThreadList* pclNewList_) { m_pclCurrent = pclNewList_;
00217
          void SetOwner(ThreadList* pclNewList_) { m_pclOwner = pclNewList_; }
void SetPriority(PORT_PRIO_TYPE uXPriority_);
00230
00231
00241
          void InheritPriority(PORT_PRIO_TYPE uXPriority_);
00242
00243 #if KERNEL_USE_DYNAMIC_THREADS
00244
          void Exit();
00255
00256 #endif
00257
00258 #if KERNEL_USE_SLEEP
00259
00267
          static void Sleep (uint32_t u32TimeMs_);
00268
00277
          static void USleep (uint32_t u32TimeUs_);
00278 #endif
00279
00287
          static void Yield(void);
00288
00296
          void SetID(uint8_t u8ID_) { m_u8ThreadID = u8ID_; }
00304
          uint8_t GetID() { return m_u8ThreadID; }
00317
          uint16_t GetStackSlack();
00318
00319 #if KERNEL_USE_EVENTFLAG
00320
00327
          uint16_t GetEventFlagMask() { return m_u16FlagMask; }
          void SetEventFlagMask(uint16_t u16Mask_) { m_u16FlagMask = u16Mask_; }
00332
          void SetEventFlagMode(EventFlagOperation_t eMode_) {
00338
     m_eFlagMode = eMode_; }
00343
          EventFlagOperation_t GetEventFlagMode() { return
      m_eFlagMode; }
00344 #endif
00345
00346 #if KERNEL USE TIMEOUTS || KERNEL USE SLEEP
00347
00350
          Timer* GetTimer();
00351 #endif
00352 #if KERNEL_USE_TIMEOUTS
00353
00361
          void SetExpired(bool bExpired );
00362
00369
         bool GetExpired();
00370 #endif
00371
00372 #if KERNEL_USE_IDLE_FUNC
00373
00378
          void InitIdle();
```

```
00379 #endif
00380
00381 #if KERNEL_USE_EXTENDED_CONTEXT
00382
00391
          void* GetExtendedContext() { return m pvExtendedContext; }
00392
          void SetExtendedContext(void* pvData_) {
00404
      m_pvExtendedContext = pvData_; }
00405 #endif
00406
          ThreadState_t GetState() { return m_eState; }
00413
00421
          void SetState(ThreadState_t eState_) { m_eState = eState_; }
00422
00427
          K_WORD* GetStack() { return m_pwStack; }
00428
00433
          uint16_t GetStackSize() { return m_u16StackSize; }
00434
00435
          friend class ThreadPort;
00436 private:
00444
          static void ContextSwitchSWI (void);
00445
00451
          void SetPriorityBase(PORT_PRIO_TYPE uXPriority_);
00452
00454
          K WORD* m pwStackTop;
00455
00457
          K_WORD* m_pwStack;
00458
00460
          uint8_t m_u8ThreadID;
00461
          PORT_PRIO_TYPE m_uXPriority;
00463
00464
00466
          PORT_PRIO_TYPE m_uXCurPriority;
00467
00469
          ThreadState_t m_eState;
00470
00471 #if KERNEL_USE_EXTENDED_CONTEXT
00472
         void* m_pvExtendedContext;
00474 #endif
00475
00476 #if KERNEL_USE_THREADNAME
00477
         const char* m_szName;
00479 #endif
00480
00482
          uint16_t m_u16StackSize;
00483
00485
          ThreadList* m_pclCurrent;
00486
00488
          ThreadList* m_pclOwner;
00489
00491
          ThreadEntry_t m_pfEntryPoint;
00492
00494
          void* m_pvArg;
00495
00496 #if KERNEL_USE_QUANTUM
00497
         uint16_t m_u16Quantum;
00499 #endif
00500
00501 #if KERNEL_USE_EVENTFLAG
00502
         uint16_t m_u16FlagMask;
00504
00506
         EventFlagOperation_t m_eFlagMode;
00507 #endif
00508
00509 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00510
         Timer m_clTimer;
00512 #endif
00513
00514 #if KERNEL_USE_TIMEOUTS
00515
        bool m_bExpired;
00517 #endif
00518 };
00519
00520 #if KERNEL_USE_IDLE_FUNC
00521 //-----
00533 typedef struct {
00534
          LinkListNode* next;
00535
          LinkListNode* prev;
00536
00538
          K_WORD* m_pwStackTop;
00539
00541
          K WORD* m pwStack;
00542
00544
          uint8_t m_u8ThreadID;
00545
00547
          PORT_PRIO_TYPE m_uXPriority;
00548
00550
          PORT_PRIO_TYPE m_uXCurPriority;
```

```
00551
00553
          ThreadState_t m_eState;
00554
00555 #if KERNEL_USE_EXTENDED_CONTEXT
00556
         void* m_pvExtendedContext;
00558 #endif
00560 #if KERNEL_USE_THREADNAME
00561
         const char* m_szName;
00563 #endif
00564
00565 } FakeThread_t;
00566 #endif
00567
00568 #endif
```

## 20.99 /home/moslevin/projects/mark3-source/kernel/public/threadlist.h File Reference

Thread linked-list declarations.

```
#include "kerneltypes.h"
#include "priomap.h"
#include "ll.h"
```

#### Classes

· class ThreadList

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

## 20.99.1 Detailed Description

Thread linked-list declarations.

Definition in file threadlist.h.

# 20.100 threadlist.h

```
00001 /*===========
00002
00003
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #ifndef __THREADLIST_H__
00023 #define ___THREADLIST_H_
00024
00025 #include "kerneltypes.h"
00026 #include "priomap.h"
00027 #include "11.h"
00028
00029 class Thread;
00030
00035 class ThreadList : public CircularLinkList
00036 {
```

```
00037 public:
          void* operator new(size_t sz, void* pv) { return (ThreadList*)pv; };
00044
          ThreadList() : m_uXPriority(0), m_pclMap(NULL)
00045
00046
00054
          void SetPriority(PORT_PRIO_TYPE uXPriority_);
00055
00065
          void SetMapPointer(PriorityMap* pclMap_);
00066
          void Add(LinkListNode* node_);
00074
00075
          void Add(LinkListNode* node_, PriorityMap* pclMap_,
00087
     PORT_PRIO_TYPE uXPriority_);
00088
00097
          void AddPriority(LinkListNode* node_);
00098
          void Remove(LinkListNode* node_);
00106
00107
00115
          Thread* HighestWaiter();
00116
00117 private:
00119
          PORT_PRIO_TYPE m_uXPriority;
00120
          PriorityMap* m_pclMap;
00122
00123 };
00124
00125 #endif
```

# 20.101 /home/moslevin/projects/mark3-source/kernel/public/timer.h File Reference

Timer object declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

## Classes

class Timer

Kernel-managed software timers.

#### **Macros**

#define TIMERLIST\_FLAG\_ONE\_SHOT (0x01)

Timer is one-shot.

#define TIMERLIST\_FLAG\_ACTIVE (0x02)

Timer is currently active.

• #define TIMERLIST\_FLAG\_CALLBACK (0x04)

Timer is pending a callback.

• #define TIMERLIST\_FLAG\_EXPIRED (0x08)

Timer is actually expired.

#define MAX\_TIMER\_TICKS (0x7FFFFFFF)

Maximum value to set.

• #define MIN\_TICKS (3)

The minimum tick value to set.

20.102 timer.h 313

## **Typedefs**

typedef void(\* TimerCallback\_t) (Thread \*pclOwner\_, void \*pvData\_)
 This type defines the callback function type for timer events.

## 20.101.1 Detailed Description

Timer object declarations.

Definition in file timer.h.

#### 20.101.2 Macro Definition Documentation

20.101.2.1 #define TIMERLIST\_FLAG\_EXPIRED (0x08)

Timer is actually expired.

Definition at line 36 of file timer.h.

## 20.101.3 Typedef Documentation

```
20.101.3.1 typedef void(* TimerCallback_t) (Thread *pclOwner_, void *pvData_)
```

This type defines the callback function type for timer events.

Since these are called from an interrupt context, they do not operate from within a thread or object context directly – as a result, the context must be manually passed into the calls.

pclOwner\_ is a pointer to the thread that owns the timer pvData\_ is a pointer to some data or object that needs to know about the timer's expiry from within the timer interrupt context.

Definition at line 95 of file timer.h.

## 20.102 timer.h

```
00001 /
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #ifndef __TIMER_H_
00022 #define __TIMER_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #include "11.h"
00028
```

```
00029 #if KERNEL_USE_TIMERS
00030 class Thread;
00031
00032 //----
00033 #define TIMERLIST_FLAG_ONE_SHOT (0x01)
00034 #define TIMERLIST_FLAG_ACTIVE (0x02)
00035 #define TIMERLIST_FLAG_CALLBACK (0x04)
00036 #define TIMERLIST_FLAG_EXPIRED (0x08)
00037
00038 //----
00039 #define TIMER_INVALID_COOKIE (0x3C)
00040 #define TIMER_INIT_COOKIE
                                         (0xC3)
00041
00042 //----
00043 #define MAX_TIMER_TICKS (0x7FFFFFFF)
00044 #define TIMER_TICKS_INVALID (0x80000000)
00045 //---
00046 #if KERNEL TIMERS TICKLESS
00048 //-
00049 /*
00050
          Ugly macros to support a wide resolution of delays.
          Given a 16-bit timer @ 16MHz & 256 cycle prescaler, this gives u16...
Max time, SECONDS_TO_TICKS: 68719s
Max time, MSECONDS_TO_TICKS: 6871.9s
00051
00052
00053
          Max time, USECONDS_TO_TICKS: 6.8719s
00054
00055
00056
          ...With a 16us tick resolution.
00057
00058
          Depending on the system frequency and timer resolution, you may want to
00059
          customize these values to suit your system more appropriately.
00060 */
00061 //---
00062 #define SECONDS_TO_TICKS(x) ((((uint32_t)x) * PORT_TIMER_FREQ))
00063 #define MSECONDS_TO_TICKS(x) ((((((uint32_t)x) * (PORT_TIMER_FREQ / 100)) + 5) / 10))
00064 #define USECONDS_TO_TICKS(x) ((((((uint32_t)x) * PORT_TIMER_FREQ) + 50000) / 1000000))
00065
00067 #define MIN_TICKS (3)
00068 //---
00069
00070 #else
00071
00072 //
00073 // add time because we don't know how far in an epoch we are when a call is made.
00074 #define SECONDS_TO_TICKS(x) (((uint32_t)(x) *1000) + 1)
00075 #define MSECONDS_TO_TICKS(x) ((uint32_t)(x + 1))
00076 \#define USECONDS_TO_TICKS(x) (((uint32_t)(x + 999)) / 1000)
00077
00078 //--
00079 #define MIN_TICKS (1)
00080 //---
00081
00082 #endif // KERNEL_TIMERS_TICKLESS
00083
00084 //-
00095 typedef void (*TimerCallback_t)(Thread* pclOwner_, void* pvData_);
00096
00097 //----
00098 class TimerList;
00099 class TimerScheduler:
00100 class Quantum;
00101
00102 //----
00112 class Timer : public LinkListNode
00113 {
00114 public:
          void* operator new(size_t sz, void* pv) { return (Timer*)pv; };
00115
00122
          Timer();
00123
00129
          void Init();
00130
00142
          void Start (bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_,
     void* pvData_);
00143
00157
00158
          Start (bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_,
      TimerCallback_t pfCallback_, void* pvData_);
00159
00168
          void Start():
00169
          void Stop();
00177
00187
          void SetFlags(uint8_t u8Flags_) { m_u8Flags = u8Flags_; }
00195
          void SetCallback(TimerCallback_t pfCallback_) {
      m_pfCallback = pfCallback_; }
         void SetData(void* pvData_) { m_pvData = pvData_; }
00203
```

```
00212
          void SetOwner(Thread* pclOwner_) { m_pclOwner = pclOwner_; }
00220
          void SetIntervalTicks(uint32_t u32Ticks_);
00221
00229
          void SetIntervalSeconds(uint32_t u32Seconds_);
00230
00238
          uint32_t GetInterval() { return m_u32Interval; }
          void SetIntervalMSeconds(uint32_t u32MSeconds_);
00247
00255
          void SetIntervalUSeconds(uint32_t u32USeconds_);
00256
00265
          void SetTolerance(uint32_t u32Ticks_);
00266
00267 private:
00268 frie
         friend class TimerList;
00269
00270 #if KERNEL_EXTRA_CHECKS
00271
00274
          void SetInitialized() { m_u8Initialized = TIMER_INIT_COOKIE; }
00275
00280
         bool IsInitialized(void) { return (m_u8Initialized == TIMER_INIT_COOKIE); }
00281
00283
         uint8_t m_u8Initialized;
00284 #endif
00285
00287
          uint8_t m_u8Flags;
00288
00290
          TimerCallback_t m_pfCallback;
00291
00293
         uint32_t m_u32Interval;
00294
00296
          uint32 t m u32TimeLeft:
00297
00299
          uint32_t m_u32TimerTolerance;
00300
00302
          Thread* m_pclOwner;
00303
00305
         void* m_pvData;
00306 };
00307
00308 #endif // KERNEL_USE_TIMERS
00309
00310 #endif
```

# 20.103 /home/moslevin/projects/mark3-source/kernel/public/timerlist.h File Reference

Timer list declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timer.h"
```

## Classes

· class TimerList

TimerList class - a doubly-linked-list of timer objects.

## 20.103.1 Detailed Description

Timer list declarations.

These classes implements a linked list of timer objects attached to the global kernel timer scheduler.

Definition in file timerlist.h.

## 20.104 timerlist.h

```
00001 /*==
00002
00003
00004
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00024 #ifndef __TIMERLIST_H__
00025 #define ___TIMERLIST_H_
00026
00027 #include "kerneltypes.h"
00028 #include "mark3cfg.h"
00029
00030 #include "timer.h"
00031 #if KERNEL_USE_TIMERS
00032
00033 //-
00037 class TimerList : public DoubleLinkList
00038 {
00039 public:
00046
         void Init();
00047
00055
         void Add(Timer* pclListNode_);
00056
00064
         void Remove(Timer* pclListNode_);
00065
00072
         void Process();
00073
00074 private:
         uint32_t m_u32NextWakeup;
00077
00079
         bool m_bTimerActive;
00080 };
00081
00082 #endif // KERNEL_USE_TIMERS
00083
00084 #endif
```

# 20.105 /home/moslevin/projects/mark3-source/kernel/public/timerscheduler.h File Reference

Timer scheduler declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "timer.h"
#include "timerlist.h"
```

#### Classes

· class TimerScheduler

"Static" Class used to interface a global TimerList with the rest of the kernel.

## 20.105.1 Detailed Description

Timer scheduler declarations.

Definition in file timerscheduler.h.

20.106 timerscheduler.h 317

## 20.106 timerscheduler.h

```
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #ifndef __TIMERSCHEDULER_H_
00022 #define __TIMERSCHEDULER_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #include "ll.h"
00028 #include "timer.h"
00029 #include "timerlist.h"
00030
00031 #if KERNEL USE TIMERS
00032
00033 //--
00038 class TimerScheduler
00039 {
00040 public:
         static void Init() { m_clTimerList.Init(); }
00047
00056
          static void Add(Timer* pclListNode_) { m_clTimerList.
     Add(pclListNode_); }
00065
          static void Remove(Timer* pclListNode_) { m_clTimerList.
     Remove(pclListNode_); }
00074
         static void Process() { m_clTimerList.Process(); }
00075 private:
00077
          static TimerList m_clTimerList;
00078 };
00079
00080 #endif // KERNEL_USE_TIMERS
00081
00082 #endif //__TIMERSCHEDULER_H_
```

# 20.107 /home/moslevin/projects/mark3-source/kernel/public/tracebuffer.h File Reference

Kernel trace buffer class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

## 20.107.1 Detailed Description

Kernel trace buffer class declaration.

Global kernel trace-buffer. used to instrument the kernel with lightweight encoded print statements. If something goes wrong, the tracebuffer can be examined for debugging purposes. Also, subsets of kernel trace information can be extracted and analyzed to provide information about runtime performance, thread-scheduling, and other nifty things in real-time.

Definition in file tracebuffer.h.

## 20.108 tracebuffer.h

```
00001 /
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00024 #ifndef __TRACEBUFFER_H_
00025 #define __TRACEBUFFER_H_
00026
00027 #include "kerneltypes.h"
00028 #include "mark3cfg.h"
00029
00030 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00031
00032 #define TRACE_BUFFER_SIZE (160)
00033
00034 typedef void (*TraceBufferCallback_t) (uint16_t* pu16Source_, uint16_t u16Len_, bool bPingPong_);
00035
00039 class TraceBuffer
00040 {
00041 public:
00047
          static void Init();
00048
          static uint16_t Increment(void) { return m_u16SyncNumber++; }
00053
00062
          static void Write(uint16_t* pu16Data_, uint16_t u16Size_);
00063
          static void SetCallback(TraceBufferCallback_t pfCallback_) { m_pfCallback = pfCallback_; }
00073 private:
00074
          static TraceBufferCallback_t m_pfCallback;
00075
          static uint16_t
                                        m_u16SyncNumber;
00076
          static uint16 t
                                        m u16Index;
00077
                                        m_au16Buffer[(TRACE_BUFFER_SIZE / sizeof(uint16_t))];
          static uint16 t
00078 };
00079
00080 #endif // KERNEL_USE_DEBUG
00081
00082 #endif
```

# 20.109 /home/moslevin/projects/mark3-source/kernel/quantum.cpp File Reference

Thread Quantum Implementation for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernelaware.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### **Functions**

static void QuantumCallback (Thread \*pclThread\_, void \*pvData\_)
 QuantumCallback.

20.110 quantum.cpp 319

## 20.109.1 Detailed Description

Thread Quantum Implementation for Round-Robin Scheduling.

Definition in file quantum.cpp.

## 20.109.2 Function Documentation

```
20.109.2.1 static void QuantumCallback ( Thread * pclThread_, void * pvData_ ) [static]
```

#### QuantumCallback.

This is the timer callback that is invoked whenever a thread has exhausted its current execution quantum and a new thread must be chosen from within the same priority level.

#### **Parameters**

pcl⊷	Pointer to the thread currently executing
Thread_	
pvData_	Unused in this context.

Definition at line 62 of file quantum.cpp.

## 20.110 quantum.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00026 #include "timerlist.h"
00027 #include "quantum.h"
00028 #include "kernelaware.h"
00029
00030 #define _CAN_HAS_DEBUG
00031 //--[Autogenerated - Do Not Modify]------00032 #include "dbg_file_list.h"
00033 #include "buffalogger.h"
00034 #if defined(DBG_FILE)
00035 #error "Debug logging file token already defined! Bailing."
00036 #else
00037 #define DBG_FILE _DBG___KERNEL_QUANTUM_CPP
00038 #endif
00039 //--[End Autogenerated content]----
00040 #include "kerneldebug.h"
00041
00042 #if KERNEL_USE_QUANTUM
00043
00044 //
00045 static volatile bool bAddQuantumTimer; // Indicates that a timer add is pending
00046
00047 //--
```

```
00048 Timer Quantum::m_clQuantumTimer; // The global timernodelist_t object
00049 bool Quantum::m_bActive;
00050 bool Quantum::m_bInTimer;
00051 //----
00062 static void QuantumCallback(Thread* pclThread_, void* pvData_)
00063 {
           // Validate thread pointer, check that source/destination match (it's
00065
          // in its real priority list). Also check that this thread was part of
         // the highest-running priority level.
if (pclThread_->GetPriority() >= Scheduler::GetCurrentThread()->
00066
00067
     GetPriority()) {
            if (pclThread_->GetCurrent()->GetHead() != pclThread_->
00068
     GetCurrent()->GetTail()) {
00069
                 bAddQuantumTimer = true;
00070
                  pclThread_->GetCurrent()->PivotForward();
00071
              }
00072
         }
00073 }
00075 //--
00076 void Quantum::SetTimer(Thread* pclThread_)
00077 {
00078
          m_clQuantumTimer.SetIntervalMSeconds(pclThread_->
     GetOuantum());
00079
         m_clQuantumTimer.SetFlags(TIMERLIST_FLAG_ONE_SHOT);
          m_clQuantumTimer.SetData(NULL);
08000
00081
          m_clQuantumTimer.SetCallback((TimerCallback_t)
     QuantumCallback);
00082
        m_clQuantumTimer.SetOwner(pclThread_);
00083 }
00084
00085 //-
00086 void Quantum::AddThread(Thread* pclThread_)
00087 {
00088
           if (m_bActive
00089 #if KERNEL_USE_IDLE_FUNC
00090 || (pclThread_ == Kernel::GetIdleThread())
00091 #endif
00092
00093
             return;
00094
          }
00095
00096
         // If this is called from the timer callback, queue a timer add...
00097
          if (m_bInTimer) {
00098
              bAddQuantumTimer = true;
00099
00100
          }
00101
          // If this isn't the only thread in the list.
00102
          if (pclThread_->GetCurrent()->GetHead() != pclThread_->
00103
     GetCurrent()->GetTail()) {
00104 #if KERNEL_EXTRA_CHECKS
00105
              m_clQuantumTimer.Init();
00106 #endif
              Quantum::SetTimer(pclThread_);
00107
              TimerScheduler::Add(&m_clQuantumTimer);
00108
              m_bActive = 1;
00110
         }
00111 }
00112
00113 //----
00114 void Quantum::RemoveThread(void)
00115 {
00116
          if (!m_bActive) {
         return;
00117
00118
00119
00120
          // Cancel the current timer
00121
          TimerScheduler::Remove(&m_clQuantumTimer);
00122
          m_bActive = 0;
00123 }
00124
00125 //---
00126 void Quantum::UpdateTimer(void)
00127 {
00128
          // If we have to re-add the quantum timer (more than 2 threads at the
00129
          // high-priority level...)
00130
          if (bAddQuantumTimer) {
              // Trigger a thread yield - this will also re-schedule the // thread \star and \star reset the round-robin scheduler.
00131
00132
00133
              Thread::Yield();
00134
              bAddQuantumTimer = false;
00135
00136 }
00137
00138 #endif // KERNEL_USE_QUANTUM
```

# 20.111 /home/moslevin/projects/mark3-source/kernel/scheduler.cpp File Reference

Strict-Priority + Round-Robin thread scheduler implementation.

```
#include "kerneltypes.h"
#include "ll.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "kernel.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### **Variables**

volatile Thread \* g\_pclNext

Pointer to the currently-chosen next-running thread.

• Thread \* g\_pclCurrent

Pointer to the currently-running thread.

#### 20.111.1 Detailed Description

Strict-Priority + Round-Robin thread scheduler implementation.

Definition in file scheduler.cpp.

## 20.112 scheduler.cpp

```
00001 /*
00002
00003
00004
00005
00006
80000
00009 -- [Mark3 Realtime Platform] -----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "11.h"
00024 #include "scheduler.h"
00025 #include "thread.h"
00026 #include "threadport.h"
00027 #include "kernel.h"
00028
00029 #define _CAN_HAS_DEBUG
00030 //--[Autogenerated - Do Not Modify]-----
00031 #include "dbg_file_list.h"
00032 #include "buffalogger.h"
00033 #if defined(DBG_FILE)
00034 #error "Debug logging file token already defined! Bailing."
00035 #else
00036 #define DBG_FILE _DBG___KERNEL_SCHEDULER_CPP
00037 #endif
00038 //--[End Autogenerated content]-----
00039
00040 #include "kerneldebug.h"
```

```
00041 volatile Thread* g_pclNext;
                     g_pclCurrent;
00043
00044 //----
00045 bool Scheduler::m bEnabled;
00046 bool Scheduler::m bOueuedSchedule;
00048 //---
00049 ThreadList Scheduler::m_clStopList;
00050 ThreadList Scheduler::m_aclPriorities[
      KERNEL_NUM_PRIORITIES];
00051 PriorityMap Scheduler::m_clPrioMap;
00054 void Scheduler::Init()
00055 {
          for (int i = 0; i < KERNEL_NUM_PRIORITIES; i++) {
   m_aclPriorities[i].SetPriority(i);</pre>
00056
00057
              m_aclPriorities[i].SetMapPointer(&
00058
     m_clPrioMap);
        }
00059
00060 }
00061
00062 //---
00063 void Scheduler::Schedule()
00064 {
00065
          PORT_PRIO_TYPE uXPrio;
00066
00067
         uXPrio = m_clPrioMap.HighestPriority();
00068
00069 #if KERNEL_USE_IDLE_FUNC
        if (uXPrio == 0) {
00071
              // There aren't any active threads at all - set g_pclNext to IDLE
              g_pclNext = Kernel::GetIdleThread();
00072
00073
         } else
00074 #endif
00075
       {
              if (uXPrio == 0) {
00077
                  Kernel::Panic(PANIC_NO_READY_THREADS);
00078
              // Priorities are one-indexed
00079
08000
              uXPrio--;
00081
00082
              // Get the thread node at this priority.
00083
              g_pclNext = (Thread*) (m_aclPriorities[uXPrio].GetHead());
00084
00085
         KERNEL_TRACE_1("Next Thread: %d\n", (uint16_t)((Thread*)g_pclNext)->GetID());
00086 }
00087
00088 //-
00089 void Scheduler::Add(Thread* pclThread_)
00090 {
00091
          m_aclPriorities[pclThread_->GetPriority()].Add(pclThread_);
00092 }
00093
00094 //
00095 void Scheduler::Remove(Thread* pclThread_)
00096 {
00097
          m_aclPriorities[pclThread_->GetPriority()].Remove(pclThread_);
00098 }
00099
00100 //-
00101 bool Scheduler::SetScheduler(bool bEnable_)
00102 {
00103
          bool bRet;
          CS_ENTER();
00104
                     = m bEnabled;
00105
          bRet.
          m_bEnabled = bEnable_;
00106
00107
         // If there was a queued scheduler evevent, dequeue and trigger an
00108
          // immediate Yield
00109
         if (m_bEnabled && m_bQueuedSchedule) {
00110
              m_bQueuedSchedule = false;
          Thread::Yield();
00111
00112
          CS_EXIT();
00113
00114
          return bRet;
00115 }
```

## 20.113 /home/moslevin/projects/mark3-source/kernel/thread.cpp File Reference

Platform-Independent thread class Definition.

20.114 thread.cpp 323

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "scheduler.h"
#include "kernelswi.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "quantum.h"
#include "priomap.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### **Functions**

static void ThreadSleepCallback (Thread \*pclOwner\_, void \*pvData\_)
 This callback is used to wake up a thread once the interval has expired.

## 20.113.1 Detailed Description

Platform-Independent thread class Definition.

Definition in file thread.cpp.

## 20.114 thread.cpp

```
00001 /*=
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00026 #include "scheduler.h"
00027 #include "kernelswi.h"
00028 #include "timerlist.h"
00029 #include "ksemaphore.h"
00030 #include "quantum.h"
00031 #include "kernel.h"
00032 #include "priomap.h"
00033
00034 #define _CAN_HAS_DEBUG
00035 //--[Autogenerated - Do Not Modify]------
00036 #include "dbg_file_list.h"
00037 #include "buffalogger.h"
00038 #if defined(DBG_FILE)
00039 #error "Debug logging file token already defined! Bailing."
00040 #else
00041 #define DBG_FILE _DBG___KERNEL_THREAD_CPP
00042 #endif
00043 //--[End Autogenerated content]-----
00044
```

```
00045 #include "kerneldebug.h"
00046 //--
00047 Thread::~Thread()
00048 {
            // On destruction of a thread located on a stack,
00049
00050
           // ensure that the thread is either stopped, or exited.
           // If the thread is stopped, move it to the exit state.
00052
           // If not in the exit state, kernel panic -- it's catastrophic to have
00053
           \ensuremath{//} running threads on stack suddenly disappear.
00054
           if (m_eState == THREAD_STATE_STOP) {
               CS_ENTER();
00055
               m_pclCurrent->Remove(this);
00056
               m_pclCurrent = 0;
m_pclOwner = 0;
00057
00058
00059
                m_eState
                              = THREAD_STATE_EXIT;
00060
               CS_EXIT();
00061 } else if (m_eState != THREAD_STATE_EXIT) {
00062 #if KERNEL_AWARE_SIMULATION
00063
               KernelAware::Trace(0, 0, m_u8ThreadID,
      m_eState);
00064 #endif
00065
                Kernel::Panic(PANIC_RUNNING_THREAD_DESCOPED);
00066
00067 }
00068
00070 void Thread::Init(
00071
          K_WORD* pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_,
      ThreadEntry_t pfEntryPoint_, void* pvArg_)
00072 {
00073
           static uint8 t u8ThreadID = 0;
00074
00075
           KERNEL_ASSERT (pwStack_);
00076
           KERNEL_ASSERT (pfEntryPoint_);
00077
00078
           ClearNode();
00079
           m_u8ThreadID = u8ThreadID++;
00081 #if KERNEL_USE_IDLE_FUNC
00082 if (u8ThreadID == 255) {
00083
                u8ThreadID = 0;
00084
00085 #endif
00086
           KERNEL_TRACE_1("Stack Size: %d", u16StackSize_);
KERNEL_TRACE_1("Thread Pri: %d", (uint8_t)uXPriority_);
KERNEL_TRACE_1("Thread Id: %d", (uint16_t)m_u8ThreadID);
KERNEL_TRACE_1("Entrypoint: %x", (uint16_t)pfEntryPoint_);
00087
00088
00089
00090
00091
00092
           // Initialize the thread parameters to their initial values.
           m_pwStack = pwStack;
m_pwStackTop = TOP_OF_STACK(pwStack_, u16StackSize_);
00093
00094
00095
00096
           m u16StackSize = u16StackSize ;
00097
00098 #if KERNEL_USE_QUANTUM
           m_u16Quantum = THREAD_QUANTUM_DEFAULT;
00100 #endif
00101
                             = uXPriority_;
00102
           m_uXPriority
           m_uXcrroitty
m_uXcurPriority = m_uXPriority;
m_pfEntryPoint = pfEntryPoint_;
m_pvArg = pvArg_;
00103
00104
00105
00106
00107 #if KERNEL_USE_THREADNAME
00108
         m_szName = NULL;
00109 #endif
00110 #if KERNEL_USE_TIMERS
00111
         m clTimer.Init():
00112 #endif
00113
00114
           // Call CPU-specific stack initialization
00115
           ThreadPort::InitStack(this);
00116
00117
           // Add to the global "stop" list.
           CS_ENTER();
00118
           m_pclOwner
00119
                          = Scheduler::GetThreadList(
      m_uXPriority);
00120
           m_pclCurrent = Scheduler::GetStopList();
m_eState = THREAD_STATE_STOP;
00121
           m_pclCurrent->Add(this);
00122
           CS_EXIT();
00124
00125 #if KERNEL_USE_THREAD_CALLOUTS
00126
        ThreadCreateCallout_t pfCallout = Kernel::GetThreadCreateCallout();
00127
           if (pfCallout) {
00128
               pfCallout(this);
```

20.114 thread.cpp 325

```
00129
00130 #endif
00131
00132 }
00133
00134 #if KERNEL_USE_AUTO_ALLOC
00135 //--
00136 Thread* Thread::Init(uint16_t ul6StackSize_, PORT_PRIO_TYPE uXPriority_,
     ThreadEntry_t pfEntryPoint_, void* pvArg_)
00137 {
00138
          Thread* pclNew = (Thread*)AutoAlloc::Allocate(sizeof(Thread));
          K_WORD* pwStack = (K_WORD*)AutoAlloc::Allocate(u16StackSize_);
00139
00140
         pclNew->Init(pwStack, u16StackSize_, uXPriority_, pfEntryPoint_, pvArg_);
00141
         return pclNew;
00142 }
00143 #endif
00144
00145 //-
00146 void Thread::Start(void)
00147 {
00148 #if KERNEL_EXTRA_CHECKS
00149
         KERNEL_ASSERT(IsInitialized());
00150 #endif
00151
00152
          // Remove the thread from the scheduler's "stopped" list, and add it
          // to the scheduler's ready list at the proper priority.
00153
00154
         KERNEL_TRACE_1("Starting Thread %d", (uint16_t)m_u8ThreadID);
00155
00156
          CS_ENTER();
00157
         Scheduler::GetStopList()->Remove(this);
00158
         Scheduler::Add(this);
00159
          m_pclOwner
                      = Scheduler::GetThreadList(
     m_uXPriority);
        m_pclCurrent = m_pclOwner;
m_eState = THREAD_STATE_READY;
00160
         m_eState
00161
00162
00163 #if KERNEL_USE_QUANTUM
       if (Kernel::IsStarted()) {
00164
00165
              if (GetCurPriority() >= Scheduler::GetCurrentThread()->
     GetCurPriority()) {
00166
                 // Deal with the thread Quantum
00167
                  Quantum::RemoveThread();
00168
                  Quantum::AddThread(this);
00169
             }
00170
00171 #endif
00172
00173
          if (Kernel::IsStarted()) {
              if (GetCurPriority() >= Scheduler::GetCurrentThread()->
00174
     GetCurPriority()) {
00175
                 Thread::Yield();
00176
00177
00178
         CS_EXIT();
00179 }
00180
00182 void Thread::Stop()
00183 {
00184 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00185
00186 #endif
00187
00188
          bool bReschedule = 0;
00189
          if (m_eState == THREAD_STATE_STOP) {
             return;
00190
00191
         }
00192
00193
         CS_ENTER();
00194
00195
          // If a thread is attempting to stop itself, ensure we call the scheduler
00196
          if (this == Scheduler::GetCurrentThread()) {
00197
              bReschedule = true;
00198
00199
00200
          // Add this thread to the stop-list (removing it from active scheduling)
00201
          // Remove the thread from scheduling
00202
          if (m_eState == THREAD_STATE_READY) {
00203
              Scheduler::Remove(this);
         } else if (m_eState == THREAD_STATE_BLOCKED) {
00204
             m_pclCurrent->Remove(this);
00205
00206
00207
00208
         m_pclOwner = Scheduler::GetStopList();
          m_pclCurrent = m_pclOwner;
00209
          m_pclOwner->Add(this);
00210
          m_eState = THREAD_STATE_STOP;
00211
```

```
00212
00213 #if KERNEL_USE_TIMERS
         // Just to be safe - attempt to remove the thread's timer // from the timer-scheduler (does no harm if it isn't
00214
00215
          // in the timer-list)
00216
00217
          TimerScheduler::Remove(&m_clTimer);
00218 #endif
00219
00220
          CS_EXIT();
00221
          if (bReschedule) {
00222
00223
              Thread::Yield():
00224
00225 }
00226
00227 #if KERNEL_USE_DYNAMIC_THREADS
00228 //---
00229 void Thread::Exit()
00231 #if KERNEL_EXTRA_CHECKS
00232
          KERNEL_ASSERT(IsInitialized());
00233 #endif
00234
          bool bReschedule = 0:
00235
00236
          KERNEL_TRACE_1("Exit Thread %d", m_u8ThreadID);
00237
          if (m_eState == THREAD_STATE_EXIT) {
00238
00239
00240
          CS_ENTER();
00241
00242
00243
          // If this thread is the actively-running thread, make sure we run the
00244
          // scheduler again.
00245
          if (this == Scheduler::GetCurrentThread()) {
00246
              bReschedule = 1;
00247
00248
          // Remove the thread from scheduling
00250
          if (m_eState == THREAD_STATE_READY) {
00251
               Scheduler::Remove(this);
          } else if ((m_eState == THREAD_STATE_BLOCKED) || (m_eState == THREAD_STATE_STOP)) {
00252
             m_pclCurrent->Remove(this);
00253
          }
00254
00255
00256
          m_pclCurrent = 0;
          m_pclOwner = 0;
m_estate = THREAD_STATE_EXIT;
00257
00258
00259
00260
          // We've removed the thread from scheduling, but interrupts might
          // trigger checks against this thread's currently priority before
00261
          // we get around to scheduling new threads. As a result, set the
00262
00263
          // priority to idle to ensure that we always wind up scheduling
          // new threads.
00264
00265
          m_uXCurPriority = 0;
00266
                           = 0;
          m_uXPriority
00267
00268 #if KERNEL_USE_TIMERS
         // Just to be safe - attempt to remove the thread's timer // from the timer-scheduler (does no harm if it isn't // in the timer-list)
00269
00270
00271
00272
          TimerScheduler::Remove(&m_clTimer);
00273 #endif
00274
          CS_EXIT();
00275
00276 #if KERNEL_USE_THREAD_CALLOUTS
00277
          ThreadExitCallout_t pfCallout = Kernel::GetThreadExitCallout();
00278
          if (pfCallout) {
              pfCallout(this);
00279
00280
00281 #endif
00282
00283
          if (bReschedule) {
              // Choose a new "next" thread if we must
Thread::Yield();
00284
00285
00286
          }
00287 }
00288 #endif
00289
00290 #if KERNEL_USE_SLEEP
00291 //---
00293 static void ThreadSleepCallback(Thread* pclOwner_, void* pvData_)
00294 {
00295
           Semaphore* pclSemaphore = static_cast<Semaphore*>(pvData_);
00296
          // Post the semaphore, which will wake the sleeping thread.
00297
          pclSemaphore->Post();
00298 }
00299
```

20.114 thread.cpp 327

```
00301 void Thread::Sleep(uint32_t u32TimeMs_)
00302 {
00303
          Semaphore clSemaphore;
00304
          Timer*
                    pclTimer = g_pclCurrent->GetTimer();
00305
          // Create a semaphore that this thread will block on
00307
          clSemaphore. Init (0, 1);
00308
00309
          // Create a one-shot timer that will call a callback that posts the
          // semaphore, waking our thread.
pclTimer->Init();
00310
00311
00312
          pclTimer->SetIntervalMSeconds(u32TimeMs_);
00313
          pclTimer->SetCallback(ThreadSleepCallback);
00314
          pclTimer->SetData((void*)&clSemaphore);
00315
          pclTimer->SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00316
00317
           // Add the new timer to the timer scheduler, and block the thread
          TimerScheduler::Add(pclTimer);
00318
00319
          clSemaphore.Pend();
00320 }
00321
00322 //---
00323 void Thread::USleep(uint32_t u32TimeUs_)
00324 {
00325
          Semaphore clSemaphore;
00326
                   pclTimer = g_pclCurrent->GetTimer();
          Timer*
00327
00328
          \ensuremath{//} Create a semaphore that this thread will block on
00329
          clSemaphore.Init(0, 1);
00330
00331
          // Create a one-shot timer that will call a callback that posts the
00332
          // semaphore, waking our thread.
00333
          pclTimer->Init();
00334
          pclTimer->SetIntervalUSeconds(u32TimeUs_);
          pclTimer->SetCallback(ThreadSleepCallback);
00335
00336
          pclTimer->SetData((void*)&clSemaphore);
00337
          pclTimer->SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00338
00339
           // Add the new timer to the timer scheduler, and block the thread
00340
          TimerScheduler::Add(pclTimer);
00341
          clSemaphore.Pend();
00342 }
00343 #endif // KERNEL_USE_SLEEP
00344
00345 //----
00346 uint16_t Thread::GetStackSlack()
00347 {
00348 #if KERNEL EXTRA CHECKS
          KERNEL_ASSERT(IsInitialized());
00349
00350 #endif
00351
00352
          K_ADDR wTop
                         = (K_ADDR)m_u16StackSize - 1;
          K_ADDR wBottom = (K_ADDR)0;
K_ADDR wMid = ((wTop + wBottom) + 1) / 2;
00353
00354
00355
00356
00357
          // Logarithmic bisection - find the point where the contents of the // stack go from 0xFF's to non 0xFF. Not Definitive, but accurate enough
00358
00359
          while ((wTop - wBottom) > 1) {
00360
00361 #if STACK_GROWS_DOWN
00362
              if (m_pwStack[wMid] != (K_WORD)(-1))
00363 #else
00364
              if (m_pwStack[wMid] == (K_WORD)(-1))
00365 #endif
              {
  wTop = wMid;
00366
00368
00369
                wBottom = wMid;
00370
00371
00372
              wMid = (wTop + wBottom + 1) / 2;
00373
          }
00374
00375
          CS EXIT();
00376
00377
          return wMid;
00378 }
00379
00380 //---
00381 void Thread::Yield()
00382 {
00383
00384
          CS_ENTER();
00385
          // Run the scheduler
          if (Scheduler::IsEnabled()) {
00386
00387
              Scheduler::Schedule():
```

```
00388
00389
              // Only switch contexts if the new task is different than the old task
00390
              if (Scheduler::GetCurrentThread() !=
     Scheduler::GetNextThread()) {
00391 #if KERNEL_USE_QUANTUM
00392
                  // new thread scheduled. Stop current quantum timer (if it exists),
                  // and restart it for the new thread (if required).
00393
00394
                  Quantum::RemoveThread();
00395
                  Quantum::AddThread((Thread*)g_pclNext);
00396 #endif
00397
                  Thread::ContextSwitchSWI();
00398
              }
00399
         } else {
00400
             Scheduler::QueueScheduler();
00401
         }
00402
          CS EXIT();
00403
00404 }
00405
00406 //-
00407 void Thread::SetPriorityBase(PORT_PRIO_TYPE uXPriority_)
00408 {
00409 #if KERNEL_EXTRA_CHECKS
00410
         KERNEL_ASSERT(IsInitialized());
00411 #endif
00412
00413
          GetCurrent()->Remove(this);
00414
00415
          SetCurrent (Scheduler::GetThreadList (
     m_uXPriority));
00416
00417
          GetCurrent()->Add(this);
00418 }
00419
00420 //---
00421 void Thread::SetPriority(PORT_PRIO_TYPE uXPriority_)
00422 {
00423 #if KERNEL_EXTRA_CHECKS
00424
         KERNEL_ASSERT(IsInitialized());
00425 #endif
00426
00427
         bool bSchedule = 0;
00428
00429
          CS_ENTER();
          // If this is the currently running thread, it's a good idea to reschedule
00430
00431
          // Or, if the new priority is a higher priority than the current thread's.
00432
          if ((g_pclCurrent == this) || (uXPriority_ > g_pclCurrent->
     GetPriority())) {
00433
             bSchedule = 1;
00434
00435
          Scheduler::Remove(this);
00436
          CS_EXIT();
00437
00438
          m_uXCurPriority = uXPriority_;
                          = uXPriority ;
00439
          m_uXPriority
00440
00441
          CS_ENTER();
00442
          Scheduler::Add(this);
00443
         CS_EXIT();
00444
00445
          if (bSchedule) {
              if (Scheduler::IsEnabled()) {
00446
00447
                  CS_ENTER();
00448
                  Scheduler::Schedule();
00449 #if KERNEL_USE_QUANTUM
                 // new thread scheduled. Stop current quantum timer (if it exists), // and restart it for the new thread (if required).
00450
00451
00452
                  Ouantum::RemoveThread();
00453
                  Quantum::AddThread((Thread*)g_pclNext);
00454 #endif
00455
                  CS_EXIT();
00456
                  Thread::ContextSwitchSWI();
00457
              } else {
00458
                 Scheduler::QueueScheduler();
00459
              }
00460
         }
00461 }
00462
00463 //--
00464 void Thread::InheritPriority(PORT PRIO TYPE uXPriority)
00465 {
00466 #if KERNEL_EXTRA_CHECKS
00467
          KERNEL_ASSERT(IsInitialized());
00468 #endif
00469
          SetOwner(Scheduler::GetThreadList(uXPriority));
00470
00471
          m_uXCurPriority = uXPriority_;
```

20.114 thread.cpp 329

```
00472 }
00473
00474 //--
00475 void Thread::ContextSwitchSWI()
00476 {
00477
          // Call the context switch interrupt if the scheduler is enabled.
         if (Scheduler::IsEnabled() == 1) {
00479
              KERNEL_TRACE_1("Context switch to Thread %d", (uint16_t)((
     Thread*)g_pclNext)->GetID());
00480 #if KERNEL_USE_STACK_GUARD
00481
             uint16_t u16Slack;
00482 #if KERNEL_USE_IDLE_FUNC
00483 if (g_pclCurrent->GetID() != 255) { 00484 #endif
00485
                  if (g_pclCurrent->GetStackSlack() <= Kernel::GetStackGuardThreshold())</pre>
     KernelAware::Trace(DBG_FILE, __LINE__,
g_pclCurrent->GetID(), g_pclCurrent->GetStackSlack());
Kernel::Panic(PANIC_STACK_SLACK_VIOLATED);
00486
00487
00488
00489 #if KERNEL_USE_IDLE_FUNC
00490
              }
00491 #endif
00492 #endif
00493
00494 #if KERNEL_USE_THREAD_CALLOUTS
00495
              ThreadContextCallout_t pfCallout = Kernel::GetThreadContextSwitchCallout
00496
              if (pfCallout) {
00497
                  pfCallout(g_pclCurrent);
00498
              }
00499 #endif
00500
              KernelSWI::Trigger();
00501
00502 }
00503
00504 #if KERNEL USE TIMEOUTS || KERNEL USE SLEEP
00506 Timer* Thread::GetTimer()
00507
00508 #if KERNEL_EXTRA_CHECKS
        KERNEL_ASSERT(IsInitialized());
00509
00510 #endif
00511
00512
         return &m_clTimer;
00513 }
00514 #endif
00515 #if KERNEL_USE_TIMEOUTS
00516 //---
00517 void Thread::SetExpired(bool bExpired_)
00518 {
00519 #if KERNEL_EXTRA_CHECKS
00520
         KERNEL_ASSERT(IsInitialized());
00521 #endif
00522
00523
          m bExpired = bExpired;
00524 }
00525
00526 //---
00527 bool Thread::GetExpired()
00528 {
00529 #if KERNEL_EXTRA_CHECKS
00530
         KERNEL_ASSERT(IsInitialized());
00531 #endif
00532
00533
          return m_bExpired;
00534 }
00535 #endif
00536
00537 #if KERNEL_USE_IDLE_FUNC
00538 //--
00539 void Thread::InitIdle(void)
00540 {
00541
          m eState
                           = THREAD STATE READY:
00542
          ClearNode();
00543
00544
          m_uXPriority
00545
          m_uXCurPriority = 0;
          m_pfEntryPoint = 0;
m_pvArg = 0;
00546
         m_pvArg
00547
          m_u8ThreadID
                           = 255;
00548
00549 #if KERNEL_USE_THREADNAME
00550
         m_szName = "IDLE";
00551 #endif
00552 }
00553 #endif
```

# 20.115 /home/moslevin/projects/mark3-source/kernel/threadlist.cpp File Reference

Thread linked-list definitions.

```
#include "kerneltypes.h"
#include "ll.h"
#include "threadlist.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

#### 20.115.1 Detailed Description

Thread linked-list definitions.

Definition in file threadlist.cpp.

# 20.116 threadlist.cpp

```
00001 /*
00002
00003
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00022 #Include kernertypes.n
00023 #include "ll.h"
00024 #include "threadlist.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]------
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_THREADLIST_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037 #include "kerneldebug.h"
00038
00039 //--
00040 void ThreadList::SetPriority(PORT_PRIO_TYPE uXPriority_)
00041 {
00042
          m uXPriority = uXPriority ;
00043 }
00044
00045 //--
00046 void ThreadList::SetMapPointer(PriorityMap* pclMap_)
00047 {
00048
          m_pclMap = pclMap_;
00049 }
00050
00051 //--
00052 void ThreadList::Add(LinkListNode* node_)
00053 {
00054
           CircularLinkList::Add(node);
00055
          CircularLinkList::PivotForward();
00056
```

```
// We've specified a bitmap for this threadlist
00058
          if (m_pclMap) {
00059
               // Set the flag for this priority level
00060
              m_pclMap->Set(m_uXPriority);
00061
00062 }
00064 //---
00065 void ThreadList::AddPriority(LinkListNode* node_)
00066 {
00067
          Thread* pclCurr = static_cast<Thread*>(GetHead());
          if (!pclCurr) {
00068
00069
              Add (node );
00070
              return;
00071
00072
          PORT_PRIO_TYPE uXHeadPri = pclCurr->GetCurPriority();
00073
00074
          Thread* pclTail = static_cast<Thread*>(GetTail());
Thread* pclNode = static_cast<Thread*>(node_);
00076
00077
          // Set the threadlist's priority level, flag pointer, and then add the
00078
          // thread to the threadlist
00079
          PORT_PRIO_TYPE uXPriority = pclNode->GetCurPriority();
00080
          do {
00081
              if (uXPriority > pclCurr->GetCurPriority()) {
00082
00083
              pclCurr = static_cast<Thread*>(pclCurr->GetNext());
00084
00085
          } while (pclCurr != pclTail);
00086
00087
          // Insert pclNode before pclCurr in the linked list.
00088
          InsertNodeBefore(pclNode, pclCurr);
00089
00090
          // If the priority is greater than current head, reset
00091
          // the head pointer.
         if (uXPriority > uXHeadPri) {
   m_pstHead = pclNode;
   m_pstTail = m_pstHead->prev;
00092
00093
00095
          } else if (pclNode->GetNext() == m_pstHead) {
00096
             m_pstTail = pclNode;
00097
          }
00098 }
00099
00100 //---
00101 void ThreadList::Add(LinkListNode* node_, PriorityMap* pclMap_,
     PORT_PRIO_TYPE uXPriority_)
00102 {
00103
          \ensuremath{//} Set the threadlist's priority level, flag pointer, and then add the
          // thread to the threadlist
00104
          SetPriority(uXPriority_);
00105
00106
          SetMapPointer(pclMap_);
00107
          Add (node_);
00108 }
00109
00110 //----
00111 void ThreadList::Remove(LinkListNode* node)
00112 {
00113
           // Remove the thread from the list
00114
         CircularLinkList::Remove(node_);
00115
          // If the list is empty...
00116
00117
         if (!m_pstHead && m_pclMap) {
    // Clear the bit in the bitmap at this priority level
00118
00119
              m_pclMap->Clear(m_uXPriority);
00120
          }
00121 }
00122
00123 //---
00124 Thread* ThreadList::HighestWaiter()
00125 {
00126
          return static_cast<Thread*>(GetHead());
00127 }
```

## 20.117 /home/moslevin/projects/mark3-source/kernel/timer.cpp File Reference

Timer implementations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

## 20.117.1 Detailed Description

Timer implementations.

Definition in file timer.cpp.

# 20.118 timer.cpp

```
00001 /*=
00002
00003
00004
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h" 00023 #include "mark3cfg.h"
00024
00025 #include "timer.h"
00026 #include "timerlist.h"
00027 #include "timerscheduler.h"
00028 #include "kerneltimer.h"
00029 #include "threadport.h"
00030 #include "quantum.h"
00031
00032 #define _CAN_HAS_DEBUG
00033 //--[Autogenerated - Do Not Modify]------
00034 #include "dbg_file_list.h"
00035 #include "buffalogger.h"
00036 #if defined(DBG_FILE)
00037 #error "Debug logging file token already defined! Bailing."
00038 #else
00039 #define DBG_FILE _DBG___KERNEL_TIMER_CPP
00040 #endif
00041 //--[End Autogenerated content]-----
00042
00043 #include "kerneldebug.h"
00044
00045 #if KERNEL_USE_TIMERS
00046
00047 //----
00048 Timer::Timer()
00049 {
00050 #if KERNEL_EXTRA_CHECKS
00051
          m_u8Initialized = TIMER_INVALID_COOKIE;
00052 #endif
00053
          m_u8Flags = 0;
00054 }
00055
00056 //---
00057 void Timer::Init()
```

20.118 timer.cpp 333

```
00058 {
00059 #if KERNEL_EXTRA_CHECKS
       if (IsInitialized()) {
00060
            KERNEL_ASSERT((m_u8Flags & TIMERLIST_FLAG_ACTIVE) == 0);
00061
00062
00063 #endif
00064
00065
         ClearNode();
                             = 0;
00066
         m_u32Interval
00067
         m_u32TimerTolerance = 0;
00068
         m_u32TimeLeft = 0;
00069
        m_u8Flags
00070
00071 #if KERNEL_EXTRA_CHECKS
00072
        SetInitialized();
00073 #endif
00074 }
00075
00077 void Timer::Start (bool bRepeat_, uint32_t u32IntervalMs_,
      TimerCallback_t pfCallback_, void* pvData_)
00078 {
00079 #if KERNEL EXTRA CHECKS
08000
        KERNEL ASSERT (IsInitialized());
00081 #endif
00083
          if (m_u8Flags & TIMERLIST_FLAG_ACTIVE) {
         __uofla
return;
}
00084
00085
00086
00087
         SetIntervalMSeconds(u32IntervalMs_);
         m_u32TimerTolerance = 0;
m_pfCallback = pfCallback_;
m_pvData = pvData_;
00088
00089
00090
00091
00092
         if (!bRepeat_) {
00093
            m_u8Flags = TIMERLIST_FLAG_ONE_SHOT;
         } else {
         m_u8Flags = 0;
00095
00096
00097
00098
         Start();
00099 }
00100
00102 void Timer::Start(
00103
         bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_,
     TimerCallback_t pfCallback_, void* pvData_)
00104 {
00105 #if KERNEL_EXTRA_CHECKS
        KERNEL_ASSERT(IsInitialized());
00107 #endif
00108
00109
          if (m_u8Flags & TIMERLIST_FLAG_ACTIVE) {
         __uoFlavreturn;
00110
00111
00112
00113
          m_u32TimerTolerance = MSECONDS_TO_TICKS(u32ToleranceMs_);
00114
         Start(bRepeat_, u32IntervalMs_, pfCallback_, pvData_);
00115 }
00116
00117 //---
00118 void Timer::Start()
00119 {
00120 #if KERNEL_EXTRA_CHECKS
00121
        KERNEL_ASSERT(IsInitialized());
00122 #endif
00123
00124
          if (m_u8Flags & TIMERLIST_FLAG_ACTIVE) {
         __uorla
return;
}
00125
00126
00127
00128
         m_pclOwner = Scheduler::GetCurrentThread();
         TimerScheduler::Add(this);
00129
00130 }
00131
00132 //---
00133 void Timer::Stop()
00134 (
00135 #if KERNEL EXTRA CHECKS
         KERNEL_ASSERT(IsInitialized());
00136
00137 #endif
00138
00139
          if (!(m_u8Flags & TIMERLIST_FLAG_ACTIVE)) {
                 return;
00140
00141
00142
          TimerScheduler::Remove(this);
```

```
00145 //--
00146 void Timer::SetIntervalTicks(uint32_t u32Ticks_)
00147 {
00148 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00151
00152
          m u32Interval = u32Ticks ;
00153 }
00154
00155 //----
00158 void Timer::SetIntervalSeconds(uint32_t u32Seconds_)
00159
00160 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00161
00162 #endif
00164
          m_u32Interval = SECONDS_TO_TICKS(u32Seconds_);
00165 }
00166
00167 //---
00168 void Timer::SetIntervalMSeconds(uint32_t u32MSeconds_)
00170 #if KERNEL_EXTRA_CHECKS
00171
         KERNEL_ASSERT(IsInitialized());
00172 #endif
00173
00174
          m u32Interval = MSECONDS TO TICKS(u32MSeconds);
00175 }
00176
00177 //---
00178 void Timer::SetIntervalUSeconds(uint32_t u32USeconds_)
00179 {
00180 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00182 #endif
00183
00184 #if KERNEL_TIMERS_TICKLESS
       if (u32USeconds_ < KERNEL_TIMERS_MINIMUM_DELAY_US) {
    u32USeconds_ = KERNEL_TIMERS_MINIMUM_DELAY_US;</pre>
00185
00186
00187
00188 #endif
00189
00190
          m_u32Interval = USECONDS_TO_TICKS(u32USeconds_);
00191 }
00192
00193 //--
00194 void Timer::SetTolerance(uint32_t u32Ticks_)
00195 {
00196 #if KERNEL_EXTRA_CHECKS
00197
         KERNEL_ASSERT(IsInitialized());
00198 #endif
00199
         m u32TimerTolerance = u32Ticks ;
00200 }
00201
00202 #endif
```

## 20.119 /home/moslevin/projects/mark3-source/kernel/timerlist.cpp File Reference

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timerlist.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.120 timerlist.cpp 335

## 20.119.1 Detailed Description

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

Definition in file timerlist.cpp.

## 20.120 timerlist.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025
00026 #include "timerlist.h" 00027 #include "kerneltimer.h"
00028 #include "threadport.h"
00029 #include "quantum.h"
00030
00031 #define _CAN_HAS_DEBUG
00032 //--[Autogenerated - Do Not Modify]-----
00033 #include "dbg_file_list.h"
00034 #include "buffalogger.h"
00035 #if defined(DBG_FILE)
00036 #error "Debug logging file token already defined! Bailing."
00037 #else
00038 #define DBG_FILE _DBG___KERNEL_TIMERLIST_CPP
00039 #endif
00040 //--[End Autogenerated content]-----
00041
00042 #include "kerneldebug.h"
00043
00044 #if KERNEL_USE_TIMERS
00045 //--
00046 TimerList TimerScheduler::m_clTimerList;
00047
00048 //--
00049 void TimerList::Init(void)
00050 {
00051
          m_bTimerActive = 0;
00052
          m_u32NextWakeup = 0;
00053 }
00054
00055 //--
00056 void TimerList::Add(Timer* pclListNode_)
00057 (
00058 #if KERNEL_TIMERS_TICKLESS
00059
          bool
                  bStart = 0;
00060
          int32_t lDelta;
00061 #endif
00062
00063
          CS_ENTER();
00064
00065 #if KERNEL_TIMERS_TICKLESS
         if (GetHead() == NULL) {
00066
00067
              bStart = 1;
00068
00069
          if (pclListNode_->m_u32Interval < PORT_MIN_TIMER_TICKS) {</pre>
00070
              pclListNode_->m_u32Interval = PORT_MIN_TIMER_TICKS;
00071
00072 #endif
00073
00074
          pclListNode_->ClearNode();
00075
          DoubleLinkList::Add(pclListNode_);
00076
00077
          // Set the initial timer value
00078
          pclListNode_->m_u32TimeLeft = pclListNode_->m_u32Interval;
00080 #if KERNEL_TIMERS_TICKLESS
```

```
if (!bStart) {
             // If the new interval is less than the amount of time remaining...
lDelta = (int32_t)((uint32_t)KernelTimer::TimeToExpiry() - pclListNode_->
00082
00083
     m_u32Interval);
00084
00085
               if (lDelta > 0) {
                   // Set the new expiry time on the timer.
00087
                   m_u32NextWakeup = (uint32_t)
      KernelTimer::SubtractExpiry((uint32_t)lDelta);
00088
             }
00089
          } else {
00090
             m_u32NextWakeup = pclListNode_->m_u32Interval;
               KernelTimer::SetExpiry(m_u32NextWakeup);
00091
00092
              KernelTimer::Start();
00093
00094 #endif
00095
00096
          // Set the timer as active.
          pclListNode_->m_u8Flags |= TIMERLIST_FLAG_ACTIVE;
00098
          CS_EXIT();
00099 }
00100
00101 //---
00102 void TimerList::Remove(Timer* pclLinkListNode_)
00103 {
00104
          CS ENTER();
00105
00106
          DoubleLinkList::Remove(pclLinkListNode_);
00107
          pclLinkListNode_->m_u8Flags &= ~TIMERLIST_FLAG_ACTIVE;
00108
00109 #if KERNEL_TIMERS_TICKLESS
        if (this->GetHead() == NULL) {
00110
00111
              KernelTimer::Stop();
00112
00113 #endif
00114
00115
          CS EXIT();
00116 }
00117
00118 //---
00119 void TimerList::Process(void)
00120 {
00121 #if KERNEL_TIMERS_TICKLESS
       uint32_t u32NewExpiry;
00122
          uint32_t u320vertime;
00123
00124
          bool
                   bContinue;
00125 #endif
00126
         Timer* pclNode;
Timer* pclPrev;
00127
00128
00130 #if KERNEL_USE_QUANTUM
00131
        Quantum::SetInTimer();
00132 #endif
00133 #if KERNEL_TIMERS_TICKLESS
00134 // Clear the timer and its expiry time - keep it running though
          KernelTimer::ClearExpiry();
         do {
00136
00137 #endif
00138
               pclNode = static_cast<Timer*>(GetHead());
              pclPrev = NULL;
00139
00140
00141 #if KERNEL_TIMERS_TICKLESS
              bContinue
              u32NewExpiry = MAX_TIMER_TICKS; // Used to indicate that no timers are pending
00143
00144 #endif
00145
00146
              \ensuremath{//} Subtract the elapsed time interval from each active timer.
00147
              while (pclNode) {
               // Active timers only...
00149
                   if (pclNode->m_u8Flags & TIMERLIST_FLAG_ACTIVE) {
00150 // Did the timer expire?
00151 #if KERNEL_TIMERS_TICKLESS
                       if (pclNode->m_u32TimeLeft <= m_u32NextWakeup)</pre>
00152
00153 #else
00154
                       pclNode->m_u32TimeLeft--;
00155
                       if (0 == pclNode->m_u32TimeLeft)
00156 #endif
00157
                           // Yes - set the "callback" flag - we'll execute the callbacks later
00158
                           pclNode->m_u8Flags |= TIMERLIST_FLAG_CALLBACK;
00159
00160
00161
                            if (pclNode->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT) {
00162
                                // If this was a one-shot timer, deactivate the timer.
                                pclNode->m_u8Flags |= TIMERLIST_FLAG_EXPIRED;
pclNode->m_u8Flags &= ~TIMERLIST_FLAG_ACTIVE;
00163
00164
00165
                            } else {
```

20.120 timerlist.cpp 337

```
00166
                                // Reset the interval timer.
                                 // I think we're good though..
00168
00169
                                pclNode->m_u32TimeLeft = pclNode->
      m_u32Interval;
00170
00171 #if KERNEL_TIMERS_TICKLESS
                                // If the time remaining (plus the length of the tolerance interval)
                                 // is less than the next expiry interval, set the next expiry interval.
00173
00174
                                uint32_t u32Tmp = pclNode->m_u32TimeLeft + pclNode->
      m_u32TimerTolerance;
00175
00176
                                if (u32Tmp < u32NewExpiry) {</pre>
00177
                                    u32NewExpiry = u32Tmp;
00178
00179 #endif
00180
00181
00182 #if KERNEL_TIMERS_TICKLESS
                       else {
00184
                            // Not expiring, but determine how long to run the next timer interval for.
00185
                            pclNode->m_u32TimeLeft -= m_u32NextWakeup;
00186
                            if (pclNode->m_u32TimeLeft < u32NewExpiry) {</pre>
                                u32NewExpiry = pclNode->m_u32TimeLeft;
00187
00188
00189
                        }
00190 #endif
00191
00192
                   pclNode = static_cast<Timer*>(pclNode->GetNext());
00193
               }
00194
00195
               \ensuremath{//} Process the expired timers callbacks.
00196
               pclNode = static_cast<Timer*>(GetHead());
00197
               while (pclNode) {
00198
                   pclPrev = pclNode;
                   pclNode = static_cast<Timer*>(pclNode->GetNext());
00199
00200
                   // If the timer expired, run the callbacks now.
if (pclPrev->m_u8Flags & TIMERLIST_FLAG_CALLBACK) {
00201
00202
00203
                        bool bRemove = false;
00204
                        // If this was a one-shot timer, tag it for removal
00205
                        if (pclPrev->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT) {
00206
                            bRemove = true;
00207
00208
00209
                        // Run the callback. these callbacks must be very fast...
00210
                       pclPrev->m_pfCallback(pclPrev->m_pclOwner, pclPrev->
      m_pvData);
00211
                        pclPrev->m_u8Flags &= ~TIMERLIST_FLAG_CALLBACK;
00212
00213
                        // Remove one-shot-timers
00214
                        if (bRemove) {
00215
                            Remove (pclPrev);
00216
00217
                   }
               }
00218
00219
00220 #if KERNEL_TIMERS_TICKLESS
              // Check to see how much time has elapsed since the time we // acknowledged the interrupt...
00221
00222
00223
               u32Overtime = (uint32_t)KernelTimer::GetOvertime();
00224
00225
               if (u320vertime >= u32NewExpiry) {
                   m_u32NextWakeup = u32Overtime;
bContinue = 1;
00226
00227
                   bContinue
00228
00229
               // If it's taken longer to go through this loop than would take us to
00230
00231
               \ensuremath{//} the next expiry, re-run the timing loop
00232
00233
          } while (bContinue);
00234
00235
          // This timer elapsed, but there's nothing more to do...
          // Turn the timer off.
if (u32NewExpiry >= MAX_TIMER_TICKS) {
00236
00237
               KernelTimer::Stop();
00238
00239
          } else {
00240
               // Update the timer with the new "Next Wakeup" value, plus whatever
00241
               // overtime has accumulated since the last time we called this handler
00242
              m_u32NextWakeup = (uint32_t)KernelTimer::SetExpiry(
00243
     u32NewExpiry + u32Overtime);
00244
00245 #endif
00246 #if KERNEL_USE_QUANTUM
00247
          Quantum::ClearInTimer();
00248 #endif
00249 }
```

```
00250
00251 #endif // KERNEL_USE_TIMERS
```

# 20.121 /home/moslevin/projects/mark3-source/kernel/tracebuffer.cpp File Reference

Kernel trace buffer class definition.

```
#include "kerneltypes.h"
#include "tracebuffer.h"
#include "mark3cfg.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

## 20.121.1 Detailed Description

Kernel trace buffer class definition.

Definition in file tracebuffer.cpp.

## 20.122 tracebuffer.cpp

```
00001 /*==========
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-----
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00019 #include "kerneltypes.h"
00020 #include "tracebuffer.h"
00021 #include "mark3cfg.h"
00022
00023 #define _CAN_HAS_DEBUG
00024 //--[Autogenerated - Do Not Modify]-----
00025 #include "dbg_file_list.h"
00026 #include "buffalogger.h"
00027 #if defined(DBG_FILE)
00028 #error "Debug logging file token already defined! Bailing."
00029 #else
00030 #define DBG_FILE _DBG___KERNEL_TRACEBUFFER_CPP
00031 #endif
00032
00033 #include "kerneldebug.h"
00034
00035 //--[End Autogenerated content]-----
00037 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00038 //--
00039 TraceBufferCallback_t TraceBuffer::m_pfCallback;
00040 uint16 t
                             TraceBuffer::m_u16Index;
00041 uint16_t
                             TraceBuffer::m_u16SyncNumber;
00042 uint16_t
                             TraceBuffer::m_au16Buffer[(TRACE_BUFFER_SIZE / sizeof(uint16_t))];
00043
00044 //---
00045 void TraceBuffer::Init()
00046 {
00047 }
00048
```

```
00050 void TraceBuffer::Write(uint16_t* pu16Data_, uint16_t u16Size_)
00051 {
00052
           // Pipe the data directly to the circular buffer
00053
          uint16 t u16Start;
00054
          // Update the circular buffer index in a critical section. The
00056
          // rest of the operations can take place in any context.
00057
          CS_ENTER();
00058
          uint16_t u16NextIndex;
          ul6Start = m_ul6Index;
ul6NextIndex = m_ul6Index + ul6Size_;
00059
00060
          if (u16NextIndex >= (sizeof(m_au16Buffer) / sizeof(uint16_t))) {
00061
00062
              u16NextIndex -= (sizeof(m_au16Buffer) / sizeof(uint16_t));
00063
          m_u16Index = u16NextIndex;
00064
00065
          CS_EXIT();
00066
00067
          // Write the data into the circular buffer.
00068
          uint16_t i;
00069
                    bCallback = false;
00070
          bool
                   bPingPong = false;
         for (i = 0; i < u16Size_; i++) {
    m_au16Buffer[u16Start++] = pu16Data_[i];
    if (u16Start >= (sizeof(m_au16Buffer) / sizeof(uint16_t))) {
        u16Start = 0;
    }
}
00071
00072
00073
00074
00075
                   bCallback = true;
00076
             } else if (ul6Start == ((sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2)) {
00077
                  bPingPong = true;
                  bCallback = true;
00078
00079
              }
08000
         }
00081
00082
          // Done writing - see if there's a 50% or rollover callback
00083
         if (bCallback && m_pfCallback) {
          uint16_t u16Size = (sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2;
00084
00085
              if (bPingPong) {
00086
                  m_pfCallback(m_au16Buffer, u16Size, bPingPong);
00087
              } else {
88000
                 m_pfCallback(m_au16Buffer + u16Size, u16Size, bPingPong);
00089
              }
00090
          }
00091 }
00092
00093 #endif
```

# 20.123 /home/moslevin/projects/mark3-source/libs/mark3c/public/fake\_types.h File Reference

C-struct definitions that mirror.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

## 20.123.1 Detailed Description

C-struct definitions that mirror.

This header contains a set of "fake" structures that have the same memory layout as the kernel objects in C++ (taking into account inheritence, etc.). These are used for sizing the opaque data blobs that are declared in C, which then become instantiated as C++ kernel objects via the bindings provided.

Definition in file fake\_types.h.

## 20.124 fake\_types.h

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00026 #include "kerneltypes.h"
00027 #include "mark3cfg.h"
00028
00029 #ifndef ___FAKE_TYPES_H__
00030 #define ___FAKE_TYPES_H_
00031
00032 #if defined(__cplusplus)
00033 extern "C" {
00034 #endif
00035
00036 //----
00037 typedef struct {
         void* prev;
00038
00039
          void* next;
00040 } Fake_LinkedListNode;
00041
00042 //----
00043 typedef struct {
00044
         void* head;
         void* tail;
00045
00046 } Fake_LinkedList;
00047
00048 //----
00049 typedef struct {
       Fake_LinkedList fake_list;
00050
00051
         PORT_PRIO_TYPE m_uXPriority;
00052
         void*
                          m_pclMap;
00053 } Fake_ThreadList;
00054
00055 //----
00056 typedef struct {
         Fake_LinkedListNode m_ll_node;
00057
00058 #if KERNEL_EXTRA_CHECKS
00059
         uint8_t
                              m_u8Initialized;
00060 #endif
00061
         uint8 t
                             m u8Flags;
                             m_pfCallback;
00062
         void*
00063
         uint32_t
                             m_u32Interval;
00064
                             m_u32TimeLeft;
         uint32 t
         uint32_t
00065
                              m_u32TimerTolerance;
                             m_pclOwner;
00066
         void*
00067
         void*
                              m_pvData;
00068 } Fake_Timer;
00069
00071 typedef struct {
00072
         Fake_LinkedListNode m_ll_node;
00073
         K_WORD*
                              m_pwStackTop;
00074
         K WORD*
                              m_pwStack;
00075
                              m_u8ThreadID;
         uint8 t
00076
         PORT_PRIO_TYPE
                              m uXPriority;
         PORT_PRIO_TYPE
                              m_uXCurPriority;
00078
          uint8_t
                              m_eState;
00079 #if KERNEL_USE_EXTENDED_CONTEXT
08000
         void*
                  m_pvExtendedContext;
00081 #endif
00082 #if KERNEL_USE_THREADNAME
00083
         const char* m_szName;
00084 #endif
00085
         uint16_t m_u16StackSize;
00086
         void*
                 m_pclCurrent;
00087
          void*
                   m_pclOwner;
00088
         void*
                   m_pfEntryPoint;
00089
          void*
                   m_pvArq;
00090 #if KERNEL_USE_QUANTUM
00091
         uint16_t m_u16Quantum;
00092 #endif
00093 #if KERNEL_USE_EVENTFLAG
         uint16_t m_u16FlagMask;
uint8_t m_eFlagMode;
00094
00095
00096 #endif
```

20.124 fake\_types.h 341

```
00097 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00098
         Fake_Timer m_clTimer;
00099 #endif
00100 #if KERNEL_USE_TIMEOUTS
00101
        bool m_bExpired;
00102 #endif
00103 } Fake_Thread;
00104
00105 //----
00106 typedef struct {
         Fake_ThreadList thread_list;
00107
00108 #if KERNEL_EXTRA_CHECKS
                     m_u8Initialized;
00109
         uint8_t
00110 #endif
00113 } Fake_Semaphore;
00114
00115 //----
00116 typedef struct {
00117
         Fake_ThreadList thread_list;
00118 #if KERNEL_EXTRA_CHECKS
                      m_u8Initialized;
00119
        uint8_t
00120 #endif
                       m_u8Recurse;
m_bReady;
m_u8MaxPri;
m_pc10wner;
       uint8_t
bool
00121
00122
00123
         uint8_t
        void*
00124
00125 } Fake_Mutex;
00126
00127 //---
00128 typedef struct {
00129 Fake_LinkedListNode list_node;
00130 void* m_pvData;
                   m_pvData;
m_u16Code;
00131
         uint16 t
00132 } Fake_Message;
00133
00135 typedef struct {
00136 Fake_Semaphore m_clSemaphore;
00137 Fake_LinkedList m_clLinkList;
00138 } Fake_MessageQueue;
00139
00140 //----
00141 typedef struct {
       uint16_t
                        m_u16Head;
00142
00143
         uint16_t
                        m_u16Tail;
00144
         uint16_t
                        m_u16Count;
                        m_u16Free;
00145
         uint16 t
00146
         uint16_t
                        m u16ElementSize:
00147
         void*
                        m_pvBuffer;
00148
         Fake_Semaphore m_clRecvSem;
00149 #if KERNEL_USE_TIMEOUTS
00150
        Fake_Semaphore m_clSendSem;
00151 #endif
00152 } Fake_Mailbox;
00154 //----
00155 typedef struct {
00156
         Fake_ThreadList thread_list;
00157 #if KERNEL_EXTRA_CHECKS
00158
       uint8_t
                        m u8Initialized;
00159 #endif
00160 } Fake_Notify;
00161
00162 //----
00163 typedef struct {
         Fake_ThreadList thread_list;
00164
00165 #if KERNEL_EXTRA_CHECKS
00166
         uint8_t m_u8Initialized;
00167 #endif
00168
        uint16_t
                        m_u16EventFlag;
00169 } Fake_EventFlag;
00170
00171 #if defined(__cplusplus)
00172 }
00173 #endif
00174
00175 #endif // __FAKE_TYPES_H__
```

# 20.125 /home/moslevin/projects/mark3-source/libs/mark3c/public/mark3c.h File Reference

Header providing C-language API bindings for the Mark3 kernel.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "fake_types.h"
#include "driver3c.h"
#include <stdint.h>
#include <stdbool.h>
```

## **Typedefs**

```
typedef void * EventFlag_t
```

EventFlag opaque handle data type.

typedef void \* Mailbox\_t

Mailbox opaque handle data type.

• typedef void \* Message\_t

Message opaque handle data type.

typedef void \* MessageQueue\_t

MessageQueue opaque handle data type.

typedef void \* Mutex\_t

Mutex opaque handle data type.

typedef void \* Notify\_t

Notification object opaque handle data type.

typedef void \* Semaphore\_t

Semaphore opaque handle data type.

typedef void \* Thread\_t

Thread opaque handle data type.

typedef void \* Timer\_t

Timer opaque handle data type.

#### **Functions**

```
void * AutoAlloc (uint16_t u16Size_)
```

AutoAlloc.

Semaphore\_t Alloc\_Semaphore (void)

Alloc\_Semaphore.

Mutex\_t Alloc\_Mutex (void)

Alloc\_Mutex.

EventFlag\_t Alloc\_EventFlag (void)

Alloc EventFlag.

Message\_t Alloc\_Message (void)

Alloc\_Message.

• MessageQueue\_t Alloc\_MessageQueue (void)

Alloc\_MessageQueue.

Notify\_t Alloc\_Notify (void)

Alloc\_Notify.

```
    Mailbox_t Alloc_Mailbox (void)

     Alloc_Mailbox.

    Thread_t Alloc_Thread (void)

     Alloc_Thread.

    Timer_t Alloc_Timer (void)

     Alloc_Timer.

    void Kernel Init (void)

     Kernel_Init.

    void Kernel_Start (void)

     Kernel Start.
· bool Kernel IsStarted (void)
     Kernel IsStarted.

    void Kernel_SetPanic (PanicFunc_t pfPanic_)

     Kernel_SetPanic.

    bool Kernel IsPanic (void)

     Kernel_IsPanic.

    void Kernel_Panic (uint16_t u16Cause_)

     Kernel Panic.

    void Kernel_SetIdleFunc (IdleFunc_t pfIdle_)

     Kernel_SetIdleFunc.

    void Kernel_SetThreadCreateCallout (thread_create_callout_t pfCreate_)

     Kernel SetThreadCreateCallout.

    void Kernel_SetThreadExitCallout (thread_exit_callout_t pfExit_)

     Kernel_SetThreadExitCallout.

    void Kernel_SetThreadContextSwitchCallout (thread_context_callout_t pfContext_)

     Kernel SetThreadContextSwitchCallout.

    thread_create_callout_t Kernel_GetThreadCreateCallout (void)

     Kernel_GetThreadCreateCallout.

    thread_exit_callout_t Kernel_GetThreadExitCallout (void)

     Kernel GetThreadExitCallout.

    thread_context_callout_t Kernel_GetThreadContextSwitchCallout (void)

     Kernel_GetThreadContextSwitchCallout.

    void Scheduler_Enable (bool bEnable_)

     Scheduler_Enable.
• bool Scheduler_IsEnabled (void)
     Scheduler_IsEnabled.

    Thread t Scheduler GetCurrentThread (void)

     Scheduler_GetCurrentThread.

    void Thread_Init (Thread_t handle, K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE u ←

  XPriority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)
      Thread Init.

    void Thread_Start (Thread_t handle)

      Thread Start.

    void Thread_Stop (Thread_t handle)

      Thread_Stop.

    PORT_PRIO_TYPE Thread_GetPriority (Thread_t handle)

      Thread_GetPriority.

    PORT_PRIO_TYPE Thread_GetCurPriority (Thread_t handle)

      Thread_GetCurPriority.

    void Thread SetQuantum (Thread t handle, uint16 t u16Quantum )

      Thread SetQuantum.
```

```
    uint16_t Thread_GetQuantum (Thread_t handle)

     Thread_GetQuantum.
• void Thread SetPriority (Thread t handle, PORT PRIO TYPE uXPriority )
     Thread_SetPriority.

    void Thread_Exit (Thread_t handle)

     Thread_Exit.

    void Thread Sleep (uint32 t u32TimeMs )

     Thread_Sleep.

    void Thread_USleep (uint32_t u32TimeUs_)

     Thread_USleep.

    void * Thread GetExtendedContext (Thread t handle)

     Thread GetExtendedContext.

    void Thread_SetExtendedContext (Thread_t handle, void *pvData_)

      Thread_SetExtendedContext.

    void Thread_Yield (void)

     Thread Yield.

    void Thread_SetID (Thread_t handle, uint8_t u8ID_)

     Thread_SetID.
• uint8_t Thread_GetID (Thread_t handle)
     Thread_GetID.

    uint16 t Thread GetStackSlack (Thread t handle)

     Thread_GetStackSlack.

    ThreadState t Thread GetState (Thread t handle)

     Thread GetState.

    void Timer_Init (Timer_t handle)

    void Timer_Start (Timer_t handle, bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_

  , TimerCallbackC_t pfCallback_, void *pvData_)
     Timer_Start.
• void Timer_Restart (Timer_t handle)
     Timer_Restart.

    void Timer_Stop (Timer_t handle)

     Timer_Stop.
• void Semaphore_Init (Semaphore_t handle, uint16_t u16InitVal_, uint16_t u16MaxVal_)
     Semaphore_Init.

    void Semaphore_Post (Semaphore_t handle)

     Semaphore_Post.

    void Semaphore Pend (Semaphore t handle)

     Semaphore Pend.

    bool Semaphore_TimedPend (Semaphore_t handle, uint32_t u32WaitTimeMS_)

     Semaphore_TimedPend.

    void Mutex Init (Mutex t handle)

     Mutex Init.

    void Mutex_Claim (Mutex_t handle)

     Mutex_Claim.

    void Mutex_Release (Mutex_t handle)

     Mutex_Release.

    bool Mutex TimedClaim (Mutex t handle, uint32 t u32WaitTimeMS )

     Mutex_TimedClaim.

    void EventFlag Init (EventFlag t handle)
```

EventFlag Init.

```
    uint16_t EventFlag_Wait (EventFlag_t handle, uint16_t u16Mask_, EventFlagOperation_t eMode_)

     EventFlag_Wait.

    uint16 t EventFlag TimedWait (EventFlag t handle, uint16 t u16Mask , EventFlagOperation t eMode ←

  , uint32 t u32TimeMS )
     EventFlag_TimedWait.

    void EventFlag_Set (EventFlag_t handle, uint16_t u16Mask_)

     EventFlag Set.

    void EventFlag_Clear (EventFlag_t handle, uint16_t u16Mask_)

     EventFlag_Clear.

    uint16_t EventFlag_GetMask (EventFlag_t handle)

     EventFlag GetMask.

    void Notify_Init (Notify_t handle)

     Notify_Init.

    void Notify_Signal (Notify_t handle)

     Notify_Signal.

    void Notify Wait (Notify t handle, bool *pbFlag )

     Notify Wait.
• bool Notify_TimedWait (Notify_t handle, uint32_t u32WaitTimeMS_, bool *pbFlag_)
     Notify TimedWait.

    void Message_Init (Message_t handle)

     Message Init.
• void Message_SetData (Message_t handle, void *pvData )
     Message_SetData.

    void * Message_GetData (Message_t handle)

     Message_GetData.

    void Message_SetCode (Message_t handle, uint16_t u16Code_)

     Message_SetCode.

    uint16 t Message GetCode (Message t handle)

     Message GetCode.

    void GlobalMessagePool_Push (Message_t handle)

     GlobalMessagePool Push.

    Message_t GlobalMessagePool_Pop (void)

     GlobalMessagePool_Pop.
• void MessageQueue_Init (MessageQueue_t handle)
     MessageQueue_Init.

    Message_t MessageQueue_Receive (MessageQueue_t handle)

     MessageQueue_Receive.

    Message t MessageQueue TimedReceive (MessageQueue t handle, uint32 t u32TimeWaitMS)

     MessageQueue_TimedReceive.

    void MessageQueue Send (MessageQueue t handle, Message t hMessage)

     MessageQueue Send.

    uint16_t MessageQueue_GetCount (void)

     MessageQueue GetCount.

    void Mailbox_Init (Mailbox_t handle, void *pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_)

     Mailbox_Init.

    bool Mailbox_Send (Mailbox_t handle, void *pvData_)

     Mailbox_Send.

    bool Mailbox_SendTail (Mailbox_t handle, void *pvData_)

     Mailbox_SendTail.

    bool Mailbox TimedSend (Mailbox t handle, void *pvData , uint32 t u32TimeoutMS )

     Mailbox_TimedSend.
```

```
    bool Mailbox_TimedSendTail (Mailbox_t handle, void *pvData_, uint32_t u32TimeoutMS_)

     Mailbox_TimedSendTail.

    void Mailbox_Receive (Mailbox_t handle, void *pvData_)

     Mailbox_Receive.

    void Mailbox_ReceiveTail (Mailbox_t handle, void *pvData_)

     Mailbox_ReceiveTail.

    bool Mailbox TimedReceive (Mailbox t handle, void *pvData , uint32 t u32TimeoutMS )

     Mailbox_TimedReceive.

    bool Mailbox TimedReceiveTail (Mailbox t handle, void *pvData , uint32 t u32TimeoutMS )

     Mailbox_TimedReceiveTail.

    uint16_t Mailbox_GetFreeSlots (Mailbox_t handle)

     Mailbox_GetFreeSlots.

    bool Mailbox IsFull (Mailbox t handle)

     Mailbox IsFull.
• bool Mailbox_IsEmpty (Mailbox_t handle)
     Mailbox_IsEmpty.

    void KernelAware_ProfileInit (const char *szStr_)

     KernelAware_ProfileInit.

    void KernelAware_ProfileStart (void)

     KernelAware_ProfileStart.

    void KernelAware_ProfileStop (void)

     KernelAware_ProfileStop.

    void KernelAware ProfileReport (void)

     KernelAware ProfileReport.

    void KernelAware_ExitSimulator (void)

     KernelAware_ExitSimulator.

    void KernelAware_Print (const char *szStr_)

     KernelAware Print.

    void KernelAware_Trace (uint16_t u16File_, uint16_t u16Line_)

     KernelAware_Trace.
• void KernelAware_Trace1 (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)
     KernelAware_Trace1.

    void KernelAware_Trace2 (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_)

     KernelAware_Trace2.

    bool KernelAware_IsSimulatorAware (void)

     KernelAware_IsSimulatorAware.
```

## 20.125.1 Detailed Description

Header providing C-language API bindings for the Mark3 kernel.

Definition in file mark3c.h.

```
20.125.2 Function Documentation
20.125.2.1 EventFlag_t Alloc_EventFlag ( void )
Alloc_EventFlag.
See also
     EventFlag* AutoAlloc::NewEventFlag()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.2 Mailbox_t Alloc_Mailbox ( void )
Alloc_Mailbox.
See also
     Mailbox* AutoAlloc::NewMailbox()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.3 Message_t Alloc_Message (void)
Alloc_Message.
See also
     AutoAlloc::NewMessage()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.4 MessageQueue_t Alloc_MessageQueue ( void )
Alloc_MessageQueue.
See also
     MesageQueue* AutoAlloc::NewMessageQueue()
Returns
     Handle to an allocated object, or NULL if heap exhausted
```

```
20.125.2.5 Mutex_t Alloc_Mutex ( void )
Alloc_Mutex.
See also
     Mutex* AutoAlloc::NewMutex()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.6 Notify_t Alloc_Notify ( void )
Alloc_Notify.
See also
     Notify* AutoAlloc::NewNotify()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.7 Semaphore_t Alloc_Semaphore (void)
Alloc_Semaphore.
See also
     Semaphore* AutoAlloc::NewSemaphore()
Returns
     Handle to an allocated object, or NULL if heap exhausted
20.125.2.8 Thread_t Alloc_Thread ( void )
Alloc_Thread.
See also
     Thread* AutoAlloc::NewThread()
Returns
     Handle to an allocated object, or NULL if heap exhausted
```

20.125.2.9 Timer\_t Alloc\_Timer ( void )

Alloc\_Timer.

See also

Timer\* AutoAlloc::NewTimer()

#### Returns

Handle to an allocated object, or NULL if heap exhausted

20.125.2.10 void\* AutoAlloc ( uint16\_t u16Size\_ )

AutoAlloc.

See also

void\* AutoAlloc::Allocate(uint16\_t u16Size\_)

#### **Parameters**

<i>u</i> 16⇔	Size in bytes to allocate from the one-time-allocate heap
Size_	

## Returns

Pointer to an allocated blob of memory, or NULL if heap exhausted

20.125.2.11 void EventFlag\_Clear ( EventFlag\_t handle, uint16\_t u16Mask\_ )

EventFlag\_Clear.

See also

void EventFlag::Clear(uint16\_t u16Mask\_)

#### **Parameters**

handle	Handle of the event flag object
u16⇔	Bits to clear in the eventflag's internal condition regster
Mask_	

20.125.2.12 uint16\_t EventFlag\_GetMask ( EventFlag\_t handle )

EventFlag\_GetMask.

See also

void EventFlag::GetMask()

#### **Parameters**

#### Returns

Return the current bitmask

20.125.2.13 void EventFlag\_Init ( EventFlag\_t handle )

EventFlag\_Init.

See also

void EventFlag::Init()

#### **Parameters**

ŀ	handle	Handle of the event flag object
---	--------	---------------------------------

20.125.2.14 void EventFlag\_Set ( EventFlag\_t handle, uint16\_t u16Mask\_ )

EventFlag\_Set.

See also

void EventFlag::Set(uint16\_t u16Mask\_)

#### **Parameters**

handle	Handle of the event flag object
u16⇔ Mask_	Bits to set in the eventflag's internal condition register

20.125.2.15 uint16\_t EventFlag\_TimedWait ( EventFlag\_t handle, uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_, uint32\_t u32TimeMS\_ )

 $EventFlag\_TimedWait.$ 

See also

uint16\_t EventFlag::Wait(uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_, uint32\_t u32TimeMS\_)

#### **Parameters**

handle	Handle of the event flag object
u16Mask_	condition flags to wait for
eMode_	Specify conditions under which the thread will be unblocked
u32TimeM← S	Time in ms to wait before aborting the operation

#### Returns

bitfield contained in the eventflag on unblock, or 0 on expiry.

20.125.2.16 uint16\_t EventFlag\_Wait ( EventFlag\_t handle, uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_ )

EventFlag\_Wait.

#### See also

uint16\_t EventFlag::Wait(uint16\_t u16Mask\_, EventFlagOperation\_t eMode\_)

#### **Parameters**

handle	Handle of the event flag object
u16⇔	condition flags to wait for
Mask_	
eMode_	Specify conditions under which the thread will be unblocked

#### Returns

bitfield contained in the eventflag on unblock

20.125.2.17 Message\_t GlobalMessagePool\_Pop ( void )

GlobalMessagePool\_Pop.

See also

Message\_t GlobalMessagePool::Pop()

### Returns

Pointer to a Message object

20.125.2.18 void GlobalMessagePool\_Push ( Message\_t handle )

GlobalMessagePool\_Push.

See also

void GlobalMessagePool::Push()

#### **Parameters**

handle Handle of the message object

20.125.2.19 thread\_context\_callout\_t Kernel\_GetThreadContextSwitchCallout (void)

Kernel\_GetThreadContextSwitchCallout.

See also

Kernel::GetThreadContextSwitchCallout

#### Returns

Current function called on each context switch

20.125.2.20 thread\_create\_callout\_t Kernel\_GetThreadCreateCallout ( void )

 $Kernel\_GetThreadCreateCallout.$ 

See also

Kernel::GetThreadCreateCallout

#### Returns

Current function called on each thread creation

20.125.2.21 thread\_exit\_callout\_t Kernel\_GetThreadExitCallout ( void )

Kernel\_GetThreadExitCallout.

See also

Kernel::GetThreadExitCallout

## Returns

Current function called on each thread exit

20.125.2.22 void Kernel\_Init (void)

Kernel\_Init.

See also

void Kernel::Init()

```
20.125.2.23 bool Kernel_IsPanic (void)
Kernel_IsPanic.
See also
     bool Kernel::IsPanic()
Returns
      Whether or not the kernel is in a panic state
20.125.2.24 bool Kernel_IsStarted (void)
Kernel_IsStarted.
See also
     bool Kernel::IsStarted()
Returns
     Whether or not the kernel has started - true = running, false = not started
20.125.2.25 void Kernel_Panic ( uint16_t u16Cause_ )
Kernel_Panic.
See also
     void Kernel::Panic(uint16_t u16Cause_)
Parameters
 u16⇔
                Reason for the kernel panic
 Cause_
20.125.2.26 void Kernel_SetIdleFunc ( IdleFunc_t pfldle_ )
Kernel_SetIdleFunc.
See also
     void Kernel::SetIdleFunc(IdleFunc_t pfIdle_)
```

#### **Parameters**

pf←	Pointer to the idle function
ldle⊷	

20.125.2.27 void Kernel\_SetPanic ( PanicFunc\_t pfPanic\_ )

Kernel\_SetPanic.

See also

void Kernel::SetPanic(PanicFunc\_t pfPanic\_)

#### **Parameters**

pf⇔	Panic function pointer
Panic⊷	
_	

20.125.2.28 void Kernel\_SetThreadContextSwitchCallout ( thread\_context\_callout\_t pfContext\_ )

 $Kernel\_SetThreadContextSwitchCallout.$ 

See also

Kernel::SetThreadContextSwitchCallout

## **Parameters**

pf⇔	Function to call prior to each context switch
Context←	

20.125.2.29 void Kernel\_SetThreadCreateCallout ( thread\_create\_callout\_t pfCreate\_ )

 $Kernel\_SetThreadCreateCallout.$ 

See also

Kernel::SetThreadCreateCallout

## Parameters

pf⇔	Function to calll on thread creation
Create←	
_	

```
20.125.2.30 void Kernel_SetThreadExitCallout ( thread_exit_callout_t pfExit_ )
Kernel_SetThreadExitCallout.
See also
      Kernel::SetThreadExitCallout
Parameters
 pf⇔
            Function to call on thread exit
 Exit⊷
20.125.2.31 void Kernel_Start (void)
Kernel_Start.
See also
     void Kernel::Start()
20.125.2.32 void KernelAware_ExitSimulator (void )
KernelAware_ExitSimulator.
See also
     void KernelAware::ExitSimulator()
20.125.2.33 bool KernelAware_IsSimulatorAware (void)
KernelAware_IsSimulatorAware.
See also
     void Kernel::IsSimulatorAware()
Returns
     true if the runtime environment/simulator is aware that it is running the Mark3 kernel.
20.125.2.34 void KernelAware_Print ( const char * szStr_ )
KernelAware_Print.
See also
     void KernelAware::Print(const char *szStr_)
```

#### **Parameters**

SZ⊷	String to print to the kernel-aware simulator	
Str_		

```
20.125.2.35 void KernelAware_ProfileInit ( const char * \textit{szStr}_{\_} )
```

KernelAware\_ProfileInit.

See also

```
void KernelAware::ProfileInit(const char *szStr_);
```

#### **Parameters**

```
sz

String to use as a tag for the profilng session.

Str_
```

```
20.125.2.36 void KernelAware_ProfileReport (void )
```

KernelAware ProfileReport.

See also

void KernelAware::ProfileReport()

```
20.125.2.37 void KernelAware_ProfileStart (void)
```

KernelAware ProfileStart.

See also

void KernelAware::ProfileStart()

20.125.2.38 void KernelAware\_ProfileStop (void )

KernelAware\_ProfileStop.

See also

void KernelAware::ProfileStop()

```
20.125.2.39 void KernelAware_Trace ( uint16_t u16File_, uint16_t u16Line_ )
```

KernelAware\_Trace.

See also

void KernelAware::Trace(uint16\_t u16File\_, uint16\_t u16Line\_);

#### **Parameters**

u16⇔	16-bit code representing the file
File_	
u16⇔	16-bit code representing the line in the file
Line_	

20.125.2.40 void KernelAware\_Trace1 ( uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_ )

KernelAware\_Trace1.

#### See also

void KernelAware::Trace(uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_);

#### **Parameters**

u16File←	16-bit code representing the file
_	
<i>u</i> 16⇔	16-bit code representing the line in the file
Line_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg1_	

20.125.2.41 void KernelAware\_Trace2 ( uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_, uint16\_t u16Arg2\_ )

KernelAware\_Trace2.

#### See also

void KernelAware::Trace(uint16\_t u16File\_, uint16\_t u16Line\_, uint16\_t u16Arg1\_, uint16\_t u16Arg2\_);

## **Parameters**

u16File⊷	16-bit code representing the file
_	
u16⇔	16-bit code representing the line in the file
Line_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg1_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg2_	

20.125.2.42 uint16\_t Mailbox\_GetFreeSlots ( Mailbox\_t handle )

Mailbox\_GetFreeSlots.

#### See also

uint16\_t Mailbox::GetFreeSlots()

#### **Parameters**

#### Returns

Number of free slots in the mailbox

20.125.2.43 void Mailbox\_Init ( Mailbox\_t handle, void \* pvBuffer\_, uint16\_t u16BufferSize\_, uint16\_t u16ElementSize\_ )

Mailbox\_Init.

#### See also

void Mailbox::Init(void \*pvBuffer\_, uint16\_t u16BufferSize\_, uint16\_t u16ElementSize\_)

#### **Parameters**

handle	Handle of the mailbox object
pvBuffer_	Pointer to the static buffer to use for the mailbox
u16BufferSize_	Size of the mailbox buffer, in bytes
u16Element <i>⊷</i> Size_	Size of each envelope, in bytes

20.125.2.44 bool Mailbox\_lsEmpty ( Mailbox\_t handle )

Mailbox\_IsEmpty.

See also

bool Mailbox::IsEmpty()

#### **Parameters**

handle	Handle of the mailbox object

## Returns

true if the mailbox is empty, false otherwise

20.125.2.45 bool Mailbox\_lsFull ( Mailbox\_t handle )

Mailbox\_IsFull.

See also

bool Mailbox::lsFull()

#### **Parameters**

#### Returns

true if the mailbox is full, false otherwise

20.125.2.46 void Mailbox\_Receive ( Mailbox\_t handle, void \* pvData\_ )

Mailbox\_Receive.

See also

void Mailbox::Receive(void \*pvData\_)

#### **Parameters**

	handle	Handle of the mailbox object
ſ	pv⊷	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
	Data_	

20.125.2.47 void Mailbox\_ReceiveTail ( Mailbox\_t handle, void \* pvData\_ )

Mailbox\_ReceiveTail.

See also

void Mailbox::ReceiveTail(void \*pvData\_)

#### **Parameters**

handle	Handle of the mailbox object
pv⇔	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
Data_	

20.125.2.48 bool Mailbox\_Send (  $Mailbox_t handle$ ,  $void * pvData_$  )

Mailbox\_Send.

See also

bool Mailbox::Send(void \*pvData\_)

#### **Parameters**

handle	Handle of the mailbox object
pv⊷ Data	Pointer to the data object to send to the mailbox.

#### Returns

true - envelope was delivered, false - mailbox is full.

20.125.2.49 bool Mailbox\_SendTail ( Mailbox\_t handle, void \* pvData\_ )

Mailbox\_SendTail.

#### See also

bool Mailbox::SendTail(void \*pvData\_)

#### **Parameters**

handle	Handle of the mailbox object
pv⊷	Pointer to the data object to send to the mailbox.
Data_	

## Returns

true - envelope was delivered, false - mailbox is full.

20.125.2.50 bool Mailbox\_TimedReceive ( Mailbox\_t handle, void \* pvData\_, uint32\_t u32TimeoutMS\_ )

Mailbox\_TimedReceive.

## See also

bool Mailbox::Receive(void \*pvData\_, uint32\_t u32TimeoutMS\_)

#### **Parameters**

handle	Handle of the mailbox object
pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⊷ S_	Maximum time to wait for delivery.

## Returns

true - envelope was delivered, false - delivery timed out.

20.125.2.51 bool Mailbox\_TimedReceiveTail ( Mailbox\_t handle, void \* pvData\_, uint32\_t u32TimeoutMS\_ )

Mailbox\_TimedReceiveTail.

#### See also

bool Mailbox::ReceiveTail(void \*pvData , uint32 t u32TimeoutMS )

#### **Parameters**

handle	Handle of the mailbox object
pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⊷ S_	Maximum time to wait for delivery.

#### Returns

true - envelope was delivered, false - delivery timed out.

20.125.2.52 bool Mailbox\_TimedSend ( Mailbox\_t handle, void \* pvData\_, uint32\_t u32TimeoutMS\_ )

Mailbox\_TimedSend.

#### See also

bool Mailbox::Send(void \*pvData\_, uint32\_t u32TimeoutMS\_)

### Parameters

handle	Handle of the mailbox object
pvData_	Pointer to the data object to send to the mailbox.
u32TimeoutM⇔	Maximum time to wait for a free transmit slot
S_	

## Returns

true - envelope was delivered, false - mailbox is full.

20.125.2.53 bool Mailbox\_TimedSendTail ( Mailbox\_t handle, void \* pvData\_, uint32\_t u32TimeoutMS\_ )

Mailbox\_TimedSendTail.

## See also

bool Mailbox::Send(void \*pvData\_, uint32\_t u32TimeoutMS\_)

#### **Parameters**

Handle of the mailbox object
Pointer to the data object to send to the mailbox.
Maximum time to wait for a free transmit slot
_

#### Returns

true - envelope was delivered, false - mailbox is full.

20.125.2.54 uint16\_t Message\_GetCode ( Message\_t handle )

Message\_GetCode.

See also

uint16\_t Message::GetCode()

#### **Parameters**

handle	Handle of the message object
--------	------------------------------

## Returns

user code set in the object

20.125.2.55 void\* Message\_GetData ( Message\_t handle )

Message\_GetData.

See also

void\* Message::GetData()

#### **Parameters**

handle	Handle of the message object
--------	------------------------------

#### Returns

Pointer to the data set in the message object

20.125.2.56 void Message\_Init ( Message\_t handle )

Message\_Init.

See also

void Message::Init()

#### **Parameters**

handle	Handle of the message object
handle	Handle of the message object

20.125.2.57 void Message\_SetCode ( Message\_t handle, uint16\_t u16Code\_ )

Message\_SetCode.

See also

void Message::SetCode(uint16\_t u16Code\_)

#### **Parameters**

handle	Handle of the message object
<i>u</i> 16⇔	Data code to set in the object
Code_	

20.125.2.58 void Message\_SetData ( Message\_t handle, void \* pvData\_ )

Message\_SetData.

See also

void Message::SetData(void \*pvData\_)

#### **Parameters**

handle	Handle of the message object
pv⊷	Pointer to the data object to send in the message
Data	

20.125.2.59 uint16\_t MessageQueue\_GetCount ( void )

MessageQueue\_GetCount.

See also

uint16\_t MessageQueue::GetCount()

#### Returns

Count of pending messages in the queue.

20.125.2.60 void MessageQueue\_Init ( MessageQueue\_t handle )

MessageQueue\_Init.

See also

void MessageQueue::Init()

#### **Parameters**

handle	Handle to the message queue to initialize
--------	---

20.125.2.61 Message\_t MessageQueue\_Receive ( MessageQueue\_t handle )

MessageQueue\_Receive.

See also

Message\_t MessageQueue::Receive()

#### **Parameters**

handle	Handle of the message queue object
--------	------------------------------------

#### Returns

Pointer to a message object at the head of the queue

20.125.2.62 void MessageQueue\_Send ( MessageQueue\_t handle, Message\_t hMessage\_ )

MessageQueue\_Send.

See also

void MessageQueue::Send(Message \*pclMessage\_)

## Parameters

handle	Handle of the message queue object
h⇔ Message⊷	Handle to the message to send to the given queue

20.125.2.63 Message\_t MessageQueue\_TimedReceive ( MessageQueue\_t handle, uint32\_t u32TimeWaitMS\_ )

MessageQueue\_TimedReceive.

#### See also

Message t MessageQueue::TimedReceive(uint32 t u32TimeWaitMS )

#### **Parameters**

handle	Handle of the message queue object
u32TimeWaitM⊷ S_	The amount of time in ms to wait for a message before timing out and unblocking the waiting thread.

#### Returns

Pointer to a message object at the head of the queue or NULL on timeout.

20.125.2.64 void Mutex\_Claim ( Mutex\_t handle )

Mutex\_Claim.

See also

void Mutex::Claim()

#### **Parameters**

han	dle	Handle of the mutex
Hui	uic	riarialo di tilo illatox

20.125.2.65 void Mutex\_Init ( Mutex\_t handle )

Mutex\_Init.

See also

void Mutex::Init()

#### **Parameters**

handle	Handle of the mutex

20.125.2.66 void Mutex\_Release ( Mutex\_t handle )

Mutex\_Release.

#### See also

void Mutex::Release()

# **Parameters**

handle	Handle of the mutex
--------	---------------------

20.125.2.67 bool Mutex\_TimedClaim ( Mutex\_t handle, uint32\_t u32WaitTimeMS\_ )

Mutex\_TimedClaim.

See also

bool Mutex::Claim(uint32\_t u32WaitTimeMS\_)

#### **Parameters**

handle	Handle of the mutex
u32WaitTimeM⊷	Time to wait before aborting
S_	

#### Returns

true if mutex was claimed, false on timeout

20.125.2.68 void Notify\_Init ( Notify\_t handle )

Notify\_Init.

See also

void Notify::Init()

## **Parameters**

handle	Handle of the notification object
--------	-----------------------------------

20.125.2.69 void Notify\_Signal ( Notify\_t handle )

Notify\_Signal.

See also

void Notify::Signal()

#### **Parameters**

handle	Handle of the notification object
handle	Handle of the notification object

20.125.2.70 bool Notify\_TimedWait ( Notify\_t handle, uint32\_t u32WaitTimeMS\_, bool \* pbFlag\_ )

Notify\_TimedWait.

#### See also

bool Notify::Wait(uint32\_t u32WaitTimeMS\_, bool \*pbFlag\_)

#### **Parameters**

handle	Handle of the notification object
u32WaitTimeM⊷	Maximum time to wait for notification in ms
<i>S</i> _	
pbFlag_	Flag to set to true on notification

#### Returns

true on unblock, false on timeout

20.125.2.71 void Notify\_Wait ( Notify\_t handle, bool \* pbFlag\_ )

Notify\_Wait.

See also

void Notify::Wait(bool \*pbFlag\_)

# Parameters

handle	Handle of the notification object
pb⇔	Flag to set to true on notification
Flag_	

20.125.2.72 void Scheduler\_Enable ( bool bEnable\_ )

Scheduler\_Enable.

See also

void Scheduler::SetScheduler(bool bEnable\_)

#### **Parameters**

benable_true   to enable, false to disable the scheduler	bEnable_true	to enable, false to disable the scheduler	
--	--------------	---	--

20.125.2.73 Thread\_t Scheduler\_GetCurrentThread ( void )

 $Scheduler\_GetCurrentThread.$ 

See also

Thread\* Scheduler::GetCurrentThread()

#### Returns

Handle of the currently-running thread

20.125.2.74 bool Scheduler\_IsEnabled (void)

Scheduler\_IsEnabled.

#### See also

bool Scheduler::IsEnabled()

## Returns

true - scheduler enabled, false - disabled

20.125.2.75 void Semaphore\_Init ( Semaphore\_t handle, uint16\_t u16InitVal\_, uint16\_t u16MaxVal\_ )

Semaphore\_Init.

## See also

void Semaphore::Init(uint16\_t u16InitVal\_, uint16\_t u16MaxVal\_)

# Parameters

handle	Handle of the semaphore
u16InitVal⊷	Initial value of the semaphore
_	
u16Max⊷	Maximum value that can be held for a semaphore
Val	

20.125.2.76 void Semaphore\_Pend ( Semaphore\_t handle )

Semaphore\_Pend.

See also

void Semaphore::Pend()

#### **Parameters**

handle	Handle of the semaphore
--------	-------------------------

20.125.2.77 void Semaphore\_Post ( Semaphore\_t handle )

Semaphore\_Post.

See also

void Semaphore::Post()

#### **Parameters**

handle	Handle of the semaphore
--------	-------------------------

20.125.2.78 bool Semaphore\_TimedPend ( Semaphore\_t handle, uint32\_t u32WaitTimeMS\_ )

Semaphore\_TimedPend.

See also

bool Semaphore::Pend(uint32\_t u32WaitTimeMS\_)

# **Parameters**

handle	Handle of the semaphore
u32WaitTimeM⊷	Time in ms to wait
S_	

#### Returns

true if semaphore was acquired, false on timeout

20.125.2.79 void Thread\_Exit ( Thread\_t handle )

Thread\_Exit.

See also

void Thread::Exit()

**Parameters** 

handle Handle of the thread

20.125.2.80 PORT\_PRIO\_TYPE Thread\_GetCurPriority ( Thread\_t handle )

Thread\_GetCurPriority.

See also

PORT\_PRIO\_TYPE Thread::GetCurPriority()

**Parameters** 

handle Handle of the thread

Returns

Current priority of the thread considering priority inheritence

20.125.2.81 void\* Thread\_GetExtendedContext (  $Thread\_t \ \textit{handle}$  )

Thread\_GetExtendedContext.

See also

Thread::GetExtendedContext()

**Parameters** 

handle Handle of the thread

Returns

Pointer to the Thread's extended context

20.125.2.82 uint8\_t Thread\_GetID ( Thread\_t handle )

Thread\_GetID.

See also

uint8\_t Thread::GetID()

**Parameters** 

handle Handle of the thread

Returns

Return ID assigned to the thread

20.125.2.83 PORT\_PRIO\_TYPE Thread\_GetPriority ( Thread\_t handle )

Thread GetPriority.

See also

PORT\_PRIO\_TYPE Thread::GetPriority()

**Parameters** 

handle Handle of the thread

Returns

Current priority of the thread not considering priority inheritence

20.125.2.84 uint16\_t Thread\_GetQuantum ( Thread\_t handle )

Thread\_GetQuantum.

See also

uint16\_t Thread::GetQuantum()

**Parameters** 

handle Handle of the thread

Returns

Thread's current execution quantum

20.125.2.85 uint16\_t Thread\_GetStackSlack ( Thread\_t handle )

Thread\_GetStackSlack.

See also

uint16\_t Thread::GetStackSlack()

#### **Parameters**

dle Handle of the th	read
----------------------	------

# Returns

Return the amount of unused stack on the given thread

20.125.2.86 ThreadState\_t Thread\_GetState ( Thread\_t handle )

Thread GetState.

#### See also

ThreadState\_t Thread::GetState()

#### **Parameters**

handle	Handle of the thread
--------	----------------------

#### Returns

The thread's current execution state

20.125.2.87 void Thread\_Init ( Thread\_t handle, K\_WORD \* pwStack\_, uint16\_t u16StackSize\_, PORT\_PRIO\_TYPE uXPriority\_, ThreadEntry\_t pfEntryPoint\_, void \* pvArg\_ )

Thread\_Init.

#### See also

```
void Thread::Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, Thread← Entry_t pfEntryPoint_, void *pvArg_)
```

#### **Parameters**

handle	Handle of the thread to initialize
pwStack_	Pointer to the stack to use for the thread
u16Stack⇔	Size of the stack (in bytes)
Size_	
uXPriority_	Priority of the thread (0 = idle, 7 = max)
pfEntryPoint←	This is the function that gets called when the thread is started
_	
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

20.125.2.88 void Thread\_SetExtendedContext ( Thread\_t handle, void \* pvData\_ )

Thread\_SetExtendedContext.

See also

Thread::SetExtendedContext(void\* pvData\_)

#### **Parameters**

handle	Handle of the Thread
pv⊷	Pointer to Object to assign to Thread's extended context
Data_	

20.125.2.89 void Thread\_SetID ( Thread\_t handle, uint8\_t u8ID\_ )

Thread\_SetID.

See also

void Thread::SetID(uint8\_t u8ID\_)

#### **Parameters**

handle	Handle of the thread
u8l⊷	ID To assign to the thread
D_	

20.125.2.90 void Thread\_SetPriority ( Thread\_t handle, PORT\_PRIO\_TYPE uXPriority\_ )

 $Thread\_SetPriority.$ 

See also

void Thread::SetPriority(PORT\_PRIO\_TYPE uXPriority\_)

#### **Parameters**

handle	Handle of the thread
uX⇔	New priority level
Priority	

20.125.2.91 void Thread\_SetQuantum ( Thread\_t handle, uint16\_t u16Quantum\_ )

Thread\_SetQuantum.

#### See also

void Thread::SetQuentum(uint16\_t u16Quantum\_)

# **Parameters**

handle	Handle of the thread
u16 <b></b>	Time (in ticks) to set for the thread execution quantum
Quantum_	

20.125.2.92 void Thread\_Sleep ( uint32\_t u32TimeMs\_ )

Thread\_Sleep.

See also

void Thread::Sleep(uint32\_t u32TimeMs\_)

#### **Parameters**

u32Time←	Time in ms to block the thread for
Ms_	

20.125.2.93 void Thread\_Start ( Thread\_t handle )

Thread\_Start.

See also

void Thread::Start()

#### **Parameters**

-		
	handle	Handle of the thread to start

20.125.2.94 void Thread\_Stop ( Thread\_t handle )

Thread\_Stop.

See also

void Thread::Stop()

## **Parameters**

handle Handle of the t	hread to stop
------------------------	---------------

```
20.125.2.95 void Thread_USleep ( uint32_t u32TimeUs_ )
Thread_USleep.
See also
     void Thread::USleep(uint32_t u32TimeUs_)
Parameters
 u32Time←
                 Time in us to block the thread for
 Us_
20.125.2.96 void Thread_Yield (void)
Thread_Yield.
See also
     void Thread::Yield()
20.125.2.97 void Timer_Init ( Timer_t handle )
Timer_Init.
See also
     void Timer::Init()
Parameters
 handle
           Handle of the timer
20.125.2.98 void Timer_Restart ( Timer_t handle )
Timer_Restart.
See also
     void Timer::Start()
Parameters
 handler
```

Handle of the timer to restart.

20.125.2.99 void Timer\_Start ( Timer\_t handle, bool bRepeat\_, uint32\_t u32IntervalMs\_, uint32\_t u32ToleranceMs\_, TimerCallbackC\_t pfCallback\_, void \* pvData\_ )

Timer\_Start.

#### See also

void Timer::Start(bool bRepeat\_, uint32\_t u32IntervalMs\_, uint32\_t u32ToleranceMs\_, TimerCallbackC\_t pf ← Callback\_, void \*pvData\_)

#### **Parameters**

handle	Handle of the timer
bRepeat_	Restart the timer continuously on expiry
u32IntervalMs_	Time in ms to expiry
u32Tolerance← Ms_	Group with other timers if they expire within the amount of time specified
pfCallback_	Callback to run on timer expiry
pvData_	Data to pass to the callback on expiry

20.125.2.100 void Timer\_Stop ( Timer\_t handle )

Timer\_Stop.

## See also

void Timer::Stop()

#### **Parameters**

handle Handle of the timer
----------------------------

# 20.126 mark3c.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "mark3cfg.h"
00022 #include "kerneltypes.h"
00023 #include "fake_types.h"
00024 #include "driver3c.h"
00025
00026 #include <stdint.h>
00027 #include <stdbool.h>
```

20.126 mark3c.h 377

```
00028
00029 #ifndef __MARK3C_H
00030 #define __MARK3C_H_
00031
00032 #if defined(__cplusplus)
00033 extern "C" {
00034 #endif
00035
00036 //-
00037 // Define a series of handle types to be used in place of the underlying classes
00038 // of Mark3.
00039 typedef void* EventFlag_t;
00040 typedef void* Mailbox_t;
00041 typedef void* Message_t;
00042 typedef void* MessageQueue_t;
00043 typedef void* Mutex_t;
00044 typedef void* Notify_t;
00045 typedef void* Semaphore_t;
00046 typedef void* Thread_t;
00047 typedef void* Timer_t;
00048
00049 //--
00050 // Function pointer types used by Kernel APIs
00051 typedef void (*thread_create_callout_t)(Thread_t hThread_);
00052 typedef void (*thread_exit_callout_t) (Thread_t hThread_);
00053 typedef void (*thread_context_callout_t)(Thread_t hThread_);
00054
00055 //-
00056 // Use the sizes of the structs in fake_types.h to generate opaque object-blobs 00057 // that get instantiated as kernel objects (from the C++ code) later.
00058 #define THREAD_SIZE (sizeof(Fake_Thread))
00059 #define TIMER_SIZE (sizeof(Fake_Timer))
00060 #define SEMAPHORE_SIZE (sizeof(Fake_Semaphore))
00061 #define MUTEX_SIZE (sizeof(Fake_Mutex))
00062 #define MESSAGE_SIZE (sizeof(Fake_Message))
00063 #define MESSAGEQUEUE_SIZE (sizeof(Fake_MessageQueue))
00064 #define MAILBOX_SIZE (sizeof(Fake_Mailbox))
00065 #define NOTIFY_SIZE (sizeof(Fake_Notify))
00066 #define EVENTFLAG_SIZE (sizeof(Fake_EventFlag))
00067
00068 /
00069 // Macros for declaring opaque buffers of an appropriate size for the given
00070 // kernel objects
00071 #define TOKEN_1(x, y) x##y
00072 #define TOKEN_2(x, y) TOKEN_1(x, y)
00073
00074 // Ensure that opaque buffers are sized to the nearest word - which is
00075 // a platform-dependent value.
00076 \#define WORD_ROUND(x) (((x) + (sizeof(K_WORD) - 1)) / sizeof(K_WORD))
00077
00078 #define DECLARE_THREAD(name)
          K_WORD
00079
                    TOKEN_2(__thread_, name)[WORD_ROUND(THREAD_SIZE)];
00080
          Thread_t name = (Thread_t)TOKEN_2(__thread_, name);
00081
00082 #define DECLARE_TIMER(name)
00083
                  TOKEN_2(__timer_, name)[WORD_ROUND(TIMER_SIZE)];
00084
          Timer t name = (Timer t) TOKEN 2( timer, name);
00085
00086 #define DECLARE_SEMAPHORE(name)
00087
          K WORD
                       TOKEN_2(__semaphore_, name)[WORD_ROUND(SEMAPHORE_SIZE)];
00088
          Semaphore_t name = (Semaphore_t)TOKEN_2(__semaphore_, name);
00089
00090 #define DECLARE MUTEX(name)
00091
                  TOKEN_2(__mutex_, name)[WORD_ROUND(MUTEX_SIZE)];
00092
          Mutex_t name = (Mutex_t)TOKEN_2(__mutex_, name);
00093
00094 #define DECLARE MESSAGE (name)
00095
                     TOKEN_2(__message_, name)[WORD_ROUND(MESSAGE_SIZE)];
          K_WORD
00096
          Message_t name = (Message_t)TOKEN_2(__message_, name);
00097
00098 #define DECLARE MESSAGEOUEUE(name)
00099
                          TOKEN_2(__messagequeue_, name)[WORD_ROUND(MESSAGEQUEUE_SIZE)];
00100
          MessageQueue_t name = (MessageQueue_t)TOKEN_2(__messagequeue_, name);
00101
00102 #define DECLARE_MAILBOX(name)
```

```
00103
          K_WORD
                    TOKEN_2(__mailbox_, name)[WORD_ROUND(MAILBOX_SIZE)];
00104
          Mailbox_t name = (Mailbox_t)TOKEN_2(__mailbox_, name);
00105
00106 #define DECLARE_NOTIFY(name)
00107
          K_WORD
                   TOKEN_2(__notify_, name)[WORD_ROUND(NOTIFY_SIZE)];
          Notify_t name = (Notify_t)TOKEN_2(__notify_, name);
00108
00109
00110 #define DECLARE_EVENTFLAG(name)
                      TOKEN_2(__eventflag_, name)[WORD_ROUND(EVENTFLAG_SIZE)];
00111
          K_WORD
00112
          EventFlag_t name = (EventFlag_t)TOKEN_2(__eventflag_, name);
00113
00114 //-
00115 // Allocate-once Memory managment APIs
00116 #if defined KERNEL_USE_AUTO_ALLOC
00117
00123 void* AutoAlloc(uint16_t u16Size_);
00124 #if KERNEL_USE_SEMAPHORE
00125
00130 Semaphore_t Alloc_Semaphore(void);
00131 #endif
00132 #if KERNEL_USE_MUTEX
00133
00138 Mutex_t Alloc_Mutex(void);
00139 #endif
00140 #if KERNEL_USE_EVENTFLAG
00141
00146 EventFlag_t Alloc_EventFlag(void);
00147 #endif
00148 #if KERNEL_USE_MESSAGE
00149
00154 Message t Alloc Message (void);
00160 MessageQueue_t Alloc_MessageQueue(void);
00161 #endif
00162 #if KERNEL_USE_NOTIFY
00163
00168 Notify_t Alloc_Notify(void);
00169 #endif
00170 #if KERNEL_USE_MAILBOX
00171
00176 Mailbox_t Alloc_Mailbox(void);
00177 #endif
00178
00183 Thread_t Alloc_Thread(void);
00184 #if KERNEL_USE_TIMERS
00185
00190 Timer_t Alloc_Timer(void);
00191 #endif
00192 #endif
00193
00194 //
00195 // Kernel APIs
00200 void Kernel_Init(void);
00205 void Kernel_Start(void);
00212 bool Kernel_IsStarted(void);
00218 void Kernel_SetPanic(PanicFunc_t pfPanic_);
00224 bool Kernel_IsPanic(void);
00230 void Kernel_Panic(uint16_t u16Cause_);
00231 #if KERNEL_USE_IDLE_FUNC
00232
00237 void Kernel_SetIdleFunc(IdleFunc_t pfIdle_);
00238 #endif
00239
00240 #if KERNEL_USE_THREAD_CALLOUTS
00241
00246 void Kernel_SetThreadCreateCallout(thread_create_callout_t pfCreate_);
00252 void Kernel_SetThreadExitCallout(thread_exit_callout_t pfExit_);
00253
00259 void Kernel SetThreadContextSwitchCallout(thread context callout t
      pfContext_);
00260
00266 thread_create_callout_t Kernel_GetThreadCreateCallout(void);
00267
00273 thread_exit_callout_t Kernel_GetThreadExitCallout(void);
00274
00280 thread context callout t Kernel GetThreadContextSwitchCallout(void);
00281 #endif
00282
00283 #if KERNEL_USE_STACK_GUARD
00284
00290 static void Kernel_SetStackGuardThreshold(uint16_t u16Threshold_);
00291
```

20.126 mark3c.h 379

```
00297 static uint16_t Kernel_GetStackGuardThreshold(void);
00299 //----
00300 // Scheduler APIs
00306 void Scheduler_Enable(bool bEnable_);
00312 bool Scheduler_IsEnabled(void);
00318 Thread_t Scheduler_GetCurrentThread(void);
00319
00320 //---
00321 // Thread APIs
00335 void Thread_Init(Thread_t
                                       handle,
                                     pwStack_
00336
                        K WORD*
00337
                        uint16_t
                                       u16StackSize
00338
                        PORT_PRIO_TYPE
00339
                        ThreadEntry_t pfEntryPoint_,
00340
                        void*
                                       pvArg_);
00346 void Thread_Start(Thread_t handle);
00352 void Thread_Stop(Thread_t handle);
00353 #if KERNEL_USE_THREADNAME
00360 void Thread_SetName(Thread_t handle, const char* szName_);
00367 const char* Thread_GetName(Thread_t handle);
00368 #endif
00369
00375 PORT_PRIO_TYPE Thread_GetPriority(Thread_t handle);
00382 PORT_PRIO_TYPE Thread_GetCurPriority(Thread_t handle);
00383 #if KERNEL_USE_QUANTUM
00384
00390 void Thread_SetQuantum(Thread_t handle, uint16_t u16Quantum_);
00397 uint16_t Thread_GetQuantum(Thread_t handle);
00398 #endif
00399
00405 void Thread_SetPriority(Thread_t handle, PORT_PRIO_TYPE uXPriority_);
00406 #if KERNEL_USE_DYNAMIC_THREADS
00407
00412 void Thread_Exit(Thread_t handle);
00413 #endif
00414 #if KERNEL_USE_SLEEP
00415
00420 void Thread_Sleep(uint32_t u32TimeMs_);
00426 void Thread_USleep(uint32_t u32TimeUs_);
00427 #endif
00428 #if KERNEL USE EXTENDED CONTEXT
00429
00435 void* Thread_GetExtendedContext(Thread_t handle);
00436
00443 void Thread_SetExtendedContext(Thread_t handle, void* pvData_);
00444
00445 #endif
00446
00450 void Thread_Yield(void);
00457 void Thread_SetID(Thread_t handle, uint8_t u8ID_);
00464 uint8_t Thread_GetID(Thread_t handle);
00471 uint16_t Thread_GetStackSlack(Thread_t handle);
00478 ThreadState_t Thread_GetState(Thread_t handle);
00479
00480 //--
00481 // Timer APIs
00482 #if KERNEL_USE_TIMERS
00483 typedef void (*TimerCallbackC_t)(Thread_t hOwner_, void* pvData_);
00489 void Timer_Init(Timer_t handle);
00501 void Timer_Start(Timer_t
                                          handle,
                        bool
                                          bRepeat_,
00503
                                          u32IntervalMs_,
00504
                        uint32 t
                                          u32ToleranceMs_,
00505
                        TimerCallbackC_t pfCallback_,
00506
                        void*
                                          pvData_);
00507
00513 void Timer_Restart(Timer_t handle);
00520 void Timer_Stop(Timer_t handle);
00521 #endif
00522
00523 //---
00524 // Semaphore APIs
00525 #if KERNEL_USE_SEMAPHORE
00526
00533 void Semaphore_Init(Semaphore_t handle, uint16_t u16InitVal_, uint16_t u16MaxVal_);
00539 void Semaphore_Post(Semaphore_t handle);
00545 void Semaphore_Pend(Semaphore_t handle);
00546 #if KERNEL USE TIMEOUTS
00554 bool Semaphore_TimedPend(Semaphore_t handle, uint32_t u32WaitTimeMS_);
00555 #endif
00556 #endif
00557
00558 //-
```

```
00559 // Mutex APIs
00560 #if KERNEL_USE_MUTEX
00561
00566 void Mutex_Init(Mutex_t handle);
00572 void Mutex_Claim(Mutex_t handle);
00578 void Mutex_Release(Mutex_t handle);
00579 #if KERNEL_USE_TIMEOUTS
00580
00587 bool Mutex_TimedClaim(Mutex_t handle, uint32_t u32WaitTimeMS_);
00588 #endif
00589 #endif
00590
00591 //-
00592 // EventFlag APIs
00593 #if KERNEL_USE_EVENTFLAG
00594
00599 void EventFlag_Init (EventFlag_t handle);
00609 #if KERNEL_USE_TIMEOUTS
00610
00619 uint16_t EventFlag_TimedWait(EventFlag_t handle, uint16_t u16Mask_,
      EventFlagOperation_t eMode_, uint32_t u32TimeMS_);
00620 #endif
00621
00627 void EventFlag_Set(EventFlag_t handle, uint16_t u16Mask_);
00634 void EventFlag_Clear(EventFlag_t handle, uint16_t u16Mask_);
00641 uint16_t EventFlag_GetMask(EventFlag_t handle);
00642 #endif
00643
00644 //
00645 // Notification APIs
00646 #if KERNEL_USE_NOTIFY
00647
00652 void Notify_Init(Notify_t handle);
00658 void Notify_Signal(Notify_t handle);
00665 void Notify_Wait(Notify_t handle, bool* pbFlag_);
00666 #if KERNEL USE TIMEOUTS
00675 bool Notify_TimedWait(Notify_t handle, uint32_t u32WaitTimeMS_, bool* pbFlag_);
00676 #endif
00677 #endif
00678
00679 //-
00680 // Atomic Functions
00681 #if KERNEL_USE_ATOMIC
00682
00689 uint8_t Atomic_Set8(uint8_t* pu8Source_, uint8_t u8Val_);
00697 uint16_t Atomic_Set16(uint16_t * pu16Source_, uint16_t u16Val_);
00705 uint32_t Atomic_Set32(uint32_t* pu32Source_, uint32_t u32Val_);
00713 uint8_t Atomic_Add8(uint8_t* pu8Source_, uint8_t u8Val_);
00721 uint16_t Atomic_Add16(uint16_t* pu16Source_, uint16_t u16Val_);
00729 uint32_t Atomic_Add32(uint32_t* pu32Source_, uint32_t u32Val_);
00737 uint8_t Atomic_Sub8(uint8_t* pu8Source_, uint8_t u8Val_);
00745 uint16_t Atomic_Sub16(uint16_t* pu16Source_, uint16_t u16Val_);
00753 uint32_t Atomic_Sub32(uint32_t* pu32Source_, uint32_t u32Val_);
00762 bool Atomic_TestAndSet(bool* pbLock);
00763 #endif
00764
00765 //--
00766 // Message/Message Queue APIs
00767 #if KERNEL_USE_MESSAGE
00773 void Message_Init(Message_t handle);
00780 void Message_SetData(Message_t handle, void* pvData_);
00787 void* Message_GetData(Message_t handle);
00794 void Message_SetCode(Message_t handle, uint16_t u16Code_);
00801 uint16 t Message GetCode (Message t handle);
00807 void GlobalMessagePool_Push(Message_t handle);
00813 Message_t GlobalMessagePool_Pop(void);
00819 void MessageQueue_Init(MessageQueue_t handle);
00826 Message_t MessageQueue_Receive(MessageQueue_t handle);
00827 #if KERNEL_USE_TIMEOUTS
00828
00838 Message t MessageQueue TimedReceive (MessageQueue t handle, uint32 t u32TimeWaitMS
      );
00839 #endif
00840
00847 void MessageQueue_Send(MessageQueue_t handle, Message_t hMessage_);
00848
00854 uint16_t MessageQueue_GetCount(void);
00855 #endif
00856
00857 //--
00858 // Mailbox APIs
00859 #if KERNEL_USE_MAILBOX
00860
```

20.126 mark3c.h 381

```
00869 void Mailbox_Init(Mailbox_t handle, void* pvBuffer_, uint16_t u16BufferSize_, uint16_t
      u16ElementSize_);
00870
00878 bool Mailbox_Send(Mailbox_t handle, void* pvData_);
00879
00887 bool Mailbox_SendTail(Mailbox_t handle, void* pvData_);
00897 bool Mailbox_TimedSend(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
00898
00907 bool Mailbox_TimedSendTail(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
00908
00916 void Mailbox_Receive(Mailbox_t handle, void* pvData_);
00917
00925 void Mailbox_ReceiveTail(Mailbox_t handle, void* pvData_);
00926 #if KERNEL_USE_TIMEOUTS
00927
00937 bool Mailbox_TimedReceive(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
00938
00948 bool Mailbox_TimedReceiveTail(Mailbox_t handle, void* pvData_, uint32_t
     u32TimeoutMS_);
00949
00956 uint16_t Mailbox_GetFreeSlots(Mailbox_t handle);
00957
00964 bool Mailbox IsFull (Mailbox t handle);
00965
00972 bool Mailbox_IsEmpty(Mailbox_t handle);
00973 #endif
00974 #endif
00975
00976 //---
00977 // Kernel-Aware Simulation APIs
00978 #if KERNEL_AWARE_SIMULATION
00979
00985 void KernelAware_ProfileInit(const char* szStr_);
00986
00991 void KernelAware_ProfileStart (void);
00992
00997 void KernelAware_ProfileStop(void);
00998
01003 void KernelAware_ProfileReport(void);
01004
01010 void KernelAware ExitSimulator(void);
01011
01017 void KernelAware_Print(const char* szStr_);
01018
01025 void KernelAware_Trace(uint16_t u16File_, uint16_t u16Line_);
01026
01034 void KernelAware_Tracel(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_);
01043 void KernelAware_Trace2(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t
      u16Arg2_);
01053 bool KernelAware_IsSimulatorAware(void);
01054 #endif
01055
01056 #if defined(__cplusplus)
01057
01058 #endif
01060 #endif // __MARK3C_H_
```

# **Chapter 21**

# **Example Documentation**

# 21.1 buffalogger/main.cpp

This example demonstrates how low-overhead logging can be implemented using buffalogger.

```
Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
See license.txt for more information
#include "mark3.h"
#include "kerneldebug.h"
#include "drvUART.h"
#include "tracebuffer.h"
#include "ksemaphore.h"
Example - Logging data via buffalogger/debug APIs.
#if !(KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION)
# error "Buffalogger demo requires tracebuffer support"
#if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
#define _CAN_HAS_DEBUG
//--[Autogenerated - Do Not Modify]------
#include "dbg_file_list.h"
#include "buffalogger.h"
#if defined(DBG FILE)
#error "Debug logging file token already defined! Bailing."
#define DBG_FILE _DBG___EXAMPLES_AVR_BUFFALOGGER_MAIN_CPP
//--[End Autogenerated content]-----
// This block declares the thread data for the main application thread.
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP_STACK_SIZE (192 / sizeof(K_WORD))
static Thread clAppThread;
static K_WORD awAppStack[APP_STACK_SIZE];
static void AppMain(void* unused_);
```

```
#define IDLE_STACK_SIZE (192 / sizeof(K_WORD))
static Thread clIdleThread;
static K_WORD awIdleStack[APP_STACK_SIZE];
static void IdleMain(void* unused_);
#define LOGGER_STACK_SIZE (192 / sizeof(K_WORD))
static Thread clLoggerThread;
static K_WORD awLoggerStack[APP_STACK_SIZE];
static void LoggerMain(void* unused_);
static volatile bool bPingPong;
static Semaphore
                     clSem;
static ATMegaUART clUART;
#define UART_SIZE_TX (32)
#define UART_SIZE_RX (8)
static uint8_t aucTxBuffer[UART_SIZE_TX];
static uint8_t aucRxBuffer[UART_SIZE_RX];
static volatile uint16_t* pu16Log;
static volatile uint16_t u16LogLen;
extern "C" {
void __cxa_pure_virtual(void)
void IdleMain(void* unused_)
    while (1) {
}
void LoggerCallback(uint16_t* pu16Data_, uint16_t u16Len_, bool bPingPong_)
    CS_ENTER();
    bPingPong = bPingPong_;
pu16Log = pu16Data_;
u16LogLen = u16Len_;
    CS_EXIT();
    clSem.Post();
}
void LoggerMain(void* unused_)
    while (1) {
        uint8_t* src;
        uint16_t len;
        clSem.Pend();
        CS_ENTER();
        src = (uint8_t*)pu16Log;
len = u16LogLen * sizeof(uint16_t);
        CS_EXIT();
        uint16_t written = 0;
        while (len != written) {
            written += cluart.Write(len - written, src + written);
    }
}
int main(void)
    Kernel::Init();
    // Example assumes use of built-in idle.
    clAppThread.Init(awAppStack, APP_STACK_SIZE, 2, AppMain, 0);
    clAppThread.Start();
    clLoggerThread.Init(awLoggerStack, LOGGER STACK SIZE, 1, LoggerMain, 0);
    clLoggerThread.Start();
    clIdleThread.Init(awIdleStack, IDLE_STACK_SIZE, 0, IdleMain, 0);
    clIdleThread.Start();
    cluart.SetName("/dev/tty");
    clUART.Init();
```

```
clUART.Open();
   DriverList::Add(&clUART);
    Kernel::Start();
    return 0;
void AppMain(void* unused_)
       uint32_t u32Baud = 57600 * 4;
        cluart.Control(CMD_SET_BAUDRATE, &u32Baud, 0, 0, 0);
    clUART.Control(CMD_SET_BUFFERS, (void*)aucRxBuffer, UART_SIZE_RX, (void*)aucTxBuffer, UART_SIZE_TX);
    clSem.Init(0, 1);
    TraceBuffer::SetCallback(LoggerCallback);
    volatile uint16_t u16Iteration = 0;
    while (1) {
        Thread::Sleep(100);
       USER_TRACE("Beginning of the main application loop!");
        Thread::Sleep(100);
       USER_TRACE_1(" Iteration: %d", u16Iteration++);
        Thread::Sleep(100);
       USER_TRACE("End of the main application loop!");
#endif //#if KERNEL USE DEBUG && !KERNEL AWARE SIMULATION
```

# 21.2 lab10\_notifications/main.cpp

This examples demonstrates how to use notification objects as a thread synchronization mechanism.

```
static Thread clApplThread;
static K_WORD awApp1Stack[APP_STACK_SIZE];
static void ApplMain(void* unused_);
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP_STACK_SIZE];
static void App2Main(void* unused_);
// Notification object used in the example.
static Notify clNotify;
int main(void)
    \ensuremath{//} See the annotations in previous labs for details on init.
    Kernel::Init();
    // Initialize notifer and notify-ee threads
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp1Thread.Start();
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    clApp2Thread.Start();
    // Initialize the Notify objects
    clNotify.Init();
    Kernel::Start();
    return 0;
void ApplMain(void* unused_)
    while (1) {
        bool bNotified = false;
        // Block the thread until the notification object is signalled from
        // elsewhere.
        clNotify.Wait(&bNotified);
        KernelAware::Print("T1: Notified\n");
}
void App2Main(void* unused_)
    while (1) {
        // Wait a while, then signal the notification object
        KernelAware::Print("T2: Wait 1s\n");
        Thread::Sleep(1000);
        KernelAware::Print("T2: Notify\n");
        clNotify.Signal();
```

# 21.3 lab11\_mailboxes/main.cpp

This examples shows how to use mailboxes to deliver data between threads in a synchronized way.

```
Lab Example 11: Mailboxes
Lessons covered in this example include:
- Initialize a mailbox for use as an IPC mechanism.
- Create and use mailboxes to pass data between threads.
- Mailboxes are a powerful IPC mechanism used to pass messages of a fixed-size
 between threads.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
#define APP_STACK_SIZE (256 / sizeof(K_WORD))
static Thread clapp1Thread;
static K_WORD awApp1Stack[APP_STACK_SIZE];
static void ApplMain(void* unused_);
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP_STACK_SIZE];
static void App2Main(void* unused_);
static Mailbox clMailbox;
static uint8_t au8MBData[100];
typedef struct {
    uint8_t au8Buffer[10];
} MBType_t;
int main (void)
     // See the annotations in previous labs for details on init.
    Kernel::Init();
    // Initialize the threads used in this example
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp1Thread.Start();
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 2, App2Main, 0);
    clApp2Thread.Start();
    // Initialize the mailbox used in this example
clMailbox.Init(au8MBData, 100, sizeof(MBType_t));
    Kernel::Start();
    return 0:
}
void ApplMain(void* unused_)
    while (1) {
        MBType_t stMsg;
         // Wait until there is an envelope available in the shared mailbox, and
         // then log a trace message.
        clMailbox.Receive(&stMsg);
        KernelAware::Trace(0, __LINE__, stMsg.au8Buffer[0], stMsg.au8Buffer[9]);
}
void App2Main(void* unused_)
    while (1) {
        MBType_t stMsg;
         // Place a bunch of envelopes in the mailbox, and then wait for a
         // while. Note that this thread has a higher priority than the other
         \ensuremath{//} thread, so it will keep pushing envelopes to the other thread until
         // it gets to the sleep, at which point the other thread will be allowed
         // to execute.
```

```
KernelAware::Print("Messages Begin\n");

for (uint8_t i = 0; i < 10; i++) {
    for (uint8_t j = 0; j < 10; j++) {
        stMsg.au8Buffer[j] = (i * 10) + j;
    }
    clMailbox.Send(&stMsg);
}

KernelAware::Print("Messages End\n");
Thread::Sleep(2000);
}</pre>
```

# 21.4 lab1\_kernel\_setup/main.cpp

This example demonstrates basic kernel setup with two threads.

```
-- [Mark3 Realtime Platform]
Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
See license.txt for more information
#include "mark3.h"
/*-----
Lab Example 1: Initializing the Mark3 RTOS kernel with two threads.
The following example code presents a working example of how to initialize
the Mark3 RTOS kernel, configure two application threads, and execute the \,
configured tasks. This example also uses the flAVR kernel-aware module to
print out messages when run through the flAVR AVR Simulator. This is a
turnkey-ready example of how to use the Mark3 RTOS at its simplest level,
and should be well understood before moving on to other examples.
Lessons covered in this example include:
- usage of the Kernel class - configuring and starting the kernel - usage of the Thread class - initializing and starting static threads.
- Demonstrate the relationship between Thread objects, stacks, and entry
  functions.
- usage of Thread::Sleep() to block execution of a thread for a period of time - When using an idle thread, the idle thread MUST not block.
- Add another application thread that prints a message, flashes an LED, etc.
 using the code below as an example.
Takeaway:
At the end of this example, the reader should be able to use the Mark3
Kernel and Thread APIs to initialize and start the kernel with any number
of static threads.
extern "C" {
void ___cxa_pure_virtual(void)
// This block declares the thread data for the main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clAppThread;
static K_WORD awAppStack[APP_STACK_SIZE];
static void AppMain(void* unused_);
```

```
\ensuremath{//} This block declares the thread data for the idle thread. It defines a
\ensuremath{//} thread object, stack (in word-array form), and the entry-point function
// used by the idle thread.
#define IDLE_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clIdleThread;
static K_WORD awIdleStack[IDLE_STACK_SIZE];
static void IdleMain(void* unused_);
int main (void)
    // Before any Mark3 RTOS APIs can be called, the user must call Kernel::Init().
    // Note that if you have any hardware-specific init code, it can be called
    // before Kernel::Init, so long as it does not enable interrupts, or
    // rely on hardware peripherals (timer, software interrupt, etc.) used by the
    // kernel.
    Kernel::Init();
    // Once the kernel initialization has been complete, the user can add their
    // application thread(s) and idle thread. Threads added before the kerel
// is started are refered to as the "static threads" in the system, as they
    // are the default working-set of threads that make up the application on
    // kernel startup.
    \ensuremath{//} Initialize the application thread to use a specified word-array as its stack.
    // The thread will run at priority level "1", and start execution the
    // "AppMain" function when it's started.
    clAppThread.Init(awAppStack, sizeof(awAppStack), 1, AppMain, 0);
       Initialize the idle thread to use a specific word-array as its stack.
    // The thread will run at priority level "0", which is reserved for the idle
    // priority thread. IdleMain will be run when the thread is started.
    clIdleThread.Init(awIdleStack, sizeof(awIdleStack), 0, IdleMain, 0);
    // Once the static threads have been added, the user must then ensure that the // threads are ready to execute. By default, creating a thread is created
    // in a STOPPED state. All threads must manually be started using the
    // Start() API before they will be scheduled by the system. Here, we are
    // starting the application and idle threads before starting the kernel - and
    \ensuremath{//} that's OK. When the kernel is started, it will choose which thread to run
    // first from the pool of ready threads.
    clAppThread.Start();
    clIdleThread.Start();
    \ensuremath{//} All threads have been initialized and made ready. The kernel will now
    // select the first thread to run, enable the hardware required to run the
    // kernel (Timers, software interrupts, etc.), and then do whatever is // necessary to maneuver control of thread execution to the kernel. At this
       point, execution will transition to the highest-priority ready thread.
    // This function will not return.
    Kernel::Start();
    // As Kernel::Start() results in the operating system being executed, control
    // will not be relinquished back to main(). The "return 0" is simply to
    // avoid warnings.
    return 0:
}
void AppMain(void* unused_)
    // This function is run from within the application thread. Here, we
    // simply print a friendly greeting and allow the thread to sleep for a // while before repeating the message. Note that while the thread is
    // sleeping, CPU execution will transition to the Idle thread.
        KernelAware::Print("Hello World!\n");
        Thread::Sleep(1000);
void IdleMain(void* unused)
    while (1) {
        // Low priority task + power management routines go here.
         // The actions taken in this context must *not* cause the thread
         // to block, as the kernel requires that at least one thread is
         // schedulable at all times when not using an idle thread.
         // Note that if you have no special power-management code or idle
```

```
// tasks, an empty while (1) {} loop is sufficient to guarantee that // condition. }
```

# 21.5 lab2\_idle\_function/main.cpp

This example demonstrates how to use the idle function, instead of an idle thread to manage system inactivity.

```
--[Mark3 Realtime Platform]-
Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
See license.txt for more information
 #include "mark3.h"
Lab Example 2: Initializing the Mark3 RTOS kernel with one thread.
The following example code presents a working example of how to initialize
the Mark3 RTOS kernel, configured to use an application thread and the special Kernel-Idle function. This example is functionally identical to lab1, although it uses less memory as a result of only requiring one thread. This example also
uses the flAVR kernel-aware module to print out messages when run through the
flavR AVR Simulator.
Lessons covered in this example include:
- usage of the Kernel::SetIdleFunc() API
- Changing an idle thread into an idle function % \left( 1\right) =\left( 1\right) +\left( 1\right) +\left(
 - You can save a thread and a stack by using an idle function instead of a
     dedicated idle thread.
Takeaway:
The Kernel-Idle context allows you to run the Mark3 RTOS without running
a dedicated idle thread (where supported). This results in a lower overall
memory footprint for the application, as you can avoid having to declare
a thread object and stack for Idle functionality.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
 // This block declares the thread data for the main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clAppThread;
static K_WORD awAppStack[APP_STACK_SIZE];
static void AppMain(void* unused_);
// This block declares the special function called from with the special
 // Kernel-Idle context. We use the Kernel::SetIdleFunc() API to ensure that
 // this function is called to provide our idle context.
static void IdleMain(void);
int main (void)
                // See the annotations in lab1.
              Kernel::Init();
```

```
// Initialize the main application thread, as in lab1. Note that even
    // though we're using an Idle function and not a dedicated thread, priority
    // level 0 is still reserved for idle functionality. Application threads
    // should never be scheduled at priority level 0 when the idle function is
    // used instead of an idle thread.
    clAppThread.Init(awAppStack, sizeof(awAppStack), 1, AppMain, 0);
    clAppThread.Start();
    // This function is used to install our specified idle function to be called
    // whenever there are no ready threads in the system. Note that if no
// Idle function is specified, a default will be used. Note that this default
    // function is essentially a null operation.
    Kernel::SetIdleFunc(IdleMain);
    Kernel::Start();
    return 0;
void AppMain(void* unused_)
    // Same as in lab1.
    while (1) {
        KernelAware::Print("Hello World!\n");
        Thread::Sleep(1000);
}
void IdleMain(void)
    // Low priority task + power management routines go here.
    // The actions taken in this context must *not* cause a blocking call,
    // similar to the requirements for an idle thread.
    // Note that unlike an idle thread, the idle function must run to
    // completion. As this is also called from a nested interrupt context,
    // it's worthwhile keeping this function brief, limited to absolutely
    // necessary functionality, and with minimal stack use.
```

# 21.6 lab3\_round\_robin/main.cpp

This example demonstrates how to use round-robin thread scheduling with multiple threads of the same priority.

```
#endif
extern "C" {
void __cxa_pure_virtual(void)
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApplThread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP2_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP2_STACK_SIZE];
static void App2Main(void* unused_);
int main(void)
    // See the annotations in lab1.
    Kernel::Init();
    // In this exercise, we create two threads at the same priority level.
    \ensuremath{//} As a result, the CPU will automatically swap between these threads
    // at runtime to ensure that each get a chance to execute.
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    // Set the threads up so that Thread 1 can get 4ms of CPU time uninterrupted,
    // but Thread 2 can get 8ms of CPU time uninterrupted. This means that // in an ideal situation, Thread 2 will get to do twice as much work as
    // Thread 1 - even though they share the same scheduling priority.
    // Note that if SetQuantum() isn't called on a thread, a default value
    // is set such that each thread gets equal timeslicing in the same
    // priority group by default. You can play around with these values and
    \ensuremath{//} observe how it affects the execution of both threads.
    clApp1Thread.SetOuantum(4);
    clApp2Thread.SetQuantum(8);
    clApp1Thread.Start();
    clApp2Thread.Start();
    Kernel::Start();
void ApplMain(void* unused_)
     // Simple loop that increments a volatile counter to 1000000 then resets
    // it while printing a message.
    volatile uint32_t u32Counter = 0;
    while (1) {
        u32Counter++;
        if (u32Counter == 1000000) {
             u32Counter = 0;
             KernelAware::Print("Thread 1 - Did some work\n");
    }
}
void App2Main(void* unused_)
    \ensuremath{//} Same as ApplMain. However, as this thread gets twice as much CPU time
    ^{\prime\prime} // as Thread 1, you should see its message printed twice as often as the
    // above function.
    volatile uint32_t u32Counter = 0;
    while (1) {
        u32Counter++;
         if (u32Counter == 1000000) {
             u32Counter = 0;
              KernelAware::Print("Thread 2 - Did some work\n");
```

```
}
}
```

# 21.7 lab4\_semaphores/main.cpp

This example demonstrates how to use semaphores for Thread synchronization.

```
--[Mark3 Realtime Platform]-
Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
See license.txt for more information
#include "mark3.h"
Lab Example 4: using binary semaphores
In this example, we implement two threads, synchronized using a semaphore to
model the classic producer-consumer pattern. One thread does work, and then posts the semaphore indicating that the other thread can consume that work.
The blocking thread just waits idly until there is data for it to consume.
Lessons covered in this example include:
-Use of a binary semaphore to implement the producer-consumer pattern
-Synchronization of threads (within a single priority, or otherwise)
using a semaphore
Takeaway:
Semaphores can be used to control which threads execute at which time. This
allows threads to work cooperatively to achieve a goal in the system.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApplThread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
\ensuremath{//} This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP2_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP2_STACK_SIZE];
static void App2Main(void* unused_);
// This is the semaphore that we'll use to synchronize two threads in this
// demo application
static Semaphore clMySem;
int main (void)
    // See the annotations in previous labs for details on init.
```

```
Kernel::Init();
    // In this example we create two threads to illustrate the use of a
    \ensuremath{//} binary semaphore as a synchronization method between two threads.
    // Thread 1 is a "consumer" thread -- It waits, blocked on the semaphore
    // until thread 2 is done doing some work. Once the semaphore is posted,
    // the thread is unblocked, and does some work.
    // Thread 2 is thus the "producer" thread -- It does work, and once that
    // work is done, the semaphore is posted to indicate that the other thread // can use the producer's work product.
    clApp1Thread.Init(awApp1Stack, APP1_STACK_SIZE, 1, App1Main, 0);
    clApp2Thread.Init(awApp2Stack, APP2_STACK_SIZE, 1, App2Main, 0);
    clApplThread.Start();
    clApp2Thread.Start();
    // Initialize a binary semaphore (maximum value of one, initial value of
    clMySem.Init(0, 1);
    Kernel::Start();
    return 0;
void ApplMain(void* unused_)
    while (1) {
        \ensuremath{//} Wait until the semaphore is posted from the other thread
        KernelAware::Print("Wait\n");
        clMySem.Pend();
        // Producer thread has finished doing its work -- do something to
        // consume its output. Once again - a contrived example, but we
        // can imagine that printing out the message is "consuming" the output
        // from the other thread.
        KernelAware::Print("Triggered!\n");
}
void App2Main(void* unused_)
    volatile uint32_t u32Counter = 0;
    while (1) {
        // Do some work. Once the work is complete, post the semaphore. This
        // will cause the other thread to wake up and then take some action.
        // It's a bit contrived, but imagine that the results of this process
        // are necessary to drive the work done by that other thread.
        u32Counter++;
        if (u32Counter == 1000000) {
            u32Counter = 0;
            KernelAware::Print("Posted\n");
            clMySem.Post();
```

# 21.8 lab5 mutexes/main.cpp

This example demonstrates how to use mutexes to protect against concurrent access to resources.

```
#include "mark3.h"
/*----
Lab Example 5: using Mutexes.
Lessons covered in this example include:
-You can use mutexes to lock accesses to a shared resource
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
extern "C" {
void __cxa_pure_virtual(void)
\ensuremath{//} This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApp1Thread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP2_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP2_STACK_SIZE];
static void App2Main(void* unused_);
// This is the mutex that we'll use to synchronize two threads in this
// demo application.
static Mutex clMyMutex;
// This counter variable is the "shared resource" in the example, protected
// by the mutex. Only one thread should be given access to the counter at
// any time.
static volatile uint32 t u32Counter = 0:
int main (void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    clApp1Thread.Start();
    clApp2Thread.Start();
      Initialize the mutex used in this example.
    clMyMutex.Init();
    Kernel::Start();
    return 0:
void ApplMain(void* unused_)
    while (1) {
        // Claim the mutex. This will prevent any other thread from claiming
        // this lock simulatenously. As a result, the other thread has to
        // wait until we're done before it can do its work. You will notice
        // that the Start/Done prints for the thread will come as a pair (i.e. // you won't see "Thread2: Start" then "Thread1: Start").
        clMyMutex.Claim();
        // Start our work (incrementing a counter). Notice that the Start and
        // Done prints wind up as a pair when simuated with flAVR.
        KernelAware::Print("Thread1: Start\n");
        u32Counter++;
```

```
while (u32Counter <= 1000000) {</pre>
                u32Counter++;
           u32Counter = 0;
           KernelAware::Print("Thread1: Done\n");
           // Release the lock, allowing the other thread to do its thing.
}
void App2Main(void* unused_)
     while (1) {
           // Claim the mutex. This will prevent any other thread from claiming // this lock simulatenously. As a result, the other thread has to // wait until we're done before it can do its work. You will notice // that the Start/Done prints for the thread will come as a pair (i.e.
           // you won't see "Thread2: Start" then "Thread1: Start").
           clMyMutex.Claim();
           /\!/ Start our work (incrementing a counter). Notice that the Start and /\!/ Done prints wind up as a pair when simuated with flAVR.
           KernelAware::Print("Thread2: Start\n");
           u32Counter++;
           while (u32Counter <= 1000000) {</pre>
                u32Counter++;
           u32Counter = 0;
           KernelAware::Print("Thread2: Done\n");
           // Release the lock, allowing the other thread to do its thing.
           clMyMutex.Release();
```

# 21.9 lab6\_timers/main.cpp

This example demonstrates how to create and use software timers.

```
// function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApplThread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
static void PeriodicCallback(Thread* owner, void* pvData_);
static void OneShotCallback(Thread* owner, void* pvData_);
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
   clApp1Thread.Start();
    Kernel::Start();
    return 0;
void PeriodicCallback(Thread* owner, void* pvData_)
    // Timer callback function used to post a semaphore. Posting the semaphore
    // will wake up a thread that's pending on that semaphore.
    Semaphore* pclSem = (Semaphore*)pvData_;
    pclSem->Post();
void OneShotCallback(Thread* owner, void* pvData_)
    KernelAware::Print("One-shot timer expired.\n");
void ApplMain(void* unused_)
    Timer clMyTimer; // Periodic timer object
   Timer clOneShot; // One-shot timer object
    Semaphore clMySem; // Semaphore used to wake this thread
    // Initialize a binary semaphore (maximum value of one, initial value of
    // zero).
    clMySem.Init(0, 1);
    // Start a timer that triggers every 500\,\mathrm{ms} that will call PeriodicCallback.
    \ensuremath{//} This timer simulates an external stimulus or event that would require
    // an action to be taken by this thread, but would be serviced by an
    // interrupt or other high-priority context.
    // PeriodicCallback will post the semaphore which wakes the thread
    // up to perform an action. Here that action consists of a trivial message
    // print.
    clMyTimer.Start(true, 500, PeriodicCallback, (void*)&clMySem);
    // Set up a one-shot timer to print a message after 2.5 seconds, asynchronously
    // from the execution of this thread.
    clOneShot.Start(false, 2500, OneShotCallback, 0);
    while (1) {
        // Wait until the semaphore is posted from the timer expiry
        clMySem.Pend();
        // Take some action after the timer posts the semaphore to wake this
        // thread.
        KernelAware::Print("Thread Triggered.\n");
```

# 21.10 lab7\_events/main.cpp

This example demonstrates how to create and use event groups

```
--[Mark3 Realtime Platform]----
Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
See license.txt for more information
#include "mark3.h"
Lab Example 7: using Event Flags
Lessons covered in this example include:
-Using the EventFlag Class to synchronize thread execution
-Explore the behavior of the EVENT_FLAG_ANY and EVENT_FLAG_ALL, and the
 event-mask bitfield.
Takeaway:
Like Semaphores and Mutexes, EventFlag objects can be used to synchronize
the execution of threads in a system. The EventFlag class allows for many
threads to share the same object, blocking on different event combinations.
This provides an efficient, robust way for threads to process asynchronous system events that occur with a unified interface.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApplThread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
// This block declares the thread data for one main application thread. It // defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread. #define APP2_STACK_SIZE (320 / sizeof(K_WORD))
static Thread clApp2Thread;
static K_WORD awApp2Stack[APP2_STACK_SIZE];
static void App2Main(void* unused_);
static EventFlag clFlags;
int main(void)
     // See the annotations in previous labs for details on init.
     Kernel::Init();
     \verb|clApp1Thread.Init| (awApp1Stack, size of (awApp1Stack), 1, App1Main, 0); \\
     clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
     clApp1Thread.Start();
    clApp2Thread.Start();
     clFlags.Init();
    Kernel::Start():
     return 0;
void ApplMain(void* unused_)
```

```
while (1) {
         // Block this thread until any of the event flags have been set by
         // some outside force (here, we use Thread 2). As an exercise to the // user, try playing around with the event mask to see the effect it
         // has on which events get processed. Different threads can block on
         // different bitmasks - this allows events with different real-time
         // priorities to be handled in different threads, while still using
         // the same event-flag object.
         // Also note that {\tt EVENT\_FLAG\_ANY} indicates that the thread will be // unblocked whenever any of the flags in the mask are selected.
         // you wanted to trigger an action that only takes place once multiple
         // bits are set, you could block the thread waiting for a specific
         // event bitmask with EVENT_FLAG_ALL specified.
        u16Flags = clFlags.Wait(0xFFFF, EVENT_FLAG_ANY);
         // Print a message indicaating which bit was set this time.
         switch (u16Flags) {
             case 0x0001: KernelAware::Print("Event1\n"); break;
             case 0x0002: KernelAware::Print("Event2\n"); break;
             case 0x0004: KernelAware::Print("Event3\n"); break;
             case 0x0008: KernelAware::Print("Event4\n"); break;
             case 0x0010: KernelAware::Print("Event5\n"); break;
             case 0x0020: KernelAware::Print("Event6\n"); break;
             case 0x0040: KernelAware::Print("Event7\n"); break;
             case 0x0080: KernelAware::Print("Event8\n"); break;
             case 0x0100: KernelAware::Print("Event9\n"); break;
case 0x0200: KernelAware::Print("Event10\n"); break;
             case 0x0400: KernelAware::Print("Event11\n"); break;
             case 0x0800: KernelAware::Print("Event12\n"); break;
             case 0x1000: KernelAware::Print("Event13\n"); break;
             case 0x2000: KernelAware::Print("Event14\n"); break;
             case 0x4000: KernelAware::Print("Event15\n"); break;
             case 0x8000: KernelAware::Print("Event16\n"); break;
             default: break;
         // Clear the event-flag that we just printed a message about. This
         // will allow u16 to acknowledge further events in that bit in the future.
         clFlags.Clear(u16Flags);
}
void App2Main(void* unused_)
    uint16_t u16Flag = 1;
    while (1) {
        Thread::Sleep(100);
         // Event flags essentially map events to bits in a bitmap.
         // set one bit each 100ms. In this loop, we cycle through bits 0-15 // repeatedly. Note that this will wake the other thread, which is
         ^{\prime\prime} // blocked, waiting for *any* of the flags in the bitmap to be set.
         clFlags.Set (u16Flag);
         // Bitshift the flag value to the left. This will be the flag we set
         // the next time this thread runs through its loop.
         if (u16Flag != 0x8000) {
             u16Flag <<= 1;
             u16Flag = 1;
    }
```

# 21.11 lab8\_messages/main.cpp

This example demonstrates how to pass data between threads using message passing.

```
--[Mark3 Realtime Platform]-----
 Copyright (c) 2012-2016 Funkenstein Software Consulting, all rights reserved.
 See license.txt for more information
 #include "mark3.h"
Lab Example 8: using messages for IPC.
 In this example, we present a typical asynchronous producer/consumer pattern
using Mark3's message-driven IPC.
Lessons covered in this example include:
 - use of Message and MessageQueue objects to send data between threads % \left( 1\right) =\left( 1\right) \left( 
 - use of GlobalMessagePool to allocate and free message objects
 Takeawav:
Unlike cases presented in previous examples that relied on semaphores or
 event flags, messages carry substantial context, specified in its "code" and "data" members. This mechanism can be used to pass data between threads
 extremely efficiently, with a simple and flexible API. Any number of threads
 can write to/block on a single message queue, which give this method of
 IPC even more flexibility.
 #if !KERNEL USE IDLE FUNC
 #error "This demo requires KERNEL_USE_IDLE_FUNC"
 #endif
 extern "C" {
 void __cxa_pure_virtual(void)
 \ensuremath{//} This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point
 // function used by the application thread.
#define APP1_STACK_SIZE (320 / sizeof(K_WORD))
 static Thread clApplThread;
 static K_WORD awApp1Stack[APP1_STACK_SIZE];
 static void ApplMain(void* unused_);
 // This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point
 // function used by the application thread.
 #define APP2_STACK_SIZE (320 / sizeof(K_WORD))
 static Thread clApp2Thread;
 static K_WORD awApp2Stack[APP2_STACK_SIZE];
static void App2Main(void* unused_);
 static MessageQueue clMsgQ;
 int main(void)
               // See the annotations in previous labs for details on init.
              Kernel::Init();
             clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
              clApp1Thread.Start();
              clApp2Thread.Start();
             clMsgQ.Init();
             Kernel::Start();
              return 0;
 void ApplMain(void* unused_)
              uint16_t u16Data = 0;
              while (1) {
                        // This thread grabs a message from the global message pool, sets a
                          // code-value and the message data pointer, then sends the message to // a message queue object. Another thread (Thread2) is blocked, waiting
```

```
// for a message to arrive in the queue.
         // Get the message object
         Message* pclMsg = GlobalMessagePool::Pop();
         // Set the message object's data (contrived in this example)
         pclMsg->SetCode(0x1337);
         pclMsg->SetData(&u16Data);
         // Send the message to the shared message queue
         clMsqQ.Send(pclMsq);
         // Wait before sending another message.
         Thread::Sleep(200);
void App2Main(void* unused_)
    while (1) {
         \ensuremath{//} This thread waits until it receives a message on the shared global
         \ensuremath{//} message queue. When it gets the message, it prints out information
         // message quark. When I gets the message, reprints our instance in a final message and data, before returning the message object // back to the global message pool. In a more practical application,
         // the user would typically use the code to tell the receiving thread
         // what kind of message was sent, and what type of data to expect in the
         // data field.
         \ensuremath{//} Wait for a message to arrive on the specified queue. Note that once
         // this thread receives the message, it is "owned" by the thread, and
         // must be returned back to its source message pool when it is no longer
         // needed.
         Message* pclMsg = clMsgQ.Receive();
         // We received a message, now print out its information KernelAware::Print("Received Message \n");
         KernelAware::Trace(0, __LINE__, pclMsg->GetCode(), *((uint16_t*)pclMsg->
      GetData()));
         // Done with the message, return it back to the global message queue.
         GlobalMessagePool::Push(pclMsg);
```

## 21.12 lab9\_dynamic\_threads/main.cpp

This example demonstrates how to create and destroy threads dynamically at runtime.

```
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
#if !KERNEL_USE_THREAD_CALLOUTS
#error "This demo requires KERNEL_USE_THREAD_CALLOUTS"
#endif
#if !KERNEL_TIMERS_TICKLESS
#error "This demo requires KERNEL_TIMERS_TICKLESS"
#endif
extern "C" {
void __cxa_pure_virtual(void)
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-poi nt
// function used by the application thread.
#define APP1_STACK_SIZE (400 / sizeof(K_WORD))
static Thread clApp1Thread;
static K_WORD awApp1Stack[APP1_STACK_SIZE];
static void ApplMain(void* unused_);
// This block declares the thread stack data for a thread that we'll create
// dynamically.
#define APP2_STACK_SIZE (400 / sizeof(K_WORD))
static K_WORD awApp2Stack[APP2_STACK_SIZE];
#if KERNEL_USE_THREAD_CALLOUTS
#define MAX_THREADS (10)
static Thread* apclActiveThreads[10];
static uint32_t aul6ActiveTime[10];
static void PrintThreadSlack(void)
     KernelAware::Print("Stack Slack");
     for (uint8_t i = 0; i < MAX_THREADS; i++) {
    if (apclActiveThreads[i] != 0) {</pre>
              char szStr[10];
              uint16_t u16Slack = apclActiveThreads[i] ->GetStackSlack();
              MemUtil::DecimalToHex((K_ADDR)apclActiveThreads[i], szStr);
              KernelAware::Print(szStr);
KernelAware::Print(" ");
              MemUtil::DecimalToString(u16Slack, szStr);
              KernelAware::Print(szStr);
              KernelAware::Print("\n");
    }
}
static void PrintCPUUsage (void)
     KernelAware::Print("Cpu usage\n");
for (int i = 0; i < MAX_THREADS; i++) {
   if (apclActiveThreads[i] != 0) {</pre>
              KernelAware::Trace(0, __LINE__, (K_ADDR)apclActiveThreads[i],
       au16ActiveTime[i]);
    }
}
static void ThreadCreateCallout(Thread* pclThread)
     KernelAware::Print("TC\n");
     CS_ENTER();
     for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
         if (apclActiveThreads[i] == 0) {
    apclActiveThreads[i] = pclThread_;
             break;
         }
     CS_EXIT();
     PrintThreadSlack():
     PrintCPUUsage();
static void ThreadExitCallout(Thread* pclThread_)
     KernelAware::Print("TX\n");
     CS_ENTER();
```

```
for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
        if (apclActiveThreads[i] == pclThread_) {
    apclActiveThreads[i] = 0;
            au16ActiveTime[i] = 0;
            break;
        }
    CS_EXIT();
    PrintThreadSlack();
    PrintCPUUsage();
static void ThreadContextSwitchCallback(Thread* pclThread_)
    {\tt KernelAware::Print("CS\n");}
    static uint16_t u16LastTick = 0;
                    u16Ticks = KernelTimer::Read();
    uint16 t
    CS_ENTER();
    for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
        if (apclActiveThreads[i] == pclThread_) {
   aul6ActiveTime[i] += ul6Ticks - ul6LastTick;
            break;
    CS_EXIT();
    u16LastTick = u16Ticks;
#endif
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    Kernel::SetThreadCreateCallout(ThreadCreateCallout);
    Kernel::SetThreadExitCallout(ThreadExitCallout);
    {\tt Kernel::SetThreadContextSwitchCallout\,(ThreadContextSwitchCallback)}
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp1Thread.Start();
    Kernel::Start();
    return 0:
}
static void WorkerMain1(void* arg_)
    Semaphore* pclSem = (Semaphore*)arg_;
   uint32_t u32Count = 0;
    // Do some work. Post a semaphore to notify the other thread that the
    // work has been completed.
    while (u32Count < 1000000) {
       u32Count++;
    KernelAware::Print("Worker1 -- Done Work\n");
   pclSem->Post();
    // Work is completed, just spin now. Let another thread destory u16.
    while (1) {
static void WorkerMain2(void* arg_)
    uint32_t u32Count = 0;
    while (u32Count < 1000000) {
       u32Count++;
    KernelAware::Print("Worker2 -- Done Work\n");
    // A dynamic thread can self-terminate as well:
    Scheduler::GetCurrentThread()->Exit();
void ApplMain(void* unused_)
```

```
clMyThread;
    Thread
    Semaphore clMySem;
    clMySem.Init(0, 1);
    while (1) {
    // Example 1 - create a worker thread at our current priority in order to
         // parallelize some work.
        clMyThread.Init(awApp2Stack, sizeof(awApp2Stack), 1, WorkerMain1, (void*)&clMySem);
        clMyThread.Start();
         \ensuremath{//} Do some work of our own in parallel, while the other thread works on its project.
        uint32_t u32Count = 0;
        while (u32Count < 100000) {
             u32Count++;
        KernelAware::Print("Thread -- Done Work\n");
        PrintThreadSlack();
         // Wait for the other thread to finish its job.
        clMySem.Pend();
        // Once the thread has signalled u16, we can safely call "Exit" on the thread to // remove it from scheduling and recycle it later.
        clMyThread.Exit();
         // Spin the thread up again to do something else in parallel. This time, the thread
        // will run completely asynchronously to this thread. clMyThread.Init(awApp2Stack, sizeof(awApp2Stack), 1, WorkerMain2, 0);
        clMyThread.Start();
        u32Count = 0;
        while (u32Count < 1000000) {</pre>
             u32Count++;
        KernelAware::Print("Thread -- Done Work\n");
         // Check that we're sure the worker thread has terminated before we try running the
        // test loop again.
while (clMyThread.GetState() != THREAD_STATE_EXIT) {
        KernelAware::Print(" Test Done\n");
         Thread::Sleep(1000);
        PrintThreadSlack();
}
```

## Index

```
/home/moslevin/projects/mark3-source/kernel/atomic. ←
                                                                  h. 260
         cpp, 199
                                                        /home/moslevin/projects/mark3-source/kernel/public/autoalloc.←
/home/moslevin/projects/mark3-source/kernel/autoalloc. ←
                                                                  h, 261
         cpp, 201
                                                        /home/moslevin/projects/mark 3-source/kernel/public/blocking. \hookleftarrow
/home/moslevin/projects/mark3-source/kernel/blocking. ←
                                                                  h, 262, 263
         cpp, 203, 204
                                                        /home/moslevin/projects/mark3-source/kernel/public/buffalogger. -
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc/Refnelprofile.
         cpp, 205
                                                        /home/moslevin/projects/mark3-source/kernel/public/driver. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc/ActinelSovi. ←
         cpp, 206, 207
                                                        /home/moslevin/projects/mark3-source/kernel/public/eventflag. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc/kernel/bmer.←
         cpp, 207, 208
                                                        /home/moslevin/projects/mark3-source/kernel/public/kernel. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc@bli@Bernelprofile.←
         h, 210
                                                        /home/moslevin/projects/mark3-source/kernel/public/kernelaware. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc@dblia/kernelswi. ←
         h, 211, 212
                                                        /home/moslevin/projects/mark3-source/kernel/public/kerneldebug. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc@dbli@7kerneltimer. ←
         h, 212, 213
                                                        /home/moslevin/projects/mark3-source/kernel/public/kerneltypes. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbc/public/portcfg. ←
         h, 213, 216
                                                        /home/moslevin/projects/mark3-source/kernel/public/ksemaphore. ←
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbcβtblicatbreadport. ←
                                                        /home/moslevin/projects/mark3-source/kernel/public/II.
         h, 216, 218
/home/moslevin/projects/mark3-source/kernel/cpu/avr/atmega328p/gbcatertalpreadport. ←
         cpp, 222, 223
                                                        /home/moslevin/projects/mark3-source/kernel/public/mailbox. ←
/home/moslevin/projects/mark3-source/kernel/driver. ←
         cpp, 225, 226
                                                        /home/moslevin/projects/mark3-source/kernel/public/manual. ←
/home/moslevin/projects/mark3-source/kernel/eventflag. ←
                                                                  h. 285
         cpp, 227, 228
                                                        /home/moslevin/projects/mark3-source/kernel/public/mark3. ←
/home/moslevin/projects/mark3-source/kernel/kernel. ←
                                                                  h, 286
         cpp. 232, 233
                                                        /home/moslevin/projects/mark3-source/kernel/public/mark3cfg. ←
/home/moslevin/projects/mark3-source/kernel/kernelaware. ←
                                                                  h, 287, 294
         cpp, 234, 235
                                                        /home/moslevin/projects/mark3-source/kernel/public/message. ←
/home/moslevin/projects/mark3-source/kernel/ksemaphore. -
                                                                  h, 295, 297
         cpp, 237, 238
                                                        /home/moslevin/projects/mark3-source/kernel/public/mutex.←
/home/moslevin/projects/mark3-source/kernel/ll.cpp,
                                                                  h, 298, 299
                                                        /home/moslevin/projects/mark3-source/kernel/public/notify. -
/home/moslevin/projects/mark3-source/kernel/mailbox. ←
                                                                  h, 300
                                                        /home/moslevin/projects/mark3-source/kernel/public/paniccodes. ←
                                                                  h, 301
/home/moslevin/projects/mark3-source/kernel/message. ←
         cpp, 247
                                                        /home/moslevin/projects/mark3-source/kernel/public/priomap. ←
/home/moslevin/projects/mark3-source/kernel/mutex.←
                                                                  h. 302
                                                        /home/moslevin/projects/mark3-source/kernel/public/profile. ←
         cpp, 250
/home/moslevin/projects/mark3-source/kernel/notify. ←
                                                                  h, 303, 304
                                                        /home/moslevin/projects/mark3-source/kernel/public/guantum.
         cpp, 254
/home/moslevin/projects/mark3-source/kernel/priomap. -
                                                                  h, 305
         cpp, 256, 257
                                                        /home/moslevin/projects/mark3-source/kernel/public/scheduler. -
/home/moslevin/projects/mark3-source/kernel/profile. ←
                                                                  h, 306, 307
         cpp, 258
                                                        /home/moslevin/projects/mark3-source/kernel/public/thread. ←
/home/moslevin/projects/mark3-source/kernel/public/atomic.
                                                                  h, 307, 308
```

/home/moslevin/projects/mark3-source/kernel/public/threa	<b>oAilso</b> .c <u>⊸</u> Thread
h, 311	mark3c.h, 348
/home/moslevin/projects/mark3-source/kernel/public/timer	.Alloc_Timer
h, 312, 313	mark3c.h, 348
/home/moslevin/projects/mark3-source/kernel/public/timer	li <b>&amp;</b> uteAlloc
h, 315, 316	mark3c.h, 349
/home/moslevin/projects/mark3-source/kernel/public/timer	scheduler. <i>←</i>
h, 316, 317	Block
/home/moslevin/projects/mark3-source/kernel/public/trace	bufferBlockingObject, 96
h, 317, 318	BlockPriority
/home/moslevin/projects/mark3-source/kernel/quantum. ←	BlockingObject, 96
cpp, 318, 319	BlockingObject, 95
/home/moslevin/projects/mark3-source/kernel/scheduler	J Block, 96
cpp, 321	BlockPriority, 96
/home/moslevin/projects/mark3-source/kernel/thread. ←	UnBlock, 96
cpp, 322, 323	
$/home/moslevin/projects/mark 3-source/kernel/thread list. \leftarrow$	,CS_ENTER
cpp, 330	threadport.h, 217
/home/moslevin/projects/mark3-source/kernel/timer. ←	CircularLinkList, 97
cpp, 331, 332	Add, 97
/home/moslevin/projects/mark3-source/kernel/timerlist.←	InsertNodeBefore, 98
cpp, 334, 335	PivotBackward, 98
/home/moslevin/projects/mark3-source/kernel/tracebuffer.	→ PivotForward, 98
cpp, 338	Remove, 98
/home/moslevin/projects/mark3-source/libs/mark3c/public/	rskaim
_types.h, 339, 340	Mutex, 152
/home/moslevin/projects/mark3-source/libs/mark3c/public/	r <del>Glai</del> mei ←
h, 342, 376	Mutex, 153
mark3_clz8	Clear
threadport.h, 218	EventFlag, 110
threadport.n, 210	KernelSWI, 127
AVR	PriorityMap, 157
portcfg.h, 214	ClearExpiry
Add	KernelTimer, 129
CircularLinkList, 97	ClearInTimer
•	
DoubleLinkList, 103	Quantum, 163
DoubleLinkList, 103 DriverList, 108	Quantum, 163 ClearNode
DriverList, 108	ClearNode
DriverList, 108 Scheduler, 165	ClearNode LinkListNode, 135
DriverList, 108 Scheduler, 165 ThreadList, 185	ClearNode LinkListNode, 135 Close
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195	ClearNode LinkListNode, 135 Close DevNull, 100
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197	ClearNode LinkListNode, 135 Close DevNull, 100 Driver, 105
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority	ClearNode LinkListNode, 135 Close DevNull, 100 Driver, 105 ComputeCurrentTicks
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186	ClearNode LinkListNode, 135 Close DevNull, 100 Driver, 105 ComputeCurrentTicks ProfileTimer, 161
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread	ClearNode LinkListNode, 135 Close DevNull, 100 Driver, 105 ComputeCurrentTicks ProfileTimer, 161 Config
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox	ClearNode LinkListNode, 135 Close DevNull, 100 Driver, 105 ComputeCurrentTicks ProfileTimer, 161 Config KernelSWI, 127 KernelTimer, 129 ContextSwitchSWI Thread, 175
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_Mutex	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData Mailbox, 137
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData Mailbox, 137  DevNull, 99
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Notify	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData Mailbox, 137  DevNull, 99 Close, 100
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Notify mark3c.h, 348	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData Mailbox, 137  DevNull, 99 Close, 100 Control, 100
DriverList, 108 Scheduler, 165 ThreadList, 185 TimerList, 195 TimerScheduler, 197 AddPriority ThreadList, 186 AddThread Quantum, 163 Alloc_EventFlag mark3c.h, 347 Alloc_Mailbox mark3c.h, 347 Alloc_Message mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_MessageQueue mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Mutex mark3c.h, 347 Alloc_Notify	ClearNode LinkListNode, 135  Close DevNull, 100 Driver, 105  ComputeCurrentTicks ProfileTimer, 161  Config KernelSWI, 127 KernelTimer, 129  ContextSwitchSWI Thread, 175  Control DevNull, 100 Driver, 105  CopyData Mailbox, 137  DevNull, 99 Close, 100

Read, 101	EventFlag_Wait
Write, 101	mark3c.h, 351
DI	EventFlagOperation_t
KernelSWI, 127	kerneltypes.h, 278
KernelTimer, 129	eventflag.cpp
DoubleLinkList, 102	TimedEventFlag_Callback, 228
Add, 103	Exit
DoubleLinkList, 103	Thread, 175
Remove, 103	ExitSimulator
Driver, 103	KernelAware, 122
Close, 105	,
Control, 105	FakeThread_t, 113
GetPath, 105	FindByPath
Init, 105	DriverList, 108
Open, 106	
Read, 106	g_blsKernelAware
SetName, 106	kernelaware.cpp, 235
Write, 107	g_stKAData
driver.cpp	kernelaware.cpp, 235
DrvCmp, 225	GLOBAL_MESSAGE_POOL_SIZE
DriverList, 107	mark3cfg.h, 289
Add, 108	GetAverage
FindByPath, 108	ProfileTimer, 161
Init, 108	GetCode
Remove, 108	Message, 144
DrvCmp	GetCount
driver.cpp, 225	MessageQueue, 149
απνειτορρ, 223	Semaphore, 169
EVENT FLAG ALL CLEAR	GetCurPriority
kerneltypes.h, 278	Thread, 175
EVENT FLAG ALL	GetCurrent
kerneltypes.h, 278	ProfileTimer, 161
EVENT_FLAG_ANY_CLEAR	Thread, 175
kerneltypes.h, 278	GetCurrentThread
EVENT_FLAG_ANY	Scheduler, 165
kerneltypes.h, 278	GetData
EVENT_FLAG_MODES	Message, 144
kerneltypes.h, 278	GetEpoch
EVENT_FLAG_PENDING_UNBLOCK	Profiler, 159
kerneltypes.h, 278	GetEventFlagMask
El	Thread, 175
KernelTimer, 130	GetEventFlagMode
EventFlag, 109	Thread, 176
Clear, 110	GetExpired
GetMask, 110	Thread, 176
Set, 110	GetExtendedContext
Wait, 111	Thread, 176
Wait_i, 112	GetHead
WakeMe, 112	GlobalMessagePool, 114
EventFlag_Clear	LinkList, 133
mark3c.h, 349	MessagePool, 147
EventFlag_GetMask	GetHeadPointer
mark3c.h, 349	Mailbox, 137
EventFlag_Init	GetID
<del>-</del>	
mark3c.h, 350	Thread, 176 GetIdleThread
EventFlag_Set	
mark3c.h, 350	Kernel, 117 GetInterval
EventFlag_TimedWait	Timer, 190
mark3c.h, 350	rimer, 190

GetMask	Thread, 178
EventFlag, 110	Init
GetNext	DevNull, 100
LinkListNode, 135	Driver, 105
GetNextThread	DriverList, 108
Scheduler, 165	GlobalMessagePool, 114
GetOvertime	Kernel, 118
KernelTimer, 130	LinkList, 133
GetOwner	Mailbox, 138
Thread, 177	Message, 145
GetPath	MessagePool, 147
Driver, 105	MessageQueue, 149
GetPool	Mutex, 153
GlobalMessagePool, 114	Notify, 155
GetPrev	ProfileTimer, 161
LinkListNode, 135	Profiler, 159
GetPriority	Scheduler, 166
Thread, 177	Semaphore, 169
GetQuantum	Thread, 179
Thread, 177	Timer, 190
GetStack	TimerList, 195
Thread, 177	TimerScheduler, 197
GetStackSize	InitIdle
Thread, 178	Thread, 179
GetStackSlack	InitStack
Thread, 178	ThreadPort, 188
GetState	InsertNodeBefore
Thread, 178	CircularLinkList, 98
GetStopList	IsEnabled
Scheduler, 166	Scheduler, 166
GetTail	IsPanic
LinkList, 133	Kernel, 118
GetTailPointer	IsSimulatorAware
Mailbox, 138	KernelAware, 122
GetThreadContextSwitchCallout	IsStarted
Kernel, 117	Kernel, 118
GetThreadCreateCallout	K WORD
Kernel, 117	portefg.h, 214
GetThreadExitCallout	KA COMMAND EXIT SIMULATOR
Kernel, 118	kernelaware.h, 271
GetThreadList	KA_COMMAND_IDLE
Scheduler, 166	kernelaware.h, 271
GlobalMessagePool, 113	KA COMMAND PRINT
GetHead, 114	kernelaware.h, 271
GetPool, 114	KA COMMAND PROFILE INIT
Init, 114	kernelaware.h, 271
Pop, 115	KA_COMMAND_PROFILE_REPORT
Push, 115	kernelaware.h, 271
GlobalMessagePool_Pop mark3c.h, 351	KA_COMMAND_PROFILE_START
	kernelaware.h, 271
GlobalMessagePool_Push	KA_COMMAND_PROFILE_STOP
mark3c.h, 351	kernelaware.h, 271
HighestPriority	KA_COMMAND_TRACE_0
PriorityMap, 157	kernelaware.h, 271
HighestWaiter	KA_COMMAND_TRACE_1
ThreadList, 186	kernelaware.h, 271
,	
	KA_COMMAND_TRACE_2
InheritPriority	

KERNEL_AWARE_SIMULATION	Start, 121
mark3cfg.h, 289	$Kernel\_GetThreadContextSwitchCallout$
KERNEL_ENABLE_LOGGING	mark3c.h, 352
mark3cfg.h, 289	Kernel_GetThreadCreateCallout
KERNEL_ENABLE_USER_LOGGING	mark3c.h, 352
mark3cfg.h, 289	Kernel_GetThreadExitCallout
KERNEL_EXTRA_CHECKS	mark3c.h, 352
mark3cfg.h, 289	Kernel_Init
KERNEL_NUM_PRIORITIES	mark3c.h, 352
mark3cfg.h, 290	Kernel_IsPanic
KERNEL_TIMERS_MINIMUM_DELAY_US	mark3c.h, 352
mark3cfg.h, 290	Kernel_IsStarted
KERNEL_TIMERS_TICKLESS	mark3c.h, 353
mark3cfg.h, 290	Kernel_Panic
KERNEL_USE_ATOMIC	mark3c.h, 353
mark3cfg.h, 290	Kernel SetIdleFunc
KERNEL_USE_AUTO_ALLOC	mark3c.h, 353
mark3cfg.h, 290	Kernel SetPanic
KERNEL_USE_DYNAMIC_THREADS	mark3c.h, 354
mark3cfg.h, 291	Kernel_SetThreadContextSwitchCallout
KERNEL USE EVENTFLAG	mark3c.h, 354
mark3cfg.h, 291	Kernel_SetThreadCreateCallout
KERNEL USE IDLE FUNC	mark3c.h, 354
mark3cfg.h, 291	Kernel_SetThreadExitCallout
KERNEL_USE_MAILBOX	mark3c.h, 355
mark3cfg.h, 291	Kernel_Start
KERNEL_USE_MESSAGE	mark3c.h, 355
mark3cfg.h, 291	KernelAware, 121
KERNEL_USE_PROFILER	ExitSimulator, 122
mark3cfg.h, 292	IsSimulatorAware, 122
KERNEL_USE_QUANTUM	Print, 122
mark3cfg.h, 292	ProfilePapert 100
KERNEL_USE_SEMAPHORE	ProfileReport, 123
mark3cfg.h, 292	ProfileStart, 123
KERNEL_USE_STACK_GUARD	ProfileStop, 123
mark3cfg.h, 292	Trace, 123, 124
KERNEL_USE_THREAD_CALLOUTS	Trace_i, 125
mark3cfg.h, 292	KernelAware_ExitSimulator
KERNEL_USE_THREADNAME	mark3c.h, 355
mark3cfg.h, 293	KernelAware_IsSimulatorAware
KERNEL_USE_TIMEOUTS	mark3c.h, 355
mark3cfg.h, 293	KernelAware_Print
KERNEL_USE_TIMERS	mark3c.h, 355
mark3cfg.h, 293	KernelAware_ProfileInit
Kernel, 116	mark3c.h, 356
GetIdleThread, 117	KernelAware_ProfileReport
GetThreadContextSwitchCallout, 117	mark3c.h, 356
GetThreadCreateCallout, 117	KernelAware_ProfileStart
GetThreadExitCallout, 118	mark3c.h, 356
Init, 118	KernelAware_ProfileStop
IsPanic, 118	mark3c.h, 356
IsStarted, 118	KernelAware_Trace
Panic, 118	mark3c.h, 356
SetIdleFunc, 119	KernelAware_Trace1
SetPanic, 119	mark3c.h, 357
SetThreadContextSwitchCallout, 119	KernelAware_Trace2
SetThreadCreateCallout, 120	mark3c.h, 357
SetThreadExitCallout, 120	KernelAwareCommand_t

kernelaware.h, 271	Mailbox, 143
KernelAwareData_t, 125	Mailbox, 136
KernelSWI, 126	CopyData, 137
Clear, 127	GetHeadPointer, 137
Config, 127	GetTailPointer, 138
DI, 127	Init, 138
RI, 127	m_clSendSem, 143
Start, 128	MoveHeadBackward, 138
Stop, 128	MoveHeadForward, 138
Trigger, 128	MoveTailBackward, 139
KernelTimer, 128	MoveTailForward, 139
ClearExpiry, 129	Receive, 139
Config, 129	Receive_i, 140
DI, 129	ReceiveTail, 140
EI, 130	Send, 141
GetOvertime, 130	Send_i, 142
Read, 130	SendTail, 142, 143
RI, 130	Mailbox_GetFreeSlots
SetExpiry, 131	mark3c.h, 357
Start, 131	Mailbox_Init
Stop, 131	mark3c.h, 358
SubtractExpiry, 131	Mailbox_IsEmpty
TimeToExpiry, 132	mark3c.h, 358
kernelaware.cpp	Mailbox_IsFull
g_blsKernelAware, 235	mark3c.h, 358
g_stKAData, 235	Mailbox_Receive
kernelaware.h	mark3c.h, 359
KA_COMMAND_EXIT_SIMULATOR, 271	Mailbox_ReceiveTail
KA_COMMAND_IDLE, 271	mark3c.h, 359
KA_COMMAND_PRINT, 271	Mailbox_Send
KA_COMMAND_PROFILE_INIT, 271	mark3c.h, 359
KA_COMMAND_PROFILE_REPORT, 271	Mailbox_SendTail
KA_COMMAND_PROFILE_START, 271	mark3c.h, 360
KA_COMMAND_PROFILE_STOP, 271 KA_COMMAND_TRACE_0, 271	Mailbox_TimedReceive
KA_COMMAND_TRACE_0, 271 KA_COMMAND_TRACE_1, 271	mark3c.h, 360
KA_COMMAND_TRACE_1, 271 KA_COMMAND_TRACE_2, 271	Mailbox_TimedReceiveTail
KernelAwareCommand_t, 271	mark3c.h, 360
kerneltypes.h	Mailbox_TimedSend
EVENT FLAG ALL CLEAR, 278	mark3c.h, 361
EVENT FLAG ALL, 278	Mailbox_TimedSendTail
EVENT FLAG ANY CLEAR, 278	mark3c.h, 361
EVENT FLAG ANY, 278	mark3c.h
EVENT FLAG MODES, 278	Alloc_EventFlag, 347
EVENT FLAG PENDING UNBLOCK, 278	Alloc_Mailbox, 347
EventFlagOperation_t, 278	Alloc_Message, 347
ksemaphore.cpp	Alloc_MessageQueue, 347
TimedSemaphore_Callback, 237	Alloc_Mutex, 347
· - /	Alloc_Notify, 348
LinkList, 132	Alloc_Semaphore, 348
GetHead, 133	Alloc_Thread, 348
GetTail, 133	Alloc_Timer, 348
Init, 133	AutoAlloc, 349
LinkListNode, 134	EventFlag_Clear, 349
ClearNode, 135	EventFlag_GetMask, 349
GetNext, 135	EventFlag_Init, 350
GetPrev, 135	EventFlag_Set, 350
m alCandCom	EventFlag_TimedWait, 350
m_clSendSem	EventFlag_Wait, 351

GlobalMessagePool_Pop, 351	Semaphore_Init, 368
GlobalMessagePool_Push, 351	Semaphore_Pend, 368
Kernel_GetThreadContextSwitchCallout, 352	Semaphore_Post, 369
Kernel_GetThreadCreateCallout, 352	Semaphore_TimedPend, 369
Kernel_GetThreadExitCallout, 352	Thread_Exit, 369
Kernel_Init, 352	Thread_GetCurPriority, 370
Kernel_IsPanic, 352	Thread_GetExtendedContext, 370
Kernel_IsStarted, 353	Thread_GetID, 370
Kernel_Panic, 353	Thread_GetPriority, 371
Kernel_SetIdleFunc, 353	Thread_GetQuantum, 371
Kernel_SetPanic, 354	Thread_GetStackSlack, 371
Kernel_SetThreadContextSwitchCallout, 354	Thread_GetState, 372
Kernel_SetThreadCreateCallout, 354	Thread_Init, 372
Kernel_SetThreadExitCallout, 355	Thread_SetExtendedContext, 372
Kernel_Start, 355	Thread_SetID, 373
KernelAware_ExitSimulator, 355	Thread_SetPriority, 373
KernelAware_IsSimulatorAware, 355	Thread_SetQuantum, 373
KernelAware_Print, 355	Thread_Sleep, 374
KernelAware_ProfileInit, 356	Thread_Start, 374
KernelAware_ProfileReport, 356	Thread_Stop, 374
KernelAware_ProfileStart, 356	Thread_USleep, 375
KernelAware_ProfileStop, 356	Thread_Yield, 375
KernelAware_Trace, 356	Timer_Init, 375
KernelAware_Trace1, 357	Timer_Restart, 375
KernelAware_Trace2, 357	Timer_Start, 375
Mailbox_GetFreeSlots, 357	Timer_Stop, 376
Mailbox_Init, 358	mark3cfg.h
Mailbox_IsEmpty, 358	GLOBAL_MESSAGE_POOL_SIZE, 289
Mailbox_IsFull, 358	KERNEL_AWARE_SIMULATION, 289
Mailbox_Receive, 359	KERNEL_ENABLE_LOGGING, 289
Mailbox_ReceiveTail, 359	KERNEL_ENABLE_USER_LOGGING, 289
Mailbox_Send, 359	KERNEL_EXTRA_CHECKS, 289
Mailbox_SendTail, 360	KERNEL_NUM_PRIORITIES, 290
Mailbox_TimedReceive, 360	
Malibux_Timeuneceive, 300	KERNEL_TIMERS_MINIMUM_DELAY_US, 290
Mailbox_TimedReceiveTail, 360	KERNEL_TIMERS_MINIMUM_DELAY_US, 290 KERNEL_TIMERS_TICKLESS, 290
Mailbox_TimedReceiveTail, 360	KERNEL_TIMERS_TICKLESS, 290
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREAD_CALLOUTS, 292
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_TimedClaim, 366	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMERS, 293 SAFE_UNLINK, 293
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_Release, 365	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMERS, 293
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_TimedClaim, 366 Notify_Init, 366 Notify_Signal, 366	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMEOUTS, 293 SAFE_UNLINK, 293 THREAD_QUANTUM_DEFAULT, 293 Message, 143
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_TimedClaim, 366 Notify_Init, 366 Notify_Signal, 366 Notify_TimedWait, 367	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMERS, 293 SAFE_UNLINK, 293 THREAD_QUANTUM_DEFAULT, 293
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_TimedClaim, 366 Notify_Signal, 366	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMERS, 293 SAFE_UNLINK, 293 THREAD_QUANTUM_DEFAULT, 293 Message, 143 GetCode, 144
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_Release, 365 Mutex_TimedClaim, 366 Notify_Init, 366 Notify_Signal, 366 Notify_TimedWait, 367 Notify_Wait, 367	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREADNAME, 293 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMERS, 293 SAFE_UNLINK, 293 THREAD_QUANTUM_DEFAULT, 293 Message, 143 GetCode, 144 GetData, 144
Mailbox_TimedReceiveTail, 360 Mailbox_TimedSend, 361 Mailbox_TimedSendTail, 361 Message_GetCode, 362 Message_GetData, 362 Message_Init, 362 Message_SetCode, 363 Message_SetData, 363 MessageQueue_GetCount, 363 MessageQueue_Init, 363 MessageQueue_Receive, 364 MessageQueue_Send, 364 MessageQueue_TimedReceive, 364 MessageQueue_TimedReceive, 364 Mutex_Claim, 365 Mutex_Init, 365 Mutex_Release, 365 Mutex_TimedClaim, 366 Notify_Init, 366 Notify_Signal, 366 Notify_TimedWait, 367 Notify_Wait, 367 Scheduler_Enable, 367	KERNEL_TIMERS_TICKLESS, 290 KERNEL_USE_ATOMIC, 290 KERNEL_USE_AUTO_ALLOC, 290 KERNEL_USE_DYNAMIC_THREADS, 291 KERNEL_USE_EVENTFLAG, 291 KERNEL_USE_IDLE_FUNC, 291 KERNEL_USE_MAILBOX, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_MESSAGE, 291 KERNEL_USE_PROFILER, 292 KERNEL_USE_QUANTUM, 292 KERNEL_USE_SEMAPHORE, 292 KERNEL_USE_STACK_GUARD, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_THREAD_CALLOUTS, 292 KERNEL_USE_TIMEOUTS, 293 KERNEL_USE_TIMEOUTS, 293 SAFE_UNLINK, 293 THREAD_QUANTUM_DEFAULT, 293 Message, 143 GetCode, 144 GetData, 144 Init, 145

Message_GetCode	Signal, 155
mark3c.h, 362	Wait, 155, 156
Message_GetData	WakeMe, 156
mark3c.h, 362	Notify_Init
Message_Init	mark3c.h, 366
mark3c.h, 362	Notify_Signal
Message_SetCode	mark3c.h, 366
mark3c.h, 363	Notify_TimedWait
Message_SetData	mark3c.h, 367
mark3c.h, 363	Notify_Wait
MessagePool, 146	mark3c.h, 367
GetHead, 147	0.5.5
Init, 147	Open
Pop, 147	DevNull, 100
Push, 147	Driver, 106
MessageQueue, 148	PORT PRIO TYPE
GetCount, 149	portcfg.h, 214
Init, 149	PORT_SYSTEM_FREQ
Receive, 149	portefg.h, 215
Receive_i, 150	PORT_TIMER_COUNT_TYPE
Send, 150	portefg.h, 215
MessageQueue_GetCount	PORT_TIMER_FREQ
mark3c.h, 363	portefg.h, 215
MessageQueue_Init	Panic
mark3c.h, 363	Kernel, 118
MessageQueue_Receive	Pend
mark3c.h, 364	Semaphore, 170
MessageQueue_Send	Pend i
mark3c.h, 364	Semaphore, 170
MessageQueue_TimedReceive	PivotBackward
mark3c.h, 364	CircularLinkList, 98
MoveHeadBackward	PivotForward
Mailbox, 138	CircularLinkList, 98
MoveHeadForward	Pop
Mailbox, 138	GlobalMessagePool, 115
MoveTailBackward	MessagePool, 147
Mailbox, 139	portcfg.h
MoveTailForward	AVR, 214
Mailbox, 139	K WORD, 214
Mutex, 151	PORT PRIO TYPE, 214
Claim, 152	PORT SYSTEM FREQ, 215
Claim_i, 153	PORT TIMER COUNT TYPE, 215
Init, 153	PORT TIMER FREQ, 215
Release, 153	Post
WakeMe, 153	Semaphore, 171
WakeNext, 154	Print
mutex.cpp	KernelAware, 122
TimedMutex_Calback, 250	PriorityMap, 157
Mutex_Claim	Clear, 157
mark3c.h, 365	HighestPriority, 157
Mutex_Init	PriorityMap, 157
mark3c.h, 365	Set, 158
Mutex_Release	Process
mark3c.h, 365	Profiler, 159
Mutex_TimedClaim	TimerList, 195
mark3c.h, 366	TimerScheduler, 197
Notify, 154	ProfileInit
Init, 155	KernelAware, 123
ant, 100	Norman Ward, 120

ProfileReport	TimerList, 196
KernelAware, 123	TimerScheduler, 197
ProfileStart	RemoveThread
KernelAware, 123	Quantum, 163
ProfileStop	RI
KernelAware, 123	KernelSWI, 127
ProfileTimer, 160	KernelTimer, 130
ComputeCurrentTicks, 161	
GetAverage, 161	SAFE_UNLINK
GetCurrent, 161	mark3cfg.h, 293
Init, 161	Schedule
Start, 162	Scheduler, 167
Stop, 162	Scheduler, 164
Profiler, 158	Add, 165
GetEpoch, 159	GetCurrentThread, 165
Init, 159	GetNextThread, 165
Process, 159	GetStopList, 166
Read, 159	GetThreadList, 166
Start, 159	Init, 166
Stop, 159	IsEnabled, 166
Push	QueueScheduler, 167
	Remove, 167
GlobalMessagePool, 115	Schedule, 167
MessagePool, 147	SetScheduler, 167
Quantum, 162	Scheduler Enable
AddThread, 163	mark3c.h, 367
	Scheduler_GetCurrentThread
ClearInTimer, 163	mark3c.h, 368
RemoveThread, 163	Scheduler_IsEnabled
SetInTimer, 163	mark3c.h, 368
SetTimer, 163	Semaphore, 168
UpdateTimer, 164	•
quantum.cpp	GetCount, 169
QuantumCallback, 319	Init, 169
QuantumCallback	Pend, 170
quantum.cpp, 319	Pend_i, 170
QueueScheduler	Post, 171
Scheduler, 167	WakeMe, 171
	WakeNext, 171
Read	Semaphore_Init
DevNull, 101	mark3c.h, 368
Driver, 106	Semaphore_Pend
KernelTimer, 130	mark3c.h, 368
Profiler, 159	Semaphore_Post
Receive	mark3c.h, 369
Mailbox, 139	Semaphore_TimedPend
MessageQueue, 149	mark3c.h, 369
Receive_i	Send
Mailbox, 140	Mailbox, 141
MessageQueue, 150	MessageQueue, 150
ReceiveTail	Send_i
Mailbox, 140	Mailbox, 142
Release	SendTail
Mutex, 153	Mailbox, 142, 143
Remove	Set
CircularLinkList, 98	EventFlag, 110
DoubleLinkList, 103	PriorityMap, 158
DriverList, 108	SetCallback
Scheduler, 167	Timer, 190
ThreadList, 186	SetCode
,	

Message, 145	SetTimer
SetCurrent	Quantum, 163
Thread, 179	SetTolerance
SetData	Timer, 193
Message, 145	Signal
Timer, 191	Notify, 155
SetEventFlagMask	Sleep
Thread, 180	Thread, 183
SetEventFlagMode	Start
Thread, 180	Kernel, 121
SetExpired	KernelSWI, 128
Thread, 180	KernelTimer, 131
SetExpiry	ProfileTimer, 162 Profiler, 159
KernelTimer, 131	Thread, 183
SetExtendedContext	Timer, 193, 194
Thread, 180	StartThreads
SetFlags	ThreadPort, 188
Timer, 191	Stop
SetID	KernelSWI, 128
Thread, 181 SetIdleFunc	KernelTimer, 131
	ProfileTimer, 162
Kernel, 119 SetInTimer	Profiler, 159
	Thread, 183
Quantum, 163 SetIntervalMSeconds	Timer, 194
Timer, 191	SubtractExpiry
SetIntervalSeconds	KernelTimer, 131
Timer, 191	
SetIntervalTicks	THREAD_QUANTUM_DEFAULT
Timer, 192	mark3cfg.h, 293
SetIntervalUSeconds	TIMERLIST_FLAG_EXPIRED
Timer, 192	timer.h, 313
SetMapPointer	Thread, 172
ThreadList, 186	ContextSwitchSWI, 175
SetName	Exit, 175
Driver, 106	GetCurrent 175
SetOwner	GetCurrent, 175 GetEventFlagMask, 175
Thread, 181	GetEventFlagMode, 176
Timer, 192	GetExpired, 176
SetPanic	GetExtendedContext, 176
Kernel, 119	GetID, 176
SetPriority	GetOwner, 177
Thread, 181	GetPriority, 177
ThreadList, 187	GetQuantum, 177
SetPriorityBase	GetStack, 177
Thread, 182	GetStackSize, 178
SetQuantum	GetStackSlack, 178
Thread, 182	GetState, 178
SetScheduler	InheritPriority, 178
Scheduler, 167	Init, 179
SetState	InitIdle, 179
Thread, 182	SetCurrent, 179
SetThreadContextSwitchCallout	SetEventFlagMask, 180
Kernel, 119	SetEventFlagMode, 180
SetThreadCreateCallout	SetExpired, 180
Kernel, 120	SetExtendedContext, 180
SetThreadExitCallout	SetID, 181
Kernel, 120	SetOwner, 181

SetPriority, 181	CS_ENTER, 217
SetPriorityBase, 182	TimeToExpiry
SetQuantum, 182	KernelTimer, 132
SetState, 182	TimedEventFlag_Callback
Sleep, 183	eventflag.cpp, 228
Start, 183	TimedMutex_Calback
Stop, 183	mutex.cpp, 250
USleep, 183	TimedSemaphore_Callback
Yield, 184	ksemaphore.cpp, 237
Thread_Exit	Timer, 188
mark3c.h, 369	GetInterval, 190
Thread_GetCurPriority	Init, 190
mark3c.h, 370	SetCallback, 190
Thread_GetExtendedContext	SetData, 191
mark3c.h, 370	SetFlags, 191
Thread_GetID	SetIntervalMSeconds, 191
mark3c.h, 370	SetIntervalSeconds, 191
Thread_GetPriority	SetIntervalTicks, 192
mark3c.h, 371	SetIntervalUSeconds, 192
Thread_GetQuantum	SetOwner, 192
mark3c.h, 371	SetTolerance, 193
Thread_GetStackSlack	Start, 193, 194
mark3c.h, 371	Stop, 194
Thread_GetState	Timer, 190
mark3c.h, 372	timer.h
Thread_Init	TIMERLIST_FLAG_EXPIRED, 313
mark3c.h, 372	TimerCallback_t, 313
Thread SetExtendedContext	Timer_Init
mark3c.h, 372	mark3c.h, 375
Thread_SetID	Timer_Restart
mark3c.h, 373	mark3c.h, 375
Thread_SetPriority	Timer_Start
mark3c.h, 373	mark3c.h, 375
Thread_SetQuantum	Timer_Stop
mark3c.h, 373	mark3c.h, 376
Thread Sleep	TimerCallback_t
mark3c.h, 374	timer.h, 313
Thread Start	TimerList, 194
mark3c.h, 374	Add, 195
Thread_Stop	Init, 195
mark3c.h, 374	Process, 195
Thread_USleep	Remove, 196
mark3c.h, 375	TimerScheduler, 196
Thread Yield	Add, 197
mark3c.h, 375	Init, 197
ThreadList, 184	Process, 197
Add, 185	Remove, 197
AddPriority, 186	Trace
HighestWaiter, 186	KernelAware, 123, 124
-	Trace_i
Remove, 186	KernelAware, 125
SetMapPointer, 186	Trigger
SetPriority, 187	KernelSWI, 128
ThreadPost 187	LIClass
ThreadPort, 187	USleep
InitStack, 188	Thread, 183
StartThreads, 188	UnBlock
threadport.h	BlockingObject, 96
mark3_clz8, 218	UpdateTimer

## Quantum, 164 Wait EventFlag, 111 Notify, 155, 156 Wait\_i EventFlag, 112 WakeMe EventFlag, 112 Mutex, 153 Notify, 156 Semaphore, 171 WakeNext Mutex, 154 Semaphore, 171 Write DevNull, 101 Driver, 107 Yield Thread, 184