Mark3 Realtime Kernel

Generated by Doxygen 1.8.7

Sat Dec 5 2015 22:15:43

Contents

1 The Mark3 Realtime Kernel			1					
2	Pref	Preface						
	2.1	Who should read this	3					
	2.2	Why Mark3?	3					
3	Can	you Afford an RTOS?	5					
	3.1	Intro	5					
	3.2	Memory overhead:	6					
	3.3	Code Space Overhead:	7					
	3.4	Runtime Overhead	7					
4	Sup	erloops erloops	9					
	4.1	Intro to Superloops	9					
	4.2	The simplest loop	9					
	4.3	Interrupt-Driven Super-loop	10					
	4.4	Cooperative multi-tasking	11					
	4.5	Hybrid cooperative/preemptive multi-tasking	12					
	4.6	Problems with superloops	13					
5	Mari	k3 Overview	15					
	5.1	Intro	15					
	5.2	Features	15					
	5.3	Design Goals	16					
6	Getting Started 1							
	6.1	Kernel Setup	17					
	6.2	Threads	18					
		6.2.1 Thread Setup	18					
		6.2.2 Entry Functions	19					
	6.3	Timers	19					
	6.4	Semaphores	20					
6.E. Mutavaa		Mutavas	01					

iv CONTENTS

	6.6	Event F	Flags	21
	6.7	Messag	ges	22
		6.7.1	Message Objects	22
		6.7.2	Global Message Pool	23
		6.7.3	Message Queues	23
		6.7.4	Messaging Example	23
	6.8	Mailbox	xes	24
		6.8.1	Mailbox Example	24
	6.9	Notifica	ation Objects	25
		6.9.1	Notification Example	25
	6.10	Sleep		25
	6.11	Round-	-Robin Quantum	26
7	Build	d Syster		27
	7.1	Source	Layout	27
	7.2	^	g the kernel	27
	7.3	Building	g on Windows	29
8	Licer	nse		31
Ŭ	8.1		9	31
	0.1	LICCIISC		01
9	Profi	iling Re	sults	33
	9.1	Date Po	erformed	33
	9.2	Compil	er Information	33
	9.3	Profilin	g Results	33
10		e Size P	-	35
			ation	35
			ler Version	35
	10.3	Profilin	g Results	35
11	Hiera	archical	Index	37
	11.1	Class F	Hierarchy	37
12		s Index		39
	12.1	Class L	_ist	39
12	File I	Indev		41
13			st	41
	13.1	I IIC LIS		+1
14	Class	s Docur	mentation	45
	14.1	Blockin	ngObject Class Reference	45

CONTENTS

	14.1.2	Member Function Documentation	46
		14.1.2.1 Block	46
		14.1.2.2 BlockPriority	46
		14.1.2.3 UnBlock	46
14.2	Circula	rLinkList Class Reference	46
	14.2.1	Detailed Description	47
	14.2.2	Member Function Documentation	47
		14.2.2.1 Add	47
		14.2.2.2 InsertNodeBefore	47
		14.2.2.3 PivotBackward	48
		14.2.2.4 PivotForward	48
		14.2.2.5 Remove	48
14.3	DevNul	I Class Reference	48
	14.3.1	Detailed Description	49
	14.3.2	Member Function Documentation	49
		14.3.2.1 Close	49
		14.3.2.2 Control	49
		14.3.2.3 Init	50
		14.3.2.4 Open	50
		14.3.2.5 Read	50
		14.3.2.6 Write	51
14.4	Double	LinkList Class Reference	51
	14.4.1	Detailed Description	51
	14.4.2	Constructor & Destructor Documentation	52
		14.4.2.1 DoubleLinkList	52
	14.4.3	Member Function Documentation	52
		14.4.3.1 Add	52
		14.4.3.2 Remove	52
14.5	Driver (Class Reference	52
	14.5.1	Detailed Description	53
	14.5.2	Member Function Documentation	53
		14.5.2.1 Close	53
		14.5.2.2 Control	54
		14.5.2.3 GetPath	55
		14.5.2.4 Init	55
		14.5.2.5 Open	55
		14.5.2.6 Read	55
		14.5.2.7 SetName	56
		14.5.2.8 Write	56
14.6	DriverL	ist Class Reference	56

vi CONTENTS

Detailed Description	57
Member Function Documentation	57
14.6.2.1 Add	57
14.6.2.2 FindByPath	57
14.6.2.3 Init	57
14.6.2.4 Remove	57
Flag Class Reference	58
Detailed Description	59
Member Function Documentation	59
14.7.2.1 Clear	59
14.7.2.2 GetMask	59
14.7.2.3 Set	59
14.7.2.4 Wait	59
14.7.2.5 Wait	60
14.7.2.6 Wait_i	60
14.7.2.7 WakeMe	60
hread_t Struct Reference	61
Detailed Description	61
IMessagePool Class Reference	61
Detailed Description	62
Member Function Documentation	62
14.9.2.1 Init	62
14.9.2.2 Pop	62
14.9.2.3 Push	62
l Class Reference	63
.1 Detailed Description	64
.2 Member Function Documentation	64
14.10.2.1 GetIdleThread	64
14.10.2.2 Init	64
14.10.2.3 IsPanic	64
14.10.2.4 IsStarted	64
14.10.2.5 Panic	64
14.10.2.6 SetIdleFunc	65
14.10.2.7 SetPanic	65
14.10.2.8 Start	65
IAware Class Reference	65
.1 Detailed Description	66
.2 Member Function Documentation	66
14.11.2.1 ExitSimulator	66
14.11.2.2 IsSimulatorAware	66
	14.6.2.1 Add 14.6.2.2 FindByPath 14.6.2.3 Init 14.6.2.4 Remove Flag Class Reference Detailed Description 2 Member Function Documentation 14.7.2.1 Clear 14.7.2.2 GetMask 14.7.2.3 Set 14.7.2.4 Wait 14.7.2.5 Wait 14.7.2.7 WakeMe Thread_t Struct Reference Detailed Description 2 Member Function Documentation 14.9.2.1 Init 14.9.2.2 Pop 14.9.2.3 Push 1 Class Reference 1 Detailed Description 2 Member Function Documentation 14.9.2.1 Init 14.9.2.2 Pop 14.9.2.3 Push 1 Class Reference 1 Detailed Description 2 Member Function Documentation 14.10.2.1 SetTuct Reference 1 1 Detailed Description 2 Member Function Documentation 14.10.2.1 GetIdleThread 14.10.2.2 Init 14.10.2.3 IsPanic 14.10.2.4 IsStarted 14.10.2.5 Panic 14.10.2.6 SetIdleFunc 14.10.2.7 SetPanic 14.10.2.8 Start 14.40.2.8 Start

CONTENTS vii

14.11.2.3 Print	67
14.11.2.4 ProfileInit	67
14.11.2.5 ProfileReport	67
14.11.2.6 ProfileStart	67
14.11.2.7 ProfileStop	67
14.11.2.8 Trace	67
14.11.2.9 Trace	68
14.11.2.10Trace	68
14.11.2.11Trace_i	68
14.12KernelAwareData_t Union Reference	69
14.12.1 Detailed Description	69
14.13KernelSWI Class Reference	69
14.13.1 Detailed Description	70
14.13.2 Member Function Documentation	70
14.13.2.1 Clear	70
14.13.2.2 Config	70
14.13.2.3 DI	70
14.13.2.4 RI	70
14.13.2.5 Start	70
14.13.2.6 Stop	71
14.13.2.7 Trigger	71
14.14KernelTimer Class Reference	71
14.14.1 Detailed Description	72
14.14.2 Member Function Documentation	72
14.14.2.1 ClearExpiry	72
14.14.2.2 Config	72
14.14.2.3 DI	72
14.14.2.4 El	72
14.14.2.5 GetOvertime	72
14.14.2.6 Read	73
14.14.2.7 RI	73
14.14.2.8 SetExpiry	73
14.14.2.9 Start	73
14.14.2.10Stop	73
14.14.2.11SubtractExpiry	73
14.14.2.12TimeToExpiry	74
14.15LinkList Class Reference	74
14.15.1 Detailed Description	75
14.15.2 Member Function Documentation	75
14.15.2.1 Add	75

viii CONTENTS

14.15.2.2 GetHead	75
14.15.2.3 GetTail	75
14.15.2.4 Init	75
14.15.2.5 Remove	76
14.16LinkListNode Class Reference	76
14.16.1 Detailed Description	77
14.16.2 Member Function Documentation	77
14.16.2.1 ClearNode	77
14.16.2.2 GetNext	77
14.16.2.3 GetPrev	77
14.17Message Class Reference	78
14.17.1 Detailed Description	78
14.17.2 Member Function Documentation	78
14.17.2.1 GetCode	78
14.17.2.2 GetData	79
14.17.2.3 Init	79
14.17.2.4 SetCode	79
14.17.2.5 SetData	79
14.18MessageQueue Class Reference	79
14.18.1 Detailed Description	80
14.18.2 Member Function Documentation	80
14.18.2.1 GetCount	80
14.18.2.2 Init	80
14.18.2.3 Receive	80
14.18.2.4 Receive	81
14.18.2.5 Receive_i	81
14.18.2.6 Send	81
14.19Mutex Class Reference	82
14.19.1 Detailed Description	82
14.19.2 Member Function Documentation	83
14.19.2.1 Claim	83
14.19.2.2 Claim	83
14.19.2.3 Claim_i	83
14.19.2.4 Init	83
14.19.2.5 Release	83
14.19.2.6 WakeMe	84
14.19.2.7 WakeNext	84
14.20 Profiler Class Reference	84
14.20.1 Detailed Description	84
14.20.2 Member Function Documentation	85

CONTENTS

14.20.2.1 GetEpoch	85
14.20.2.2 Init	85
14.20.2.3 Process	85
14.20.2.4 Read	85
14.20.2.5 Start	85
14.20.2.6 Stop	85
14.21 ProfileTimer Class Reference	85
14.21.1 Detailed Description	86
14.21.2 Member Function Documentation	86
14.21.2.1 ComputeCurrentTicks	86
14.21.2.2 GetAverage	87
14.21.2.3 GetCurrent	87
14.21.2.4 Init	87
14.21.2.5 Start	87
14.21.2.6 Stop	87
14.22Quantum Class Reference	88
14.22.1 Detailed Description	88
14.22.2 Member Function Documentation	88
14.22.2.1 AddThread	88
14.22.2.2 ClearInTimer	88
14.22.2.3 RemoveThread	89
14.22.2.4 SetInTimer	89
14.22.2.5 SetTimer	89
14.22.2.6 UpdateTimer	89
14.23 Scheduler Class Reference	89
14.23.1 Detailed Description	90
14.23.2 Member Function Documentation	90
14.23.2.1 Add	90
14.23.2.2 GetCurrentThread	91
14.23.2.3 GetNextThread	91
14.23.2.4 GetStopList	91
14.23.2.5 GetThreadList	91
14.23.2.6 Init	91
14.23.2.7 IsEnabled	92
14.23.2.8 QueueScheduler	92
14.23.2.9 Remove	92
14.23.2.10Schedule	92
14.23.2.11SetScheduler	92
14.24Semaphore Class Reference	93
14.24.1 Detailed Description	93

CONTENTS

14.24.2 Member Function Documentation	94
14.24.2.1 GetCount	94
14.24.2.2 Init	94
14.24.2.3 Pend	94
14.24.2.4 Pend	94
14.24.2.5 Pend_i	94
14.24.2.6 Post	95
14.24.2.7 WakeMe	95
14.25Thread Class Reference	95
14.25.1 Detailed Description	98
14.25.2 Member Function Documentation	98
14.25.2.1 ContextSwitchSWI	98
14.25.2.2 Exit	98
14.25.2.3 GetCurPriority	98
14.25.2.4 GetCurrent	98
14.25.2.5 GetEventFlagMask	99
14.25.2.6 GetEventFlagMode	99
14.25.2.7 GetExpired	99
14.25.2.8 GetID	99
14.25.2.9 GetOwner	99
14.25.2.10GetPriority	100
14.25.2.11GetQuantum	100
14.25.2.12GetStackSlack	100
14.25.2.13GetState	100
14.25.2.14InheritPriority	100
14.25.2.15nit	101
14.25.2.1@nitldle	101
14.25.2.17SetCurrent	101
14.25.2.18SetEventFlagMask	101
14.25.2.19SetEventFlagMode	101
14.25.2.20SetExpired	102
14.25.2.21SetID	102
14.25.2.2SetOwner	102
14.25.2.23SetPriority	102
14.25.2.24SetPriorityBase	102
14.25.2.25SetQuantum	103
14.25.2.26SetState	103
14.25.2.27Sleep	103
14.25.2.28Start	103
14.25.2.29Stop	103

CONTENTS xi

14.25.2.30USleep	4
14.25.2.31Yield	4
14.26ThreadList Class Reference	4
14.26.1 Detailed Description	15
14.26.2 Constructor & Destructor Documentation	15
14.26.2.1 ThreadList	15
14.26.3 Member Function Documentation	15
14.26.3.1 Add	15
14.26.3.2 Add	15
14.26.3.3 AddPriority	6
14.26.3.4 HighestWaiter	6
14.26.3.5 Remove	6
14.26.3.6 SetFlagPointer	6
14.26.3.7 SetPriority	6
14.27ThreadPort Class Reference	8
14.27.1 Detailed Description	8
14.27.2 Member Function Documentation	8
14.27.2.1 InitStack	8
14.27.2.2 StartThreads	9
14.28Timer Class Reference	9
14.28.1 Detailed Description	0
14.28.2 Constructor & Destructor Documentation	0
14.28.2.1 Timer	0
14.28.3 Member Function Documentation	1
14.28.3.1 GetInterval	1
14.28.3.2 Init	1
14.28.3.3 SetCallback	1
14.28.3.4 SetData	1
14.28.3.5 SetFlags	1
14.28.3.6 SetIntervalMSeconds	1
14.28.3.7 SetIntervalSeconds	2
14.28.3.8 SetIntervalTicks	2
14.28.3.9 SetIntervalUSeconds	2
14.28.3.10SetOwner	2
14.28.3.11SetTolerance	2
14.28.3.12Start	3
14.28.3.13Start	
14.28.3.14Stop	3
14.29TimerList Class Reference	3
14.29.1 Detailed Description	4

xii CONTENTS

		14.29.2 Member Function Documentation	114
		14.29.2.1 Add	114
		14.29.2.2 Init	114
		14.29.2.3 Process	115
		14.29.2.4 Remove	115
	14.30	OTimerScheduler Class Reference	115
		14.30.1 Detailed Description	115
		14.30.2 Member Function Documentation	116
		14.30.2.1 Add	116
		14.30.2.2 Init	116
		14.30.2.3 Process	116
		14.30.2.4 Remove	116
15	Eilo I	Documentation	117
13		/home/vm/mark3/trunk/embedded/kernel/atomic.cpp File Reference	
	13.1	15.1.1 Detailed Description	
	15.2	atomic.cpp	
		/home/vm/mark3/trunk/embedded/kernel/autoalloc.cpp File Reference	
	10.0	15.3.1 Detailed Description	
	15.4	autoalloc.cpp	
		/home/vm/mark3/trunk/embedded/kernel/blocking.cpp File Reference	
	.0.0	15.5.1 Detailed Description	
	15.6	blocking.cpp	
			121
		15.7.1 Detailed Description	
	15.8	kernelprofile.cpp	
		/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp File Reference	
			123
	15.10		123
	15.1	1/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp File Reference	124
		15.11.1 Detailed Description	124
	15.12	2kerneltimer.cpp	124
	15.10	3/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h File Reference	126
		15.13.1 Detailed Description	127
	15.14	4kernelprofile.h	127
	15.15	5/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h File Reference	127
		15.15.1 Detailed Description	128
	15.16	6kernelswi.h	128
	15.17	7/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h File Reference	128

CONTENTS xiii

XIV

15.37/home/vm/mark3/trunk/embedded/kernel/message.cpp File Reference
15.37.1 Detailed Description
15.38message.cpp
15.39/home/vm/mark3/trunk/embedded/kernel/mutex.cpp File Reference
15.39.1 Detailed Description
15.39.2 Function Documentation
15.39.2.1 TimedMutex_Calback
15.40 mutex.cpp
15.41/home/vm/mark3/trunk/embedded/kernel/notify.cpp File Reference
15.41.1 Detailed Description
15.42notify.cpp
15.43/home/vm/mark3/trunk/embedded/kernel/profile.cpp File Reference
15.43.1 Detailed Description
15.44profile.cpp
15.45/home/vm/mark3/trunk/embedded/kernel/public/atomic.h File Reference
15.45.1 Detailed Description
15.46atomic.h
15.47/home/vm/mark3/trunk/embedded/kernel/public/autoalloc.h File Reference
15.47.1 Detailed Description
15.48autoalloc.h
15.49/home/vm/mark3/trunk/embedded/kernel/public/blocking.h File Reference
15.49.1 Detailed Description
15.50blocking.h
15.51/home/vm/mark3/trunk/embedded/kernel/public/buffalogger.h File Reference
15.51.1 Detailed Description
15.52buffalogger.h
15.53/home/vm/mark3/trunk/embedded/kernel/public/driver.h File Reference
15.53.1 Detailed Description
15.53.2 Intro
15.53.3 Driver Design
15.53.4 Driver API
15.54driver.h
15.55/home/vm/mark3/trunk/embedded/kernel/public/eventflag.h File Reference
15.55.1 Detailed Description
15.56eventflag.h
15.57/home/vm/mark3/trunk/embedded/kernel/public/kernel.h File Reference
15.57.1 Detailed Description
15.58kernel.h
15.59/home/vm/mark3/trunk/embedded/kernel/public/kernelaware.h File Reference
15.59.1 Detailed Description

CONTENTS xv

15.59.2 Enumeration Type Documentation	76
15.59.2.1 KernelAwareCommand_t	76
15.60kernelaware.h	77
15.61/home/vm/mark3/trunk/embedded/kernel/public/kerneldebug.h File Reference	78
15.61.1 Detailed Description	78
15.62kerneldebug.h	78
15.63/home/vm/mark3/trunk/embedded/kernel/public/kerneltypes.h File Reference	31
15.63.1 Detailed Description	32
15.63.2 Enumeration Type Documentation	32
15.63.2.1 EventFlagOperation_t	32
15.64kerneltypes.h	32
15.65/home/vm/mark3/trunk/embedded/kernel/public/ksemaphore.h File Reference	33
15.65.1 Detailed Description	33
15.66ksemaphore.h	33
15.67/home/vm/mark3/trunk/embedded/kernel/public/II.h File Reference	34
15.67.1 Detailed Description	34
15.68ll.h	34
15.69/home/vm/mark3/trunk/embedded/kernel/public/mailbox.h File Reference	36
15.69.1 Detailed Description	36
15.70 mailbox.h	36
15.71/home/vm/mark3/trunk/embedded/kernel/public/manual.h File Reference	38
15.71.1 Detailed Description	38
15.72manual.h	38
15.73/home/vm/mark3/trunk/embedded/kernel/public/mark3.h File Reference	38
15.73.1 Detailed Description	39
15.74mark3.h	39
15.75/home/vm/mark3/trunk/embedded/kernel/public/mark3cfg.h File Reference	90
15.75.1 Detailed Description	91
15.75.2 Macro Definition Documentation	91
15.75.2.1 GLOBAL_MESSAGE_POOL_SIZE) 1
15.75.2.2 KERNEL_AWARE_SIMULATION	€1
15.75.2.3 KERNEL_ENABLE_LOGGING)2
15.75.2.4 KERNEL_ENABLE_USER_LOGGING)2
15.75.2.5 KERNEL_TIMERS_TICKLESS)2
15.75.2.6 KERNEL_USE_ATOMIC)2
15.75.2.7 KERNEL_USE_AUTO_ALLOC)2
15.75.2.8 KERNEL_USE_DYNAMIC_THREADS	
15.75.2.9 KERNEL_USE_EVENTFLAG	33
15.75.2.10KERNEL_USE_IDLE_FUNC	
15.75.2.11KERNEL_USE_MAILBOX	Э3

xvi CONTENTS

15.75.2.12KERNEL_USE_MESSAGE
15.75.2.13KERNEL_USE_PROFILER
15.75.2.14KERNEL_USE_QUANTUM
15.75.2.15KERNEL_USE_SEMAPHORE
15.75.2.16KERNEL_USE_THREADNAME
15.75.2.17KERNEL_USE_TIMEOUTS
15.75.2.18KERNEL_USE_TIMERS
15.75.2.19SAFE_UNLINK
15.75.2.20THREAD_QUANTUM_DEFAULT
15.76mark3cfg.h
15.77/home/vm/mark3/trunk/embedded/kernel/public/message.h File Reference
15.77.1 Detailed Description
15.77.2 using Messages, Queues, and the Global Message Pool
15.78message.h
15.79/home/vm/mark3/trunk/embedded/kernel/public/mutex.h File Reference
15.79.1 Detailed Description
15.79.2 Initializing
15.79.3 Resource protection example
15.80mutex.h
15.81/home/vm/mark3/trunk/embedded/kernel/public/notify.h File Reference
15.81.1 Detailed Description
15.82notify.h
15.83/home/vm/mark3/trunk/embedded/kernel/public/paniccodes.h File Reference
15.83.1 Detailed Description
15.84paniccodes.h
15.85/home/vm/mark3/trunk/embedded/kernel/public/profile.h File Reference
15.85.1 Detailed Description
15.86profile.h
15.87/home/vm/mark3/trunk/embedded/kernel/public/quantum.h File Reference
15.87.1 Detailed Description
15.88quantum.h
15.89/home/vm/mark3/trunk/embedded/kernel/public/scheduler.h File Reference
15.89.1 Detailed Description
15.90scheduler.h
15.91/home/vm/mark3/trunk/embedded/kernel/public/thread.h File Reference
15.91.1 Detailed Description
15.92thread.h
15.93/home/vm/mark3/trunk/embedded/kernel/public/threadlist.h File Reference
15.93.1 Detailed Description
15.94threadlist.h


CONTENTS xvii

15.95/home/vm/mark3/trunk/embedded/kernel/public/timer.h File Reference	10
15.95.1 Detailed Description	11
15.95.2 Macro Definition Documentation	11
15.95.2.1 TIMERLIST_FLAG_EXPIRED	11
15.95.3 Typedef Documentation	11
15.95.3.1 TimerCallback_t	11
15.96timer.h	11
15.97/home/vm/mark3/trunk/embedded/kernel/public/timerlist.h File Reference	13
15.97.1 Detailed Description	13
15.98timerlist.h	13
15.99/home/vm/mark3/trunk/embedded/kernel/public/timerscheduler.h File Reference	14
15.99.1 Detailed Description	14
15.10 6 merscheduler.h	14
15.101/home/vm/mark3/trunk/embedded/kernel/public/tracebuffer.h File Reference	15
15.101. Detailed Description	15
15.10 2 acebuffer.h	15
15.102home/vm/mark3/trunk/embedded/kernel/quantum.cpp File Reference	16
15.103. Detailed Description	16
15.103. Function Documentation	16
15.103.2.1QuantumCallback	16
15.10 4 uantum.cpp	17
15.105home/vm/mark3/trunk/embedded/kernel/scheduler.cpp File Reference	18
15.105. Detailed Description	19
15.105.2/ariable Documentation	19
15.105.2.1aucCLZ	19
15.10 6 cheduler.cpp	19
15.107/home/vm/mark3/trunk/embedded/kernel/thread.cpp File Reference	21
15.107. Detailed Description	21
15.108hread.cpp	21
15.10@home/vm/mark3/trunk/embedded/kernel/threadlist.cpp File Reference	26
15.109. Detailed Description	27
15.11 6 hreadlist.cpp	27
15.111/home/vm/mark3/trunk/embedded/kernel/timer.cpp File Reference	28
15.111. Detailed Description	28
15.11 2 mer.cpp	29
15.112home/vm/mark3/trunk/embedded/kernel/timerlist.cpp File Reference	30
15.113. Detailed Description	30
15.11 4 merlist.cpp	30
15.115home/vm/mark3/trunk/embedded/kernel/tracebuffer.cpp File Reference	33
15.115. Detailed Description	34

xviii	 CONT	ENTS
15.116 acebuffer.cpp	 	. 234
Index		236

Chapter 1

The Mark3 Realtime Kernel



Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved See license.txt for more information

The Mark3 Realtime Kernel is a completely free, open-source, real-time operating system aimed at bringing multi-tasking to microcontroller systems without MMUs.

It uses modern programming languages and concepts (it's written entirely in C_{++}) to minimize code duplication, and its object-oriented design enhances readibility. The API is simple - there are only six functions required to set up the kernel, initialize threads, and start the scheduler.

The source is fully-documented with example code provided to illustrate concepts. The result is a performant RTOS, which is easy to read, easy to understand, and easy to extend to fit your needs.

But Mark3 is bigger than just a real-time kernel, it also contains a number of class-leading features:

- Device driver HAL which provides a meaningful abstraction around device-specific peripherals.
- Capable recursive-make driven build system which can be used to build all libraries, examples, tests, documentation, and user-projects for any number of targets from the command-line.
- Graphics and UI code designed to simplify the implementation of systems using displays, keypads, joysticks, and touchscreens
- · Standards-based custom communications protocol used to simplify the creation of host tools
- · A bulletproof, well-documented bootloader for AVR microcontrollers
- · Support for kernel-aware simulators, specifically, Funkenstein Software's own flAVR AVR simulator

2	The Mark3 Realtime Kerne
•	

Chapter 2

Preface

2.1 Who should read this

As the cover clearly states, this is a book about the Mark3 real-time kernel. I assume that if you're reading this book you have an interest in some, if not all, of the following subjects:

- · Embedded systems
- · Real-time systems
- · Operating system kernel design

And if you're interested in those topics, you're likely familiar with C and C++ and the more you know, the easier you'll find this book to read. And if C++ scares you, and you don't like embedded, real-time systems, you're probably looking for another book. If you're unfamiliar with RTOS fundamentals, I highly suggest searching through the vast amount of RTOS-related articles on the internet to familiarize yourself with the concepts.

2.2 Why Mark3?

My first job after graduating from university in 2005 was with a small company that had a very old-school, low-budget philosophy when it came to software development. Every make-or-buy decision ended with "make" when it came to tools. It was the kind of environment where vendors cost u16 money, but manpower was free. In retrospect, we didn't have a ton of business during the time that I worked there, and that may have had something to do with the fact that we were constantly short on ready cash for things we could code ourselves.

Early on, I asked why we didn't use industry-standard tools - like JTAG debuggers or IDEs. One senior engineer scoffed that debuggers were tools for wimps - and something that a good programmer should be able to do without. After all - we had serial ports, GPIOs, and a bi-color LED on our boards. Since these were built into the hardware, they didn't cost u16 a thing. We also had a single software "build" server that took 5 minutes to build a 32k binary on its best days, so when we had to debug code, it was a painful process of trial and error, with lots of Youtube between iterations. We complained that tens of thousands of dollars of productivity was being flushed away that could have been solved by implementing a proper build server - and while we eventually got our wish, it took far more time than it should have.

Needless to say, software development was painful at that company. We made life hard on ourselves purely out of pride, and for the right to say that we walked "up-hills both ways through 3 feet of snow, everyday". Our code was tied ever-so-tightly to our hardware platform, and the system code was indistinguishable from the application. While we didn't use an RTOS, we had effectively implemented a 3-priority threading scheme using a carefully designed interrupt nesting scheme with event flags and a while(1) superloop running as a background thread. Nothing was abstracted, and the code was always optimized for the platform, presumably in an effort to save on code size and wasted cycles. I asked why we didn't use an RTOS in any of our systems and received dismissive scoffs - the overhead from thread switching and maintaining multiple threads could not be tolerated in our systems according

4 Preface

to our chief engineers. In retrospect, our ad-hoc system was likely as large as my smallest kernel, and had just as much context switching (althrough it was hidden by the compiler).

And every time a new iteration of our product was developed, the firmware took far too long to bring up, because the algorithms and data structures had to be re-tooled to work with the peripherals and sensors attached to the new boards. We worked very hard in an attempt to reinvent the wheel, all in the name of producing "efficient" code.

Regardless, I learned a lot about software development.

Most important, I learned that good design is the key to good software; and good design doesn't have to come at a price. In all but the smallest of projects, the well-designed, well-abstracted code is not only more portable, but it's usually smaller, easier to read, and easier to reuse.

Also, since we had all the time in the world to invest in developing our own tools, I gained a lot of experience building them, and making use of good, free PC tools that could be used to develop and debug a large portion of our code. I ended up writing PC-based device and peripheral simulators, state-machine frameworks, and abstractions for our horrible ad-hoc system code. At the end of the day, I had developed enough tools that I could solve a lot of our development problems without having to re-inventing the wheel at each turn. Gaining a background in how these tools worked gave me a better understanding of how to use them - making me more productive at the jobs that I've had since.

I am convinced that designing good software takes honest effort up-front, and that good application code cannot be written unless it is based on a solid framework. Just as the wise man builds his house on rocks, and not on sand, wise developers write applications based on a well-defined platforms. And while you can probably build a house using nothing but a hammer and sheer will, you can certainly build one a lot faster with all the right tools.

This conviction lead me to development my first RTOS kernel in 2009 - FunkOS. It is a small, yet surprisingly full-featured kernel. It has all the basics (semaphores, mutexes, round-robin and preemptive scheduling), and some pretty advanced features as well (device drivers and other middleware). However, it had two major problems - it doesn't scale well, and it doesn't support many devices.

While I had modest success with this kernel (it has been featured on some blogs, and still gets around 125 downloads a month), it was nothing like the success of other RTOS kernels like u8/OS-II and FreeRTOS. To be honest, as a one-man show, I just don't have the resources to support all of the devices, toolchains, and evaluation boards that a real vendor can. I had never expected my kernel to compete with the likes of them, and I don't expect Mark3 to change the embedded landscape either.

My main goal with Mark3 was to solve the technical shortfalls in the FunkOS kernel by applying my experience in kernel development. As a result, Mark3 is better than FunkOS in almost every way; it scales better, has lower interrupt latency, and is generally more thoughtfully designed (all at a small cost to code size).

Another goal I had was to create something easy to understand, that could be documented and serve as a good introduction to RTOS kernel design. The end result of these goals is the kernel as presented in this book - a full source listing of a working OS kernel, with each module completely documented and explained in detail.

Finally, I wanted to prove that a kernel written entirely in C++ could perform just as well as one written in C, without incurring any extra overhead. Comparing the same configuration of Mark2 to Mark3, the code size is remarkably similar, and the execution performance is just as good. Not only that, but there are fewer lines of code. The code is more readable and easier to understand as a result of making use of object-oriented concepts provided by C++. Applications are easier to write because common concepts are encapsulated into objects (Threads, Semaphores, Mutexes, etc.) with their own methods and data, as opposed to APIs which rely on lots of explicit pointer-passing, type casting, and other operations that are typically considered "unsafe" or "advaned topics" in C.

Chapter 3

Can you Afford an RTOS?

Of course, since you're reading the manual for an RTOS that I've been developing for the last few years, you can guess that the conclusion that I draw is a resounding "yes".

If your code is of any sort of non-trivial complexity (say, at least a few-thousand lines), then a more appropriate question would be "can you afford *not* to use an RTOS in your system?".

In short, there are simply too many benefits of an RTOS to ignore.

- Sophisticated synchronization objects
- · The ability to efficiently block and wait
- · Enhanced responsiveness for high-priority tasks
- · Built in timers
- · Built in efficient memory management

Sure, these features have a cost in code space and RAM, but from my experience the cost of trying to code around a lack of these features will cost you as much - if not more. The results are often far less maintainable, error prone, and complex. And that simply adds time and cost. Real developers ship, and the RTOS is quickly becoming one of the standard tools that help keep developers shipping.

3.1 Intro

(Note - this article was written for the C-based Mark2 kernel, which is slightly different. While the general principles are the same, the numbers are not an 100% accurate reflection of the current costs of the Mark3 kernel.)

One of the main arguments against using an RTOS in an embedded project is that the overhead incurred is too great to be justified. Concerns over "wasted" RAM caused by using multiple stacks, added CPU utilization, and the "large" code footprint from the kernel cause a large number of developers to shun using a preemptive RTOS, instead favoring a non-preemptive, application-specific solution.

I believe that not only is the impact negligible in most cases, but that the benefits of writing an application with an RTOS can lead to savings around the board (code size, quality, reliability, and development time). While these other benefits provide the most compelling case for using an RTOS, they are far more challenging to demonstrate in a quantitative way, and are clearly documented in numerous industry-based case studies.

While there is some overhead associated with an RTOS, the typical arguments are largely unfounded when an RTOS is correctly implemented in a system. By measuring the true overhead of a preemptive RTOS in a typical application, we will demonstrate that the impact to code space, RAM, and CPU usage is minimal, and indeed acceptable for a wide range of CPU targets.

To illustrate just how little an RTOS impacts the size of an embedded software design we will look at a typical microcontroller project and analyze the various types of overhead associated with using a pre-emptive realtime kernel versus a similar non-preemptive event-based framework.

RTOS overhead can be broken into three distinct areas:

- Code space: The amount of code space eaten up by the kernel (static)
- Memory overhead: The RAM associated wtih running the kernel and application threads.
- Runtime overhead: The CPU cycles required for the kernel's functionality (primarily scheduling and thread switching)

While there are other notable reasons to include or avoid the use of an RTOS in certain applications (determinism, responsiveness, and interrupt latency among others), these are not considered in this discussion - as they are difficult to consider for the scope of our "canned" application. Application description:

For the purpose of this comparison, we first create an application using the standard preemptive Mark3 kernel with 2 system threads running: A foreground thread and a background thread. This gives three total priority levels in the system - the interrupt level (high), and two application priority threads (medium and low), which is quite a common paradigm for microcontroller firmware designs. The foreground thread processes a variety of time-critical events at a fixed frequency, while the background thread processes lower priority, aperiodic events. When there are no background thread events to process, the processor enters its low-power mode until the next interrupt is acknowledged.

The contents of the threads themselves are unimportant for this comparison, but we can assume they perform a variety of I/O using various user-input devices and a serial graphics display. As a result, a number of Mark3 device drivers are also implemented.

The application is compiled for an ATMega328p processor which contains 32kB of code space in flash, and 2kB of RAM, which is a lower-mid-range microcontroller in Atmel's 8-bit AVR line of microcontrollers. using the WinAVR GCC compiler with -O2 level optimizations, an executable is produced with the following code/RAM utilization:

31600 Bytes Code Space 2014 Bytes RAM

An alternate version of this project is created using a custom "super-loop" kernel, which uses a single application thread and provides 2 levels of priority (interrupt and application). In this case, the event handler processes the different priority application events to completion from highest to lowest priority.

This approach leaves the application itself largely unchanged. using the same optimization levels as the preemptive kernel, the code compiles as follows:

29904 Bytes Code Space 1648 Bytes RAM

3.2 Memory overhead:

At first glance, the difference in RAM utilization seems quite a lot higher for the preemptive mode version of the application, but the raw numbers don't tell the whole story.

The first issue is that the cooperative-mode total does not take into account the system stack - whereas these values are included in the totals for RTOS version of the project. As a result, some further analysis is required to determine how the stack sizes truly compare.

In cooperative mode, there is only one thread of execution - so considering that multiple event handlers are executed in turn, the stack requirements for cooperative mode is simply determined by those of the most stack-intensive event handler.

In contrast, the preemptive kernel requires a separate stack for each active thread, and as a result the stack usage of the system is the sum of the stacks for all threads.

Since the application and idle events are the same for both preemptive and cooperative mode, we know that their (independent) stack requirements will be the same in both cases.

For cooperative mode, we see that the idle thread stack utilization is lower than that of the application thread, and so the application thread's determines the stack size requirement. Again, with the preemptive kernel the stack utilization is the sum of the stacks defined for both threads.

As a result, the difference in overhead between the two cases becomes the extra stack required for the idle thread - which in our case is (a somewhat generous) 64 bytes.

The numbers still don't add up completely, but looking into the linker output we see that the rest of the difference comes from the extra data structures used to declare the threads in preemptive mode.

With this taken into account, the true memory cost of a 2-thread system ends up being around 150 bytes of R← AM - which is less than 8% of the total memory available on this particular microcontroller. Whether or not this is reasonable certainly depends on the application, but more importantly, it is not so unreasonable as to eliminate an RTOS-based solution from being considered.

3.3 Code Space Overhead:

The difference in code space overhead between the preemptive and cooperative mode solutions is less of an issue. Part of this reason is that both the preemptive and cooperative kernels are relatively small, and even an average target device (like the Atmega328 we've chosen) has plenty of room.

Mark3 can be configured so that only features necessary for the application are included in the RTOS - you only pay for the parts of the system that you use. In this way, we can measure the overhead on a feature-by-feature basis, which is shown below for the kernel as configured for this application:

3466 Bytes

The configuration tested in this comparison uses the thread/port module with timers, drivers, and semaphores, for a total kernel size of \sim 3.5KB, with the rest of the code space occupied by the application.

The custom cooperative-mode framework has a similar structure which is broken down by module as follows:

1850 Bytes

As can be seen from the compiler's output, the difference in code space between the two versions of the application is about 1.7kB - or about 5% of the available code space on the selected processor. While nearly all of this comes from the added overhead of the kernel, the rest of the difference comes the changes to the application necessary to facilitate the different frameworks.

3.4 Runtime Overhead

On the cooperative kernel, the overhead associated with running the thread is the time it takes the kernel to notice a pending event flag and launch the appropriate event handler, plus the timer interrupt execution time.

Similarly, on the preemptive kernel, the overhead is the time it takes to switch contexts to the application thread, plus the timer interrupt execution time.

The timer interrupt overhead is similar for both cases, so the overhead then becomes the difference between the following:

Preemptive mode:

- · Posting the semaphore that wakes the high-priority thread
- · Performing a context switch to the high-priority thread

Cooperative mode:

- · Setting the high-priority thread's event flag
- · Acknowledging the event from the event loop

using the cycle-accurate AVR simulator, we find the end-to-end event sequence time to be 20.4us for the cooperative mode scheduler and 44.2us for the preemptive, giving a difference of 23.8us.

With a fixed high-priority event frequency of 33Hz, we achieve a runtime overhead of 983.4us per second, or 0.← 0983% of the total available CPU time. Now, obviously this value would expand at higher event frequencies and/or slower CPU frequencies, but for this typical application we find the difference in runtime overhead to be neglible for a preemptive system. Analysis:

For the selected test application and platform, including a preemptive RTOS is entirely reasonable, as the costs are low relative to a non-preemptive kernel solution. But these costs scale relative to the speed, memory and code space of the target processor. Because of these variables, there is no "magic bullet" environment suitable for every application, but Mark3 attempts to provide a framework suitable for a wide range of targets.

On the one hand, if these tests had been performed on a higher-end microcontroller such as the ATMega1284p (containing 128kB of code space and 16kB of RAM), the overhead would be in the noise. For this type of resource-rich microcontroller, there would be no reason to avoid using the Mark3 preemptive kernel.

Conversely, using a lower-end microcontroller like an ATMega88pa (which has only 8kB of code space and 1k← B of RAM), the added overhead would likely be prohibitive for including a preemptive kernel. In this case, the cooperative-mode kernel would be a better choice.

As a rule of thumb, if one budgets 10% of a microcontroller's code space/RAM for a preemptive kernel's overhead, you should only require at minimum a microcontroller with 16k of code space and 2kB of RAM as a base platform for an RTOS. Unless there are serious constraints on the system that require much better latency or responsiveness than can be achieved with RTOS overhead, almost any modern platform is sufficient for hosting a kernel. In the event you find yourself with a microprocessor with external memory, there should be no reason to avoid using an RTOS at all.

Chapter 4

Superloops

4.1 Intro to Superloops

Before we start taking a look at designing a real-time operating system, it's worthwhile taking a look through one of the most-common design patterns that developers use to manage task execution in embedded systems - Superloops.

Systems based on superloops favor the system control logic baked directly into the application code, usually under the guise of simplicity, or memory (code and RAM) efficiency. For simple systems, superloops can definitely get the job done. However, they have some serious limitations, and are not suitable for every kind of project. In a lot of cases you can squeak by using superloops - especially in extremely constrained systems, but in general they are not a solid basis for reusable, portable code.

Nonetheless, a variety of examples are presented here- from the extremely simple, to cooperative and liimted-preemptive multitasking systems, all of which are examples are representative of real-world systems that I've either written the firmware for, or have seen in my experience.

4.2 The simplest loop

Let's start with the simplest embedded system design possible - an infinite loop that performs a single task repeatedly:

```
int main()
{
    while(1)
    {
         Do_Something();
     }
}
```

Here, the code inside the loop will run a single function forever and ever. Not much to it, is there? But you might be surprised at just how much embedded system firmware is implemented using essentially the same mechanism - there isn't anything wrong with that, but it's just not that interesting.

While the execution timeline for this program is equally boring, for the sake of completeness it would look like this:

Despite its simplicity we can see the beginnings of some core OS concepts. Here, the while(1) statement can be logically seen as the he operating system kernel - this one control statement determines what tasks can run in the system, and defines the constraints that could modify their execution. But at the end of the day, that's a big part of what a kernel is - a mechanism that controls the execution of application code.

The second concept here is the task. This is application code provided by the user to perform some useful purpose in a system. In this case Do_something() represents that task - it could be monitoring blood pressure, reading a sensor and writing its data to a terminal, or playing an MP3; anything you can think of for an embedded system to do. A simple round-robin multi-tasking system can be built off of this example by simply adding additional tasks in

10 Superloops

sequence in the main while-loop. Note that in this example the CPU is always busy running tasks - at no time is the CPU idle, meaning that it is likely burning a lot of power.

While we conceptually have two separate pieces of code involved here (an operating system kernel and a set of running tasks), they are not logically separate. The OS code is indistinguishable from the application. It's like a single-celled organism - everything is crammed together within the walls of an indivisible unit; and specialized to perform its given function relying solely on instinct.

4.3 Interrupt-Driven Super-loop

In the previous example, we had a system without any way to control the execution of the task- it just runs forever. There's no way to control when the task can (or more importantly can't) run, which greatly limits the usefulness of the system. Say you only want your task to run every 100 miliseconds - in the previous code, you have to add a hard-coded delay at the end of your task's execution to ensure your code runs only when it should.

Fortunately, there is a much more elegant way to do this. In this example, we introduce the concept of the synchronization object. A Synchronization object is some data structure which works within the bounds of the operating system to tell tasks when they can run, and in many cases includes special data unique to the synchronization event. There are a whole family of synchronization objects, which we'll get into later. In this example, we make use of the simplest synchronization primitive - the global flag.

With the addition of synchronization brings the addition of event-driven systems. If you're programming a microcontroller system, you generally have scores of peripherals available to you - timers, GPIOs, ADCs, UARTs, ethernet, u16B, etc. All of which can be configured to provide a stimulus to your system by means of interrupts. This stimulus gives u16 the ability not only to program our micros to do_something(), but to do_something() if-and-only-if a corresponding trigger has occurred.

The following concepts are shown in the example below:

```
volatile bool something_to_do = false;
__interrupt__ My_Interrupt_Source(void)
{
    something_to_do = true;
}
int main()
{
    while(1)
    {
        if( something_to_do )
        {
            Do_something();
            something_to_do = false;
        }
        else
        {
            Idle();
        }
}
```

So there you have it - an event driven system which uses a global variable to synchronize the execution of our task based on the occurrence of an interrupt. It's still just a bare-metal, OS-baked-into-the-aplication system, but it's introduced a whole bunch of added complexity (and control!) into the system.

The first thing to notice in the source is that the global variable, something_to_do, is used as a synchronization object. When an interrupt occurs from some external event, triggering the My_Interrupt_Source() ISR, program flow in main() is interrupted, the interrupt handler is run, and something_to_do is set to true, letting u16 know that when we get back to main(), that we should run our Do_something() task.

Another new concept at play here is that of the idle function. In general, when running an event driven system, there are times when the CPU has no application tasks to run. In order to minimize power consumption, CPUs usually contain instructions or registers that can be set up to disable non-essential subsets of the system when there's nothing to do. In general, the sleeping system can be re-activated quickly as a result of an interrupt or other external stimulus, allowing normal processing to resume.

Now, we could just call Do_something() from the interrupt itself - but that's generally not a great solution. In general, the more time we spend inside an interrupt, the more time we spend with at least some interrupts disabled. As a result, we end up with interrupt latency. Now, in this system, with only one interrupt source and only one task this might not be a big deal, but say that Do_something() takes several seconds to complete, and in that time several other interrupts occur from other sources. While executing in our long-running interrupt, no other interrupts can be processed - in many cases, if two interrupts of the same type occur before the first is processed, one of these interrupt events will be lost. This can be utterly disastrous in a real-time system and should be avoided at all costs. As a result, it's generally preferable to use synchronization objects whenever possible to defer processing outside of the ISR.

Another OS concept that is implicitly introduced in this example is that of task priority. When an interrupt occurs, the normal execution of code in main() is preempted: control is swapped over to the ISR (which runs to completion), and then control is given back to main() where it left off. The very fact that interrupts take precedence over what's running shows that main is conceptually a "low-priority" task, and that all ISRs are "high-priority" tasks. In this example, our "high-priority" task is setting a variable to tell our "low-priority" task that it can do something useful. We will investigate the concept of task priority further in the next example.

Preemption is another key principle in embedded systems. This is the notion that whatever the CPU is doing when an interrupt occurs, it should stop, cache its current state (referred to as its context), and allow the high-priority event to be processed. The context of the previous task is then restored its state before the interrupt, and resumes processing. We'll come back to preemption frequently, since the concept comes up frequently in RTOS-based systems.

4.4 Cooperative multi-tasking

Our next example takes the previous example one step further by introducing cooperative multi-tasking:

```
// Bitfield values used to represent three distinct tasks
#define TASK_1_EVENT (0x01)
#define TASK_2_EVENT (0x02)
#define TASK_3_EVENT (0x04)
volatile uint8 t event flags = 0;
// Interrupt sources used to trigger event execution
  _interrupt__ My_Interrupt_1(void)
    event_flags |= TASK_1_EVENT;
 _interrupt__ My_Interrupt_2(void)
    event_flags |= TASK_2_EVENT;
 _interrupt__ My_Interrupt_3(void)
    event flags |= TASK 3 EVENT;
// Main tasks
int main (void)
    while(1)
        while (event_flags)
            if ( event flags & TASK 1 EVENT)
                Do_Task_1();
                event_flags &= ~TASK_1_EVENT;
            } else if( event_flags & TASK_2_EVENT) {
                Do Task 2():
                event_flags &= ~TASK_2_EVENT;
            } else if( event_flags & TASK_3_EVENT) {
                Do Task 3();
                event_flags &= ~TASK_3_EVENT;
        Idle();
}
```

12 Superloops

This system is very similar to what we had before - however the differences are worth discussing. First, we have stimulus from multiple interrupt sources: each ISR is responsible for setting a single bit in our global event flag, which is then used to control execution of individual tasks from within main().

Next, we can see that tasks are explicitly given priorities inside the main loop based on the logic of the if/else if structure. As long as there is something set in the event flag, we will always try to execute Task1 first, and only when Task1 isn't set will we attempt to execute Task2, and then Task 3. This added logic provides the notion of priority. However, because each of these tasks exist within the same context (they're just different functions called from our main control loop), we don't have the same notion of preemption that we have when dealing with interrupts.

That means that even through we may be running Task2 and an event flag for Task1 is set by an interrupt, the CPU still has to finish processing Task2 to completion before Task1 can be run. And that's why this kind of scheduling is referred to ascooperative multitasking: we can have as many tasks as we want, but unless they cooperate by means of returning back to main, the system can end up with high-priority tasks getting starved for CPU time by lower-priority, long-running tasks.

This is one of the more popu32ar Os-baked-into-the-application approaches, and is widely used in a variety of real-time embedded systems.

4.5 Hybrid cooperative/preemptive multi-tasking

The final variation on the superloop design utilizes software-triggered interrupts to simulate a hybrid cooperative/preemptive multitasking system. Consider the example code below.

```
// Bitfields used to represent high-priority tasks. Tasks in this group
// can preempt tasks in the group below - but not eachother.
#define HP_TASK_1
                         (0x01)
                         (0x02)
#define HP_TASK_2
volatile uint8_t hp_tasks = 0;
// Bitfields used to represent low-priority tasks.
#define LP_TASK_1
                        (0x01)
#define LP_TASK_2
                         (0x02)
volatile uint8 t lp tasks = 0;
// Interrupt sources, used to trigger both high and low priority tasks.
__interrupt__ System_Interrupt_1(void)
    // Set any of the other tasks from here...
    hp_tasks |= HP_TASK_1;
       Trigger the SWI that calls the High_Priority_Tasks interrupt handler
  _interrupt__ System_Interrupt_n...(void)
    // Set any of the other tasks from here...
// Interrupt handler that is used to implement the high-priority event context
 _interrupt__ High_Priority_Tasks(void)
    // Enabled every interrupt except this one
    Disable_My_Interrupt();
    Enable Interrupts();
    while( hp_tasks)
        if ( hp tasks & HP TASK 1)
            HP_Task1();
           hp_tasks &= ~HP_TASK_1;
       else if (hp_tasks & HP_TASK_2)
            HP_Task2();
           hp_tasks &= ~HP_TASK_2;
    Restore Interrupts();
    Enable_My_Interrupt();
```

In this example, High_Priority_Tasks() can be triggered at any time as a result of a software interrupt (SWI),. When a high-priority event is set, the code that sets the event calls the SWI as well, which instantly preempts whatever is happening in main, switching to the high-priority interrupt handler. If the CPU is executing in an interrupt handler already, the current ISR completes, at which point control is given to the high priority interrupt handler.

Once inside the HP ISR, all interrupts (except the software interrupt) are re-enabled, which allows this interrupt to be preempted by other interrupt sources, which is called interrupt nesting. As a result, we end up with two distinct execution contexts (main and HighPriorityTasks()), in which all tasks in the high-priority group are guaranteed to preempt main() tasks, and will run to completion before returning control back to tasks in main(). This is a very basic preemptive multitasking scenario, approximating a "real" RTOS system with two threads of different priorities.

4.6 Problems with superloops

As mentioned earlier, a lot of real-world systems are implemented using a superloop design; and while they are simple to understand due to the limited and obvious control logic involved, they are not without their problems.

Hidden Costs

It's difficult to calculate the overhead of the superloop and the code required to implement workarounds for blocking calls, scheduling, and preemption. There's a cost in both the logic used to implement workarounds (usually involving state machines), as well as a cost to maintainability that comes with breaking up into chunks based on execution time instead of logical operations. In moderate firmware systems, this size cost can exceed the overhead of a reasonably well-featured RTOS, and the deficit in maintainability is something that is measurable in terms of lost productivity through debugging and profiling.

Tightly-coupled code

Because the control logic is integrated so closely with the application logic, a lot of care must be taken not to compromise the separation between application and system code. The timing loops, state machines, and architecture-specific control mechanisms used to avoid (or simulate) preemption can all contribute to the problem. As a result, a lot of superloop code ends up being difficult to port without effectively simulating or replicating the underlying system for which the application was written. Abstraction layers can mitigate the risks, but a lot of care should be taken to fully decouple the application code from the system code.

No blocking calls

In a super-loop environment, there's no such thing as a blocking call or blocking objects. Tasks cannot stop midexecution for event-driven I/O from other contexts - they must always run to completion. If busy-waiting and polling are used as a substitute, it increases latency and wastes cycles. As a result, extra code complexity is often times necessary to work-around this lack of blocking objects, often times through implementing additional state machines. In a large enough system, the added overhead in code size and cycles can add up.

Difficult to guarantee responsiveness

14 Superloops

Without multiple levels of priority, it may be difficult to guarantee a certain degree of real-time responsiveness without added profiling and tweaking. The latency of a given task in a priority-based cooperative multitasking system is the length of the longest task. Care must be taken to break tasks up into appropriate sized chunks in order to ensure that higher-priority tasks can run in a timely fashion - a manual process that must be repeated as new tasks are added in the system. Once again, this adds extra complexity that makes code larger, more difficult to understand and maintain due to the artificial subdivision of tasks into time-based components.

Limited preemption capability

As shown in the example code, the way to gain preemption in a superloop is through the use of nested interrupts. While this isn't unwiedly for two levels of priority, adding more levels beyond this is becomes complicated. In this case, it becomes necessary to track interrupt nesting manually, and separate sets of tasks that can run within given priority loops - and deadlock becomes more difficult to avoid.

Chapter 5

Mark3 Overview

5.1 Intro

The following section details the overall design of Mark3, the goals I've set out to achieve, the features that I've intended to provide, as well as an introduction to the programming concepts used to make it happen.

5.2 Features

Mark3 is a fully-featured real-time kernel, and is feature-competitive with other open-source and commercial RTOS's in the embedded arena.

The key features of this RTOS are:

- Flexible Scheduler
 - Unlimited number of threads with 8 priority levels
 - Unlimited threads per priority level
 - Round-robin scheduling for threads at each priority level
 - Time quantum scheduling for each thread in a given priority level
- · Configurable stacks for each Thread
- · Resource protection:
 - Integrated mutual-exclusion semaphores (Mutex)
 - Priority-inheritance on Mutex objects to prevent priority inversion
- · Synchronization Objects
 - Binary and counting Semaphore to coordinate thread execution
 - Event flags with 16-bit bitfields for complex thread synchronization
- Efficient Timers
 - The RTOS is tickless, the OS only wakes up when a timer expires, not at a regular interval
 - One-shot and periodic timers with event callbacks
 - Timers are high-precision and long-counting (about 68000 seconds when used with a 16us resolution timer)
- Driver API
 - A hardware abstraction layer is provided to simplify driver development

16 Mark3 Overview

- · Robust Interprocess Communications
 - Threadsafe global Message pool and configurable message queues
- · Support for kernel-aware simulation
 - Provides advanced test and verification functionality, allowing for easy integration into continuousintegration systems
 - Provide accurate engineering data on key metrics like stack usage and realtime performance, with easyto-use APIs and little overhead

5.3 Design Goals

Lightweight

Mark3 can be configured to have an extremely low static memory footprint. Each thread is defined with its own stack, and each thread structure can be configured to take as little as 26 bytes of RAM. The complete Mark3 kernel with all features, setup code, a serial driver, and the Mark3 protocol libraries comes in at under 9K of code space and 1K of RAM on atmel AVR.

Modular

Each system feature can be enabled or disabled by modifying the kernel configuration header file. Include what you want, and ignore the rest to save code space and RAM.

Easily Portable

Mark3 should be portable to a variety of 8, 16 and 32 bit architectures without MMUs. Porting the OS to a new architecture is relatively straightforward, requiring only device-specific implementations for the lowest-level operations such as context switching and timer setup.

Easy To use

Mark3 is small by design - which gives it the advantage that it's also easy to develop for. This manual, the code itself, and the Doxygen documentation in the code provide ample documentation to get you up to speed quickly. Because you get to see the source, there's nothing left to assumption.

Simple to Understand

Not only is the Mark3 API rigorously documented (hey - that's what this book is for!), but the architecture and naming conventions are intuitive - it's easy to figure out where code lives, and how it works. Individual modules are small due to the "one feature per file" rule used in development. This makes Mark3 an ideal platform for learning about aspects of RTOS design.

Chapter 6

Getting Started

6.1 Kernel Setup

This section details the process of defining threads, initializing the kernel, and adding threads to the scheduler.

If you're at all familiar with real-time operating systems, then these setup and initialization steps should be familiar. I've tried very hard to ensure that as much of the heavy lifting is hidden from the user, so that only the bare minimum of calls are required to get things started.

The examples presented in this chapter are real, working examples taken from the ATmega328p port.

First, you'll need to create the necessary data structures and functions for the threads:

- 1. Create a Thread object for all of the "root" or "initial" tasks.
- 2. Allocate stacks for each of the Threads
- 3. Define an entry-point function for each Thread

This is shown in the example code below:

```
#include "thread.h"
#include "kernel.h"

//1) Create a thread object for all of the "root" or "initial" tasks
static Thread AppThread;
static Thread IdleThread;

//2) Allocate stacks for each thread
#define STACK_SIZE_APP (192)
#define STACK_SIZE_IDLE (128)

static uint8_t aucAppStack[STACK_SIZE_APP];
static uint8_t aucIdleStack[STACK_SIZE_IDLE];

//3) Define entry point functions for each thread
void AppThread(void);
void IdleThread(void);
```

Next, we'll need to add the required kernel initialization code to main. This consists of running the Kernel's init routine, initializing all of the threads we defined, adding the threads to the scheduler, and finally calling Kernel::

Start(), which transfers control of the system to the RTOS.

These steps are illustrated in the following example.

18 Getting Started

```
AppThread. Init ( aucAppStack,
                                     // Pointer to the stack
                STACK_SIZE_APP, // Size of 1, // Thread priority
                                      // Size of the stack
                 (void*)AppEntry, // Entry function
                                     // Entry function argument
                NULL );
                  IdleThread.Init( aucIdleStack,
                  O, // Thread priority
(void*)IdleEntry, // Entry function
NULL); // Entry function argument
                 NULL );
//3) Add the threads to the scheduler
AppThread.Start();
                             // Actively schedule the threads
IdleThread.Start();
//4) Give control of the system to the kernel
Kernel::Start();
                             // Start the kernel!
```

Not much to it, is there? There are a few noteworthy points in this code, though.

In order for the kernel to work properly, a system must always contain an idle thread; that is, a thread at priority level 0 that never blocks. This thread is responsible for performing any of the low-level power management on the CPU in order to maximize battery life in an embedded device. The idle thread must also never block, and it must never exit. Either of these operations will cause undefined behavior in the system.

The App thread is at a priority level greater-than 0. This ensures that as long as the App thread has something useful to do, it will be given control of the CPU. In this case, if the app thread blocks, control will be given back to the Idle thread, which will put the CPU into a power-saving mode until an interrupt occurs.

Stack sizes must be large enough to accommodate not only the requirements of the threads, but also the requirements of interrupts - up to the maximum interrupt-nesting level used. Stack overflows are super-easy to run into in an embedded system; if you encounter strange and unexplained behavior in your code, chances are good that one of your threads is blowing its stack.

6.2 Threads

Mark3 Threads act as independent tasks in the system. While they share the same address-space, global data, device-drivers, and system peripherals, each thread has its own set of CPU registers and stack, collectively known as the thread's **context**. The context is what allows the RTOS kernel to rapidly switch between threads at a high rate, giving the illusion that multiple things are happening in a system, when really, only one thread is executing at a time.

6.2.1 Thread Setup

Each instance of the Thread class represents a thread, its stack, its CPU context, and all of the state and metadata maintained by the kernel. Before a Thread will be scheduled to run, it must first be initialized with the necessary configuration data.

The Init function gives the user the opportunity to set the stack, stack size, thread priority, entry-point function, entry-function argument, and round-robin time quantum:

Thread stacks are pointers to blobs of memory (usually char arrays) carved out of the system's address space. Each thread must have a stack defined that's large enough to handle not only the requirements of local variables in the thread's code path, but also the maximum depth of the ISR stack.

Priorities should be chosen carefully such that the shortest tasks with the most strict determinism requirements are executed first - and are thus located in the highest priorities. Tasks that take the longest to execute (and require the least degree of responsiveness) must occupy the lower thread priorities. The idle thread must be the only thread occupying the lowest priority level.

The thread quantum only aplies when there are multiple threads in the ready queue at the same priority level. This interval is used to kick-off a timer that will cycle execution between the threads in the priority list so that they each get a fair chance to execute.

6.3 Timers 19

The entry function is the function that the kernel calls first when the thread instance is first started. Entry functions have at most one argument - a pointer to a data-object specified by the user during initialization.

An example thread initallization is shown below:

Once a thread has been initialized, it can be added to the scheduler by calling:

```
clMyThread.Start();
```

The thread will be placed into the Scheduler's queue at the designated priority, where it will wait its turn for execution.

6.2.2 Entry Functions

Mark3 Threads should not run-to-completion - they should execute as infinite loops that perform a series of tasks, appropriately partitioned to provide the responsiveness characteristics desired in the system.

The most basic Thread loop is shown below:

Threads can interact with eachother in the system by means of synchronization objects (Semaphore), mutual-exclusion objects (Mutex), Inter-process messaging (MessageQueue), and timers (Timer).

Threads can suspend their own execution for a predetermined period of time by using the static Thread::Sleep() method. Calling this will block the Thread's executin until the amount of time specified has ellapsed. Upon expiry, the thread will be placed back into the ready queue for its priority level, where it awaits its next turn to run.

6.3 Timers

Timer objects are used to trigger callback events periodic or on a one-shot (alarm) basis.

While extremely simple to use, they provide one of the most powerful execution contexts in the system. The timer callbacks execute from within the timer callback ISR in an interrupt-enabled context. As such, timer callbacks are considered higher-priority than any thread in the system, but lower priority than other interrupts. Care must be taken to ensure that timer callbacks execute as quickly as possible to minimize the impact of processing on the throughput of tasks in the system. Wherever possible, heavy-lifting should be deferred to the threads by way of semaphores or messages.

Below is an example showing how to start a periodic system timer which will trigger every second:

20 Getting Started

6.4 Semaphores

Semaphores are used to synchronized execution of threads based on the availability (and quantity) of application-specific resources in the system. They are extremely useful for solving producer-consumer problems, and are the method-of-choice for creating efficient, low latency systems, where ISRs post semaphores that are handled from within the context of individual threads. (Yes, Semaphores can be posted - but not pended - from the interrupt context).

The following is an example of the producer-consumer usage of a binary semaphore:

```
Semaphore clSemaphore; // Declare a semaphore shared between a producer and a consumer thread.

void Producer()
{
    clSemaphore.Init(0, 1);
    while(1)
    {
        // Do some work, create something to be consumed

            // Post a semaphore, allowing another thread to consume the data
            clSemaphore.Post();
    }
}

void Consumer()
{
    // Assumes semaphore initialized before use...
    While(1)
    {
            // Wait for new data from the producer thread
            clSemaphore.Pend();
            // Consume the data!
      }
}
```

And an example of using semaphores from the ISR context to perform event- driven processing.

```
Semaphore clSemaphore;
__interrupt__ MyISR()
{
    clSemaphore.Post(); // Post the interrupt. Lightweight when uncontested.
}

void MyThread()
{
    clSemaphore.Init(0, 1); // Ensure this is initialized before the MyISR interrupt is enabled.
    while(1)
    {
        // Wait until we get notification from the interrupt
        clSemaphore.Pend();
        // Interrupt has fired, do the necessary work in this thread's context
        HeavyLifting();
    }
}
```

6.5 Mutexes 21

6.5 Mutexes

Mutexes (Mutual exclusion objects) are provided as a means of creating "protected sections" around a particular resource, allowing for access of these objects to be serialized. Only one thread can hold the mutex at a time - other threads have to wait until the region is released by the owner thread before they can take their turn operating on the protected resource. Note that mutexes can only be owned by threads - they are not available to other contexts (i.e. interrupts). Calling the mutex APIs from an interrupt will cause catastrophic system failures.

Note that these objects are also not recursive- that is, the owner thread can not attempt to claim a mutex more than once.

Priority inheritence is provided with these objects as a means to avoid priority inversions. Whenever a thread at a priority than the mutex owner blocks on a mutex, the priority of the current thread is boosted to the highest-priority waiter to ensure that other tasks at intermediate priorities cannot artificically prevent progress from being made.

Mutex objects are very easy to use, as there are only three operations supported: Initialize, Claim and Release. An example is shown below.

```
Mutex clMutex; // Create a mutex globally.
void Init()
    // Initialize the mutex before use.
    clMutex.Init();
// Some function called from a thread
void Thread1Function()
    clMutex.Claim();
    \ensuremath{//} Once the mutex is owned, no other thread can
    \ensuremath{//} enter a block protect by the same mutex
    my_protected_resource.do_something();
   my_protected_resource.do_something_else();
    clMutex.Release();
// Some function called from another thread
void Thread2Function()
    clMutex.Claim();
    // Once the mutex is owned, no other thread can
    // enter a block protect by the same mutex
    my_protected_resource.do_something();
    my_protected_resource.do_different_things();
    clMutex.Release();
```

6.6 Event Flags

Event Flags are another synchronization object, conceptually similar to a semaphore.

Unlike a semaphore, however, the condition on which threads are unblocked is determined by a more complex set of rules. Each Event Flag object contains a 16-bit field, and threads block, waiting for combinations of bits within this field to become set.

A thread can wait on any pattern of bits from this field to be set, and any number of threads can wait on any number of different patterns. Threads can wait on a single bit, multiple bits, or bits from within a subset of bits within the field

As a result, setting a single value in the flag can result in any number of threads becoming unblocked simultaneously. This mechanism is extremely powerful, allowing for all sorts of complex, yet efficient, thread synchronization schemes that can be created using a single shared object.

Note that Event Flags can be set from interrupts, but you cannot wait on an event flag from within an interrupt.

22 Getting Started

Examples demonstrating the use of event flags are shown below.

```
/\!/ Simple example showing a thread blocking on a multiple bits in the /\!/ fields within an event flag.
EventFlag clEventFlag;
int main()
    clEventFlag.Init(); // Initialize event flag prior to use
void MyInterrupt()
    // Some interrupt corresponds to event 0x0020
    clEventFlag.Set (0x0020);
void MyThreadFunc()
    while(1)
        uint16 t u16WakeCondition;
        // Allow this thread to block on multiple flags
        u16WakeCondition = clEventFlag.Wait(0x00FF, EVENT_FLAG_ANY);
         // Clear the event condition that caused the thread to wake (in this case,
        \ensuremath{//} ul6WakeCondtion will equal 0x20 when triggered from the interrupt above)
        clEventFlag.Clear(u16WakeCondition);
        // <do something>
```

6.7 Messages

Sending messages between threads is the key means of synchronizing access to data, and the primary mechanism to perform asynchronous data processing operations.

Sending a message consists of the following operations:

- Obtain a Message object from the global message pool
- · Set the message data and event fields
- · Send the message to the destination message queue

While receiving a message consists of the following steps:

- Wait for a messages in the destination message queue
- · Process the message data
- Return the message back to the global message pool

These operations, and the various data objects involved are discussed in more detail in the following section.

6.7.1 Message Objects

Message objects are used to communicate arbitrary data between threads in a safe and synchronous way.

The message object consists of an event code field and a data field. The event code is used to provide context to the message object, while the data field (essentially a void * data pointer) is used to provide a payload of data corresponding to the particular event.

6.7 Messages 23

Access to these fields is marshalled by accessors - the transmitting thread uses the SetData() and SetCode() methods to seed the data, while the receiving thread uses the GetData() and GetCode() methods to retrieve it.

By providing the data as a void data pointer instead of a fixed-size message, we achieve an unprecedented measure of simplicity and flexibility. Data can be either statically or dynamically allocated, and sized appropriately for the event without having to format and reformat data by both sending and receiving threads. The choices here are left to the user - and the kernel doesn't get in the way of efficiency.

It is worth noting that you can send messages to message queues from within ISR context. This helps maintain consistency, since the same APIs can be used to provide event-driven programming facilities throughout the whole of the OS.

6.7.2 Global Message Pool

To maintain efficiency in the messaging system (and to prevent over-allocation of data), a global pool of message objects is provided. The size of this message pool is specified in the implementation, and can be adjusted depending on the requirements of the target application as a compile-time option.

Allocating a message from the message pool is as simple as calling the GlobalMessagePool::Pop() Method.

Messages are returned back to the GlobalMessagePool::Push() method once the message contents are no longer required.

One must be careful to ensure that discarded messages always are returned to the pool, otherwise a resource leak can occur, which may cripple the operating system's ability to pass data between threads.

6.7.3 Message Queues

Message objects specify data with context, but do not specify where the messages will be sent. For this purpose we have a MessageQueue object. Sending an object to a message queue involves calling the MessageQueue::Send() method, passing in a pointer to the Message object as an argument.

When a message is sent to the queue, the first thread blocked on the queue (as a result of calling the Message Queue Receive() method) will wake up, with a pointer to the Message object returned.

It's worth noting that multiple threads can block on the same message queue, providing a means for multiple threads to share work in parallel.

6.7.4 Messaging Example

```
// Message queue object shared between threads
MessageQueue clMsgQ;
// Function that initializes the shared message queue
void MsqQInit()
    clMsgQ.Init();
// Function called by one thread to send message data to
// another
void TxMessage()
    // Get a message, initialize its data
   Message *pclMesg = GlobalMessagePool::Pop();
    pclMesg->SetCode(0xAB);
   pclMesg->SetData((void*)some_data);
    // Send the data to the message queue
    clMsgQ.Send(pclMesg);
// Function called in the other thread to block until
// a message is received in the message queue.
void RxMessage()
    Message *pclMesg;
```

24 Getting Started

```
// Block until we have a message in the queue
pclMesg = clMsgQ.Receive();

// Do something with the data once the message is received
pclMesg->GetCode();

// Free the message once we're done with it.
GlobalMessagePool::Push(pclMesg);
```

6.8 Mailboxes

Another form of IPC is provided by Mark3, in the form of Mailboxes and Envelopes.

Mailboxes are similar to message queues in that they provide a synchronized interface by which data can be transmitted between threads.

Where Message Queues rely on linked lists of lightweight message objects (containing only message code and a void* data-pointer), which are inherently abstract, Mailboxes use a dedicated blob of memory, which is carved up into fixed-size chunks called Envelopes (defined by the user), which are sent and received. Unlike message queues, mailbox data is copied to and from the mailboxes dedicated pool.

Mailboxes also differ in that they provide not only a blocking "receive" call, but also a blocking "send" call, providing the opportunity for threads to block on "mailbox full" as well as "mailbox empty" conditions.

All send/receive APIs support an optional timeout parameter if the KERNEL_USE_TIMEOUTS option has been configured in mark3cfg.h

6.8.1 Mailbox Example

```
// Create a mailbox object, and define a buffer that will be used to store the
// mailbox' envelopes.
static Mailbox clMbox;
static uint8_t aucMBoxBuffer[128];
void InitMailbox(void)
    // Initialize our mailbox, telling it to use our defined buffer for envelope
    // storage. Pass in the size of the buffer, and set the size of each
    // envelope to 16 bytes. This gives u16 a mailbox capacity of (128 / 16) = 8
    // envelopes.
    clMbox.Init((void*)aucMBoxBuffer, 128, 16);
}
void SendThread(void)
    // Define a buffer that we'll eventually send to the
    // mailbox. Note the size is the same as that of an
    // envelope.
    uint8_t aucTxBuf[16];
    while(1)
        // Copy some data into aucTxBuf, a 16-byte buffer, the
        // same size as a mailbox envelope.
        // Deliver the envelope (our buffer) into the mailbox
        clMbox.Send((void*)aucTxBuf);
void RecvThred(void)
    uint8_t aucRxBuf[16];
    while(1)
        // Wait until there's a message in our mailbox. Once
// there is a message, read it into our local buffer.
        cmMbox.Receive((void*)aucRxBuf);
```

```
// Do something with the contents of aucRxBuf, which now
// contains an envelope of data read from the mailbox.
...
}
```

6.9 Notification Objects

Notification objects are the most lightweight of all blocking objects supplied by Mark3.

using this blocking primative, one or more threads wait for the notification object to be signalled by code elsewhere in the system (i.e. another thread or interrupt). Once the the notification has been signalled, all threads currently blocked on the object become unblocked.

6.9.1 Notification Example

```
static Notify clNotifier;
void MyThread(void *unused_)
     // Initialize our notification object before use
     clNotifier.Init();
     while (1)
          // Wait until our thread has been notified that it
          // can wake up.
         clNotify.Wait();
          // Thread has woken up now -- do something!
}
void SignalCallback (void)
     // Something in the system (interrupt, thread event, IPC,
     // etc.,) has called this function. As a result, we need
// our other thread to wake up. Call the Notify object's
// Signal() method to wake the thread up. Note that this
     // will have no effect if the thread is not presently
     // blocked.
     clNotify.Signal();
```

6.10 Sleep

There are instances where it may be necessary for a thread to poll a resource, or wait a specific amount of time before proceeding to operate on a peripheral or volatile piece of data.

While the Timer object is generally a better choice for performing time-sensitive operations (and certainly a better choice for periodic operations), the Thread::Sleep() method provides a convenient (and efficient) mechanism that allows for a thread to suspend its execution for a specified interval.

Note that when a thread is sleeping it is blocked, during which other threads can operate, or the system can enter its idle state.

```
int GetPeripheralData();
{
   int value;
   // The hardware manual for a peripheral specifies that
   // the "foo()" method will result in data being generated
   // that can be captured using the "bar()" method.
   // However, the value only becomes valid after 10ms
   peripheral.foo();
   Thread::Sleep(10); // Wait 10ms for data to become valid
   value = peripheral.bar();
```

26 Getting Started

```
return value;
```

6.11 Round-Robin Quantum

Threads at the same thread priority are scheduled using a round-robin scheme. Each thread is given a timeslice (which can be configured) of which it shares time amongst ready threads in the group. Once a thread's timeslice has expired, the next thread in the priority group is chosen to run until its quantum has expired - the cycle continues over and over so long as each thread has work to be done.

By default, the round-robin interval is set at 4ms.

This value can be overridden by calling the thread's SetQuantum() with a new interval specified in milliseconds.

Build System

Mark3 is distributed with a recursive makefile build system, allowing the entire source tree to be built into a series of libraries with simple make commands.

The way the scripts work, every directory with a valid makefile is scanned, as well as all of its subdirectories. The build then generates binary components for all of the components it finds -libraries and executables. All libraries that are generated can then be imported into an application using the linker without having to copy-and-paste files on a module-by-module basis. Applications built during this process can then be loaded onto a device directly, without requiring a GUI-based IDE. As a result, Mark3 integrates well with 3rd party tools for continuous-integration and automated testing.

This modular framework allows for large volumes of libraries and binaries to be built at once - the default build script leverages this to build all of the examples and unit tests at once, linking against the pre-built kernel, services, and drivers. Whatever can be built as a library is built as a library, promoting reuse throughout the platform, and enabling Mark3 to be used as a platform, with an ecosystem of libraries, services, drivers and applications.

7.1 Source Layout

One key aspect of Mark3 is that system features are organized into their own separate modules. These modules are further grouped together into folders based on the type of features represented:

```
Root
            Base folder, contains recursive makefiles for build system
   arduino
               Arduino-specific headers and API documentation files
   bootloader Mark3 Bootloader code for AVR microcontrollers
   build
               Makefiles and device-configuration data for various platforms
               Documentation (including this)
   docs
   drivers
                Device driver code for various supported devices
              Example applications
   example
              Bitmap fonts converted from TTF, used by Mark3 graphics library
   fonts
   kernel
                Basic Mark3 Components (the focus of this manual)
       cpu
                CPU-specific porting code
               Scripts used to simplify build, documentation, and profiling
   scripts
                Utility code and libraries- filesystems, graphics/GUI, etc.
   libs
   stage
                Staging directory, where the build system places artifacts
              Unit tests, written as C/C++ applications
   util
                .net-based utils: font conversion, terminal, programmer, and configuration
```

7.2 Building the kernel

The base mak file determines how the kernel, drivers, and libraries are built, for what targets, and with what options. Most of these options can be copied directly from the options found in your IDE managed projects. Below is an overview of the main variables used to configure the build.

28 Build System

```
ROOT_DIR - The location of the root source tree

ARCH - The CPU architecture to build against

VARIANT - The variant of the above CPU to target

TOOLCHAIN - Which toolchain to build with (dependent on ARCH and VARIANT)
```

Build.mak contains the logic which is used to perform the recursive make in all directories. Unless you really know what you're doing, it's best to leave this as-is.

You must make sure that all required paths are set in your system environment variables so that they are accessible through from the command-line.

Once configured, you can build the source tree using the various make targets:

- · make headers
 - copy all headers in each module's /public subdirectory to the location specified by STAGE environment variable's ./inc subdirectory.
- · make library
 - regenerate all objects copy marked as libraries (i.e. the kernel + drivers). Resulting binaries are copied into STAGE's ./lib subdirectory.
- make binary
 - build all executable projects in the root directory structure. In the default distribution, this includes the basic set of demos.

These steps are chained together automatically as part of the build.sh script found under the /scripts subdirectory. Running ./scripts/build.sh from the root of the embedded source directory will result in all headers being exported, libraries built, and applications built. This script will also default to building for atmega328p using GCC if none of the required environment variables have previously been configured.

To add new components to the recursive build system, simply add your code into a new folder beneath the root install location.

Source files, the module makefile and private header files go directly in the new folder, while public headers are placed in a ./public subdirectory. Create a ./obj directory to hold the output from the builds.

The contents of the module makefile looks something like this:

Once you've placed your code files in the right place, and configured the makefile appropriately, a fresh call to make headers, make library, then make binary will guarantee that your code is built.

Now, you can still copy-and-paste the required kernel, port, and drivers, directly into your application avoiding the whole process of using make from the command line. To do this, run "make source" from the root directory in svn, and copy the contents of /stage/src into your project. This should contain the source to the kernel, all drivers, and all services that are in the tree - along with the necessary header files.

7.3 Building on Windows

Building Mark3 on Windows is the same as on Linux, but there are a few prerequisites that need to be taken into consideration before the build scripts and makefiles will work as expected.

Step 1 - Install Latest Atmel Studio IDE

Atmel Studio contains the AVR8 GCC toolchain, which contains the necessary compilers, assemblers, and platform support required to turn the source modules into libraries and executables.

To get Atmel Studio, go to the Atmel website (http://www.atmel.com) and register to download the latest version. This is a free download (and rather large). The included IDE (if you choose to use it) is very slick, as it's based on Visual Studio, and contains a wonderful cycle-accurate simulator for AVR devices. In fact, the simulator is so good that most of the kernel and its drivers were developed using this tool.

Once you have downloaded and installed Atmel Studio, you will need to add the location of the AVR toolcahin to the PATH environment variable.

To do this, go to Control Panel -> System and Security -> System -> Advanced System Settings, and edit the PATH variable. Append the location of the toolchain bin folder to the end of the variable.

On Windows 7 x64, it should look something like this:

C: Files (x86) Toolchain GCC\Native\3.4.2.1002-gnu-toolchain

Step 2 - Install MinGW and MinSys

MinGW (and MinSys in particular) provide a unix-like environment that runs under windows. Some of the utilities provided include a version of the bash shell, and GNU standard make - both which are required by the Mark3 recursive build system.

The MinGW installer can be downloaded from its project page on SourceForge. When installing, be sure to select the "MinSys" component.

Once installed, add the MinSys binary path to the PATH environment variable, in a similar fashion as with Atmel Studio in Step 1.

Step 3 - Setup Include Paths in Platform Makefile

The AVR header file path must be added to the "platform.mak" makefile for each AVR Target you are attempting to build for. These files can be located under /embedded/build/avr/atmegaXXX/. The path to the includes directory should be added to the end of the CFLAGS and CPPFLAGS variables, as shown in the following:

```
TEST_INC="/c/Program Files (x86)/Atmel/Atmel Toolchain/AVR8 GCC/Native/3.4.2.1002/avr8-gnu-toolchain/include" CFLAGS += -I$ (TEST_INC)
CPPFLAGS += -I$ (TEST_INC)
```

Step 4 - Build Mark3 using Bash

Launch a terminal to your Mark3 base directory, and cd into the "embedded" folder. You should now be able to build Mark3 by running "bash ./build.sh" from the command-line.

Alternately, you can run bash itself, building Mark3 by running ./build.sh or the various make targets using the same synatx as documented previously.

Note - building on Windows is *slow*. This has a lot to do with how "make" performs under windows. There are faster substitutes for make (such as cs-make) that are exponentially quicker, and approach the performance of make on Linux. Other mechanisms, such as running make with multiple concurrent jobs (i.e. "make -j4") also helps significantly, especially on systems with multicore CPUs.

30 **Build System**

License

8.1 License

Copyright (c) 2012-2015, Funkenstein Software Consulting All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. Neither the name of Funkenstein Software Consulting, nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL FUNKENSTEIN SOFTWARE (MARK SLEVINSKY) BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF use, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

32 License

Profiling Results

The following profiling results were obtained using an ATMega328p @ 16MHz.

The test cases are designed to make use of the kernel profiler, which accurately measures the performance of the fundamental system APIs, in order to provide information for user comparison, as well as to ensure that regressions are not being introduced into the system.

9.1 Date Performed

Sat Dec 5 22:15:38 EST 2015

9.2 Compiler Information

The kernel and test code used in these results were built using the following compiler: Using built-in specs. COLLECT_GCC=avr-gcc COLLECT_LTO_WRAPPER=/usr/lib/gcc/avr/4.8.2/lto-wrapper Target: avr Configured with: ../src/configure -v -enable-languages=c,c++ -prefix=/usr/lib -infodir=/usr/share/info -mandir=/usr/share/man -bindir=/usr/bin -libexecdir=/usr/lib -libdir=/usr/lib -enable-shared -with-system-zlib -enable-long-long -enable-nls -without-included-gettext -disable-libssp -build=x86_64-linux-gnu -host=x86_64-linux-gnu -target=avr Thread model: single gcc version 4.8.2 (GCC)

9.3 Profiling Results

- Semaphore Initialization: 40 cycles (averaged over 167 iterations)
- Semaphore Post (uncontested): 111 cycles (averaged over 167 iterations)
- Semaphore Pend (uncontested): 78 cycles (averaged over 167 iterations)
- Semaphore Flyback Time (Contested Pend): 1663 cycles (averaged over 167 iterations)
- Mutex Init: 223 cycles (averaged over 168 iterations)
- Mutex Claim: 239 cycles (averaged over 167 iterations)
- Mutex Release: 143 cycles (averaged over 167 iterations)
- Thread Initialize: 8391 cycles (averaged over 167 iterations)
- Thread Start: 839 cycles (averaged over 167 iterations)
- Context Switch: 183 cycles (averaged over 167 iterations)
- Thread Schedule: 111 cycles (averaged over 167 iterations)

Profiling Results 34

Code Size Profiling

The following report details the size of each module compiled into the kernel.

The size of each component is dependent on the flags specified in mark3cfg.h at compile time. Note that these sizes represent the maximum size of each module before dead code elimination and any additional link-time optimization, and represent the maximum possible size that any module can take.

The results below are for profiling on Atmel AVR atmega328p-based targets using gcc. Results are not necessarily indicative of relative or absolute performance on other platforms or toolchains.

10.1 Information

Subversion Repository Information:

• Repository Root: svn+ssh://m0slevin.code.sf.net/p/mark3/source

· Revision: 263

• URL: svn+ssh://m0slevin.code.sf.net/p/mark3/source/trunk/embedded Relative URL: ^/trunk/embedded

Date Profiled: Sat Dec 5 22:15:40 EST 2015

10.2 Compiler Version

avr-gcc (GCC) 4.8.2 Copyright (C) 2013 Free Software Foundation, Inc. This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

10.3 Profiling Results

Mark3 Module Size Report:

- Allocate-once Heap.....: 0 Bytes
- Synchronization Objects Base Class.....: : 136 Bytes
- Device Driver Framework (including /dev/null)...: 226 Bytes
- Synchronization Object Event Flag.....: 770 Bytes
- Fundamental Kernel Linked-List Classes......: 536 Bytes

36 Code Size Profiling

 Message-based IPC.....: 426 Bytes • Mutex (Synchronization Object).....: : 698 Bytes • Notification Blocking Object.....: : 538 Bytes • Performance-profiling timers.....: 546 Bytes • Round-Robin Scheduling Support.....: 264 Bytes • Thread Scheduling.....: 452 Bytes • Semaphore (Synchronization Object).....: 540 Bytes Mailbox IPC Support.....: : 966 Bytes • Thread Implementation.....: 1611 Bytes • Fundamental Kernel Thread-list Data Structures.. : 308 Bytes Mark3 Kernel Base Class.....: 110 Bytes Software Timer Kernel Object.....: 378 Bytes Software Timer Management.....:: 645 Bytes • Runtime Kernel Trace Implementation.....: 0 Bytes • Atmel AVR - Kernel Aware Simulation Support.....: 250 Bytes • Atmel AVR - Basic Threading Support.....: : 598 Bytes • Atmel AVR - Kernel Interrupt Implemenation......: 56 Bytes • Atmel AVR - Kernel Timer Implementation.....: 322 Bytes • Atmel AVR - Profiling Timer Implementation...... : 256 Bytes

Mark3 Kernel Size Summary:

· Kernel: 3153 Bytes

· Synchronization Objects: 2434 Bytes

Port: 4882 Bytes

· Features: 2059 Bytes

· Total Size: 12528 Bytes

Hierarchical Index

11.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

BlockingObject	45
EventFlag	58
Mutex	82
Semaphore	93
DriverList	56
FakeThread_t	61
GlobalMessagePool	61
Kernel	63
KernelAware	65
KernelAwareData_t	69
KernelSWI	69
KernelTimer	71
LinkList	74
CircularLinkList	46
ThreadList	104
DoubleLinkList	51
TimerList	113
LinkListNode	76
Driver	52
DevNull	
Message	
Thread	_
Timer	
MessageQueue	79
Profiler	84
ProfileTimer	85
Quantum	88
Scheduler	89
	108
	115

38 **Hierarchical Index**

Class Index

12.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

45
46
48
51
52
_,
56
58
61
61
63
65
69
69
71
74
76
78
79

40 Class Index

Mutex		
	Mutual-exclusion locks, based on BlockingObject	82
Profiler	System profiling timer interface	84
ProfileTim		
	Profiling timer	85
Quantum		
	Static-class used to implement Thread quantum functionality, which is a key part of round-robin	
	scheduling	88
Schedule	r	
	Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping	89
Semapho	re	
	Counting semaphore, based on BlockingObject base class	93
Thread		
	Object providing fundamental multitasking support in the kernel	95
ThreadLis	st en	
	This class is used for building thread-management facilities, such as schedulers, and blocking	
	objects	104
ThreadPo	ort in the second of the secon	
	Class defining the architecture specific functions required by the kernel	108
Timer		
	Timer - an event-driven execution context based on a specified time interval	109
TimerList		
	TimerList class - a doubly-linked-list of timer objects	113
TimerSch	eduler	
	"Static" Class used to interface a global TimerList with the rest of the kernel	115

File Index

13.1 File List

Here is a list of all documented files with brief descripti	ions:
---	-------

/nome/vm/mark3/trunk/embedded/kernel/atomic.cpp	
Basic Atomic Operations	117
/home/vm/mark3/trunk/embedded/kernel/autoalloc.cpp	
Automatic memory allocation for kernel objects	119
/home/vm/mark3/trunk/embedded/kernel/blocking.cpp	
Implementation of base class for blocking objects	120
/home/vm/mark3/trunk/embedded/kernel/driver.cpp	
Device driver/hardware abstraction layer	135
/home/vm/mark3/trunk/embedded/kernel/eventflag.cpp	
Event Flag Blocking Object/IPC-Object implementation	137
/home/vm/mark3/trunk/embedded/kernel/kernel.cpp	
Kernel initialization and startup code	142
/home/vm/mark3/trunk/embedded/kernel/kernelaware.cpp	
Kernel aware simulation support	144
/home/vm/mark3/trunk/embedded/kernel/ksemaphore.cpp	
Semaphore Blocking-Object Implemenation	147
/home/vm/mark3/trunk/embedded/kernel/ll.cpp	
Core Linked-List implementation, from which all kernel objects are derived	150
/home/vm/mark3/trunk/embedded/kernel/mailbox.cpp	
Mailbox + Envelope IPC mechanism	153
/home/vm/mark3/trunk/embedded/kernel/message.cpp	
Inter-thread communications via message passing	157
/home/vm/mark3/trunk/embedded/kernel/mutex.cpp	
Mutual-exclusion object	159
/home/vm/mark3/trunk/embedded/kernel/notify.cpp	
5 7	163
/home/vm/mark3/trunk/embedded/kernel/profile.cpp	
1 0	165
/home/vm/mark3/trunk/embedded/kernel/quantum.cpp	
Thread Quantum Implementation for Round-Robin Scheduling	216
/home/vm/mark3/trunk/embedded/kernel/scheduler.cpp	
,	218
/home/vm/mark3/trunk/embedded/kernel/thread.cpp	
Platform-Independent thread class Definition	221
/home/vm/mark3/trunk/embedded/kernel/threadlist.cpp	
	226
/home/vm/mark3/trunk/embedded/kernel/timer.cpp	
Timer implementations	228

42 File Index

/home/vm/mark3/trunk/embedded/kernel/timerlist.cpp	
Implements timer list processing algorithms, responsible for all timer tick and expiry logic	230
/home/vm/mark3/trunk/embedded/kernel/tracebuffer.cpp	
Kernel trace buffer class definition	233
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp	
ATMega328p Profiling timer implementation	121
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp	
Kernel Software interrupt implementation for ATMega328p	123
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp	
Kernel Timer Implementation for ATMega328p	124
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/threadport.cpp	
ATMega328p Multithreading	132
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h	
Profiling timer hardware interface	126
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h	
Kernel Software interrupt declarations	127
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h	
Kernel Timer Class declaration	128
/home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/threadport.h	
ATMega328p Multithreading support	129
/home/vm/mark3/trunk/embedded/kernel/public/atomic.h	
Basic Atomic Operations	167
/home/vm/mark3/trunk/embedded/kernel/public/autoalloc.h	
Automatic memory allocation for kernel objects	168
/home/vm/mark3/trunk/embedded/kernel/public/blocking.h	
Blocking object base class declarations	169
/home/vm/mark3/trunk/embedded/kernel/public/buffalogger.h	
Super-efficient, super-secure logging routines	170
/home/vm/mark3/trunk/embedded/kernel/public/ dbg_file_list.h	??
/home/vm/mark3/trunk/embedded/kernel/public/driver.h	
Driver abstraction framework	171
/home/vm/mark3/trunk/embedded/kernel/public/eventflag.h	
Event Flag Blocking Object/IPC-Object definition	173
/home/vm/mark3/trunk/embedded/kernel/public/kernel.h	
Kernel initialization and startup class	174
/home/vm/mark3/trunk/embedded/kernel/public/kernelaware.h	
Kernel aware simulation support	175
/home/vm/mark3/trunk/embedded/kernel/public/kerneldebug.h	
Macros and functions used for assertions, kernel traces, etc	178
/home/vm/mark3/trunk/embedded/kernel/public/kerneltypes.h	
Basic data type primatives used throughout the OS	181
/home/vm/mark3/trunk/embedded/kernel/public/ksemaphore.h	
Semaphore Blocking Object class declarations	183
/home/vm/mark3/trunk/embedded/kernel/public/II.h	
Core linked-list declarations, used by all kernel list types	184
/home/vm/mark3/trunk/embedded/kernel/public/mailbox.h	
Mailbox + Envelope IPC Mechanism	186
/home/vm/mark3/trunk/embedded/kernel/public/manual.h	
Ascii-format documentation, used by doxygen to create various printable and viewable forms .	188
/home/vm/mark3/trunk/embedded/kernel/public/mark3.h	
Single include file given to users of the Mark3 Kernel API	188
/home/vm/mark3/trunk/embedded/kernel/public/mark3cfg.h	. 50
Mark3 Kernel Configuration	190
/home/vm/mark3/trunk/embedded/kernel/public/message.h	
Inter-thread communication via message-passing	196
/home/vm/mark3/trunk/embedded/kernel/public/mutex.h	
Mutual exclusion class declaration	198

13.1 File List 43

/home/vm/mark3/trunk/embedded/kernel/public/notify.h	
Lightweight thread notification - blocking object	200
/home/vm/mark3/trunk/embedded/kernel/public/paniccodes.h	
Defines the reason codes thrown when a kernel panic occurs	201
/home/vm/mark3/trunk/embedded/kernel/public/profile.h	
High-precision profiling timers	201
/home/vm/mark3/trunk/embedded/kernel/public/ profiling_results.h	??
/home/vm/mark3/trunk/embedded/kernel/public/quantum.h	
Thread Quantum declarations for Round-Robin Scheduling	203
/home/vm/mark3/trunk/embedded/kernel/public/scheduler.h	
Thread scheduler function declarations	204
/home/vm/mark3/trunk/embedded/kernel/public/ sizeprofile.h	??
/home/vm/mark3/trunk/embedded/kernel/public/thread.h	
Platform independent thread class declarations	205
/home/vm/mark3/trunk/embedded/kernel/public/threadlist.h	
Thread linked-list declarations	209
/home/vm/mark3/trunk/embedded/kernel/public/timer.h	
Timer object declarations	210
/home/vm/mark3/trunk/embedded/kernel/public/timerlist.h	
Timer list declarations	213
/home/vm/mark3/trunk/embedded/kernel/public/timerscheduler.h	
Timer scheduler declarations	214
/home/vm/mark3/trunk/embedded/kernel/public/tracebuffer.h	
Kernel trace buffer class declaration	215

44 File Index


Class Documentation

14.1 BlockingObject Class Reference

Class implementing thread-blocking primatives.

#include <blocking.h>

Inheritance diagram for BlockingObject:



Protected Member Functions

- void Block (Thread *pclThread_)
 - Block.
- void BlockPriority (Thread *pclThread_)

BlockPriority.

void UnBlock (Thread *pclThread_)

UnBlock.

Protected Attributes

• ThreadList m_clBlockList

ThreadList which is used to hold the list of threads blocked on a given object.

14.1.1 Detailed Description

Class implementing thread-blocking primatives.

used for implementing things like semaphores, mutexes, message queues, or anything else that could cause a thread to suspend execution on some external stimulus.

Definition at line 65 of file blocking.h.

46 Class Documentation

14.1.2 Member Function Documentation

14.1.2.1 void BlockingObject::Block (Thread * pclThread_) [protected]

Block.

Blocks a thread on this object. This is the fundamental operation performed by any sort of blocking operation in the operating system. All semaphores/mutexes/sleeping/messaging/etc ends up going through the blocking code at some point as part of the code that manages a transition from an "active" or "waiting" thread to a "blocked" thread.

The steps involved in blocking a thread (which are performed in the function itself) are as follows;

1) Remove the specified thread from the current owner's list (which is likely one of the scheduler's thread lists) 2) Add the thread to this object's thread list 3) Setting the thread's "current thread-list" point to reference this object's threadlist.

Parameters

pclThread_	Pointer to the thread object that will be blocked.

Definition at line 41 of file blocking.cpp.

14.1.2.2 void BlockingObject::BlockPriority (Thread * *pclThread_*) [protected]

BlockPriority.

Same as Block(), but ensures that threads are added to the block-list in priority-order, which optimizes the unblock procedure.

Parameters

```
pclThread_ Pointer to the Thread to Block.
```

Definition at line 57 of file blocking.cpp.

14.1.2.3 void BlockingObject::UnBlock (Thread * pclThread_) [protected]

UnBlock.

Unblock a thread that is already blocked on this object, returning it to the "ready" state by performing the following steps:

Parameters

pclThread_ Pointer to the thread to unblock.

1) Removing the thread from this object's threadlist 2) Restoring the thread to its "original" owner's list

Definition at line 73 of file blocking.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/blocking.h
- /home/vm/mark3/trunk/embedded/kernel/blocking.cpp

14.2 CircularLinkList Class Reference

Circular-linked-list data type, inherited from the base LinkList type.

#include <ll.h>

Inheritance diagram for CircularLinkList:



Public Member Functions

virtual void Add (LinkListNode *node_)

Add the linked list node to this linked list.

virtual void Remove (LinkListNode *node_)

Remove

void PivotForward ()

PivotForward.

• void PivotBackward ()

PivotBackward.

void InsertNodeBefore (LinkListNode *node_, LinkListNode *insert_)

InsertNodeBefore.

Additional Inherited Members

14.2.1 Detailed Description

Circular-linked-list data type, inherited from the base LinkList type.

Definition at line 201 of file II.h.

14.2.2 Member Function Documentation

14.2.2.1 void CircularLinkList::Add (LinkListNode * node_) [virtual]

Add the linked list node to this linked list.

Parameters

node_ Pointer to the node to add

Implements LinkList.

Reimplemented in ThreadList.

Definition at line 108 of file II.cpp.

14.2.2.2 void CircularLinkList::InsertNodeBefore (LinkListNode * node_, LinkListNode * insert_)

InsertNodeBefore.

Insert a linked-list node into the list before the specified insertion point.

48 Class Documentation

Parameters

node_	Node to insert into the list
insert_	Insert point.

Definition at line 191 of file II.cpp.

14.2.2.3 void CircularLinkList::PivotBackward ()

PivotBackward.

Pivot the head of the circularly linked list backward (Head = Head->prev, Tail = Tail->prev)

Definition at line 181 of file II.cpp.

14.2.2.4 void CircularLinkList::PivotForward ()

PivotForward.

Pivot the head of the circularly linked list forward (Head = Head->next, Tail = Tail->next)

Definition at line 171 of file II.cpp.

14.2.2.5 void CircularLinkList::Remove(LinkListNode * node_) [virtual]

Remove.

Add the linked list node to this linked list

Parameters

node_ Pointer to the node to remove

Implements LinkList.

Reimplemented in ThreadList.

Definition at line 133 of file II.cpp.


The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/ll.h
- /home/vm/mark3/trunk/embedded/kernel/ll.cpp

14.3 DevNull Class Reference

This class implements the "default" driver (/dev/null)

Inheritance diagram for DevNull:



Public Member Functions

```
· virtual void Init ()
```

Init.

virtual uint8 t Open ()

Open.

• virtual uint8_t Close ()

Close

virtual uint16_t Read (uint16_t u16Bytes_, uint8_t *pu8Data_)

Read

• virtual uint16_t Write (uint16_t u16Bytes_, uint8_t *pu8Data_)

Write

virtual uint16_t Control (uint16_t u16Event_, void *pvDataln_, uint16_t u16Sizeln_, void *pvDataOut_

 , uint16_t u16SizeOut)

Control.

Additional Inherited Members

14.3.1 Detailed Description

This class implements the "default" driver (/dev/null)

Definition at line 46 of file driver.cpp.

14.3.2 Member Function Documentation

```
14.3.2.1 virtual uint8_t DevNull::Close( ) [inline], [virtual]
```

Close.

Close a previously-opened device driver.

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 51 of file driver.cpp.

```
14.3.2.2 virtual uint16_t DevNull::Control ( uint16_t u16Event_, void * pvDataIn_, uint16_t u16SizeIn_, void * pvDataOut_, uint16_t u16SizeOut_ ) [inline], [virtual]
```

Control.

This is the main entry-point for device-specific io and control operations. This is used for implementing all "side-channel" communications with a device, and any device-specific IO operations that do not conform to the typical POSIX read/write paradigm. use of this funciton is analagous to the non-POSIX (yet still common) devctl() or ioctl().

Parameters

```
u16Event | Code defining the io event (driver-specific)
```

50 Class Documentation

pvDataIn_	Pointer to the intput data
u16SizeIn_	Size of the input data (in bytes)
pvDataOut_	Pointer to the output data
u16SizeOut_	Size of the output data (in bytes)

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 59 of file driver.cpp.

```
14.3.2.3 virtual void DevNull::Init() [inline], [virtual]
```

Init.

Initialize a driver, must be called prior to use

Implements Driver.

Definition at line 49 of file driver.cpp.

```
14.3.2.4 virtual uint8_t DevNull::Open() [inline], [virtual]
```

Open.

Open a device driver prior to use.

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implements Driver.

Definition at line 50 of file driver.cpp.

```
14.3.2.5 virtual uint16_t DevNull::Read ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [inline], [virtual]
```

Read.

Read a specified number of bytes from the device into a specific buffer. Depending on the driver-specific implementation, this may be a number less than the requested number of bytes read, indicating that there there was less input than desired, or that as a result of buffering, the data may not be available.

Parameters

u16Bytes_	Number of bytes to read (<= size of the buffer)
pu8Data_	Pointer to a data buffer receiving the read data

Returns

Number of bytes actually read

Implements Driver.

Definition at line 53 of file driver.cpp.

14.3.2.6 virtual uint16_t DevNull::Write (uint16_t u16Bytes_, uint8_t * pu8Data_) [inline], [virtual]

Write.

Write a payload of data of a given length to the device. Depending on the implementation of the driver, the amount of data written to the device may be less than the requested number of bytes. A result less than the requested size may indicate that the device buffer is full, indicating that the user must retry the write at a later point with the remaining data.

Parameters

u16Bytes_	Number of bytes to write (<= size of the buffer)
pu8Data_	Pointer to a data buffer containing the data to write

Returns

Number of bytes actually written

Implements Driver.

Definition at line 56 of file driver.cpp.

The documentation for this class was generated from the following file:


/home/vm/mark3/trunk/embedded/kernel/driver.cpp

14.4 DoubleLinkList Class Reference

Doubly-linked-list data type, inherited from the base LinkList type.

#include <11.h>

Inheritance diagram for DoubleLinkList:



Public Member Functions

• DoubleLinkList ()

DoubleLinkList.

virtual void Add (LinkListNode *node_)

Add

virtual void Remove (LinkListNode *node_)

Remove.

Additional Inherited Members

14.4.1 Detailed Description

Doubly-linked-list data type, inherited from the base LinkList type.

Definition at line 168 of file II.h.

52 Class Documentation

14.4.2 Constructor & Destructor Documentation

14.4.2.1 DoubleLinkList::DoubleLinkList() [inline]

DoubleLinkList.

Default constructor - initializes the head/tail nodes to NULL

Definition at line 176 of file II.h.

14.4.3 Member Function Documentation

14.4.3.1 void DoubleLinkList::Add (LinkListNode * node_) [virtual]

Add.

Add the linked list node to this linked list

Parameters

node Pointer to the node to add

Implements LinkList.

Definition at line 47 of file II.cpp.

14.4.3.2 void DoubleLinkList::Remove(LinkListNode * node_) [virtual]

Remove.

Add the linked list node to this linked list

Parameters

node Pointer to the node to remove

Implements LinkList.

Definition at line 71 of file II.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/ll.h
- /home/vm/mark3/trunk/embedded/kernel/II.cpp

14.5 Driver Class Reference

Base device-driver class used in hardware abstraction.

#include <driver.h>

Inheritance diagram for Driver:



14.5 Driver Class Reference 53

Public Member Functions

```
• virtual void Init ()=0
```

Init.

• virtual uint8 t Open ()=0

Open.

• virtual uint8 t Close ()=0

Close.

• virtual uint16_t Read (uint16_t u16Bytes_, uint8_t *pu8Data_)=0

Read

• virtual uint16_t Write (uint16_t u16Bytes_, uint8_t *pu8Data_)=0

Write.

virtual uint16_t Control (uint16_t u16Event_, void *pvDataIn_, uint16_t u16SizeIn_, void *pvDataOut_

 , uint16_t u16SizeOut_)=0

Control.

void SetName (const char *pcName)

SetName.

const char * GetPath ()

GetPath.

Private Attributes

• const char * m_pcPath

string pointer that holds the driver path (name)

Additional Inherited Members

14.5.1 Detailed Description

Base device-driver class used in hardware abstraction.

All other device drivers inherit from this class

Definition at line 121 of file driver.h.

14.5.2 Member Function Documentation

```
14.5.2.1 virtual uint8_t Driver::Close( ) [pure virtual]
```

Close.

Close a previously-opened device driver.

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

54 Class Documentation

14.5.2.2 virtual uint16_t Driver::Control (uint16_t u16Event_, void * pvDataln_, uint16_t u16Sizeln_, void * pvDataOut_, uint16_t u16SizeOut_) [pure virtual]

Control.

This is the main entry-point for device-specific io and control operations. This is used for implementing all "side-channel" communications with a device, and any device-specific IO operations that do not conform to the typical POSIX read/write paradigm. use of this funciton is analagous to the non-POSIX (yet still common) devctl() or ioctl().

Parameters

u16Event_	Code defining the io event (driver-specific)
pvDataIn_	Pointer to the intput data
u16SizeIn_	Size of the input data (in bytes)
pvDataOut_	Pointer to the output data
u16SizeOut_	Size of the output data (in bytes)

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

```
14.5.2.3 const char* Driver::GetPath() [inline]
```

GetPath.

Returns a string containing the device path.

Returns

pcName_ Return the string constant representing the device path

Definition at line 225 of file driver.h.

```
14.5.2.4 virtual void Driver::Init() [pure virtual]
```

Init.

Initialize a driver, must be called prior to use

Implemented in DevNull.

```
14.5.2.5 virtual uint8_t Driver::Open() [pure virtual]
```

Open.

Open a device driver prior to use.

Returns

Driver-specific return code, 0 = OK, non-0 = error

Implemented in DevNull.

```
14.5.2.6 virtual uint16_t Driver::Read ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [pure virtual]
```

Read.

Read a specified number of bytes from the device into a specific buffer. Depending on the driver-specific implementation, this may be a number less than the requested number of bytes read, indicating that there there was less input than desired, or that as a result of buffering, the data may not be available.

Parameters

u16Bytes_	Number of bytes to read (<= size of the buffer)
pu8Data_	Pointer to a data buffer receiving the read data

Returns

Number of bytes actually read

Implemented in DevNull.

```
14.5.2.7 void Driver::SetName ( const char * pcName_ ) [inline]
```

SetName.

Set the path for the driver. Name must be set prior to access (since driver access is name-based).

Parameters

pcName_	String constant containing the device path
---------	--

Definition at line 216 of file driver.h.

```
14.5.2.8 virtual uint16_t Driver::Write ( uint16_t u16Bytes_, uint8_t * pu8Data_ ) [pure virtual]
```

Write.

Write a payload of data of a given length to the device. Depending on the implementation of the driver, the amount of data written to the device may be less than the requested number of bytes. A result less than the requested size may indicate that the device buffer is full, indicating that the user must retry the write at a later point with the remaining data.

Parameters

u16Bytes_	Number of bytes to write (<= size of the buffer)
pu8Data_	Pointer to a data buffer containing the data to write

Returns

Number of bytes actually written

Implemented in DevNull.

The documentation for this class was generated from the following file:

• /home/vm/mark3/trunk/embedded/kernel/public/driver.h

14.6 DriverList Class Reference

List of Driver objects used to keep track of all device drivers in the system.

```
#include <driver.h>
```

Static Public Member Functions

· static void Init ()

Init

static void Add (Driver *pclDriver_)

Add.

static void Remove (Driver *pclDriver_)

Remove

static Driver * FindByPath (const char *m_pcPath)
 FindByPath.

Static Private Attributes

• static DoubleLinkList m_clDriverList

LinkedList object used to implementing the driver object management.

14.6.1 Detailed Description

List of Driver objects used to keep track of all device drivers in the system.

By default, the list contains a single entity, "/dev/null".

Definition at line 238 of file driver.h.

14.6.2 Member Function Documentation

```
14.6.2.1 static void DriverList::Add ( Driver * pclDriver_ ) [inline], [static]
```

Add.

Add a Driver object to the managed global driver-list.

Parameters

```
pclDriver_ pointer to the driver object to add to the global driver list.
```

Definition at line 258 of file driver.h.

```
14.6.2.2 Driver * DriverList::FindByPath ( const char * m_pcPath ) [static]
```

FindByPath.

Look-up a driver in the global driver-list based on its path. In the event that the driver is not found in the list, a pointer to the default "/dev/null" object is returned. In this way, unimplemented drivers are automatically stubbed out.

Definition at line 113 of file driver.cpp.

```
14.6.2.3 void DriverList::Init( ) [static]
```

Init.

Initialize the list of drivers. Must be called prior to using the device driver library.

Definition at line 104 of file driver.cpp.

```
14.6.2.4 static void DriverList::Remove ( Driver * pclDriver_ ) [inline], [static]
```

Remove.

Remove a driver from the global driver list.

Parameters

pclDriver_ Pointer to the driver object to remove from the global table

Definition at line 268 of file driver.h.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/driver.h
- /home/vm/mark3/trunk/embedded/kernel/driver.cpp

14.7 EventFlag Class Reference

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

```
#include <eventflag.h>
```

Inheritance diagram for EventFlag:



Public Member Functions

• void Init ()

Init Initializes the EventFlag object prior to use.

uint16_t Wait (uint16_t u16Mask_, EventFlagOperation_t eMode_)

Wait - Block a thread on the specific flags in this event flag group.

uint16_t Wait (uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS_)

Wait - Block a thread on the specific flags in this event flag group.

void WakeMe (Thread *pclOwner_)

WakeMe.

void Set (uint16_t u16Mask_)

Set - Set additional flags in this object (logical OR).

void Clear (uint16_t u16Mask_)

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

uint16_t GetMask ()

GetMask Returns the state of the 16-bit bitmask within this object.

Private Member Functions

uint16_t Wait_i (uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS_)
 Wait i.

Private Attributes

• uint16_t m_u16SetMask

Event flags currently set in this object.

Additional Inherited Members

14.7.1 Detailed Description

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

Each EventFlag object contains a 16-bit bitmask, which is used to trigger events on associated threads. Threads wishing to block, waiting for a specific event to occur can wait on any pattern within this 16-bit bitmask to be set. Here, we provide the ability for a thread to block, waiting for ANY bits in a specified mask to be set, or for ALL bits within a specific mask to be set. Depending on how the object is configured, the bits that triggered the wakeup can be automatically cleared once a match has occurred.

Definition at line 46 of file eventflag.h.

14.7.2 Member Function Documentation

```
14.7.2.1 void EventFlag::Clear ( uint16_t u16Mask_ )
```

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

Parameters

```
u16Mask_ - Bitmask of flags to clear
```

Definition at line 306 of file eventflag.cpp.

```
14.7.2.2 uint16_t EventFlag::GetMask()
```

GetMask Returns the state of the 16-bit bitmask within this object.

Returns

The state of the 16-bit bitmask

Definition at line 315 of file eventflag.cpp.

```
14.7.2.3 void EventFlag::Set ( uint16_t u16Mask_ )
```

Set - Set additional flags in this object (logical OR).

This API can potentially result in threads blocked on Wait() to be unblocked.

Parameters

```
u16Mask_ - Bitmask of flags to set.
```

Definition at line 187 of file eventflag.cpp.

```
14.7.2.4 uint16_t EventFlag::Wait ( uint16_t u16Mask_, EventFlagOperation_t eMode_ )
```

Wait - Block a thread on the specific flags in this event flag group.

Parameters

```
u16Mask_ - 16-bit bitmask to block on
```

eMode_	- EVENT_FLAG_ANY: Thread will block on any of the bits in the mask
	EVENT_FLAG_ALL: Thread will block on all of the bits in the mask

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

Definition at line 169 of file eventflag.cpp.

14.7.2.5 uint16_t EventFlag::Wait (uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS_)

Wait - Block a thread on the specific flags in this event flag group.

Parameters

u16Mask_	- 16-bit bitmask to block on
eMode_	- EVENT_FLAG_ANY: Thread will block on any of the bits in the mask
	EVENT_FLAG_ALL: Thread will block on all of the bits in the mask
u32TimeMS_	- Time to block (in ms)

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

Definition at line 180 of file eventflag.cpp.

```
14.7.2.6 uint16_t EventFlag::Wait_i ( uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t u32TimeMS_ )

[private]
```

Wait i.

Interal abstraction used to manage both timed and untimed wait operations

Parameters

u16Mask_	- 16-bit bitmask to block on
eMode_	- EVENT_FLAG_ANY: Thread will block on any of the bits in the mask
	EVENT_FLAG_ALL: Thread will block on all of the bits in the mask
u32TimeMS_	- Time to block (in ms)

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

! If the Yield operation causes a new thread to be chosen, there will! Be a context switch at the above CS_EXIT(). The original calling! thread will not return back until a matching SetFlags call is made! or a timeout occurs.

Definition at line 76 of file eventflag.cpp.

14.7.2.7 void EventFlag::WakeMe (Thread * pclOwner_)

WakeMe.

Wake the given thread, currently blocking on this object

Parameters

pclOwner_ Pointer to the owner thread to unblock.

Definition at line 68 of file eventflag.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/eventflag.h
- /home/vm/mark3/trunk/embedded/kernel/eventflag.cpp

14.8 FakeThread t Struct Reference

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

```
#include <thread.h>
```

Public Attributes

K_WORD * m_pwStackTop

Pointer to the top of the thread's stack.

K WORD * m pwStack

Pointer to the thread's stack.

· uint8 t m u8ThreadID

Thread ID.

uint8_t m_u8Priority

Default priority of the thread.

• uint8_t m_u8CurPriority

Current priority of the thread (priority inheritence)

ThreadState_t m_eState

Enum indicating the thread's current state.

14.8.1 Detailed Description

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

When cast to a Thread, this data structure will still result in GetPriority() calls being valid, which is all that is needed to support the tick-based/tickless times – while saving a fairly decent chunk of RAM on a small micro.

Note that this struct must have the same memory layout as the Thread class up to the last item.

Definition at line 516 of file thread.h.

The documentation for this struct was generated from the following file:

/home/vm/mark3/trunk/embedded/kernel/public/thread.h

14.9 GlobalMessagePool Class Reference

Implements a list of message objects shared between all threads.

```
#include <message.h>
```

Static Public Member Functions

```
    static void Init ()
        Init.
    static void Push (Message *pclMessage_)
        Push.
    static Message * Pop ()
```

Static Private Attributes

Pop.

• static Message m_aclMessagePool [GLOBAL_MESSAGE_POOL_SIZE]

Array of message objects that make up the message pool.

• static DoubleLinkList m_clList

Linked list used to manage the Message objects.

14.9.1 Detailed Description

Implements a list of message objects shared between all threads.

Definition at line 157 of file message.h.

14.9.2 Member Function Documentation

```
14.9.2.1 void GlobalMessagePool::Init(void) [static]
```

Init.

Initialize the message queue prior to use

Definition at line 50 of file message.cpp.

```
14.9.2.2 Message * GlobalMessagePool::Pop() [static]
```

Pop.

Pop a message from the global queue, returning it to the user to be popu32ated before sending by a transmitter.

Returns

Pointer to a Message object

Definition at line 74 of file message.cpp.

```
14.9.2.3 void GlobalMessagePool::Push ( Message * pclMessage_ ) [static]
```

Push.

Return a previously-claimed message object back to the global queue. used once the message has been processed by a receiver.

Parameters

pclMessage_ Pointer to the Message object to return back to the global queue

Definition at line 62 of file message.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/message.h
- /home/vm/mark3/trunk/embedded/kernel/message.cpp

14.10 Kernel Class Reference

Class that encapsulates all of the kernel startup functions.

```
#include <kernel.h>
```

Static Public Member Functions

· static void Init (void)

Kernel Initialization Function, call before any other OS function.

static void Start (void)

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

• static bool IsStarted ()

IsStarted.

static void SetPanic (panic_func_t pfPanic_)

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

• static bool IsPanic ()

IsPanic Returns whether or not the kernel is in a panic state.

• static void Panic (uint16 t u16Cause)

Panic Cause the kernel to enter its panic state.

static void SetIdleFunc (idle_func_t pfIdle_)

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

static void IdleFunc (void)

IdleFunc Call the low-priority idle function when no active threads are available to be scheduled.

static Thread * GetIdleThread (void)

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

Static Private Attributes

• static bool m blsStarted

true if kernel is running, false otherwise

• static bool m blsPanic

true if kernel is in panic state, false otherwise

static panic_func_t m_pfPanic

set panic function

• static idle_func_t m_pfldle

set idle function

static FakeThread_t m_clldle

Idle thread object (note: not a real thread)

14.10.1 Detailed Description

Class that encapsulates all of the kernel startup functions.

Definition at line 48 of file kernel.h.

14.10.2 Member Function Documentation

```
14.10.2.1 static Thread* Kernel::GetIdleThread(void) [inline], [static]
```

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

Note that the Thread object involved is to be used for comparisons only – the thread itself is "virtual", and doesn't represent a unique execution context with its own stack.

Returns

Pointer to the Kernel's idle thread object

Definition at line 125 of file kernel.h.

```
14.10.2.2 void Kernel::Init(void) [static]
```

Kernel Initialization Function, call before any other OS function.

Initializes all global resources used by the operating system. This must be called before any other kernel function is invoked.

Definition at line 57 of file kernel.cpp.

```
14.10.2.3 static bool Kernel::IsPanic() [inline], [static]
```

IsPanic Returns whether or not the kernel is in a panic state.

Returns

Whether or not the kernel is in a panic state

Definition at line 96 of file kernel.h.

```
14.10.2.4 static bool Kernel::IsStarted() [inline], [static]
```

IsStarted.

Returns

Whether or not the kernel has started - true = running, false = not started

Definition at line 81 of file kernel.h.

```
14.10.2.5 void Kernel::Panic ( uint16_t u16Cause_ ) [static]
```

Panic Cause the kernel to enter its panic state.

Parameters

u16Cause_ Reason for the kernel panic

Definition at line 102 of file kernel.cpp.

14.10.2.6 static void Kernel::SetIdleFunc (idle_func_t pfldle_) [inline], [static]

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

Parameters

pfldle_ Pointer to the idle function

Definition at line 110 of file kernel.h.

14.10.2.7 static void Kernel::SetPanic (panic_func_t pfPanic_) [inline], [static]

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

Parameters

pfPanic_ Panic function pointer

Definition at line 90 of file kernel.h.

14.10.2.8 void Kernel::Start (void) [static]

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

You must have at least one thread added to the kernel before calling this function, otherwise the behavior is undefined. The exception to this is if the system is configured to use the threadless idle hook, in which case the kernel is allowed to run without any ready threads.

Definition at line 93 of file kernel.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/kernel.h
- /home/vm/mark3/trunk/embedded/kernel/kernel.cpp

14.11 KernelAware Class Reference

The KernelAware class.

#include <kernelaware.h>

Static Public Member Functions

• static void ProfileInit (const char *szStr)

ProfileInit.

static void ProfileStart (void)

ProfileStart.

static void ProfileStop (void)

ProfileStop.

• static void ProfileReport (void)

ProfileReport.

static void ExitSimulator (void)

ExitSimulator.

static void Print (const char *szStr)

Print

static void Trace (uint16_t u16File_, uint16_t u16Line_)

Trace

• static void Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)

Trace

• static void Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_)

Trace

static bool IsSimulatorAware (void)

IsSimulatorAware.

Static Private Member Functions

14.11.1 Detailed Description

The KernelAware class.

This class contains functions that are used to trigger kernel-aware functionality within a supported simulation environment (i.e. flAVR).

These static methods operate on a singleton set of global variables, which are monitored for changes from within the simulator. The simulator hooks into these variables by looking for the correctly-named symbols in an elf-formatted binary being run and registering callbacks that are called whenever the variables are changed. On each change of the command variable, the kernel-aware data is analyzed and interpreted appropriately.

If these methods are run in an unsupported simulator or on actual hardware the commands generally have no effect (except for the exit-on-reset command, which will result in a jump-to-0 reset).

Definition at line 65 of file kernelaware.h.

14.11.2 Member Function Documentation

```
14.11.2.1 void KernelAware::ExitSimulator(void) [static]
```

ExitSimulator.

Instruct the kernel-aware simulator to terminate (destroying the virtual CPU).

Definition at line 114 of file kernelaware.cpp.

```
14.11.2.2 bool KernelAware::lsSimulatorAware(void) [static]
```

IsSimulatorAware.

use this function to determine whether or not the code is running on a simulator that is aware of the kernel.

Returns

true - the application is being run in a kernel-aware simulator. false - otherwise.

Definition at line 169 of file kernelaware.cpp.

14.11.2.3 void KernelAware::Print (const char * szStr_) [static]

Print.

Instruct the kernel-aware simulator to print a char string

Parameters

```
szStr
```

Definition at line 160 of file kernelaware.cpp.

```
14.11.2.4 void KernelAware::ProfileInit (const char * szStr_) [static]
```

ProfileInit.

Initializes the kernel-aware profiler. This function instructs the kernel-aware simulator to reset its accounting variables, and prepare to start counting profiling data tagged to the given string. How this is handled is the responsibility of the simulator.

Parameters

```
szStr_ String to use as a tag for the profiling session.
```

Definition at line 87 of file kernelaware.cpp.

```
14.11.2.5 void KernelAware::ProfileReport (void ) [static]
```

ProfileReport.

Instruct the kernel-aware simulator to print a report for its current profiling data.

Definition at line 108 of file kernelaware.cpp.

```
14.11.2.6 void KernelAware::ProfileStart(void) [static]
```

ProfileStart.

Instruct the kernel-aware simulator to begin counting cycles towards the current profiling counter.

Definition at line 96 of file kernelaware.cpp.

```
14.11.2.7 void KernelAware::ProfileStop (void ) [static]
```

ProfileStop.

Instruct the kernel-aware simulator to end counting cycles relative to the current profiling counter's iteration.

Definition at line 102 of file kernelaware.cpp.

```
14.11.2.8 void KernelAware::Trace ( uint16_t u16File_, uint16_t u16Line_ ) [static]
```

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16File_	16-bit code representing the file
u16Line_	16-bit code representing the line in the file

Definition at line 120 of file kernelaware.cpp.

14.11.2.9 void KernelAware::Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_) [static]

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16File_	16-bit code representing the file
u16Line_	16-bit code representing the line in the file
u16Arg1_	16-bit argument to the format string.

Definition at line 127 of file kernelaware.cpp.

```
14.11.2.10 void KernelAware::Trace ( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_ ) [static]
```

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16File_	16-bit code representing the file
u16Line_	16-bit code representing the line in the file
u16Arg1_	16-bit argument to the format string.
u16Arg2_	16-bit argument to the format string.

Definition at line 135 of file kernelaware.cpp.

```
14.11.2.11 void KernelAware::Trace_i ( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_, KernelAwareCommand_t eCmd_) [static], [private]
```

Trace_i.

Private function by which the class's Trace() methods are reflected, which allows u16 to realize a modest code saving.

Parameters

u16File_	16-bit code representing the file
u16Line_	16-bit code representing the line in the file
u16Arg1_	16-bit argument to the format string.
u16Arg2_	16-bit argument to the format string.
eCmd_	Code indicating the number of arguments to emit.

Definition at line 144 of file kernelaware.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/kernelaware.h
- /home/vm/mark3/trunk/embedded/kernel/kernelaware.cpp

14.12 KernelAwareData_t Union Reference

This structure is used to communicate between the kernel and a kernel- aware host.

Public Attributes

• volatile uint16_t au16Buffer [5]

Raw binary contents of the struct.

The Profiler struct contains data related to the code-execution profiling functionality provided by a kernel-aware host simluator.

The Trace struct contains data related to the display and output of kernel-trace strings on a kernel-aware host.

The Print struct contains data related to the display of arbitrary null-terminated ASCII strings on the kernel-aware host.

14.12.1 Detailed Description

This structure is used to communicate between the kernel and a kernel- aware host.

Its data contents is interpreted differently depending on the command executed (by means of setting the g_u8KA \leftarrow Command variable, as is done in the command handlers in this module). As a result, any changes to this struct by way of modifying or adding data must be mirrored in the kernel-aware simulator.

Definition at line 48 of file kernelaware.cpp.

The documentation for this union was generated from the following file:

/home/vm/mark3/trunk/embedded/kernel/kernelaware.cpp

14.13 KernelSWI Class Reference

Class providing the software-interrupt required for context-switching in the kernel.

```
#include <kernelswi.h>
```

Static Public Member Functions

• static void Config (void)

Config.

static void Start (void)

Start.

• static void Stop (void)

Ston

• static void Clear (void)

Clear

• static void Trigger (void)

Trigger.

```
    static uint8_t DI ()
        DI.
    static void RI (bool bEnable_)
        BI
```

14.13.1 Detailed Description

Class providing the software-interrupt required for context-switching in the kernel.

Definition at line 32 of file kernelswi.h.

14.13.2 Member Function Documentation

```
14.13.2.1 void KernelSWI::Clear (void ) [static]
```

Clear.

Clear the software interrupt

Definition at line 71 of file kernelswi.cpp.

```
14.13.2.2 void KernelSWI::Config (void ) [static]
```

Config.

Configure the software interrupt - must be called before any other software interrupt functions are called.

Definition at line 29 of file kernelswi.cpp.

```
14.13.2.3 uint8_t KernelSWI::DI() [static]
```

DI.

Disable the SWI flag itself

Returns

previous status of the SWI, prior to the DI call

Definition at line 50 of file kernelswi.cpp.

```
14.13.2.4 void KernelSWI::RI ( bool bEnable_ ) [static]
```

RI.

Restore the state of the SWI to the value specified

Parameters

```
bEnable_ true - enable the SWI, false - disable SWI
```

Definition at line 58 of file kernelswi.cpp.

```
14.13.2.5 void KernelSWI::Start (void ) [static]
```

Start

Enable ("Start") the software interrupt functionality

Definition at line 37 of file kernelswi.cpp.

```
14.13.2.6 void KernelSWI::Stop (void ) [static]

Stop.

Disable the software interrupt functionality

Definition at line 44 of file kernelswi.cpp.

14.13.2.7 void KernelSWI::Trigger (void ) [static]

Trigger.
```

Call the software interrupt

Definition at line 77 of file kernelswi.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h
- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp

14.14 KernelTimer Class Reference

Hardware timer interface, used by all scheduling/timer subsystems.

```
#include <kerneltimer.h>
```

Static Public Member Functions

```
· static void Config (void)
      Config.

    static void Start (void)

      Start.
• static void Stop (void)
      Stop.

    static uint8_t DI (void)

    static void RI (bool bEnable_)

      RI.
• static void El (void)

    static uint32_t SubtractExpiry (uint32_t u32Interval_)

      SubtractExpiry.

    static uint32_t TimeToExpiry (void)

      TimeToExpiry.

    static uint32_t SetExpiry (uint32_t u32Interval_)

      SetExpiry.

    static uint32_t GetOvertime (void)

      GetOvertime.

    static void ClearExpiry (void)
```

ClearExpiry.

Static Private Member Functions

```
    static uint16_t Read (void)
    Read.
```

14.14.1 Detailed Description

Hardware timer interface, used by all scheduling/timer subsystems.

Definition at line 33 of file kerneltimer.h.

14.14.2 Member Function Documentation

```
14.14.2.1 void KernelTimer::ClearExpiry(void) [static]
```

ClearExpiry.

Clear the hardware timer expiry register

Definition at line 142 of file kerneltimer.cpp.

```
14.14.2.2 void KernelTimer::Config (void ) [static]
```

Config.

Initializes the kernel timer before use

Definition at line 33 of file kerneltimer.cpp.

```
14.14.2.3 uint8_t KernelTimer::Dl( void ) [static]
```

DI.

Disable the kernel timer's expiry interrupt

Definition at line 150 of file kerneltimer.cpp.

```
14.14.2.4 void KernelTimer::El ( void ) [static]
```

EI.

Enable the kernel timer's expiry interrupt

Definition at line 163 of file kerneltimer.cpp.

```
14.14.2.5 uint32_t KernelTimer::GetOvertime(void) [static]
```

GetOvertime.

Return the number of ticks that have elapsed since the last expiry.

Returns

Number of ticks that have elapsed after last timer expiration

Definition at line 115 of file kerneltimer.cpp.

14.14.2.6 uint16_t KernelTimer::Read (void) [static], [private]

Read.

Safely read the current value in the timer register

Returns

Value held in the timer register

Definition at line 66 of file kerneltimer.cpp.

```
14.14.2.7 void KernelTimer::RI(bool bEnable_) [static]
```

RI.

Retstore the state of the kernel timer's expiry interrupt.

Parameters

```
bEnable_ 1 enable, 0 disable
```

Definition at line 169 of file kerneltimer.cpp.

```
14.14.2.8 uint32_t KernelTimer::SetExpiry ( uint32_t u32Interval_ ) [static]
```

SetExpiry.

Resets the kernel timer's expiry interval to the specified value

Parameters

```
u32Interval_ Desired interval in ticks to set the timer for
```

Returns

Actual number of ticks set (may be less than desired)

Definition at line 121 of file kerneltimer.cpp.

```
14.14.2.9 void KernelTimer::Start (void ) [static]
```

Start.

Starts the kernel time (must be configured first)

Definition at line 39 of file kerneltimer.cpp.

```
14.14.2.10 void KernelTimer::Stop (void ) [static]
```

Stop.

Shut down the kernel timer, used when no timers are scheduled

Definition at line 54 of file kerneltimer.cpp.

```
14.14.2.11 uint32_t KernelTimer::SubtractExpiry ( uint32_t u32Interval_ ) [static]
```

SubtractExpiry.

Subtract the specified number of ticks from the timer's expiry count register. Returns the new expiry value stored in the register.

Parameters

u32Interval_	Time (in HW-specific) ticks to subtract

Returns

Value in ticks stored in the timer's expiry register

Definition at line 84 of file kerneltimer.cpp.

```
14.14.2.12 uint32_t KernelTimer::TimeToExpiry( void ) [static]
```

TimeToExpiry.

Returns the number of ticks remaining before the next timer expiry.

Returns

Time before next expiry in platform-specific ticks

Definition at line 95 of file kerneltimer.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h
- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp

14.15 LinkList Class Reference

Abstract-data-type from which all other linked-lists are derived.

```
#include <11.h>
```

Inheritance diagram for LinkList:



Public Member Functions

• void Init ()

Init.

virtual void Add (LinkListNode *node_)=0

Add

• virtual void Remove (LinkListNode *node_)=0

Remove

LinkListNode * GetHead ()

GetHead.

LinkListNode * GetTail ()

GetTail.

Protected Attributes

LinkListNode * m_pstHead

Pointer to the head node in the list.

LinkListNode * m_pstTail

Pointer to the tail node in the list.

14.15.1 Detailed Description

Abstract-data-type from which all other linked-lists are derived.

Definition at line 113 of file II.h.

14.15.2 Member Function Documentation

```
14.15.2.1 virtual void LinkList::Add ( LinkListNode * node_ ) [pure virtual]
```

Add.

Add the linked list node to this linked list

Parameters

```
node Pointer to the node to add
```

Implemented in CircularLinkList, DoubleLinkList, and ThreadList.

```
14.15.2.2 LinkListNode* LinkList::GetHead() [inline]
```

GetHead.

Get the head node in the linked list

Returns

Pointer to the head node in the list

Definition at line 152 of file II.h.

```
14.15.2.3 LinkListNode* LinkList::GetTail() [inline]
```

GetTail.

Get the tail node of the linked list

Returns

Pointer to the tail node in the list

Definition at line 161 of file II.h.

```
14.15.2.4 void LinkList::Init (void ) [inline]
```

Init.

Clear the linked list.

Definition at line 125 of file II.h.

14.15.2.5 virtual void LinkList::Remove (LinkListNode * node_) [pure virtual]

Remove.

Add the linked list node to this linked list

Parameters

node_ Pointer to the node to remove

Implemented in CircularLinkList, DoubleLinkList, and ThreadList.

The documentation for this class was generated from the following file:


• /home/vm/mark3/trunk/embedded/kernel/public/II.h

14.16 LinkListNode Class Reference

Basic linked-list node data structure.

#include <11.h>

Inheritance diagram for LinkListNode:



Public Member Functions

LinkListNode * GetNext (void)

GetNext.

LinkListNode * GetPrev (void)

GetPrev.

Protected Member Functions

• void ClearNode ()

ClearNode.

Protected Attributes

LinkListNode * next

Pointer to the next node in the list.

LinkListNode * prev

Pointer to the previous node in the list.

Friends

- class LinkList
- · class DoubleLinkList
- · class CircularLinkList
- · class ThreadList

14.16.1 Detailed Description

Basic linked-list node data structure.

This data is managed by the linked-list class types, and can be used transparently between them.

Definition at line 68 of file II.h.

14.16.2 Member Function Documentation

```
14.16.2.1 void LinkListNode::ClearNode() [protected]
```

ClearNode.

Initialize the linked list node, clearing its next and previous node.

Definition at line 40 of file II.cpp.

```
14.16.2.2 LinkListNode* LinkListNode::GetNext(void) [inline]
```

GetNext.

Returns a pointer to the next node in the list.

Returns

a pointer to the next node in the list.

Definition at line 92 of file II.h.

```
14.16.2.3 LinkListNode* LinkListNode::GetPrev(void) [inline]
```

GetPrev.

Returns a pointer to the previous node in the list.

Returns

a pointer to the previous node in the list.

Definition at line 101 of file II.h.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/II.h
- /home/vm/mark3/trunk/embedded/kernel/II.cpp

14.17 Message Class Reference

Class to provide message-based IPC services in the kernel.

```
#include <message.h>
```

Inheritance diagram for Message:



Public Member Functions

```
• void Init ()
```

Init.

void SetData (void *pvData)

SetData.

void * GetData ()

GetData.

void SetCode (uint16_t u16Code_)

SetCode.

• uint16_t GetCode ()

GetCode.

Private Attributes

void * m pvData

Pointer to the message data.

• uint16_t m_u16Code

Message code, providing context for the message.

Additional Inherited Members

14.17.1 Detailed Description

Class to provide message-based IPC services in the kernel.

Definition at line 99 of file message.h.

14.17.2 Member Function Documentation

```
14.17.2.1 uint16_t Message::GetCode( ) [inline]
```

GetCode.

Return the code set in the message upon receipt

Returns

user code set in the object

Definition at line 143 of file message.h.

```
14.17.2.2 void* Message::GetData() [inline]
```

GetData.

Get the data pointer stored in the message upon receipt

Returns

Pointer to the data set in the message object

Definition at line 125 of file message.h.

```
14.17.2.3 void Message::Init (void ) [inline]
```

Init.

Initialize the data and code in the message.

Definition at line 107 of file message.h.

```
14.17.2.4 void Message::SetCode ( uint16_t u16Code_ ) [inline]
```

SetCode.

Set the code in the message before transmission

Parameters

```
u16Code_ Data code to set in the object
```

Definition at line 134 of file message.h.

```
14.17.2.5 void Message::SetData (void * pvData_) [inline]
```

SetData.

Set the data pointer for the message before transmission.

Parameters

```
pvData_ Pointer to the data object to send in the message
```

Definition at line 116 of file message.h.

The documentation for this class was generated from the following file:

• /home/vm/mark3/trunk/embedded/kernel/public/message.h

14.18 MessageQueue Class Reference

List of messages, used as the channel for sending and receiving messages between threads.

```
#include <message.h>
```

Public Member Functions

• void Init ()

Init.

• Message * Receive ()

```
Receive.
```

Message * Receive (uint32_t u32TimeWaitMS_)

Receive.

void Send (Message *pclSrc_)

Send.

• uint16_t GetCount ()

GetCount.

Private Member Functions

```
    Message * Receive_i (uint32_t u32TimeWaitMS_)
    Receive_i.
```

Private Attributes

• Semaphore m_clSemaphore

Counting semaphore used to manage thread blocking.

• DoubleLinkList m_clLinkList

List object used to store messages.

14.18.1 Detailed Description

List of messages, used as the channel for sending and receiving messages between threads.

Definition at line 201 of file message.h.

14.18.2 Member Function Documentation

```
14.18.2.1 uint16_t MessageQueue::GetCount()
```

GetCount.

Return the number of messages pending in the "receive" queue.

Returns

Count of pending messages in the queue.

Definition at line 160 of file message.cpp.

```
14.18.2.2 void MessageQueue::Init (void)
```

Init.

Initialize the message queue prior to use.

Definition at line 90 of file message.cpp.

```
14.18.2.3 Message * MessageQueue::Receive ( )
```

Receive.

Receive a message from the message queue. If the message queue is empty, the thread will block until a message is available.

Returns

Pointer to a message object at the head of the queue

Definition at line 96 of file message.cpp.

14.18.2.4 Message * MessageQueue::Receive (uint32_t u32TimeWaitMS_)

Receive.

Receive a message from the message queue. If the message queue is empty, the thread will block until a message is available for the duration specified. If no message arrives within that duration, the call will return with NULL.

Parameters

u32WaitTimeM⊷	The amount of time in ms to wait for a message before timing out and unblocking the waiting
S_	thread.

Returns

Pointer to a message object at the head of the queue or NULL on timeout.

Definition at line 107 of file message.cpp.

14.18.2.5 Message * MessageQueue::Receive_i (uint32_t u32TimeWaitMS_) [private]

Receive i.

Internal function used to abstract timed and un-timed Receive calls.

Parameters

u32TimeWaitM⇔	Time (in ms) to block, 0 for un-timed call.
S_	

Returns

Pointer to a message, or 0 on timeout.

Definition at line 115 of file message.cpp.

14.18.2.6 void MessageQueue::Send (Message * pclSrc_)

Send.

Send a message object into this message queue. Will un-block the first waiting thread blocked on this queue if that occurs.

Parameters

pclSrc_ Pointer to the message object to add to the queue

Definition at line 144 of file message.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/message.h
- /home/vm/mark3/trunk/embedded/kernel/message.cpp

14.19 Mutex Class Reference

Mutual-exclusion locks, based on BlockingObject.

```
#include <mutex.h>
```

Inheritance diagram for Mutex:



Public Member Functions

```
• void Init ()
```

Init.

• void Claim ()

Claim.

bool Claim (uint32_t u32WaitTimeMS_)

Claim

void WakeMe (Thread *pclOwner_)

WakeMe.

• void Release ()

Release.

Private Member Functions

```
• uint8_t WakeNext ()
```

WakeNext.

bool Claim_i (uint32_t u32WaitTimeMS_)

Claim_i.

Private Attributes

• uint8_t m_u8Recurse

The recursive lock-count when a mutex is claimed multiple times by the same owner.

bool m_bReady

State of the mutex - true = ready, false = claimed.

• uint8_t m_u8MaxPri

Maximum priority of thread in queue, used for priority inheritence.

• Thread * m_pclOwner

Pointer to the thread that owns the mutex (when claimed)

Additional Inherited Members

14.19.1 Detailed Description

Mutual-exclusion locks, based on BlockingObject.

Definition at line 68 of file mutex.h.

14.19.2 Member Function Documentation

```
14.19.2.1 void Mutex::Claim (void)
```

Claim.

Claim the mutex. When the mutex is claimed, no other thread can claim a region protected by the object.

Definition at line 215 of file mutex.cpp.

```
14.19.2.2 bool Mutex::Claim ( uint32_t u32WaitTimeMS_ )
```

Claim.

Parameters

```
u32WaitTimeM⇔ | S_ |
```

Returns

true - mutex was claimed within the time period specified false - mutex operation timed-out before the claim operation.

Definition at line 226 of file mutex.cpp.

```
14.19.2.3 bool Mutex::Claim_i ( uint32_t u32WaitTimeMS_ ) [private]
```

Claim_i.

Abstracts out timed/non-timed mutex claim operations.

Parameters

u32WaitTimeM⇔	Time in MS to wait, 0 for infinite
S_	

Returns

true on successful claim, false otherwise

Definition at line 113 of file mutex.cpp.

```
14.19.2.4 void Mutex::Init ( void )
```

Init.

Initialize a mutex object for use - must call this function before using the object.

Definition at line 102 of file mutex.cpp.

```
14.19.2.5 void Mutex::Release ( )
```

Release

Release the mutex. When the mutex is released, another object can enter the mutex-protected region.

Definition at line 233 of file mutex.cpp.

```
14.19.2.6 void Mutex::WakeMe ( Thread * pclOwner_ )
```

WakeMe.

Wake a thread blocked on the mutex. This is an internal function used for implementing timed mutexes relying on timer callbacks. Since these do not have access to the private data of the mutex and its base classes, we have to wrap this as a public method - do not use this for any other purposes.

Parameters

```
pclOwner_ Thread to unblock from this object.
```

Definition at line 71 of file mutex.cpp.

```
14.19.2.7 uint8_t Mutex::WakeNext( ) [private]
```

WakeNext.

Wake the next thread waiting on the Mutex.

Definition at line 80 of file mutex.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/mutex.h
- /home/vm/mark3/trunk/embedded/kernel/mutex.cpp

14.20 Profiler Class Reference

```
System profiling timer interface.
```

```
#include <kernelprofile.h>
```

Static Public Member Functions

```
• static void Init ()
```

Init.

• static void Start ()

Start.

· static void Stop ()

Stop.

• static uint16_t Read ()

Read.

• static void Process ()

Process.

static uint32_t GetEpoch ()

GetEpoch.

14.20.1 Detailed Description

System profiling timer interface.

Definition at line 37 of file kernelprofile.h.

14.20.2 Member Function Documentation

```
14.20.2.1 static uint32_t Profiler::GetEpoch( ) [inline],[static]
```

GetEpoch.

Return the current timer epoch

Definition at line 81 of file kernelprofile.h.

```
14.20.2.2 void Profiler::Init(void) [static]
```

Init.

Initialize the global system profiler. Must be called prior to use.

Definition at line 32 of file kernelprofile.cpp.

```
14.20.2.3 void Profiler::Process (void ) [static]
```

Process.

Process the profiling counters from ISR.

Definition at line 70 of file kernelprofile.cpp.

```
14.20.2.4 uint16_t Profiler::Read( ) [static]
```

Read.

Read the current tick count in the timer.

Definition at line 58 of file kernelprofile.cpp.

```
14.20.2.5 void Profiler::Start (void ) [static]
```

Start.

Start the global profiling timer service.

Definition at line 42 of file kernelprofile.cpp.

```
14.20.2.6 void Profiler::Stop ( ) [static]
```

Stop.

Stop the global profiling timer service

Definition at line 51 of file kernelprofile.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h
- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp

14.21 ProfileTimer Class Reference

Profiling timer.

```
#include file.h>
```

Public Member Functions

Private Member Functions

uint32_t ComputeCurrentTicks (uint16_t u16Count_, uint32_t u32Epoch_)
 ComputeCurrentTicks.

Private Attributes

• uint32_t m_u32Cumulative

Cumulative tick-count for this timer.

• uint32_t m_u32CurrentIteration

Tick-count for the current iteration.

uint16_t m_u16Initial

Initial count.

• uint32_t m_u32InitialEpoch

Initial Epoch.

• uint16_t m_u16Iterations

Number of iterations executed for this profiling timer.

• bool m_bActive

Wheter or not the timer is active or stopped.

14.21.1 Detailed Description

Profiling timer.

This class is used to perform high-performance profiling of code to see how int32_t certain operations take. useful in instrumenting the performance of key algorithms and time-critical operations to ensure real-timer behavior.

Definition at line 70 of file profile.h.

14.21.2 Member Function Documentation

14.21.2.1 uint32_t ProfileTimer::ComputeCurrentTicks (uint16_t u16Count_, uint32_t u32Epoch_) [private]

ComputeCurrentTicks.

Figure out how many ticks have elapsed in this iteration

Parameters

u16Count_	Current timer count
u32Epoch_	Current timer epoch

Returns

Current tick count

Definition at line 112 of file profile.cpp.

```
14.21.2.2 uint32_t ProfileTimer::GetAverage ( )
```

GetAverage.

Get the average time associated with this operation.

Returns

Average tick count normalized over all iterations

Definition at line 85 of file profile.cpp.

```
14.21.2.3 uint32_t ProfileTimer::GetCurrent ( )
```

GetCurrent.

Return the current tick count held by the profiler. Valid for both active and stopped timers.

Returns

The currently held tick count.

Definition at line 95 of file profile.cpp.

```
14.21.2.4 void ProfileTimer::Init ( void )
```

Init.

Initialize the profiling timer prior to use. Can also be used to reset a timer that's been used previously.

Definition at line 43 of file profile.cpp.

```
14.21.2.5 void ProfileTimer::Start (void)
```

Start.

Start a profiling session, if the timer is not already active. Has no effect if the timer is already active.

Definition at line 52 of file profile.cpp.

```
14.21.2.6 void ProfileTimer::Stop ( )
```

Stop.

Stop the current profiling session, adding to the cumulative time for this timer, and the total iteration count.

Definition at line 66 of file profile.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/profile.h
- /home/vm/mark3/trunk/embedded/kernel/profile.cpp

14.22 Quantum Class Reference

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

```
#include <quantum.h>
```

Static Public Member Functions

• static void UpdateTimer ()

UpdateTimer.

• static void AddThread (Thread *pclThread_)

AddThread.

static void RemoveThread ()

RemoveThread.

• static void SetInTimer (void)

SetInTimer.

• static void ClearInTimer (void)

ClearInTimer.

Static Private Member Functions

static void SetTimer (Thread *pclThread_)
 SetTimer.

14.22.1 Detailed Description

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling. Definition at line 41 of file quantum.h.

14.22.2 Member Function Documentation

```
14.22.2.1 void Quantum::AddThread ( Thread * pclThread_ ) [static]
```

AddThread.

Add the thread to the quantum timer. Only one thread can own the quantum, since only one thread can be running on a core at a time.

Definition at line 88 of file quantum.cpp.

```
14.22.2.2 static void Quantum::ClearInTimer(void) [inline], [static]
```

ClearInTimer.

Clear the flag once the timer callback function has been completed.

Definition at line 84 of file quantum.h.

```
14.22.2.3 void Quantum::RemoveThread (void ) [static]
```

RemoveThread.

Remove the thread from the quantum timer. This will cancel the timer.

Definition at line 117 of file quantum.cpp.

```
14.22.2.4 static void Quantum::SetInTimer (void ) [inline], [static]
```

SetInTimer.

Set a flag to indicate that the CPU is currently running within the timer-callback routine. This prevents the Quantum timer from being updated in the middle of a callback cycle, potentially resulting in the kernel timer becoming disabled.

Definition at line 77 of file quantum.h.

```
14.22.2.5 void Quantum::SetTimer ( Thread * pclThread_ ) [static], [private]
```

SetTimer.

Set up the quantum timer in the timer scheduler. This creates a one-shot timer, which calls a static callback in quantum.cpp that on expiry will pivot the head of the threadlist for the thread's priority. This is the mechanism that provides round-robin scheduling in the system.

Parameters

```
pclThread_ Pointer to the thread to set the Quantum timer on
```

Definition at line 78 of file quantum.cpp.

```
14.22.2.6 void Quantum::UpdateTimer (void ) [static]
```

UpdateTimer.

This function is called to update the thread quantum timer whenever something in the scheduler has changed. This can result in the timer being re-loaded or started. The timer is never stopped, but if may be ignored on expiry.

Definition at line 130 of file quantum.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/quantum.h
- /home/vm/mark3/trunk/embedded/kernel/quantum.cpp

14.23 Scheduler Class Reference

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

```
#include <scheduler.h>
```

Static Public Member Functions

```
· static void Init ()
```

Init.

• static void Schedule ()

Schedule.

static void Add (Thread *pclThread_)

Add.

• static void Remove (Thread *pclThread_)

Remove.

static bool SetScheduler (bool bEnable_)

SetScheduler.

static Thread * GetCurrentThread ()

GetCurrentThread.

static volatile Thread * GetNextThread ()

GetNextThread.

static ThreadList * GetThreadList (uint8_t u8Priority_)

GetThreadList.

• static ThreadList * GetStopList ()

GetStopList.

• static uint8_t IsEnabled ()

IsEnabled.

• static void QueueScheduler ()

QueueScheduler.

Static Private Attributes

static bool m_bEnabled

Scheduler's state - enabled or disabled.

• static bool m_bQueuedSchedule

Variable representing whether or not there's a queued scheduler operation.

• static ThreadList m_clStopList

ThreadList for all stopped threads.

• static ThreadList m_aclPriorities [NUM_PRIORITIES]

ThreadLists for all threads at all priorities.

• static uint8_t m_u8PriFlag

Bitmap flag for each.

14.23.1 Detailed Description

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

Definition at line 62 of file scheduler.h.

14.23.2 Member Function Documentation

```
14.23.2.1 void Scheduler::Add ( Thread * pclThread_ ) [static]
```

Add.

Add a thread to the scheduler at its current priority level.

Parameters

pclThread Pointer to the thread to add to the scheduler

Definition at line 113 of file scheduler.cpp.

14.23.2.2 static Thread* Scheduler::GetCurrentThread() [inline], [static]

GetCurrentThread.

Return the pointer to the currently-running thread.

Returns

Pointer to the currently-running thread

Definition at line 121 of file scheduler.h.

14.23.2.3 static volatile Thread* Scheduler::GetNextThread() [inline], [static]

GetNextThread.

Return the pointer to the thread that should run next, according to the last run of the scheduler.

Returns

Pointer to the next-running thread

Definition at line 131 of file scheduler.h.

14.23.2.4 static ThreadList* Scheduler::GetStopList() [inline], [static]

GetStopList.

Return the pointer to the list of threads that are in the scheduler's stopped state.

Returns

Pointer to the ThreadList containing the stopped threads

Definition at line 153 of file scheduler.h.

14.23.2.5 static ThreadList* Scheduler::GetThreadList(uint8_t u8Priority_) [inline], [static]

GetThreadList.

Return the pointer to the active list of threads that are at the given priority level in the scheduler.

Parameters

u8Priority_ Priority level of

Returns

Pointer to the ThreadList for the given priority level

Definition at line 143 of file scheduler.h.

14.23.2.6 void Scheduler::Init (void) [static]

Init.

Intiailize the scheduler, must be called before use.

Definition at line 64 of file scheduler.cpp.

```
14.23.2.7 static uint8_t Scheduler::IsEnabled() [inline], [static]
```

IsEnabled.

Return the current state of the scheduler - whether or not scheddling is enabled or disabled.

Returns

true - scheduler enabled, false - disabled

Definition at line 163 of file scheduler.h.

```
14.23.2.8 static void Scheduler::QueueScheduler( ) [inline], [static]
```

QueueScheduler.

Tell the kernel to perform a scheduling operation as soon as the scheduler is re-enabled.

Definition at line 171 of file scheduler.h.

```
14.23.2.9 void Scheduler::Remove ( Thread * pclThread_ ) [static]
```

Remove.

Remove a thread from the scheduler at its current priority level.

Parameters

```
pclThread_ Pointer to the thread to be removed from the scheduler
```

Definition at line 119 of file scheduler.cpp.

```
14.23.2.10 void Scheduler::Schedule( ) [static]
```

Schedule.

Run the scheduler, determines the next thread to run based on the current state of the threads. Note that the next-thread chosen from this function is only valid while in a critical section.

Definition at line 76 of file scheduler.cpp.

```
14.23.2.11 bool Scheduler::SetScheduler (bool bEnable_) [static]
```

SetScheduler.

Set the active state of the scheduler. When the scheduler is disabled, the *next thread* is never set; the currently running thread will run forever until the scheduler is enabled again. Care must be taken to ensure that we don't end up trying to block while the scheduler is disabled, otherwise the system ends up in an unusable state.

Parameters

```
bEnable_ true to enable, false to disable the scheduler
```

Definition at line 125 of file scheduler.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/scheduler.h
- /home/vm/mark3/trunk/embedded/kernel/scheduler.cpp

14.24 Semaphore Class Reference

Counting semaphore, based on BlockingObject base class.

```
#include <ksemaphore.h>
```

Inheritance diagram for Semaphore:



Public Member Functions

void Init (uint16_t u16InitVal_, uint16_t u16MaxVal_)

Initialize a semaphore before use.

• bool Post ()

Increment the semaphore count.

· void Pend ()

Decrement the semaphore count.

uint16_t GetCount ()

Return the current semaphore counter.

bool Pend (uint32_t u32WaitTimeMS_)

Decrement the semaphore count.

void WakeMe (Thread *pclChosenOne_)

Wake a thread blocked on the semaphore.

Private Member Functions

• uint8_t WakeNext ()

Wake the next thread waiting on the semaphore.

bool Pend_i (uint32_t u32WaitTimeMS_)

Pend_i.

Private Attributes

• uint16_t m_u16Value

Current count held by the semaphore.

• uint16_t m_u16MaxValue

Maximum count that can be held by this semaphore.

Additional Inherited Members

14.24.1 Detailed Description

Counting semaphore, based on BlockingObject base class.

Definition at line 37 of file ksemaphore.h.

14.24.2 Member Function Documentation

```
14.24.2.1 uint16_t Semaphore::GetCount()
```

Return the current semaphore counter.

This can be usedd by a thread to bypass blocking on a semaphore - allowing it to do other things until a non-zero count is returned, instead of blocking until the semaphore is posted.

Returns

The current semaphore counter value.

Definition at line 241 of file ksemaphore.cpp.

```
14.24.2.2 void Semaphore::Init ( uint16_t u16InitVal_, uint16_t u16MaxVal_ )
```

Initialize a semaphore before use.

Must be called before post/pend operations.

Parameters

u16InitVal_	Initial value held by the semaphore
u16MaxVal_	Maximum value for the semaphore

Definition at line 102 of file ksemaphore.cpp.

```
14.24.2.3 void Semaphore::Pend ( )
```

Decrement the semaphore count.

If the count is zero, the thread will block until the semaphore is pended.

Definition at line 223 of file ksemaphore.cpp.

```
14.24.2.4 bool Semaphore::Pend ( uint32_t u32WaitTimeMS_ )
```

Decrement the semaphore count.

If the count is zero, the thread will block until the semaphore is pended. If the specified interval expires before the thread is unblocked, then the status is returned back to the user.

Returns

true - semaphore was acquired before the timeout false - timeout occurred before the semaphore was claimed.

Definition at line 234 of file ksemaphore.cpp.

```
14.24.2.5 bool Semaphore::Pend_i ( uint32_t u32WaitTimeMS_ ) [private]
```

Pend_i.

Internal function used to abstract timed and untimed semaphore pend operations.

Parameters

u32WaitTimeM⇔	Time in MS to wait
S_	

Returns

true on success, false on failure.

Definition at line 167 of file ksemaphore.cpp.

```
14.24.2.6 bool Semaphore::Post ( )
```

Increment the semaphore count.

Returns

true if the semaphore was posted, false if the count is already maxed out.

Definition at line 114 of file ksemaphore.cpp.

```
14.24.2.7 void Semaphore::WakeMe ( Thread * pclChosenOne_ )
```

Wake a thread blocked on the semaphore.

This is an internal function used for implementing timed semaphores relying on timer callbacks. Since these do not have access to the private data of the semaphore and its base classes, we have to wrap this as a public method - do not used this for any other purposes.

Definition at line 75 of file ksemaphore.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/ksemaphore.h
- /home/vm/mark3/trunk/embedded/kernel/ksemaphore.cpp

14.25 Thread Class Reference

Object providing fundamental multitasking support in the kernel.

```
#include <thread.h>
```

Inheritance diagram for Thread:



Public Member Functions

 void Init (K_WORD *pwStack_, uint16_t u16StackSize_, uint8_t u8Priority_, ThreadEntry_t pfEntryPoint_, void *pvArg_)

Init.

• void Start ()

Start.

```
· void Stop ()
      Stop.

    ThreadList * GetOwner (void)

      GetOwner.

    ThreadList * GetCurrent (void)

      GetCurrent.
• uint8_t GetPriority (void)
      GetPriority.

    uint8_t GetCurPriority (void)

      GetCurPriority.

    void SetQuantum (uint16 t u16Quantum )

      SetQuantum.

    uint16_t GetQuantum (void)

      GetQuantum.

    void SetCurrent (ThreadList *pclNewList )

void SetOwner (ThreadList *pclNewList_)

    void SetPriority (uint8_t u8Priority_)

      SetPriority.
• void InheritPriority (uint8_t u8Priority_)
      InheritPriority.
• void Exit ()
• void SetID (uint8_t u8ID )
     SetID.
• uint8_t GetID ()
      GetID.

    uint16_t GetStackSlack ()

     GetStackSlack.

    uint16_t GetEventFlagMask ()

      GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag
     blocking object type.

    void SetEventFlagMask (uint16_t u16Mask_)

      SetEventFlagMask Sets the active event flag bitfield mask.

    void SetEventFlagMode (EventFlagOperation_t eMode_)

      SetEventFlagMode Sets the active event flag operation mode.
• EventFlagOperation_t GetEventFlagMode ()
      GetEventFlagMode Returns the thread's event flag's operating mode.

    Timer * GetTimer ()

      Return a pointer to the thread's timer object.

    void SetExpired (bool bExpired_)

      SetExpired.

    bool GetExpired ()

      GetExpired.
· void InitIdle ()
      InitIdle Initialize this Thread object as the Kernel's idle thread.

    ThreadState_t GetState ()

      GetState Returns the current state of the thread to the caller.

    void SetState (ThreadState_t eState_)
```

SetState Set the thread's state to a new value.

Static Public Member Functions

• static void Sleep (uint32_t u32TimeMs_)

Sleep.

• static void USleep (uint32_t u32TimeUs_)

USleep.

• static void Yield (void)

Yield.

Private Member Functions

void SetPriorityBase (uint8_t u8Priority_)
 SetPriorityBase.

Static Private Member Functions

· static void ContextSwitchSWI (void)

ContextSwitchSWI.

Private Attributes

K_WORD * m_pwStackTop

Pointer to the top of the thread's stack.

K_WORD * m_pwStack

Pointer to the thread's stack.

· uint8 t m u8ThreadID

Thread ID.

• uint8_t m_u8Priority

Default priority of the thread.

uint8_t m_u8CurPriority

Current priority of the thread (priority inheritence)

ThreadState_t m_eState

Enum indicating the thread's current state.

• uint16 t m u16StackSize

Size of the stack (in bytes)

ThreadList * m_pclCurrent

Pointer to the thread-list where the thread currently resides.

ThreadList * m_pclOwner

Pointer to the thread-list where the thread resides when active.

ThreadEntry_t m_pfEntryPoint

The entry-point function called when the thread starts.

void * m_pvArg

Pointer to the argument passed into the thread's entrypoint.

uint16_t m_u16Quantum

Thread quantum (in milliseconds)

uint16_t m_u16FlagMask

Event-flag mask.

• EventFlagOperation_t m_eFlagMode

Event-flag mode.

• Timer m_clTimer

Timer used for blocking-object timeouts.

bool m bExpired

Indicate whether or not a blocking-object timeout has occurred.

Friends

· class ThreadPort

Additional Inherited Members

14.25.1 Detailed Description

Object providing fundamental multitasking support in the kernel.

Definition at line 72 of file thread.h.

14.25.2 Member Function Documentation

```
14.25.2.1 void Thread::ContextSwitchSWI(void) [static], [private]
```

ContextSwitchSWI.

This code is used to trigger the context switch interrupt. Called whenever the kernel decides that it is necessary to swap out the current thread for the "next" thread.

Definition at line 414 of file thread.cpp.

```
14.25.2.2 void Thread::Exit ( )
```

Exit.

Remove the thread from being scheduled again. The thread is effectively destroyed when this occurs. This is extremely useful for cases where a thread encounters an unrecoverable error and needs to be restarted, or in the context of systems where threads need to be created and destroyed dynamically.

This must not be called on the idle thread.

Definition at line 193 of file thread.cpp.

```
14.25.2.3 uint8_t Thread::GetCurPriority (void ) [inline]
```

GetCurPriority.

Return the priority of the current thread

Returns

Priority of the current thread

Definition at line 196 of file thread.h.

```
14.25.2.4 ThreadList* Thread::GetCurrent(void) [inline]
```

GetCurrent.

Return the ThreadList where the thread is currently located

Returns

Pointer to the thread's current list

Definition at line 177 of file thread.h.

```
14.25.2.5 uint16_t Thread::GetEventFlagMask( ) [inline]
```

GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag blocking object type.

Returns

A copy of the thread's event flag mask

Definition at line 348 of file thread.h.

```
14.25.2.6 EventFlagOperation_t Thread::GetEventFlagMode() [inline]
```

GetEventFlagMode Returns the thread's event flag's operating mode.

Returns

The thread's event flag mode.

Definition at line 367 of file thread.h.

```
14.25.2.7 bool Thread::GetExpired ( )
```

GetExpired.

Return the status of the most-recent blocking call on the thread.

Returns

```
true - call expired, false - call did not expire
```

Definition at line 432 of file thread.cpp.

```
14.25.2.8 uint8_t Thread::GetID() [inline]
```

GetID.

Return the 8-bit ID corresponding to this thread.

Returns

Thread's 8-bit ID, set by the user

Definition at line 323 of file thread.h.

```
14.25.2.9 ThreadList* Thread::GetOwner(void) [inline]
```

GetOwner.

Return the ThreadList where the thread belongs when it's in the active/ready state in the scheduler.

Returns

Pointer to the Thread's owner list

Definition at line 168 of file thread.h.

```
14.25.2.10 uint8_t Thread::GetPriority (void ) [inline]
```

GetPriority.

Return the priority of the current thread

Returns

Priority of the current thread

Definition at line 187 of file thread.h.

```
14.25.2.11 uint16_t Thread::GetQuantum (void ) [inline]
```

GetQuantum.

Get the thread's round-robin execution quantum.

Returns

The thread's quantum

Definition at line 215 of file thread.h.

```
14.25.2.12 uint16_t Thread::GetStackSlack()
```

GetStackSlack.

Performs a (somewhat lengthy) check on the thread stack to check the amount of stack margin (or "slack") remaining on the stack. If you're having problems with blowing your stack, you can run this function at points in your code during development to see what operations cause problems. Also useful during development as a tool to optimally size thread stacks.

Returns

The amount of slack (unused bytes) on the stack

! ToDo: Take into account stacks that grow up

Definition at line 303 of file thread.cpp.

```
14.25.2.13 ThreadState_t Thread::GetState() [inline]
```

GetState Returns the current state of the thread to the caller.

Can be used to determine whether or not a thread is ready (or running), stopped, or terminated/exit'd.

Returns

ThreadState_t representing the thread's current state

Definition at line 411 of file thread.h.

```
14.25.2.14 void Thread::InheritPriority ( uint8_t u8Priority_ )
```

InheritPriority.

Allow the thread to run at a different priority level (temporarily) for the purpose of avoiding priority inversions. This should only be called from within the implementation of blocking-objects.

Parameters

u8Priority_	New Priority to boost to.
-------------	---------------------------

Definition at line 407 of file thread.cpp.

14.25.2.15 void Thread::Init (K_WORD * pwStack_, uint16_t u16StackSize_, uint8_t u8Priority_, ThreadEntry_t pfEntryPoint_, void * pvArg_)

Init.

Initialize a thread prior to its use. Initialized threads are placed in the stopped state, and are not scheduled until the thread's start method has been invoked first.

Parameters

pwStack_	Pointer to the stack to use for the thread
u16StackSize_	Size of the stack (in bytes)
u8Priority_	Priority of the thread (0 = idle, 7 = max)
pfEntryPoint_	This is the function that gets called when the thread is started
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

Definition at line 46 of file thread.cpp.

14.25.2.16 void Thread::InitIdle (void)

InitIdle Initialize this Thread object as the Kernel's idle thread.

There should only be one of these, maximum, in a given system.

Definition at line 437 of file thread.cpp.

14.25.2.17 void Thread::SetCurrent (ThreadList * pclNewList_) [inline]

SetCurrent.

Set the thread's current to the specified thread list

Parameters

pclNewList_	Pointer to the threadlist to apply thread ownership

Definition at line 225 of file thread.h.

14.25.2.18 void Thread::SetEventFlagMask (uint16_t u16Mask_) [inline]

SetEventFlagMask Sets the active event flag bitfield mask.

Parameters

u16Mask_

Definition at line 354 of file thread.h.

14.25.2.19 void Thread::SetEventFlagMode (EventFlagOperation_t eMode_) [inline]

SetEventFlagMode Sets the active event flag operation mode.

Parameters

eMode_ Event flag operation mode, defines the logical operator to apply to the event flag.

Definition at line 361 of file thread.h.

14.25.2.20 void Thread::SetExpired (bool bExpired_)

SetExpired.

Set the status of the current blocking call on the thread.

Parameters

```
bExpired_ true - call expired, false - call did not expire
```

Definition at line 429 of file thread.cpp.

14.25.2.21 void Thread::SetID (uint8_t u8ID_) [inline]

SetID.

Set an 8-bit ID to uniquely identify this thread.

Parameters

```
u8ID_ 8-bit Thread ID, set by the user
```

Definition at line 314 of file thread.h.

14.25.2.22 void Thread::SetOwner (ThreadList * pclNewList_) [inline]

SetOwner.

Set the thread's owner to the specified thread list

Parameters

pclNewList_ Pointer to the threadlist to apply thread ownership

Definition at line 234 of file thread.h.

14.25.2.23 void Thread::SetPriority (uint8_t u8Priority_)

SetPriority.

Set the priority of the Thread (running or otherwise) to a different level. This activity involves re-scheduling, and must be done so with due caution, as it may effect the determinism of the system.

This should *always* be called from within a critical section to prevent system issues.

Parameters

```
u8Priority_ New priority of the thread
```

Definition at line 363 of file thread.cpp.

14.25.2.24 void Thread::SetPriorityBase (uint8_t u8Priority_) [private]

SetPriorityBase.

Parameters

u8Priority_

Definition at line 353 of file thread.cpp.

14.25.2.25 void Thread::SetQuantum (uint16_t u16Quantum_) [inline]

SetQuantum.

Set the thread's round-robin execution quantum.

Parameters

u16Quantum_ Thread's execution quantum (in milliseconds)

Definition at line 206 of file thread.h.

14.25.2.26 void Thread::SetState (ThreadState_t eState_) [inline]

SetState Set the thread's state to a new value.

This is only to be used by code within the kernel, and is not indended for use by an end-user.

Parameters

eState_ New thread state to set.

Definition at line 420 of file thread.h.

14.25.2.27 void Thread::Sleep (uint32_t u32TimeMs_) [static]

Sleep.

Put the thread to sleep for the specified time (in milliseconds). Actual time slept may be longer (but not less than) the interval specified.

Parameters

u32TimeMs_ Time to sleep (in ms)

Definition at line 258 of file thread.cpp.

14.25.2.28 void Thread::Start (void)

Start.

Start the thread - remove it from the stopped list, add it to the scheduler's list of threads (at the thread's set priority), and continue along.

Definition at line 115 of file thread.cpp.

14.25.2.29 void Thread::Stop ()

Stop.

Stop a thread that's actively scheduled without destroying its stacks. Stopped threads can be restarted using the Start() API.

Definition at line 148 of file thread.cpp.

```
14.25.2.30 void Thread::USleep ( uint32_t u32TimeUs_ ) [static]
```

USleep.

Put the thread to sleep for the specified time (in microseconds). Actual time slept may be longer (but not less than) the interval specified.

Parameters

```
u32TimeUs_ Time to sleep (in microseconds)
```

Definition at line 280 of file thread.cpp.

```
14.25.2.31 void Thread::Yield (void ) [static]
```

Yield.

Yield the thread - this forces the system to call the scheduler and determine what thread should run next. This is typically used when threads are moved in and out of the scheduler.

Definition at line 324 of file thread.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/thread.h
- /home/vm/mark3/trunk/embedded/kernel/thread.cpp

14.26 ThreadList Class Reference

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

```
#include <threadlist.h>
```

Inheritance diagram for ThreadList:



Public Member Functions

```
• ThreadList ()
```

ThreadList.

void SetPriority (uint8_t u8Priority_)

SetPriority.

void SetFlagPointer (uint8_t *pu8Flag_)

SetFlagPointer.

void Add (LinkListNode *node_)

Add.

void Add (LinkListNode *node_, uint8_t *pu8Flag_, uint8_t u8Priority_)

Add

void AddPriority (LinkListNode *node_)

AddPriority.

void Remove (LinkListNode *node_)

Remove.

• Thread * HighestWaiter ()

HighestWaiter.

Private Attributes

• uint8_t m_u8Priority

Priority of the threadlist.

uint8_t * m_pu8Flag

Pointer to the bitmap/flag to set when used for scheduling.

Additional Inherited Members

14.26.1 Detailed Description

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

Definition at line 34 of file threadlist.h.

14.26.2 Constructor & Destructor Documentation

```
14.26.2.1 ThreadList::ThreadList() [inline]
```

ThreadList.

Default constructor - zero-initializes the data.

Definition at line 42 of file threadlist.h.

14.26.3 Member Function Documentation

```
14.26.3.1 void ThreadList::Add ( LinkListNode * node_ ) [virtual]
```

Add.

Add a thread to the threadlist.

Parameters

```
node_ Pointer to the thread (link list node) to add to the list
```

Reimplemented from CircularLinkList.

Definition at line 52 of file threadlist.cpp.

```
14.26.3.2 void ThreadList::Add ( LinkListNode * node_, uint8_t * pu8Flag_, uint8_t u8Priority_ )
```

Add.

Add a thread to the threadlist, specifying the flag and priority at the same time.

Parameters

node_	Pointer to the thread to add (link list node)
pu8Flag_	Pointer to the bitmap flag to set (if used in a scheduler context), or NULL for non-scheduler.
u8Priority_	Priority of the threadlist

Definition at line 104 of file threadlist.cpp.

14.26.3.3 void ThreadList::AddPriority (LinkListNode * node_)

AddPriority.

Add a thread to the list such that threads are ordered from highest to lowest priority from the head of the list.

Parameters

node_ Pointer to a thread to add to the list.

Definition at line 65 of file threadlist.cpp.

14.26.3.4 Thread * ThreadList::HighestWaiter ()

HighestWaiter.

Return a pointer to the highest-priority thread in the thread-list.

Returns

Pointer to the highest-priority thread

Definition at line 129 of file threadlist.cpp.

14.26.3.5 void ThreadList::Remove (LinkListNode * node_) [virtual]

Remove.

Remove the specified thread from the threadlist

Parameters

node_ Pointer to the thread to remove

Reimplemented from CircularLinkList.

Definition at line 113 of file threadlist.cpp.

14.26.3.6 void ThreadList::SetFlagPointer (uint8_t * pu8Flag_)

SetFlagPointer.

Set the pointer to a bitmap to use for this threadlist. Once again, only needed when the threadlist is being used for scheduling purposes.

Parameters

pu8Flag_ Pointer to the bitmap flag

Definition at line 46 of file threadlist.cpp.

14.26.3.7 void ThreadList::SetPriority (uint8_t u8Priority_)

SetPriority.

Set the priority of this threadlist (if used for a scheduler).

Parameters

u8Priority_ Priority level of the thread list

Definition at line 40 of file threadlist.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/threadlist.h
- /home/vm/mark3/trunk/embedded/kernel/threadlist.cpp

14.27 ThreadPort Class Reference

Class defining the architecture specific functions required by the kernel.

```
#include <threadport.h>
```

Static Public Member Functions

static void StartThreads ()
 StartThreads.

Static Private Member Functions

static void InitStack (Thread *pstThread_)
 InitStack.

Friends

· class Thread

14.27.1 Detailed Description

Class defining the architecture specific functions required by the kernel.

This is limited (at this point) to a function to start the scheduler, and a function to initialize the default stack-frame for a thread.

Definition at line 167 of file threadport.h.

14.27.2 Member Function Documentation

```
14.27.2.1 void ThreadPort::InitStack ( Thread * pstThread_ ) [static], [private]
```

InitStack.

Initialize the thread's stack.

Parameters

pstThread_ Pointer to the thread to initialize

Definition at line 39 of file threadport.cpp.

```
14.27.2.2 void ThreadPort::StartThreads() [static]
```

StartThreads.

Function to start the scheduler, initial threads, etc.

Definition at line 135 of file threadport.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/threadport.h
- /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/threadport.cpp

14.28 **Timer Class Reference**

Timer - an event-driven execution context based on a specified time interval.

```
#include <timer.h>
```

Inheritance diagram for Timer:



Public Member Functions

```
• Timer ()
      Timer.
• void Init ()
     Init.

    void Start (bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_, void *pvData_)

    void Start (bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_, TimerCallback_t pf

 Callback, void *pvData)
     Start.

    void Stop ()

     Stop.
• void SetFlags (uint8_t u8Flags_)
     SetFlags.

    void SetCallback (TimerCallback_t pfCallback_)

     SetCallback.

    void SetData (void *pvData )

     SetData.
void SetOwner (Thread *pclOwner_)
     SetOwner.

    void SetIntervalTicks (uint32_t u32Ticks_)

     SetIntervalTicks.

    void SetIntervalSeconds (uint32_t u32Seconds_)

     SetIntervalSeconds.
• uint32_t GetInterval ()
```

GetInterval.

• void SetIntervalMSeconds (uint32_t u32MSeconds_)

SetIntervalMSeconds.

• void SetIntervalUSeconds (uint32_t u32USeconds_)

SetIntervalUSeconds.

void SetTolerance (uint32_t u32Ticks_)

SetTolerance.

Private Attributes

• uint8_t m_u8Flags

Flags for the timer, defining if the timer is one-shot or repeated.

• TimerCallback t m pfCallback

Pointer to the callback function.

• uint32 t m u32Interval

Interval of the timer in timer ticks.

• uint32 t m u32TimeLeft

Time remaining on the timer.

• uint32_t m_u32TimerTolerance

Maximum tolerance (usedd for timer harmonization)

• Thread * m pclOwner

Pointer to the owner thread.

void * m_pvData

Pointer to the callback data.

Friends

class TimerList

Additional Inherited Members

14.28.1 Detailed Description

Timer - an event-driven execution context based on a specified time interval.

This inherits from a LinkListNode for ease of management by a global TimerList object.

Definition at line 102 of file timer.h.

14.28.2 Constructor & Destructor Documentation

```
14.28.2.1 Timer::Timer() [inline]
```

Timer.

Default Constructor - zero-initializes all internal data.

Definition at line 110 of file timer.h.

```
14.28.3 Member Function Documentation
```

14.28.3.1 uint32_t Timer::GetInterval() [inline]

GetInterval.

Returns

Definition at line 217 of file timer.h.

```
14.28.3.2 void Timer::Init (void ) [inline]
```

Init.

Re-initialize the Timer to default values.

Definition at line 117 of file timer.h.

```
14.28.3.3 void Timer::SetCallback ( TimerCallback_t pfCallback_ ) [inline]
```

SetCallback.

Define the callback function to be executed on expiry of the timer

Parameters

```
pfCallback_ Pointer to the callback function to call
```

Definition at line 173 of file timer.h.

```
14.28.3.4 void Timer::SetData (void * pvData_) [inline]
```

SetData.

Define a pointer to be sent to the timer callbcak on timer expiry

Parameters

```
pvData_ Pointer to data to pass as argument into the callback
```

Definition at line 182 of file timer.h.

```
14.28.3.5 void Timer::SetFlags ( uint8_t u8Flags_ ) [inline]
```

SetFlags.

Set the timer's flags based on the bits in the u8Flags_ argument

Parameters

```
u8Flags_ Flags to assign to the timer object. TIMERLIST_FLAG_ONE_SHOT for a one-shot timer, 0 for a continuous timer.
```

Definition at line 164 of file timer.h.

```
14.28.3.6 void Timer::SetIntervalMSeconds ( uint32_t u32MSeconds_ )
```

SetIntervalMSeconds.

Set the timer expiry interval in milliseconds (platform agnostic)

Parameters

u32MSeconds⇔	Time in milliseconds
_	

Definition at line 94 of file timer.cpp.

14.28.3.7 void Timer::SetIntervalSeconds (uint32_t u32Seconds_)

SetIntervalSeconds.

! The next three cost u16 330 bytes of flash on AVR...

Set the timer expiry interval in seconds (platform agnostic)

Parameters

```
u32Seconds_ Time in seconds
```

Definition at line 88 of file timer.cpp.

14.28.3.8 void Timer::SetIntervalTicks (uint32_t u32Ticks_)

SetIntervalTicks.

Set the timer expiry in system-ticks (platform specific!)

Parameters

```
u32Ticks_ Time in ticks
```

Definition at line 80 of file timer.cpp.

14.28.3.9 void Timer::SetIntervalUSeconds (uint32_t u32USeconds_)

SetIntervalUSeconds.

Set the timer expiry interval in microseconds (platform agnostic)

Parameters

u32USeconds⇔	Time in microseconds
_	

Definition at line 100 of file timer.cpp.

```
14.28.3.10 void Timer::SetOwner ( Thread * pclOwner_ ) [inline]
```

SetOwner.

Set the owner-thread of this timer object (all timers must be owned by a thread).

Parameters

```
pclOwner_ Owner thread of this timer object
```

Definition at line 192 of file timer.h.

14.28.3.11 void Timer::SetTolerance (uint32_t u32Ticks_)

SetTolerance.

Set the timer's maximum tolerance in order to synchronize timer processing with other timers in the system.

Parameters

u32Ticks_	Maximum tolerance in ticks
-----------	----------------------------

Definition at line 106 of file timer.cpp.

14.28.3.12 void Timer::Start (bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_, void * pvData_)

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

Parameters

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32IntervalMs⇔	- Interval of the timer in miliseconds
_	
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

Definition at line 48 of file timer.cpp.

```
14.28.3.13 void Timer::Start ( bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_, TimerCallback_t pfCallback_, void * pvData_ )
```

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

Parameters

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32IntervalMs⇔	- Interval of the timer in miliseconds
_	
u32ToleranceMs	- Allow the timer expiry to be delayed by an additional maximum time, in order to have as
	many timers expire at the same time as possible.
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

Definition at line 67 of file timer.cpp.

```
14.28.3.14 void Timer::Stop ( )
```

Stop.

Stop a timer already in progress. Has no effect on timers that have already been stopped.

Definition at line 74 of file timer.cpp.

The documentation for this class was generated from the following files:


- /home/vm/mark3/trunk/embedded/kernel/public/timer.h
- /home/vm/mark3/trunk/embedded/kernel/timer.cpp

14.29 TimerList Class Reference

TimerList class - a doubly-linked-list of timer objects.

```
#include <timerlist.h>
```

Inheritance diagram for TimerList:



Public Member Functions

• void Init ()

Init.

void Add (Timer *pclListNode)

Ada

void Remove (Timer *pclListNode_)

Remove.

• void Process ()

Process.

Private Attributes

uint32_t m_u32NextWakeup

The time (in system clock ticks) of the next wakeup event.

· bool m bTimerActive

Whether or not the timer is active.

Additional Inherited Members

14.29.1 Detailed Description

TimerList class - a doubly-linked-list of timer objects.

Definition at line 37 of file timerlist.h.

14.29.2 Member Function Documentation

14.29.2.1 void TimerList::Add (Timer * pclListNode_)

Add.

Add a timer to the TimerList.

Parameters

pclListNode Pointer to the Timer to Add

Definition at line 56 of file timerlist.cpp.

14.29.2.2 void TimerList::Init (void)

Init.

Initialize the TimerList object. Must be called before using the object.

Definition at line 49 of file timerlist.cpp.

14.29.2.3 void TimerList::Process (void)

Process.

Process all timers in the timerlist as a result of the timer expiring. This will select a new timer epoch based on the next timer to expire. ToDo - figure out if we need to deal with any overtime here.

Definition at line 121 of file timerlist.cpp.

14.29.2.4 void TimerList::Remove (Timer * pclListNode_)

Remove.

Remove a timer from the TimerList, cancelling its expiry.

Parameters

pclListNode_ Pointer to the Timer to remove

Definition at line 104 of file timerlist.cpp.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/timerlist.h
- /home/vm/mark3/trunk/embedded/kernel/timerlist.cpp

14.30 TimerScheduler Class Reference

"Static" Class used to interface a global TimerList with the rest of the kernel.

#include <timerscheduler.h>

Static Public Member Functions

• static void Init ()

Init.

static void Add (Timer *pclListNode_)

Add.

• static void Remove (Timer *pclListNode_)

Remove.

static void Process ()

Process.

Static Private Attributes

static TimerList m_clTimerList

TimerList object manipu32ated by the Timer Scheduler.

14.30.1 Detailed Description

"Static" Class used to interface a global TimerList with the rest of the kernel.

Definition at line 38 of file timerscheduler.h.

14.30.2 Member Function Documentation

14.30.2.1 static void TimerScheduler::Add (Timer * pclListNode_) [inline], [static]

Add.

Add a timer to the timer scheduler. Adding a timer implicitly starts the timer as well.

Parameters

```
pclListNode_ Pointer to the timer list node to add
```

Definition at line 57 of file timerscheduler.h.

```
14.30.2.2 static void TimerScheduler::Init ( void ) [inline], [static]
```

Init.

Initialize the timer scheduler. Must be called before any timer, or timer-derived functions are used.

Definition at line 47 of file timerscheduler.h.

```
14.30.2.3 static void TimerScheduler::Process (void ) [inline], [static]
```

Process.

This function must be called on timer expiry (from the timer's ISR context). This will result in all timers being updated based on the epoch that just elapsed. The next timer epoch is set based on the next Timer object to expire.

Definition at line 79 of file timerscheduler.h.

```
14.30.2.4 static void TimerScheduler::Remove ( Timer * pclListNode_ ) [inline], [static]
```

Remove.

Remove a timer from the timer scheduler. May implicitly stop the timer if this is the only active timer scheduled.

Parameters

```
pclListNode_ Pointer to the timer list node to remove
```

Definition at line 68 of file timerscheduler.h.

The documentation for this class was generated from the following files:

- /home/vm/mark3/trunk/embedded/kernel/public/timerscheduler.h
- /home/vm/mark3/trunk/embedded/kernel/timerlist.cpp

Chapter 15

File Documentation

15.1 /home/vm/mark3/trunk/embedded/kernel/atomic.cpp File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "atomic.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

15.1.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.cpp.

15.2 atomic.cpp

```
00001 /*=
00002
00003
00004
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "atomic.h"
00024 #include "threadport.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_ATOMIC_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL_USE_ATOMIC
```

118 File Documentation

```
00039 //---
00040 uint8_t Atomic::Set( uint8_t *pu8Source_, uint8_t u8Val_ )
00041 {
00042
          uint8 t u8Ret;
00043
         CS ENTER();
         u8Ret = *pu8Source_;
00044
00045
         *pu8Source_ = u8Val_;
00046
         CS_EXIT();
00047
         return u8Ret;
00048 }
00049 //-
00050 uint16_t Atomic::Set( uint16_t *pu16Source_, uint16_t u16Val_ )
00051 {
00052
          uint16_t u16Ret;
00053
         CS_ENTER();
         u16Ret = *pu16Source_;
00054
00055
         *pul6Source_ = ul6Val_;
         CS_EXIT();
00056
00057
         return u16Ret;
00058 }
00059 //---
00060 uint32_t Atomic::Set( uint32_t *pu32Source_, uint32_t u32Val_ )
00061 {
00062
         uint32_t u32Ret;
00063
         CS_ENTER();
00064
         u32Ret = *pu32Source_;
00065
         *pu32Source_ = u32Val_;
00066
         CS_EXIT();
00067
         return u32Ret:
00068 }
00069
00070 //----
00071 uint8_t Atomic::Add( uint8_t *pu8Source_, uint8_t u8Val_ )
00072 {
00073
         uint8_t u8Ret;
00074
         CS ENTER();
00075
         u8Ret = *pu8Source_;
00076
          *pu8Source_ += u8Val_;
00077
         CS_EXIT();
00078
         return u8Ret;
00079 }
00080
00081 //----
00082 uint16_t Atomic::Add( uint16_t *pu16Source_, uint16_t u16Val_ )
00083 {
00084
         uint16_t u16Ret;
00085
         CS_ENTER();
00086
         u16Ret = *pu16Source_;
00087
         *pu16Source_ += u16Val_;
00088
         CS_EXIT();
00089
         return u16Ret;
00090 }
00091
00092 //----
00093 uint32_t Atomic::Add( uint32_t *pu32Source_, uint32_t u32Val_ )
00094 {
00095
         uint32_t u32Ret;
00096
         CS_ENTER();
00097
         u32Ret = *pu32Source_;
         *pu32Source_ += u32Val_;
00098
00099
         CS EXIT();
00100
         return u32Ret;
00101 }
00102
00103 //----
00104 uint8_t Atomic::Sub( uint8_t *pu8Source_, uint8_t u8Val_ )
00105 {
00106
         uint8 t u8Ret:
00107
         CS_ENTER();
00108
         u8Ret = *pu8Source_;
00109
          *pu8Source_ -= u8Val_;
00110
         CS_EXIT();
00111
         return u8Ret;
00112 }
00113
00114 //---
00115 uint16_t Atomic::Sub( uint16_t *pu16Source_, uint16_t u16Val_ )
00116 {
00117
         uint16 t u16Ret:
00118
         CS_ENTER();
         u16Ret = *pu16Source_;
00119
00120
          *pul6Source_ -= ul6Val_;
00121
         CS_EXIT();
00122
          return u16Ret;
00123 }
00124
```

```
00126 uint32_t Atomic::Sub( uint32_t *pu32Source_, uint32_t u32Val_ )
00127 {
00128
          uint32 t u32Ret;
00129
         CS_ENTER();
u32Ret = *pu32Source_;
00130
00131
          *pu32Source_ -= u32Val_;
00132
         CS_EXIT();
00133
         return u32Ret;
00134 }
00135
00136 //---
00137 bool Atomic::TestAndSet( bool *pbLock_ )
00138 {
00139
          uint8_t u8Ret;
00140
          CS_ENTER();
          u8Ret = *pbLock_;
00141
          if (!u8Ret)
00142
00143
00144
             *pbLock_ = 1;
00145
00146
          CS_EXIT();
00147
          return u8Ret;
00148 }
00149
00150 #endif // KERNEL_USE_ATOMIC
```

15.3 /home/vm/mark3/trunk/embedded/kernel/autoalloc.cpp File Reference

Automatic memory allocation for kernel objects.

```
#include "mark3cfg.h"
#include "autoalloc.h"
#include "threadport.h"
#include "kernel.h"
```

15.3.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.cpp.

15.4 autoalloc.cpp

```
00001 /
00002
00003
00004
00005
00006 |
00007
80000
      -[Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========== */
00020 #include "mark3cfg.h"
00021 #include "autoalloc.h"
00022 #include "threadport.h"
00023 #include "kernel.h"
00024
00025 #if KERNEL USE AUTO ALLOC
00026
00027 // Align to nearest word boundary
00028 \#define ALLOC_ALIGN(x) ( ((x) + (sizeof(K_ADDR)-1)) & (sizeof(K_ADDR) - 1) )
00029
00030 //----
00031 uint8_t AutoAlloc::m_au8AutoHeap[ AUTO_ALLOC_SIZE ];
00032 K_ADDR AutoAlloc::m_aHeapTop;
00033
00034 //---
```

120 File Documentation

```
00035 void AutoAlloc::Init(void)
00037
          m_aHeapTop = (K_ADDR) (m_au8AutoHeap);
00038 }
00039
00040 //-
00041 void *AutoAlloc::Allocate( uint16_t u16Size_ )
00042 {
00043
          void *pvRet = 0;
00044
00045
          CS ENTER();
          uint16_t u16AllocSize = ALLOC_ALIGN(u16Size_);
00046
          if ((((K_ADDR)m_aHeapTop - (K_ADDR)&m_au8AutoHeap[0]) + u16AllocSize) < AUTO_ALLOC_SIZE)</pre>
00047
00048
00049
              pvRet = (void*)m_aHeapTop;
00050
              m_aHeapTop += u16AllocSize;
00051
00052
          CS EXIT();
00053
00054
          if (!pvRet)
00055
00056
              Kernel::Panic(PANIC_AUTO_HEAP_EXHUSTED);
00057
00058
00059
          return pvRet;
00060 }
00061
00062 #endif
```

15.5 /home/vm/mark3/trunk/embedded/kernel/blocking.cpp File Reference

Implementation of base class for blocking objects.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.5.1 Detailed Description

Implementation of base class for blocking objects.

Definition in file blocking.cpp.

15.6 blocking.cpp

```
00001 /
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ======
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 #include "blocking.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]-----
```

```
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 # error "Debug logging file token already defined! Bailing."
00033 #else
00034 # define DBG_FILE _DBG___KERNEL_BLOCKING_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_SEMAPHORE || KERNEL_USE_MUTEX
00040 //--
00041 void BlockingObject::Block(Thread *pclThread_)
00042 {
00043
         KERNEL_ASSERT( pclThread_ );
00044
         KERNEL_TRACE_1( "Blocking Thread %d", (uint16_t)pclThread_->
     GetID() );
00045
00046
          // Remove the thread from its current thread list (the "owner" list)
         // ... And add the thread to this object's block list
00048
         Scheduler::Remove(pclThread_);
00049
         m_clBlockList.Add(pclThread_);
00050
         // Set the "current" list location to the blocklist for this thread
00051
        pclThread_->SetCurrent(&m_clBlockList);
00052
         pclThread_->SetState(THREAD_STATE_BLOCKED);
00054 }
00055
00056 //--
00057 void BlockingObject::BlockPriority(Thread *pclThread_)
00058 {
         KERNEL_ASSERT( pclThread_ );
KERNEL_TRACE_1( "Blocking Thread %d", (uint16_t)pclThread_->
00059
     GetID() );
00061
00062
          // Remove the thread from its current thread list (the "owner" list)
00063
         // ... And add the thread to this object's block list
         Scheduler::Remove(pclThread_);
00064
00065
         m_clBlockList.AddPriority(pclThread_);
00066
00067
         // Set the "current" list location to the blocklist for this thread
00068
       pclThread_->SetCurrent(&m_clBlockList);
00069
         pclThread_->SetState(THREAD_STATE_BLOCKED);
00070 }
00071
00072 //--
00073 void BlockingObject::UnBlock(Thread *pclThread_)
00074 {
00075
         KERNEL_ASSERT( pclThread_ );
         KERNEL_TRACE_1( "Unblocking Thread %d", (uint16_t)pclThread_->
00076
     GetID() );
00077
00078
          // Remove the thread from its current thread list (the "owner" list)
00079
       pclThread_->GetCurrent()->Remove(pclThread_);
08000
00081
         // Put the thread back in its active owner's list. This is usually
         // the ready-queue at the thread's original priority.
00083
         Scheduler::Add(pclThread_);
00084
00085
         // Tag the thread's current list location to its owner
00086
         pclThread ->SetCurrent(pclThread ->GetOwner());
00087
         pclThread_->SetState(THREAD_STATE_READY);
00088 }
00090 #endif
```

15.7 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelprofile.cpp File Reference

ATMega328p Profiling timer implementation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

122 File Documentation

15.7.1 Detailed Description

ATMega328p Profiling timer implementation.

Definition in file kernelprofile.cpp.

15.8 kernelprofile.cpp

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022 #include "profile.h"
00023 #include "kernelprofile.h"
00024 #include "threadport.h"
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 #if KERNEL USE PROFILER
00029 uint32_t Profiler::m_u32Epoch;
00030
00031 //---
00032 void Profiler::Init()
00033 {
           TCCR0A = 0;
00034
           TCCROB = 0;
00035
00036
           TIFR0 = 0;
00037
           TIMSK0 = 0;
00038
           m_u32Epoch = 0;
00039 }
00040
00041 //----
00042 void Profiler::Start()
00043 {
00044
           TIFR0 = 0;
00045
           TCNT0 = 0;
           TCCR0B |= (1 << CS01);
TIMSK0 |= (1 << TOIE0);
00046
00047
00048 }
00049
00050 //--
00051 void Profiler::Stop()
00052 {
           TIFR0 = 0;
TCCR0B &= ~(1 << CS01);
00053
00054
           TIMSKO &= ~(1 << TOIE0);
00055
00056 }
00057 //---
00058 uint16_t Profiler::Read()
00059 {
           uint16_t u16Ret;
CS_ENTER();
TCCROB &= ~(1 << CSO1);
u16Ret = TCNT0;
00060
00061
00062
00063
00064
           \texttt{TCCR0B} |= (1 << \texttt{CS01});
00065
           CS EXIT():
           return u16Ret;
00066
00067 }
00068
00070 void Profiler::Process()
00071 {
           CS_ENTER();
00072
00073
           m u32Epoch++;
00074
           CS_EXIT();
00075 }
```

15.9 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kernelswi.cpp File Reference

Kernel Software interrupt implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kernelswi.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

15.9.1 Detailed Description

Kernel Software interrupt implementation for ATMega328p.

Definition in file kernelswi.cpp.

15.10 kernelswi.cpp

```
00001 /*----
00002
00003
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-----
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #include "kernelswi.h"
00024
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 //---
00029 void KernelSWI::Config(void)
00030 {
00031
          PORTD &= \sim 0 \times 04; // Clear INTO
          DDRD |= 0x04;  // Set PortD, bit 2 (INTO) As Output
EICRA |= (1 << ISC00) | (1 << ISC01);  // Rising edge on INTO
00032
00033
00034 }
00035
00036 //---
00037 void KernelSWI::Start(void)
00038 {
                                  // Clear any pending interrupts on INTO
// Enable INTO interrupt (as int32_t as I-bit is set)
00039
          EIFR &= \sim (1 << INTF0);
00040
          EIMSK \mid = (1 << INT0);
00041 }
00042
00043 //-
00044 void KernelSWI::Stop(void)
00045 {
00046
          EIMSK &= \sim (1 << INT0);
                                     // Disable INTO interrupts
00047 }
00048
00049 //-
00050 uint8_t KernelSWI::DI()
00051 {
```

124 File Documentation

```
bool bEnabled = ((EIMSK & (1 << INTO)) != 0);</pre>
00053
          EIMSK &= \sim (1 << INT0);
00054
           return bEnabled;
00055 }
00056
00057 //--
00058 void KernelSWI::RI(bool bEnable_)
00059 {
00060
           if (bEnable_)
00061
               EIMSK \mid = (1 << INTO);
00062
00063
00064
          else
00065
          {
00066
               EIMSK &= \sim (1 << INT0);
00067
00068 }
00069
00071 void KernelSWI::Clear(void)
00072 {
00073
          EIFR &= \sim (1 << INTF0);
                                      // Clear the interrupt flag for INTO
00074 }
00075
00076 //-
00077 void KernelSWI::Trigger(void)
00078 {
00079
           //if(Thread_IsSchedulerEnabled())
08000
00081
               PORTD &= \sim 0 \times 0.4;
00082
               PORTD I = 0 \times 04;
00083
00084 }
```

15.11 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/kerneltimer.cpp File Reference

Kernel Timer Implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kerneltimer.h"
#include "mark3cfg.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

15.11.1 Detailed Description

Kernel Timer Implementation for ATMega328p.

Definition in file kerneltimer.cpp.

15.12 kerneltimer.cpp

15.12 kerneltimer.cpp 125

```
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 #define TCCR1B INIT
                             ((1 << ....
(1 << OCIE1A)
                               ((1 << WGM12) | (1 << CS12))
00029 #define TIMER_IMSK
                           (1 << OCIE1.
(1 << OCF1A)
00030 #define TIMER_IFR
00032 //---
00033 void KernelTimer::Config(void)
00034 {
00035
         TCCR1B = TCCR1B INIT;
00036 }
00037
00038 //----
00039 void KernelTimer::Start(void)
00040 {
00044 #else
00045
        TCCR1B |= (1 << CS12);
00046 #endif
00047
00048
         TCNT1 = 0;
TIFR1 &= ~TIMER_IFR;
00049
00050
         TIMSK1 |= TIMER_IMSK;
00051 }
00052
00053 //---
00054 void KernelTimer::Stop(void)
00055 {
00056 #if KERNEL_TIMERS_TICKLESS
00057 TIFR1 &= ~TIMER_IFR;
00058
         TIMSK1 &= ~TIMER_IMSK;
         TCCR1B &= ~(1 << CS12);
00059
                                    // Disable count...
         TCNT1 = 0;
00060
00061
        OCR1A = 0;
00062 #endif
00063 }
00064
00065 //----
00066 uint16_t KernelTimer::Read(void)
00067 {
00068 #if KERNEL_TIMERS_TICKLESS
      volatile uint16_t u16Read1;
00069
00070
         volatile uint16_t u16Read2;
00071
00072
            u16Read1 = TCNT1;
00073
             u16Read2 = TCNT1;
00074
         } while (u16Read1 != u16Read2);
00076
00077
         return u16Read1;
00078 #else
00079
       return 0;
00080 #endif
00081 }
00082
00083 //----
00084 uint32_t KernelTimer::SubtractExpiry(uint32_t u32Interval_)
00085 {
00086 #if KERNEL_TIMERS_TICKLESS
00087 OCR1A -= (uint16_t)u32Interval_;
00088
         return (uint32_t)OCR1A;
00089 #else
00090
        return 0;
00091 #endif
00092 }
00093
00094 //--
00095 uint32_t KernelTimer::TimeToExpiry(void)
00096 {
00097 #if KERNEL_TIMERS_TICKLESS
         uint16_t u16Read = KernelTimer::Read();
00098
         uint16_t u160CR1A = OCR1A;
00099
00100
00101
         if (u16Read >= u16OCR1A)
00102
         {
00103
             return 0:
         }
00104
00105
         else
00106
         {
00107
             return (uint32_t) (u160CR1A - u16Read);
00108
00109 #else
00110
       return 0;
00111 #endif
```

126 File Documentation

```
00112 }
00114 //--
00115 uint32_t KernelTimer::GetOvertime(void)
00116 {
          return KernelTimer::Read();
00117
00119
00120 //---
00121 uint32_t KernelTimer::SetExpiry(uint32_t u32Interval_)
00122 {
00123 #if KERNEL_TIMERS_TICKLESS
       uint16_t u16SetInterval;
00124
00125
          if (u32Interval_ > 65535)
00126
00127
              u16SetInterval = 65535;
00128
00129
          else
00130
00131
              u16SetInterval = (uint16_t)u32Interval_ ;
00132
00133
        OCR1A = u16SetInterval;
00134
          return (uint32_t)u16SetInterval;
00135
00136 #else
00137
00138 #endif
00139 }
00140
00141 //-----
00142 void KernelTimer::ClearExpiry(void)
00144 #if KERNEL_TIMERS_TICKLESS
00145
        OCR1A = 65535;
                                        // Clear the compare value
00146 #endif
00147 }
00148
00150 uint8_t KernelTimer::DI(void)
00151 {
00152 #if KERNEL_TIMERS_TICKLESS
00153 bool bEnabled = ((TIMSK1 & (TIMER_IMSK)) != 0);

00154 TIFR1 &= ~TIMER_IFR; // Clear interrupt flags

00155 TIMSK1 &= ~TIMER_IMSK; // Disable interrupt
00156
          return bEnabled;
00157 #else
00158
         return 0:
00159 #endif
00160 }
00161
00162 //---
00163 void KernelTimer::EI(void)
00164 {
00165
          KernelTimer::RI(0);
00166 }
00167
00169 void KernelTimer::RI(bool bEnable_)
00170 {
00171 #if KERNEL_TIMERS_TICKLESS
00172 if (bEnable_)
00173 {
              TIMSK1 |= (1 << OCIE1A);  // Enable interrupt</pre>
        }
else
{
00175
00176
00177
00178
              TIMSK1 &= \sim (1 << OCIE1A);
00179
00180 #endif
00181 }
```

15.13 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelprofile.h File Reference

Profiling timer hardware interface.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

15.14 kernelprofile.h

Classes

· class Profiler

System profiling timer interface.

15.13.1 Detailed Description

Profiling timer hardware interface.

Definition in file kernelprofile.h.

15.14 kernelprofile.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ----- */
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022 #include "11.h"
00023
00024 #ifndef ___KPROFILE_H__
00025 #define ___KPROFILE_H_
00026
00027 #if KERNEL_USE_PROFILER
00028
00029 //----
00030 #define TICKS_PER_OVERFLOW
00031 #define CLOCK DIVIDE
                                             (8)
00033 //---
00037 class Profiler
00038 {
00039 public:
00046
         static void Init();
00047
00053
         static void Start();
00054
00060
         static void Stop();
00061
         static uint16_t Read();
00067
00068
00074
         static void Process();
00075
00081
         static uint32_t GetEpoch() { return m_u32Epoch; }
00082 private:
00083
00084
         static uint32_t m_u32Epoch;
00085 };
00086
00087 #endif //KERNEL_USE_PROFILER
00088
00089 #endif
00090
```

15.15 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kernelswi.h File Reference

Kernel Software interrupt declarations.

```
#include "kerneltypes.h"
```

Classes

class KernelSWI

Class providing the software-interrupt required for context-switching in the kernel.

15.15.1 Detailed Description

Kernel Software interrupt declarations.

Definition in file kernelswi.h.

15.16 kernelswi.h

```
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00023 #include "kerneltypes.h"
00024 #ifndef ___KERNELSWI_H_
00025 #define ___KERNELSWI_H_
00026
00027 //-
00032 class KernelSWI
00033 {
00034 public:
00041
          static void Config(void);
00042
00048
          static void Start (void);
00049
00055
          static void Stop(void);
00056
00062
          static void Clear (void);
00063
00070
          static void Trigger (void);
00071
00079
          static uint8_t DI();
08000
88000
          static void RI(bool bEnable_);
00089 };
00090
00091
00092 #endif // __KERNELSIW_H_
```

15.17 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/kerneltimer.h File Reference

Kernel Timer Class declaration.

```
#include "kerneltypes.h"
```

Classes

class KernelTimer

Hardware timer interface, used by all scheduling/timer subsystems.

15.18 kerneltimer.h

15.17.1 Detailed Description

Kernel Timer Class declaration.

Definition in file kerneltimer.h.

15.18 kerneltimer.h

```
00001 /
00002
00003
00004
00005
00006
00007
80000
00009
       -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ==========
00021 #include "kerneltypes.h"
00022 #ifndef __KERNELTIMER_H_
00023 #define __KERNELTIMER_H_
00024
00025 //---
00026 #define SYSTEM_FREQ
                                  ((uint32_t)16000000)
00027 #define TIMER_FREQ
                                 ((uint32_t)(SYSTEM_FREQ / 256)) // Timer ticks per second...
00028
00029 //
00033 class KernelTimer
00034 {
00035 public:
00041
          static void Config(void);
00042
00048
          static void Start (void);
00049
00055
          static void Stop(void);
00056
00062
          static uint8_t DI (void);
00063
00071
          static void RI(bool bEnable_);
00072
00078
          static void EI(void);
00079
00090
          static uint32_t SubtractExpiry(uint32_t u32Interval_);
00091
00100
          static uint32_t TimeToExpiry(void);
00101
00110
          static uint32_t SetExpiry(uint32_t u32Interval_);
00111
          static uint32 t GetOvertime (void);
00120
00121
00127
          static void ClearExpiry(void);
00128
00129 private:
00137
          static uint16_t Read(void);
00138
00139 };
00140
00141 #endif //__KERNELTIMER_H_
```

15.19 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/public/threadport.h File Reference

ATMega328p Multithreading support.

```
#include "kerneltypes.h"
#include "thread.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

Classes

· class ThreadPort

Class defining the architecture specific functions required by the kernel.

Macros

• #define ASM(x) asm volatile(x);

ASM Macro - simplify the use of ASM directive in C.

• #define SR 0x3F

Status register define - map to 0x003F.

• #define SPH_ 0x3E

Stack pointer define.

• #define TOP_OF_STACK(x, y) (uint8_t*) (((uint16_t)x) + (y-1))

Macro to find the top of a stack given its size and top address.

#define PUSH_TO_STACK(x, y) *x = y; x--;

Push a value y to the stack pointer x and decrement the stack pointer.

#define Thread_SaveContext()

Save the context of the Thread.

• #define Thread RestoreContext()

Restore the context of the Thread.

• #define CS_ENTER()

These macros must be used in pairs!

• #define CS_EXIT()

Exit critical section (restore status register)

• #define ENABLE_INTS() ASM("sei");

Initiate a contex switch without using the SWI.

15.19.1 Detailed Description

ATMega328p Multithreading support.

Definition in file threadport.h.

15.19.2 Macro Definition Documentation

```
15.19.2.1 #define CS_ENTER( )
```

Value:

```
{ \
volatile uint8_t x; \
x = _SFR_IO8(SR_); \
ASM("cli");
```

These macros *must* be used in pairs!

Enter critical section (copy status register, disable interrupts)

Definition at line 142 of file threadport.h.

15.20 threadport.h

15.20 threadport.h

```
00001 /*-----
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #ifndef ___THREADPORT_H_
00022 #define __THREADPORT_H_
00023
00024 #include "kerneltypes.h"
00025 #include "thread.h"
00026
00027 #include <avr/io.h>
00028 #include <avr/interrupt.h>
00029
00030 //----
00032 #define ASM(x)
                          asm volatile(x);
00033 #define SR_
                            0x3F
00035 #define SPH_
                            0x3E
00037 #define SPL_
                            0x3D
00038
00039
00040 //----
00042 #define TOP_OF_STACK(x, y)
                                        (uint8_t*) ( ((uint16_t)x) + (y-1) )
00043 #define PUSH_TO_STACK(x, y)
                                             *x = y; x--;
00045
00046 //--
00048 #define Thread_SaveContext() \
00049 ASM("push r0"); \
00050 ASM("in r0, __SREG__"); \
00051 ASM("cli"); \
00051 ASM(CII), (
00052 ASM("push r0");
00053 ASM("push r1");
00054 ASM("clr r1");
00055 ASM("push r2");
00056 ASM("push r3");
00057 ASM("push r4");
00058 ASM("push r5");
00059 ASM("push r6");
00060 ASM("push r7");
00061 ASM("push r8");
00062 ASM("push r9");
00063 ASM("push r10");
00064 ASM("push r11");
00065 ASM("push r12");
00066 ASM("push r13");
00067 ASM("push r14");
00068 ASM("push r15");
00069 ASM("push r16");
00070 ASM("push r17");
00071 ASM("push r18");
00072 ASM("push r19");
00073 ASM("push r20");
00074 ASM("push r21");
00075 ASM("push r22");
00076 ASM("push r23");
00077 ASM("push r24");
00078 ASM("push r25");
00079 ASM("push r26");
00080 ASM("push r27");
00081 ASM("push r28");
00082 ASM("push r29");
00083 ASM("push r30");
00084 ASM("push r31");
00085 ASM("lds r26, g_pclCurrent");
00086 ASM("lds r27, g_pclCurrent + 1"); \
00087 ASM("adiw r26, 4");
00088 ASM("in
                r0, 0x3D");
                x+, r0"); \
r0, 0x3E"); \
x+, r0");
00089 ASM("st
00090 ASM("in
00091 ASM("st
00092
00093 //----
00095 #define Thread_RestoreContext() \
00096 ASM("lds r26, g_pclCurrent"); \
00097 ASM("lds r27, g_pclCurrent + 1"); \
00098 ASM("adiw r26, 4"); \
```

```
r28, x+"); \
00099 ASM("ld
00100 ASM("out 0x3D, r28"); \
00101 ASM("ld
                 r29, x+");
00102 ASM("out 0x3E, r29"); \
00103 ASM("pop r31");
00104 ASM("pop r30");
00105 ASM("pop r29");
00106 ASM("pop r28");
00107 ASM("pop r27");
00108 ASM("pop r26");
00109 ASM("pop r25");
00110 ASM("pop r24");
00111 ASM("pop r23");
00112 ASM("pop r22");
00113 ASM("pop r21");
00114 ASM("pop r20");
00115 ASM("pop r19");
00116 ASM("pop r18");
00117 ASM("pop r17");
00118 ASM("pop r16");
00119 ASM("pop r15");
00120 ASM("pop r14");
00121 ASM("pop r13");
00122 ASM("pop r12");
00123 ASM("pop r11");
00124 ASM("pop r10");
00125 ASM("pop r9");
00126 ASM("pop r8");
00127 ASM("pop r7");
00128 ASM("pop r6");
00129 ASM("pop r5");
00130 ASM("pop r4");
00131 ASM("pop r3");
00132 ASM("pop r2");
00133 ASM("pop r1");
00134 ASM("pop r0"); \
00135 ASM("out __SREG__, r0"); \
00136 ASM("pop r0");
00137
00138 //----
00140 //-----
00142 #define CS ENTER()
00143 { \
00144 volatile uint8_t x; \
00145 x = _SFR_IO8(SR_); \
00146 ASM("cli");
00147 //----
00149 #define CS_EXIT() \
00150 _SFR_IO8(SR_) = x;\
00151 }
00153 //----
00155 #define ENABLE_INTS() ASM("sei");
00156 #define DISABLE_INTS() ASM("cli");
00157
00158 //-
00159 class Thread;
00167 class ThreadPort
00168 {
00169 public:
00175 static void StartThreads();
00176 friend class Thread;
00177 private:
00178
00186
         static void InitStack(Thread *pstThread_);
00187 };
00188
00189 #endif //__ThreadPORT_H_
```

15.21 /home/vm/mark3/trunk/embedded/kernel/cpu/avr/atmega328p/gcc/threadport.cpp File Reference

ATMega328p Multithreading.

15.22 threadport.cpp 133

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "threadport.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernel.h"
#include "kernelaware.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

Functions

ISR (TIMER1_COMPA_vect)

ISR(TIMER1_COMPA_vect) Timer interrupt ISR - causes a tick, which may cause a context switch.

15.21.1 Detailed Description

ATMega328p Multithreading.

Definition in file threadport.cpp.

15.22 threadport.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024 #include "thread.h"
00025 #include "threadport.h"
00026 #include "kernelswi.h"
00027 #include "kerneltimer.h"
00028 #include "timerlist.h
00029 #include "quantum.h"
00030 #include "kernel.h"
00031 #include "kernelaware.h"
00032 #include <avr/io.h>
00033 #include <avr/interrupt.h>
00034
00035 //--
00036 Thread *g_pclCurrentThread;
00037
00038 //--
00039 void ThreadPort::InitStack(Thread *pclThread_)
00040 {
00041
          // Initialize the stack for a Thread
00042
          uint16_t u16Addr;
00043
         uint8_t *pu8Stack;
00044
         uint16_t i;
00045
00046
          // Get the address of the thread's entry function
         u16Addr = (uint16_t) (pclThread_->m_pfEntryPoint);
```

```
00049
            // Start by finding the bottom of the stack
00050
           pu8Stack = (uint8_t*)pclThread_->m_pwStackTop;
00051
           // clear the stack, and initialize it to a known-default value (easier // to debug when things go sour with stack corruption or overflow) for (i = 0; i < pclThread_->m_u16StackSize; i++)
00052
00053
00054
00055
00056
                pclThread_->m_pwStack[i] = 0xFF;
00057
00058
00059
            // Our context starts with the entry function
           PUSH_TO_STACK(pu8Stack, (uint8_t)(u16Addr & 0x00FF));
PUSH_TO_STACK(pu8Stack, (uint8_t)((u16Addr >> 8) & 0x00FF));
00060
00061
00062
00063
00064
           PUSH TO STACK (pu8Stack, 0x00);
                                                 // RO
00065
00066
            // Push status register and R1 (which is used as a constant zero)
           PUSH_TO_STACK(pu8Stack, 0x80); // SR
PUSH_TO_STACK(pu8Stack, 0x00); // R1
00067
00068
00069
00070
           // Push other registers for (i = 2; i <= 23; i++) //R2-R23
00071
00072
           {
00073
                PUSH_TO_STACK(pu8Stack, i);
00074
00075
      // Assume that the argument is the only stack variable
PUSH_TO_STACK(pu8Stack, (uint8_t)(((uint16_t)(pc1Thread_->
m_pvArg)) & 0x00FF)); //R24
00076
00077
      PUSH_TO_STACK(pu8Stack, (uint8_t)((((uint16_t)(pclThread_-> m_pvArg))>>8) & 0x00FF)); //R25
00078
00079
           // Push the rest of the registers in the context for (i = 26; i <=31; i++)
08000
00081
00082
           {
00083
                PUSH_TO_STACK(pu8Stack, i);
00084
00085
           // Set the top o' the stack.
00086
           pclThread_->m_pwStackTop = (uint8_t*)pu8Stack;
00087
00088
00089
           // That's it! the thread is ready to run now.
00090 }
00091
00092 //----
00093 static void Thread_Switch(void)
00094 {
00095 #if KERNEL_USE_IDLE_FUNC
00096
           // If there's no next-thread-to-run...
00097
           if (g_pclNext == Kernel::GetIdleThread())
00098
00099
                g_pclCurrent = Kernel::GetIdleThread();
00100
00101
                // Disable the SWI, and re-enable interrupts -- enter nested interrupt
00102
                 // mode.
00103
                KernelSWI::DI();
00104
00105
                uint8_t u8SR = \_SFR_IO8(SR_);
00106
00107
                // So long as there's no "next-to-run" thread, keep executing the Idle
00108
                // function to conclusion...
00109
00110
                while (g_pclNext == Kernel::GetIdleThread())
00111
                    \ensuremath{//} Ensure that we run this block in an interrupt enabled context (but
00112
00113
                    // with the rest of the checks being performed in an interrupt disabled
                    // context).
00114
00115
                    ASM( "sei" );
00116
                    Kernel::IdleFunc();
                    ASM( "cli" );
00117
00118
                }
00119
                // Progress has been achieved -- an interrupt-triggered event has caused
00120
00121
                // the scheduler to run, and choose a new thread. Since we've already
00122
                // saved the context of the thread we've hijacked to run idle, we can
00123
                /\!/ proceed to disable the nested interrupt context and switch to the /\!/ new thread.
00124
00125
00126
                 SFR IO8(SR) = u8SR;
00127
                KernelSWI::RI( true );
00128
00129 #endif
00130
           g_pclCurrent = (Thread*)g_pclNext;
00131 }
00132
```

```
00133
00134 //---
00135 void ThreadPort::StartThreads()
00136 {
       KernelSWI::Config();
KernelTT'
      00137
00138
00139
      Scheduler::SetScheduler(1);  // enable the scheduler
Scheduler::Schedule();  // run the scheduler - determine the first
00140
00141
thread to run 00142
00143
                                    // Set the next scheduled thread to the current thread
       Thread Switch():
00144
                               // enable the kernel timer
       KernelTimer::Start();
00145
00146
       KernelSWI::Start();
                                     // enable the task switch SWI
00147
       00148
00149
00150
00151 }
00152
00153 //-----
00158 //-----
00159 ISR(INTO_vect) __attribute__ ( ( signal, naked ) );
00160 ISR(INTO_vect)
00161 {
O0162 Thread_SaveContext(); // Push the context (registers) of the current task
O0163 Thread_Switch(); // Switch to the next task
O0164 Thread_RestoreContext(); // Pop the context (registers) of the next task
O0165 ASM("reti"); // Return to the next task
00166 }
00167
00168 //-----
00173 //----
00174 ISR(TIMER1_COMPA_vect)
00175 {
00176 #if KERNEL_USE_TIMERS
     TimerScheduler::Process();
00179 #if KERNEL_USE_QUANTUM
00180
      Quantum::UpdateTimer();
00181 #endif
00182 }
```

15.23 /home/vm/mark3/trunk/embedded/kernel/driver.cpp File Reference

Device driver/hardware abstraction layer.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "driver.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Classes

class DevNull

This class implements the "default" driver (/dev/null)

Functions

static uint8_t DrvCmp (const char *szStr1_, const char *szStr2_)
 DrvCmp.

Variables

• static DevNull clDevNull

Default driver included to allow for run-time "stubbing".

15.23.1 Detailed Description

Device driver/hardware abstraction layer.

Definition in file driver.cpp.

15.23.2 Function Documentation

```
15.23.2.1 static uint8_t DrvCmp ( const char * szStr1_, const char * szStr2_ ) [static]
```

DrvCmp.

String comparison function used to compare input driver name against a known driver name in the existing driver list

Parameters

szStr1_	user-specified driver name
szStr2_	name of a driver, provided from the driver table

Returns

1 on match, 0 on no-match

Definition at line 81 of file driver.cpp.

15.24 driver.cpp

```
00001 /*===
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "driver.h"
00024
00025 #define CAN HAS DEBUG
00026 //--[Autogenerated - Do Not Modify]-----
00027 #include "dbg_file_list.h"
00028 #include "buffalogger.h"
00029 #if defined(DBG_FILE)
00030 # error "Debug logging file token already defined! Bailing."
00031 #else
00032 # define DBG_FILE _DBG___KERNEL_DRIVER_CPP
00033 #endif
00034 //--[End Autogenerated content]-----
00035
00036 #include "kerneldebug.h"
00037
00038 //---
00039 #if KERNEL_USE_DRIVER
00040
00041 DoubleLinkList DriverList::m_clDriverList;
00042
00046 class DevNull : public Driver 00047 {
00048 public:
00049
         virtual void Init() { SetName("/dev/null"); };
00050
          virtual uint8_t Open() { return 0; }
```

```
virtual uint8_t Close() { return 0; }
00052
00053
          virtual uint16_t Read( uint16_t u16Bytes_,
00054
          uint8_t *pu8Data_) { return 0; }
00055
00056
          virtual uint16_t Write( uint16_t u16Bytes_,
         uint8_t *pu8Data_) { return 0; }
00058
00059
          virtual uint16_t Control( uint16_t u16Event_,
00060
              void *pvDataIn_,
00061
              uint16_t u16SizeIn_,
00062
              void *pvDataOut .
00063
              uint16_t u16SizeOut_ ) { return 0; }
00064
00065 };
00066
00067 //----
00068 static DevNull clDevNull;
00081 static uint8_t DrvCmp( const char *szStr1_, const char *szStr2_)
00082 {
          char *szTmp1 = (char*) szStr1_;
char *szTmp2 = (char*) szStr2_;
00083
00084
00085
          while (*szTmp1 && *szTmp2)
00087
00088
              if (*szTmp1++ != *szTmp2++)
00089
              {
00090
                  return 0:
00091
              }
00092
         }
00093
00094
          // Both terminate at the same length
00095
          if (!(*szTmp1) && !(*szTmp2))
00096
00097
              return 1;
00099
00100
         return 0;
00101 }
00102
00103 //--
00104 void DriverList::Init()
00105 {
00106
          \ensuremath{//} Ensure we always have at least one entry - a default in case no match
00107
          // is found (/dev/null)
         clDevNull.Init();
00108
00109
          Add(&clDevNull);
00110 }
00111
00112 //----
00113 Driver *DriverList::FindByPath( const char *m_pcPath )
00114 {
          KERNEL_ASSERT( m_pcPath );
00115
          Driver *pclTemp = static_cast<Driver*>(m_clDriverList.
00116
00117
00118
          // Iterate through the list of drivers until we find a match, or we
00119
          // exhaust our list of installed drivers
00120
          while (pclTemp)
00121
00122
              if (DrvCmp (m_pcPath, pclTemp->GetPath()))
00123
              {
00124
                  return pclTemp;
00125
              pclTemp = static_cast<Driver*>(pclTemp->GetNext());
00126
00127
00128
         // No matching driver found - return a pointer to our /dev/null driver
          return &clDevNull;
00130 }
00131
00132 #endif
```

15.25 /home/vm/mark3/trunk/embedded/kernel/eventflag.cpp File Reference

Event Flag Blocking Object/IPC-Object implementation.

```
#include "mark3cfg.h"
#include "blocking.h"
#include "kernel.h"
#include "thread.h"
#include "eventflag.h"
#include "kernelaware.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "timerlist.h"
```

Functions

void TimedEventFlag_Callback (Thread *pclOwner_, void *pvData_)
 TimedEventFlag_Callback.

15.25.1 Detailed Description

Event Flag Blocking Object/IPC-Object implementation.

Definition in file eventflag.cpp.

15.25.2 Function Documentation

```
15.25.2.1 void TimedEventFlag_Callback ( Thread * pclOwner_, void * pvData_ )
```

TimedEventFlag_Callback.

This function is called whenever a timed event flag wait operation fails in the time provided. This function wakes the thread for which the timeout was requested on the blocking call, sets the thread's expiry flags, and reschedules if necessary.

Parameters

pclOwner_	Thread to wake
pvData_	Pointer to the event-flag object

Definition at line 53 of file eventflag.cpp.

15.26 eventflag.cpp

```
00001 /*==
00002
00003
00004
00005
00006
00007
80000
00009
     --[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00019 #include "mark3cfg.h"
00020 #include "blocking.h"
00021 #include "kernel.h"
00022 #include "thread.h"
00023 #include "eventflag.h"
00024 #include "kernelaware.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
```

15.26 eventflag.cpp 139

```
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_EVENTFLAG_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL USE EVENTFLAG
00038
00039 #if KERNEL USE TIMEOUTS
00040 #include "timerlist.h'
00041 //--
00053 void TimedEventFlag_Callback(Thread *pclOwner_, void *pvData_)
00054 {
          EventFlag *pclEventFlag = static_cast<EventFlag*>(pvData_);
00055
00056
00057
         pclEventFlag->WakeMe(pclOwner_);
00058
         pclOwner_->SetExpired(true);
00059
          pclOwner_->SetEventFlagMask(0);
00060
00061
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      ()->GetCurPriority())
00062
         {
00063
              Thread::Yield();
00064
00065 }
00066
00067 //----
00068 void EventFlag::WakeMe(Thread *pclChosenOne_)
00069 {
00070
          UnBlock(pclChosenOne_);
00071 }
00072 #endif
00073
00074 //--
00075 #if KERNEL_USE_TIMEOUTS
00076
         uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
      EventFlagOperation_t eMode_, uint32_t u32TimeMS_)
00077 #else
00078
         uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
     EventFlagOperation_t eMode_)
00079 #endif
00080 {
00081
          bool bThreadYield = false;
00082
         bool bMatch = false;
00083
00084 #if KERNEL USE TIMEOUTS
00085 Timer clEventTimer;
00086
         bool bUseTimer = false;
00087 #endif
00088
00089
          // Ensure we're operating in a critical section while we determine
00090
          // whether or not we need to block the current thread on this object.
00091
         CS ENTER();
00092
00093
          // Check to see whether or not the current mask matches any of the
00094
          // desired bits.
00095
          g_pclCurrent->SetEventFlagMask(u16Mask_);
00096
          if ((eMode_ == EVENT_FLAG_ALL) || (eMode_ ==
00097
     EVENT_FLAG_ALL_CLEAR) )
00098
        {
00099
              // Check to see if the flags in their current state match all of
00100
              // the set flags in the event flag group, with this mask.
00101
              if ((m_u16SetMask & u16Mask_) == u16Mask_)
00102
              {
00103
                  bMatch = true;
00104
                 g_pclCurrent->SetEventFlagMask(u16Mask_);
00105
             }
00106
00107
          else if ((eMode_ == EVENT_FLAG_ANY) || (eMode_ ==
     EVENT_FLAG_ANY_CLEAR))
00108
00109
              // Check to see if the existing flags match any of the set flags in
00110
              // the event flag group with this mask
00111
              if (m_u16SetMask & u16Mask_)
00112
              {
00113
                  bMatch = true:
                  g_pclCurrent->SetEventFlagMask(m_u16SetMask & u16Mask_);
00114
00115
             }
00116
00117
00118
          // We're unable to match this pattern as-is, so we must block.
00119
          if (!bMatch)
00120
```

```
// Reset the current thread's event flag mask & mode
00122
              g_pclCurrent->SetEventFlagMask(u16Mask_);
00123
              g_pclCurrent->SetEventFlagMode(eMode_);
00124
00125 #if KERNEL USE TIMEOUTS
              if (u32TimeMS_)
00126
00127
              {
00128
                  g_pclCurrent->SetExpired(false);
00129
                  clEventTimer.Init();
00130
                  clEventTimer.Start(0, u32TimeMS_, TimedEventFlag_Callback, (void*)
     this);
00131
                  bUseTimer = true;
00132
              }
00133 #endif
00134
00135
              // Add the thread to the object's block-list.
00136
              BlockPriority(g_pclCurrent);
00137
00138
              // Trigger that
00139
              bThreadYield = true;
00140
         }
00141
          // If bThreadYield is set, it means that we've blocked the current thread,
00142
00143
          // and must therefore rerun the scheduler to determine what thread to
00144
          // switch to.
00145
          if (bThreadYield)
00146
          {
00147
               // Switch threads immediately
00148
              Thread::Yield();
00149
          }
00150
00151
          // Exit the critical section and return back to normal execution
00152
          CS_EXIT();
00153
00158 #if KERNEL USE TIMEOUTS
00159
         if (bUseTimer && bThreadYield)
00160
00161
              clEventTimer.Stop();
00162
00163 #endif
00164
00165
          return g_pclCurrent->GetEventFlagMask();
00166 }
00167
00169 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_)
00170 {
00171 #if KERNEL_USE_TIMEOUTS
00172
         return Wait_i(u16Mask_, eMode_, 0);
00173 #else
         return Wait_i(u16Mask_, eMode_);
00175 #endif
00176 }
00177
00178 #if KERNEL_USE_TIMEOUTS
00179 //-
00180 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_,
       uint32_t u32TimeMS_)
00181 {
00182
          return Wait_i(u16Mask_, eMode_, u32TimeMS_);
00183 }
00184 #endif
00185
00186 //---
00187 void EventFlag::Set(uint16_t u16Mask_)
00188 {
00189
          Thread *pclPrev;
          Thread *pclCurrent;
00190
00191
          bool bReschedule = false;
00192
          uint16_t u16NewMask;
00193
00194
          CS_ENTER();
00195
          // Walk through the whole block list, checking to see whether or not
00196
00197
          // the current flag set now matches any/all of the masks and modes of
00198
          // the threads involved.
00199
00200
          m_u16SetMask |= u16Mask_;
00201
          u16NewMask = m_u16SetMask;
00202
          // Start at the head of the list, and iterate through until we hit the // "head" element in the list again. Ensure that we handle the case where
00203
00204
00205
          // we remove the first or last elements in the list, or if there's only
00206
          // one element in the list.
00207
          pclCurrent = static_cast<Thread*>(m_clBlockList.GetHead());
00208
00209
          // Do nothing when there are no objects blocking.
```

15.26 eventflag.cpp 141

```
00210
          if (pclCurrent)
00211
00212
               // First loop - process every thread in the block-list and check to
              // see whether or not the current flags match the event-flag conditions
00213
00214
              // on the thread.
00215
00216
              {
00217
                  pclPrev = pclCurrent;
00218
                  pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00219
00220
                  // Read the thread's event mask/mode
00221
                  uint16_t u16ThreadMask = pclPrev->GetEventFlagMask();
                  EventFlagOperation_t eThreadMode = pclPrev->
00222
      GetEventFlagMode();
00223
00224
                   // For the "any" mode - unblock the blocked threads if one or more bits
                  // in the thread's bitmask match the object's bitmask
00225
                   if ((EVENT_FLAG_ANY == eThreadMode) || (
00226
     EVENT_FLAG_ANY_CLEAR == eThreadMode))
00227
                  {
00228
                       if (u16ThreadMask & m_u16SetMask)
00229
00230
                           pclPrev->SetEventFlagMode(
      EVENT_FLAG_PENDING_UNBLOCK);
00231
                           pclPrev->SetEventFlagMask(m_u16SetMask & u16ThreadMask);
00232
                           bReschedule = true;
00233
00234
                           // If the "clear" variant is set, then clear the bits in the mask
00235
                           // that caused the thread to unblock.
                           if (EVENT_FLAG_ANY_CLEAR == eThreadMode)
00236
00237
00238
                               u16NewMask &=~ (u16ThreadMask & u16Mask_);
00239
00240
00241
                  // For the "all" mode, every set bit in the thread's requested bitmask must // match the object's flag mask.
00242
00243
                  else if ((EVENT_FLAG_ALL == eThreadMode) || (
     EVENT_FLAG_ALL_CLEAR == eThreadMode))
00245
00246
                       if ((u16ThreadMask & m_u16SetMask) == u16ThreadMask)
00247
                           pclPrev->SetEventFlagMode(
00248
      EVENT_FLAG_PENDING_UNBLOCK);
00249
                           pclPrev->SetEventFlagMask(u16ThreadMask);
00250
                           bReschedule = true;
00251
                           // If the "clear" variant is set, then clear the bits in the mask
00252
                           // that caused the thread to unblock.
00253
00254
                           if (EVENT_FLAG_ALL_CLEAR == eThreadMode)
                           {
00256
                               u16NewMask &=~ (u16ThreadMask & u16Mask_);
00257
00258
                       }
00259
                  }
00260
              ^{\prime\prime} // To keep looping, ensure that there's something in the list, and
00262
              // that the next item isn't the head of the list.
00263
              while (pclPrev != m_clBlockList.GetTail());
00264
00265
              // Second loop - go through and unblock all of the threads that
              // were tagged for unblocking.
00266
00267
              pclCurrent = static_cast<Thread*>(m_clBlockList.
     GetHead());
00268
              bool bIsTail = false;
00269
00270
              {
00271
                  pclPrev = pclCurrent;
                  pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00272
00274
                  // Check to see if this is the condition to terminate the loop
00275
                  if (pclPrev == m_clBlockList.GetTail())
00276
00277
                       bIsTail = true:
00278
                  }
00279
00280
                  // If the first pass indicated that this thread should be
00281
                  \ensuremath{//} unblocked, then unblock the thread
                  if (pclPrev->GetEventFlagMode() ==
00282
     EVENT_FLAG_PENDING_UNBLOCK)
00283
                  {
00284
                      UnBlock (pclPrev);
00285
00286
00287
              while (!bIsTail);
          }
00288
00289
```

```
// If we awoke any threads, re-run the scheduler
00291
          if (bReschedule)
00292
00293
              Thread::Yield();
00294
          }
00295
00296
         // Update the bitmask based on any "clear" operations performed along
00297
00298
          m_u16SetMask = u16NewMask;
00299
          // Restore interrupts - will potentially cause a context switch if a
00300
00301
          // thread is unblocked.
00302
          CS_EXIT();
00303 }
00304
00305 //---
00306 void EventFlag::Clear(uint16_t u16Mask_)
00307 {
          // Just clear the bitfields in the local object.
00309
          CS_ENTER();
          m_u16SetMask &= ~u16Mask_;
00310
00311
         CS_EXIT();
00312 }
00313
00314 //--
00315 uint16_t EventFlag::GetMask()
00316 {
00317
          // Return the presently held event flag values in this object. Ensure
00318
          \ensuremath{//} we get this within a critical section to guarantee atomicity.
00319
          uint16 t u16Return;
          CS_ENTER();
00320
00321
          u16Return = m_u16SetMask;
00322
00323
          return u16Return;
00324 }
00325
00326 #endif // KERNEL USE EVENTFLAG
```

15.27 /home/vm/mark3/trunk/embedded/kernel/kernel.cpp File Reference

Kernel initialization and startup code.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernel.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "timerlist.h"
#include "message.h"
#include "driver.h"
#include "profile.h"
#include "kernelprofile.h"
#include "autoalloc.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "tracebuffer.h"
```

15.27.1 Detailed Description

Kernel initialization and startup code.

Definition in file kernel.cpp.

15.28 kernel.cpp 143

15.28 kernel.cpp

```
00001 /*========
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 #include "kernel.h"
00025 #include "scheduler.h"
00026 #include "thread.h"
00027 #include "threadport.h"
00028 #include "timerlist.h"
00029 #include "message.h"
00030 #include "driver.h"
00031 #include "profile.h"
00032 #include "kernelprofile.h"
00033 #include "autoalloc.h'
00034
00035 #define _CAN_HAS_DEBUG
00036 //--[Autogenerated - Do Not Modify]-----
00037 #include "dbg_file_list.h"
00038 #include "buffalogger.h"
00039 #if defined(DBG FILE)
00040 # error "Debug logging file token already defined! Bailing."
00041 #else
00042 # define DBG_FILE _DBG___KERNEL_KERNEL_CPP
00043 #endif
00044 //--[End Autogenerated content]------
00045 #include "kerneldebug.h"
00046 #include "tracebuffer.h"
00047
00048 bool Kernel::m_bIsStarted;
00049 bool Kernel::m_bIsPanic;
00050 panic_func_t Kernel::m_pfPanic;
00051
00052 #if KERNEL_USE_IDLE_FUNC
00053 idle_func_t Kernel::m_pfIdle;
00054 FakeThread_t Kernel::m_clIdle;
00055 #endif
00056 //--
00057 void Kernel::Init(void)
00058 {
00059
          m_bIsStarted = false;
00060
          m_bIsPanic = false;
00061
          m_pfPanic = 0;
00062 #if KERNEL_USE_AUTO_ALLOC
00063
          AutoAlloc::Init();
00064 #endif
00065 #if KERNEL_USE_IDLE_FUNC
00066
          ((Thread*)&m_clIdle)->InitIdle();
00067
          m_pfIdle = 0;
00068 #endif
00069 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
          TraceBuffer::Init();
00070
00071 #endif
00072
          KERNEL_TRACE( "Initializing Mark3 Kernel" );
00073
00074
          // Initialize the global kernel data - scheduler, timer-scheduler, and
          \ensuremath{//} the global message pool.
00075
00076
          Scheduler::Init();
00077 #if KERNEL_USE_DRIVER
          DriverList::Init();
00079 #endif
00080 #if KERNEL_USE_TIMERS
00081
          TimerScheduler::Init();
00082 #endif
00083 #if KERNEL_USE_MESSAGE
00084
          GlobalMessagePool::Init();
00085 #endif
00086 #if KERNEL_USE_PROFILER
00087
          Profiler::Init();
00088 #endif
00089
00090 }
00091
```

```
00093 void Kernel::Start(void)
00094 {
          KERNEL_TRACE( "Starting Mark3 Scheduler");
m_bIsStarted = true;
ThreadPort::StartThreads();
00095
00096
00097
00098
          KERNEL_TRACE( "Error starting Mark3 Scheduler" );
00099 }
00100
00101 //---
00102 void Kernel::Panic(uint16_t u16Cause_)
00103 {
00104
          m_bIsPanic = true;
00105
          if (m_pfPanic)
00106
00107
               m_pfPanic(u16Cause_);
00108
00109
        else
00110
00111 #if KERNEL_AWARE_SIMULATION
00112
              KernelAware::ExitSimulator();
00113 #endif
00114
               while(1);
00115
          }
00116 }
```

15.29 /home/vm/mark3/trunk/embedded/kernel/kernelaware.cpp File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernelaware.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

Classes

· union KernelAwareData t

This structure is used to communicate between the kernel and a kernel- aware host.

Variables

• volatile bool g_blsKernelAware = false

Will be set to true by a kernel-aware host.

volatile uint8_t g_u8KACommand

Kernel-aware simulator command to execute.

KernelAwareData_t g_stKAData

Data structure used to communicate with host.

15.29.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.cpp.

15.29.2 Variable Documentation

15.30 kernelaware.cpp 145

15.29.2.1 volatile bool g_blsKernelAware = false

Will be set to true by a kernel-aware host.

Definition at line 81 of file kernelaware.cpp.

15.29.2.2 KernelAwareData_t g_stKAData

Data structure used to communicate with host.

Definition at line 83 of file kernelaware.cpp.

15.30 kernelaware.cpp

```
00002
00003
00004
00005 1
                 1.11
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "kernelaware.h'
00024 #include "threadport.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_KERNELAWARE_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL AWARE SIMULATION
00038
00039 //--
00048 typedef union
00049 {
00050
          volatile uint16_t au16Buffer[5];
00051
00055
          struct
00056
          {
00057
              volatile const char *szName;
00058
          } Profiler;
00063
          struct
00064
00065
              volatile uint16 t u16File:
00066
              volatile uint16_t u16Line;
00067
              volatile uint16_t u16Arg1;
00068
              volatile uint16_t u16Arg2;
00069
          } Trace;
00074
          struct
00075
          {
00076
              volatile const char *szString;
00077
          } Print;
00078 } KernelAwareData_t;
00079
00080 //---
00081 volatile bool
                          q_bIsKernelAware = false;
00082 volatile uint8 t
                               q u8KACommand;
00083 KernelAwareData_t
                               g_stKAData;
00084
00085
00086 //---
00087 void KernelAware::ProfileInit(const char *szStr_)
00088 {
00089
          CS_ENTER();
00090
          g_stKAData.Profiler.szName = szStr_;
```

```
g_u8KACommand = KA_COMMAND_PROFILE_INIT;
00092
         CS_EXIT();
00093 }
00094
00095 //---
00096 void KernelAware::ProfileStart(void)
00097 {
00098
         g_u8KACommand = KA_COMMAND_PROFILE_START;
00099 }
00100
00101 //-----
00102 void KernelAware::ProfileStop(void)
00103 {
00104
         g_u8KACommand = KA_COMMAND_PROFILE_STOP;
00105 }
00106
00107 //--
00108 void KernelAware::ProfileReport(void)
00109 {
00110
         g_u8KACommand = KA_COMMAND_PROFILE_REPORT;
00111 }
00112
00113 //---
00114 void KernelAware::ExitSimulator(void)
00115 {
00116
         g_u8KACommand = KA_COMMAND_EXIT_SIMULATOR;
00117 }
00118
00119 //---
00120 void KernelAware::Trace( uint16_t u16File_,
00121
                               uint16 t u16Line )
00122 {
00123
         Trace_i( u16File_, u16Line_, 0, 0, KA_COMMAND_TRACE_0 );
00124 }
00125
00126 //----
00127 void KernelAware::Trace( uint16 t u16File ,
                               uint16_t u16Line_,
00129
                               uint16_t u16Arg1_)
00130 {
00131
         Trace_i( u16File_, u16Line_, u16Arg1_, 0 ,KA_COMMAND_TRACE_1 );
00132
00133 }
00134 //----
00135 void KernelAware::Trace( uint16_t u16File_,
00136
                               uint16_t u16Line_,
00137
                                uint16_t u16Arg1_,
00138
                                uint16_t u16Arg2_)
00139 {
00140
         Trace i(ul6File, ul6Line, ul6Argl, ul6Argl, KA COMMAND TRACE 2):
00141 }
00142
00143 //---
00144 void KernelAware::Trace_i( uint16_t u16File_,
00145
                                uint16_t u16Line_,
00146
                                uint16 t u16Arg1 ,
00147
                                uint16_t u16Arg2_,
00148
                                KernelAwareCommand_t eCmd_ )
00149 {
         CS_ENTER();
00150
         g_stKAData.Trace.u16File = u16File_;
00151
         g_stKAData.Trace.u16Line = u16Line_;
00152
00153
         g_stKAData.Trace.u16Arg1 = u16Arg1_;
00154
         g_stKAData.Trace.u16Arg2 = u16Arg2_;
          g_u8KACommand = eCmd_;
00155
00156
         CS_EXIT();
00157 }
00158
00159 //-
00160 void KernelAware::Print(const char *szStr_)
00161 {
00162
         CS_ENTER();
         g_stKAData.Print.szString = szStr_;
00163
00164
         g_u8KACommand = KA_COMMAND_PRINT;
         CS_EXIT();
00165
00166 }
00167
00168 //--
00169 bool KernelAware::IsSimulatorAware(void)
00170 {
00171
         return g_bIsKernelAware;
00173
00174 #endif
```

15.31 /home/vm/mark3/trunk/embedded/kernel/ksemaphore.cpp File Reference

Semaphore Blocking-Object Implemenation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ksemaphore.h"
#include "blocking.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "timerlist.h"
```

Functions

void TimedSemaphore_Callback (Thread *pclOwner_, void *pvData_)
 TimedSemaphore Callback.

15.31.1 Detailed Description

Semaphore Blocking-Object Implemenation.

Definition in file ksemaphore.cpp.

15.31.2 Function Documentation

```
15.31.2.1 void TimedSemaphore_Callback ( Thread * pclOwner_, void * pvData_ )
```

TimedSemaphore_Callback.

This function is called from the timer-expired context to trigger a timeout on this semphore. This results in the waking of the thread that generated the semaphore pend call that was not completed in time.

Parameters

pclOwner_	Pointer to the thread to wake
pvData_	Pointer to the semaphore object that the thread is blocked on

Definition at line 57 of file ksemaphore.cpp.

15.32 ksemaphore.cpp

```
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "ksemaphore.h"
00026 #include "blocking.h"
00027
00028 #define _CAN_HAS_DEBUG
```

```
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG_FILE)
00033 # error "Debug logging file token already defined! Bailing."
00034 #else
00035 # define DBG_FILE _DBG___KERNEL_KSEMAPHORE_CPP
00036 #endif
00037 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040
00041 #if KERNEL_USE_SEMAPHORE
00042
00043 #if KERNEL_USE_TIMEOUTS
00044 #include "timerlist.h"
00045
00046 //
00057 void TimedSemaphore_Callback(Thread *pclOwner_, void *pvData_)
00058 {
00059
           Semaphore *pclSemaphore = static_cast<Semaphore*>(pvData_);
00060
00061
          // Indicate that the semaphore has expired on the thread
00062
          pclOwner_->SetExpired(true);
00063
00064
          // Wake up the thread that was blocked on this semaphore.
00065
          pclSemaphore->WakeMe(pclOwner_);
00066
00067
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
00068
      ()->GetCurPriority())
00069
          {
00070
               Thread::Yield();
00071
          }
00072 }
00073
00074 //--
00075 void Semaphore::WakeMe(Thread *pclChosenOne_)
00076 {
00077
           // Remove from the semaphore waitlist and back to its ready list.
00078
          UnBlock (pclChosenOne_);
00079 }
00080
00081 #endif // KERNEL_USE_TIMEOUTS
00082
00083 //---
00084 uint8_t Semaphore::WakeNext()
00085 {
00086
          Thread *pclChosenOne;
00087
00088
          pclChosenOne = m_clBlockList.HighestWaiter();
00089
00090
          \ensuremath{//} Remove from the semaphore waitlist and back to its ready list.
00091
          UnBlock (pclChosenOne);
00092
          // Call a task switch if higher or equal priority thread
00093
           if (pclChosenOne->GetCurPriority() >=
      Scheduler::GetCurrentThread()->GetCurPriority())
00095
          {
00096
               return 1:
00097
          }
00098
          return 0;
00099 }
00100
00101 //---
00102 void Semaphore::Init(uint16_t u16InitVal_, uint16_t u16MaxVal_)
00103 {
           // Copy the paramters into the object - set the maximum value for this
00104
00105
          // semaphore to implement either binary or counting semaphores, and set
          // the initial count. Clear the wait list for this object.
00106
00107
          m_u16Value = u16InitVal_;
00108
          m_u16MaxValue = u16MaxVal_;
00109
00110
          m clBlockList.Init();
00111 }
00112
00113 //--
00114 bool Semaphore::Post()
00115 {
          KERNEL TRACE 1 ( "Posting semaphore, Thread %d", (uint16 t)
00116
      g_pclCurrent->GetID() );
00117
          bool bThreadWake = 0;
00118
00119
          bool bBail = false;
          // Increment the semaphore count - we can mess with threads so ensure this // is in a critical section. We don't just disable the scheudler since // we want to be able to do this from within an interrupt context as well.
00120
00121
00122
```

```
00123
          CS_ENTER();
00124
00125
          // If nothing is waiting for the semaphore
00126
          if (m_clBlockList.GetHead() == NULL)
00127
00128
              // Check so see if we've reached the maximum value in the semaphore
              if (m_u16Value < m_u16MaxValue)</pre>
00129
00130
00131
                  // Increment the count value
00132
                  m_u16Value++;
00133
00134
              else
00135
              {
00136
                   // Maximum value has been reached, bail out.
00137
                  bBail = true;
00138
              }
00139
00140
          else
00141
00142
              // Otherwise, there are threads waiting for the semaphore to be
00143
              // posted, so wake the next one (highest priority goes first).
00144
              bThreadWake = WakeNext();
00145
          }
00146
00147
         CS_EXIT();
00148
00149
          // If we weren't able to increment the semaphore count, fail out.
00150
          if (bBail)
00151
          {
00152
              return false:
00153
00154
00155
          // if bThreadWake was set, it means that a higher-priority thread was
00156
          // woken. Trigger a context switch to ensure that this thread gets
00157
          // to execute next.
00158
          if (bThreadWake)
00159
          {
00160
              Thread::Yield();
00161
00162
          return true;
00163 }
00164
00165 //---
00166 #if KERNEL_USE_TIMEOUTS
00167 bool Semaphore::Pend_i( uint32_t u32WaitTimeMS_ )
00168 #else
00169 void Semaphore::Pend_i( void )
00170 #endif
00171 {
          KERNEL_TRACE_1( "Pending semaphore, Thread %d", (uint16_t)
00172
     g_pclCurrent->GetID() );
00173
00174 #if KERNEL_USE_TIMEOUTS
00175
         Timer clSemTimer;
00176
         bool bUseTimer = false;
00177 #endif
00178
00179
          // Once again, messing with thread data - ensure
00180
          // we're doing all of these operations from within a thread-safe context.
00181
         CS_ENTER();
00182
00183
          \ensuremath{//} Check to see if we need to take any action based on the semaphore count
00184
          if (m_u16Value != 0)
00185
00186
              // The semaphore count is non-zero, we can just decrement the count
00187
              // and go along our merry way.
00188
              m_u16Value--;
00189
         }
00190
         else
00191
         {
00192
              // The semaphore count is zero - we need to block the current thread
00193
              // and wait until the semaphore is posted from elsewhere.
00194 #if KERNEL_USE_TIMEOUTS
              if (u32WaitTimeMS )
00195
00196
              {
00197
                  g_pclCurrent->SetExpired(false);
00198
                  clSemTimer.Init();
00199
                  clSemTimer.Start(0, u32WaitTimeMS_, TimedSemaphore_Callback, (void*)this
00200
                  bUseTimer = true:
00201
              }
00202 #endif
00203
              BlockPriority(g_pclCurrent);
00204
00205
              // Switch Threads immediately
00206
              Thread::Yield();
00207
          }
```

```
00208
00209
          CS_EXIT();
00210
00211 #if KERNEL USE TIMEOUTS
         if (bUseTimer)
00212
00213
00214
              clSemTimer.Stop();
00215
             return (g_pclCurrent->GetExpired() == 0);
00216
00217
         return true;
00218 #endif
00219 }
00220
00221 //---
00222 // Redirect the untimed pend API to the timed pend, with a null timeout.
00223 void Semaphore::Pend()
00224 (
00225 #if KERNEL_USE_TIMEOUTS
00226
         Pend_i(0);
00227 #else
00228
         Pend_i();
00229 #endif
00230 }
00231
00232 #if KERNEL_USE_TIMEOUTS
00234 bool Semaphore::Pend( uint32_t u32WaitTimeMS_ )
00235 {
00236
          return Pend_i( u32WaitTimeMS_ );
00237 }
00238 #endif
00239
00240 //----
00241 uint16_t Semaphore::GetCount()
00242 {
         uint16_t u16Ret;
00243
00244
         CS_ENTER();
         u16Ret = m_u16Value;
00246
         CS_EXIT();
00247
         return u16Ret;
00248 }
00249
00250 #endif
```

15.33 /home/vm/mark3/trunk/embedded/kernel/II.cpp File Reference

Core Linked-List implementation, from which all kernel objects are derived.


```
#include "kerneltypes.h"
#include "kernel.h"
#include "ll.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.33.1 Detailed Description

Core Linked-List implementation, from which all kernel objects are derived.

Definition in file II.cpp.

15.34 II.cpp



15.34 Il.cpp 151

```
00009 -- [Mark3 Realtime Platform] -----
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00022 #include "kerneltypes.h"
00022 #Include kernelty
00023 #include "kernel.h
00024 #include "11.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]------
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_LL_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 //----
00040 void LinkListNode::ClearNode()
00041 {
00042
          next = NULL;
         prev = NULL;
00043
00044 }
00045
00046 //---
00047 void DoubleLinkList::Add(LinkListNode *node)
00048 {
00049
          KERNEL_ASSERT( node_ );
00050
00051
          \ensuremath{//} Add a node to the end of the linked list.
00052
          if (!m_pstHead)
00053
          {
00054
              // If the list is empty, initilize the nodes
00055
              m_pstHead = node_;
00056
              m_pstTail = node_;
00057
00058
             m_pstHead->prev = NULL;
             m_pstTail->next = NULL;
00059
00060
             return;
00061
          }
00062
00063
          // Move the tail node, and assign it to the new node just passed in
          m_pstTail->next = node_;
00064
00065
          node_->prev = m_pstTail;
          node_->next = NULL;
00066
00067
          m_pstTail = node_;
00068 }
00069
00070 //--
00071 void DoubleLinkList::Remove(LinkListNode *node_)
00072 {
00073
          KERNEL_ASSERT( node_ );
00074
          if (node_->prev)
00075
00076
00077 #if SAFE UNLINK
          if (node_->prev->next != node_)
00078
00079
              {
08000
                  Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00081
              }
00082 #endif
00083
             node_->prev->next = node_->next;
00084
00085
         if (node_->next)
00086
00087 #if SAFE_UNLINK
00088
              if (node_->next->prev != node_)
00089
              {
00090
                  Kernel::Panic(PANIC LIST UNLINK FAILED);
00091
              }
00092 #endif
00093
              node_->next->prev = node_->prev;
00094
          if (node_ == m_pstHead)
00095
00096
         {
00097
              m pstHead = node ->next;
00098
00099
          if (node_ == m_pstTail)
00100
00101
              m_pstTail = node_->prev;
00102
          }
00103
```

```
00104
         node_->ClearNode();
00105 }
00106
00107 //----
00108 void CircularLinkList::Add(LinkListNode *node_)
00109 {
00110
          KERNEL_ASSERT( node_ );
00111
00112
          // Add a node to the end of the linked list.
00113
          if (!m_pstHead)
00114
         {
              \ensuremath{//} If the list is empty, initilize the nodes
00115
00116
              m_pstHead = node_;
              m_pstTail = node_;
00117
00118
00119
              m_pstHead->prev = m_pstHead;
              m_pstHead->next = m_pstHead;
00120
00121
              return;
00122
          }
00123
00124
          // Move the tail node, and assign it to the new node just passed in
00125
          m_pstTail->next = node_;
00126
          node_->prev = m_pstTail;
          node_->prev = m_pstrair,
node_->next = m_pstHead;
m_pstTail = node_;
00127
00128
00129
          m_pstHead->prev = node_;
00130 }
00131
00132 //---
00133 void CircularLinkList::Remove(LinkListNode *node_)
00134 {
00135
          KERNEL_ASSERT( node_ );
00136
00137
          // Check to see if this is the head of the list...
00138
          if ((node_ == m_pstHead) && (m_pstHead == m_pstTail))
00139
00140
              \ensuremath{//} Clear the head and tail pointers - nothing else left.
              m_pstHead = NULL;
00141
00142
              m_pstTail = NULL;
00143
              return;
00144
          }
00145
00146 #if SAFE UNLINK
        // Verify that all nodes are properly connected
00147
          if ((node_->prev->next != node_) || (node_->next->prev != node_))
00148
00149
          {
00150
              Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00151
00152 #endif
00153
00154
          // This is a circularly linked list - no need to check for connection,
00155
          // just remove the node.
00156
          node_->next->prev = node_->prev;
          node_->prev->next = node_->next;
00157
00158
00159
          if (node_ == m_pstHead)
00160
00161
              m_pstHead = m_pstHead->next;
00162
00163
          if (node_ == m_pstTail)
00164
00165
              m_pstTail = m_pstTail->prev;
00166
00167
          node_->ClearNode();
00168 }
00169
00170 //--
00171 void CircularLinkList::PivotForward()
00172 {
00173
          if (m_pstHead)
00174
00175
              m_pstHead = m_pstHead->next;
              m_pstTail = m_pstTail->next;
00176
00177
00178 }
00179
00180 //---
00181 void CircularLinkList::PivotBackward()
00182 {
00183
          if (m pstHead)
00184
          {
              m_pstHead = m_pstHead->prev;
m_pstTail = m_pstTail->prev;
00185
00186
00187
          }
00188 }
00189
00190 //----
```

```
00191 void CircularLinkList::InsertNodeBefore(
      LinkListNode *node_, LinkListNode *insert_)
00192 {
00193
          KERNEL_ASSERT( node_ );
00194
00195
          node ->next = insert :
00196
          node_->prev = insert_->prev;
00197
00198
00199
              insert_->prev->next = node_;
00200
00201
00202
          insert ->prev = node ;
00203 }
00204
```

15.35 /home/vm/mark3/trunk/embedded/kernel/mailbox.cpp File Reference

Mailbox + Envelope IPC mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "ksemaphore.h"
#include "mailbox.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.35.1 Detailed Description

Mailbox + Envelope IPC mechanism.

Definition in file mailbox.cpp.

15.36 mailbox.cpp

```
00001 /
00002
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00021 #include "mark3cfg.h"
00022 #include "kerneltypes.h"
00023 #include "ksemaphore.h"
00024 #include "mailbox.h"
00025
00026 #define CAN HAS DEBUG
00027 //--[Autogenerated - Do Not Modify]------
00028 #include "dbg_file_list.h
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_MAILBOX_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MAILBOX
00040
00041 //--
```

```
00042 void Mailbox::Init( void *pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_ )
00043 {
00044
          KERNEL_ASSERT (u16BufferSize_);
          KERNEL_ASSERT(u16ElementSize_);
00045
          KERNEL_ASSERT (pvBuffer_);
00046
00047
00048
          m_pvBuffer = pvBuffer_;
00049
          m_u16ElementSize = u16ElementSize_;
00050
00051
          m_u16Count = (u16BufferSize_ / u16ElementSize_);
          m_u16Free = m_u16Count;
00052
00053
00054
          m_u16Head = 0;
00055
          m_u16Tail = 0;
00056
00057
          // We use the counting semaphore to implement blocking - with one element
          \ensuremath{//} in the mailbox corresponding to a post/pend operation in the semaphore.
00058
00059
          m_clRecvSem.Init(0, m_u16Free);
00060
00061 #if KERNEL_USE_TIMEOUTS
         // Binary semaphore is used to track any threads that are blocked on a // "send" due to lack of free slots.
00062
00063
         m_clSendSem.Init(0, 1);
00064
00065 #endif
00066 }
00067
00068 //-
00069 #if KERNEL_USE_AUTO_ALLOC
00070 Mailbox* Mailbox::Init( uint16_t u16BufferSize_, uint16_t u16ElementSize_ )
00071 {
00072
          Mailbox* pclNew = (Mailbox*)AutoAlloc::Allocate(sizeof(Mailbox));
00073
          void *pvBuffer = AutoAlloc::Allocate(u16BufferSize_);
00074
          pclNew->Init( pvBuffer, u16BufferSize_, u16ElementSize_ );
00075
          return pclNew;
00076 }
00077 #endif
00078
00079 //-
00080 void Mailbox::Receive( void *pvData_ )
00081 {
00082
          KERNEL_ASSERT( pvData_ );
00083
00084 #if KERNEL_USE_TIMEOUTS
00085
         Receive_i( pvData_, false, 0 );
00086 #else
00087
         Receive_i( pvData_, false );
00088 #endif
00089 }
00090
00091 #if KERNEL_USE_TIMEOUTS
00092 //--
00093 bool Mailbox::Receive( void *pvData_, uint32_t u32TimeoutMS_ )
00094 {
00095
          KERNEL_ASSERT( pvData_ );
00096
          return Receive_i( pvData_, false, u32TimeoutMS_ );
00097 }
00098 #endif
00099
00100 //--
00101 void Mailbox::ReceiveTail( void *pvData_ )
00102 {
00103
          KERNEL_ASSERT( pvData_ );
00104
00105 #if KERNEL_USE_TIMEOUTS
00106
         Receive_i( pvData_, true, 0 );
00107 #else
00108
        Receive_i( pvData_, true );
00109 #endif
00110 }
00111
00112 #if KERNEL_USE_TIMEOUTS
00113 //--
00114 bool Mailbox::ReceiveTail( void *pvData_, uint32_t u32TimeoutMS_ )
00115 {
          KERNEL_ASSERT( pvData_ );
00116
00117
          return Receive_i( pvData_, true, u32TimeoutMS_ );
00118 }
00119 #endif
00120
00121 //--
00122 bool Mailbox::Send( void *pvData_ )
00123 {
00124
          KERNEL_ASSERT( pvData_ );
00125
00126 #if KERNEL_USE_TIMEOUTS
00127
        return Send_i( pvData_, false, 0 );
00128 #else
```

15.36 mailbox.cpp 155

```
return Send_i( pvData_, false );
00130 #endif
00131 }
00132
00133 //--
00134 bool Mailbox::SendTail( void *pvData_ )
00135 {
00136
          KERNEL_ASSERT( pvData_ );
00137
00138 #if KERNEL_USE_TIMEOUTS
         return Send_i( pvData_, true, 0 );
00139
00140 #else
00141
         return Send_i( pvData_, true );
00142 #endif
00143 }
00144
00145 #if KERNEL USE TIMEOUTS
00146 //--
00147 bool Mailbox::Send( void *pvData_, uint32_t u32TimeoutMS_ )
00148 {
00149
          KERNEL_ASSERT( pvData_ );
00150
00151
         return Send_i( pvData_, false, u32TimeoutMS_ );
00152 }
00153
00154 //-
00155 bool Mailbox::SendTail( void *pvData_, uint32_t u32TimeoutMS_ )
00156 {
00157
         KERNEL_ASSERT( pvData_ );
00158
00159
         return Send_i( pvData_, true, u32TimeoutMS_ );
00160 }
00161 #endif
00162
00163 //--
00164 #if KERNEL USE TIMEOUTS
00165 bool Mailbox::Send_i( const void *pvData_, bool bTail_, uint32_t u32TimeoutMS_)
00166 #else
00167 bool Mailbox::Send_i( const void *pvData_, bool bTail_)
00168 #endif
00169 {
00170
         const void *pvDst;
00171
00172
         bool bRet = false;
00173
         bool bSchedState = Scheduler::SetScheduler( false );
00174
00175 #if KERNEL_USE_TIMEOUTS
00176
         bool bBlock = false;
         bool bDone = false;
00177
00178
         while (!bDone)
00179
         {
00180
              // Try to claim a slot first before resorting to blocking.
00181
              if (bBlock)
00182
              {
                  bDone = true;
00183
00184
                  Scheduler::SetScheduler( bSchedState );
00185
                  m_clSendSem.Pend( u32TimeoutMS_ );
                  Scheduler::SetScheduler( false );
00186
00187
00188 #endif
00189
              CS_ENTER();
00190
00191
              // Ensure we have a free slot before we attempt to write data
00192
              if (m_u16Free)
00193
00194
                  m_u16Free--;
00195
                  if (bTail_)
00196
00197
                  {
00198
                      pvDst = GetTailPointer();
00199
                      MoveTailBackward();
00200
00201
                  else
00202
00203
                     MoveHeadForward();
00204
                     pvDst = GetHeadPointer();
00205
00206
                  bRet = true;
00207 #if KERNEL_USE_TIMEOUTS
00208
                  bDone = true;
00209 #endif
00210
00211
00212 #if KERNEL_USE_TIMEOUTS
00213
            else if (u32TimeoutMS_)
00214
              {
00215
                  bBlock = true;
```

```
00216
              }
00217
              else
00218
              {
00219
                  bDone = true;
00220
00221 #endif
00222
00223
              CS_EXIT();
00224
00225 #if KERNEL_USE_TIMEOUTS
00226
00227 #endif
00228
00229
          // Copy data to the claimed slot, and post the counting semaphore
00230
          if (bRet)
00231
00232
              CopyData( pvData_, pvDst, m_u16ElementSize );
00233
          }
00234
00235
          Scheduler::SetScheduler( bSchedState );
00236
00237
          if (bRet)
00238
          {
              m_clRecvSem.Post();
00239
00240
          }
00241
00242
          return bRet;
00243 }
00244
00245 //----
00246 #if KERNEL_USE_TIMEOUTS
00247 bool Mailbox::Receive_i( const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_)
00248 #else
00249 void Mailbox::Receive_i( const void *pvData_, bool bTail_ )
00250 #endif
00251 {
00252
          const void *pvSrc;
00253
00254 #if KERNEL_USE_TIMEOUTS
00255
          if (!m_clRecvSem.Pend( u32WaitTimeMS_ ))
00256
              // Failed to get the notification from the counting semaphore in the \,
00257
              // time allotted. Bail.
00258
00259
              return false;
00260
00261 #else
00262
         m_clRecvSem.Pend();
00263 #endif
00264
00265
          // Disable the scheduler while we do this -- this ensures we don't have
          // multiple concurrent readers off the same queue, which could be problematic
00266
00267
          // if multiple writes occur during reads, etc.
00268
          bool bSchedState = Scheduler::SetScheduler( false );
00269
00270
          \ensuremath{//} Update the head/tail indexes, and get the associated data pointer for
00271
          // the read operation.
00272
          CS_ENTER();
00273
          m_u16Free++;
00274
00275
          if (bTail_)
00276
00277
              MoveTailForward();
00278
              pvSrc = GetTailPointer();
00279
00280
          else
00281
          {
00282
              pvSrc = GetHeadPointer();
00283
              MoveHeadBackward();
00284
00285
00286
          CS_EXIT();
00287
00288
          CopyData( pvSrc, pvData_, m_u16ElementSize );
00289
00290
          Scheduler::SetScheduler( bSchedState );
00291
00292
          // Unblock a thread waiting for a free slot to send to
00293
          m_clSendSem.Post();
00294
00295 #if KERNEL_USE_TIMEOUTS
00296
          return true;
00297 #endif
00298 }
00299
00300 #endif
```

15.37 /home/vm/mark3/trunk/embedded/kernel/message.cpp File Reference

Inter-thread communications via message passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "message.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "timerlist.h"
```

15.37.1 Detailed Description

Inter-thread communications via message passing.

Definition in file message.cpp.

15.38 message.cpp

```
00001 /
00002
00003
00004
                1.11
00005
00006 1
00007
00009
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "message.h"
00026 #include "threadport.h"
00027
00028 #define _CAN_HAS_DEBUG
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG FILE)
00033 # error "Debug logging file token already defined! Bailing."
00034 #else
00035 # define DBG_FILE _DBG___KERNEL_MESSAGE_CPP
00036 #endif
00037 //--[End Autogenerated content]------
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL_USE_MESSAGE
00041
00042 #if KERNEL_USE_TIMEOUTS
00043
         #include "timerlist.h"
00044 #endif
00045
00046 Message GlobalMessagePool::m_aclMessagePool[
     GLOBAL_MESSAGE_POOL_SIZE];
00047 DoubleLinkList GlobalMessagePool::m_clList;
00048
00049 //---
00050 void GlobalMessagePool::Init()
00051 {
00052
         uint8_t i;
00053
         GlobalMessagePool::m_clList.Init();
00054
         for (i = 0; i < GLOBAL_MESSAGE_POOL_SIZE; i++)</pre>
00055
00056
             GlobalMessagePool::m_aclMessagePool[i].Init();
00057
             {\tt GlobalMessagePool::m\_clList.Add(\&(GlobalMessagePool::m\_aclMessagePool[i]));}
00058
         }
00059 }
```

```
00060
00061 //--
00062 void GlobalMessagePool::Push( Message *pclMessage_)
00063 {
00064
          KERNEL_ASSERT( pclMessage_ );
00065
00066
         CS_ENTER();
00067
00068
         GlobalMessagePool::m_clList.Add(pclMessage_);
00069
00070
         CS EXIT();
00071 }
00072
00073 //---
00074 Message *GlobalMessagePool::Pop()
00075 {
00076
          Message *pclRet;
00077
         CS ENTER();
00078
00079
         pclRet = static_cast<Message*>( GlobalMessagePool::m_clList.GetHead() );
08000
          if (0 != pclRet)
00081
00082
              GlobalMessagePool::m_clList.Remove( static_cast<LinkListNode*>( pclRet ) );
00083
00084
00085
         CS_EXIT();
00086
         return pclRet;
00087 }
00088
00089 //----
00090 void MessageQueue::Init()
00091 {
00092
          m_clSemaphore.Init(0, GLOBAL_MESSAGE_POOL_SIZE);
00093 }
00094
00095 //----
00096 Message *MessageQueue::Receive()
00097 {
00098 #if KERNEL_USE_TIMEOUTS
00099
         return Receive_i(0);
00100 #else
00101
        return Receive i();
00102 #endif
00103 }
00104
00105 //--
00106 #if KERNEL_USE_TIMEOUTS
00107 Message *MessageQueue::Receive( uint32_t u32TimeWaitMS_)
00108 {
00109
          return Receive i ( u32TimeWaitMS );
00110 }
00111 #endif
00112
00113 //---
00114 #if KERNEL USE TIMEOUTS
00115 Message *MessageQueue::Receive_i( uint32_t u32TimeWaitMS_ )
00116 #else
00117 Message *MessageQueue::Receive_i( void )
00118 #endif
00119 {
00120
         Message *pclRet;
00121
00122
          // Block the current thread on the counting semaphore
00123 #if KERNEL_USE_TIMEOUTS
00124
          if (!m_clSemaphore.Pend(u32TimeWaitMS_))
00125
         {
00126
              return NULL;
00127
         }
00128 #else
00129
         m_clSemaphore.Pend();
00130 #endif
00131
00132
         CS_ENTER();
00133
00134
         // Pop the head of the message queue and return it
00135
         pclRet = static_cast<Message*>( m_clLinkList.GetHead() );
00136
         m_clLinkList.Remove(static_cast<Message*>(pclRet));
00137
00138
          CS EXIT():
00139
00140
          return pclRet;
00141 }
00142
00143 //--
00144 void MessageQueue::Send( Message *pclSrc_ )
00145 {
00146
         KERNEL_ASSERT( pclSrc_ );
```

```
00147
00148
         CS_ENTER();
00149
00150
         // Add the message to the head of the linked list
00151
         m_clLinkList.Add( pclSrc_ );
00152
00153
         // Post the semaphore, waking the blocking thread for the queue.
00154
         m_clSemaphore.Post();
00155
00156
         CS EXIT();
00157 }
00158
00159 //---
00160 uint16_t MessageQueue::GetCount()
00161 {
00162
         return m_clSemaphore.GetCount();
00163 3
00164 #endif //KERNEL USE MESSAGE
```

15.39 /home/vm/mark3/trunk/embedded/kernel/mutex.cpp File Reference

Mutual-exclusion object.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "mutex.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Functions

void TimedMutex_Calback (Thread *pclOwner_, void *pvData_)
 TimedMutex_Calback.

15.39.1 Detailed Description

Mutual-exclusion object.

Definition in file mutex.cpp.

15.39.2 Function Documentation

```
15.39.2.1 void TimedMutex_Calback ( Thread * pclOwner_, void * pvData_ )
```

TimedMutex Calback.

This function is called from the timer-expired context to trigger a timeout on this mutex. This results in the waking of the thread that generated the mutex claim call that was not completed in time.

Parameters

pclOwner_	Pointer to the thread to wake
pvData_	Pointer to the mutex object that the thread is blocked on

Definition at line 54 of file mutex.cpp.

15.40 mutex.cpp

```
00001 /*=========
00002
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022
00023 #include "blocking.h"
00024 #include "mutex.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_MUTEX_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MUTEX
00040
00041 #if KERNEL_USE_TIMEOUTS
00042
00043 //-
00054 void TimedMutex_Calback(Thread *pclOwner_, void *pvData_)
00055 {
00056
          Mutex *pclMutex = static_cast<Mutex*>(pvData_);
00057
00058
          // Indicate that the semaphore has expired on the thread
00059
          pclOwner_->SetExpired(true);
00060
00061
          // Wake up the thread that was blocked on this semaphore.
00062
          pclMutex->WakeMe(pclOwner_);
00063
00064
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      () ->GetCurPriority())
00065
          {
00066
              Thread::Yield();
00067
00068 }
00069
00070 //---
00071 void Mutex::WakeMe(Thread *pclOwner_)
00072 {
00073
           // Remove from the semaphore waitlist and back to its ready list.
00074
          UnBlock(pclOwner_);
00075 }
00076
00077 #endif
00078
00079 //
00080 uint8_t Mutex::WakeNext()
00081 {
00082
          Thread *pclChosenOne = NULL;
00083
00084
          // Get the highest priority waiter thread
00085
          pclChosenOne = m_clBlockList.HighestWaiter();
00086
00087
           // Unblock the thread
00088
          UnBlock (pclChosenOne);
00089
00090
          // The chosen one now owns the mutex
00091
          m_pclOwner = pclChosenOne;
00092
00093
          // Signal a context switch if it's a greater than or equal to the current priority
00094
          if (pclChosenOne->GetCurPriority() >=
      Scheduler::GetCurrentThread()->GetCurPriority())
00095
          {
00096
              return 1:
00097
00098
          return 0;
```

15.40 mutex.cpp 161

```
00099 }
00100
00101 //---
00102 void Mutex::Init()
00103 {
00104
          // Reset the data in the mutex
                             // The mutex is free.
         m_bReady = 1;
00106
          m_u8MaxPri = 0;
                                     // Set the maximum priority inheritence state
00107
          m_pclOwner = NULL;
                                     // Clear the mutex owner
00108
         m_u8Recurse = 0;
                                     // Reset recurse count
00109 }
00110
00111 //-
00112 #if KERNEL_USE_TIMEOUTS
00113 bool Mutex::Claim_i (uint32_t u32WaitTimeMS_)
00114 #else
00115 void Mutex::Claim i(void)
00116 #endif
00117 {
          KERNEL_TRACE_1( "Claiming Mutex, Thread %d", (uint16_t)
00118
     g_pclCurrent->GetID() );
00119
00120 #if KERNEL_USE_TIMEOUTS
00121
          Timer clTimer:
00122
         bool bUseTimer = false;
00123 #endif
00124
00125
          // Disable the scheduler while claiming the mutex - we're dealing with all
00126
          // sorts of private thread data, can't have a thread switch while messing
          // with internal data structures.
00127
00128
          Scheduler::SetScheduler(0);
00129
00130
          // Check to see if the mutex is claimed or not
00131
          if (m_bReady != 0)
00132
              // Mutex isn't claimed, claim it.
00133
00134
              m bReady = 0;
00135
              m_u8Recurse = 0;
00136
              m_u8MaxPri = g_pclCurrent->GetPriority();
00137
              m_pclOwner = g_pclCurrent;
00138
00139
              Scheduler::SetScheduler(1);
00140
00141 #if KERNEL_USE_TIMEOUTS
             return true;
00143 #else
00144
              return;
00145 #endif
00146
         }
00147
00148
          // If the mutex is already claimed, check to see if this is the owner thread,
00149
         // since we allow the mutex to be claimed recursively.
00150
          if (g_pclCurrent == m_pclOwner)
00151
              // Ensure that we haven't exceeded the maximum recursive-lock count
00152
              KERNEL_ASSERT( (m_u8Recurse < 255) );</pre>
00153
00154
              m_u8Recurse++;
00155
00156
              // Increment the lock count and bail
00157
              Scheduler::SetScheduler(1);
00158 #if KERNEL_USE_TIMEOUTS
00159
              return true;
00160 #else
              return;
00161
00162 #endif
00163
00164
00165
          // The mutex is claimed already - we have to block now. Move the
00166
          // current thread to the list of threads waiting on the mutex.
00167 #if KERNEL_USE_TIMEOUTS
00168
          if (u32WaitTimeMS_)
00169
00170
              g_pclCurrent->SetExpired(false);
00171
              clTimer.Init();
              clTimer.Start(0, u32WaitTimeMS_, (TimerCallback_t)
00172
     TimedMutex_Calback, (void*)this);
00173
             bUseTimer = true;
00174
00175 #endif
00176
         BlockPriority(g pclCurrent);
00177
          // Check if priority inheritence is necessary. We do this in order // to ensure that we don't end up with priority inversions in case \,
00178
00179
00180
          // multiple threads are waiting on the same resource.
00181
          if(m_u8MaxPri <= g_pclCurrent->GetPriority())
00182
00183
              m_u8MaxPri = q_pclCurrent->GetPriority();
```

```
00184
00185
              Thread *pclTemp = static_cast<Thread*>(m_clBlockList.GetHead());
00186
              while (pclTemp)
00187
              {
00188
                  pclTemp->InheritPriority(m_u8MaxPri);
                  if (pclTemp == static_cast<Thread*>(m_clBlockList.GetTail()) )
00189
00190
00191
00192
00193
                  pclTemp = static_cast<Thread*>(pclTemp->GetNext());
00194
              }
00195
              m_pclOwner->InheritPriority(m_u8MaxPri);
00196
          }
00197
00198
          // Done with thread data -reenable the scheduler
00199
          Scheduler::SetScheduler(1);
00200
00201
          // Switch threads if this thread acquired the mutex
00202
          Thread::Yield();
00203
00204 #if KERNEL_USE_TIMEOUTS
00205
          if (bUseTimer)
00206
00207
              clTimer.Stop();
00208
             return (g_pclCurrent->GetExpired() == 0);
00209
         }
00210
          return true;
00211 #endif
00212 }
00213
00214 //---
00215 void Mutex::Claim(void)
00216 {
00217 #if KERNEL_USE_TIMEOUTS
00218
         Claim_i(0);
00219 #else
        Claim_i();
00220
00221 #endif
00222 }
00223
00224 //----
00225 #if KERNEL_USE_TIMEOUTS
00226 bool Mutex::Claim(uint32_t u32WaitTimeMS_)
00227 {
00228
          return Claim_i(u32WaitTimeMS_);
00229 }
00230 #endif
00231
00232 //---
00233 void Mutex::Release()
00234 {
          KERNEL_TRACE_1( "Releasing Mutex, Thread %d", (uint16_t)
00235
      g_pclCurrent->GetID() );
00236
00237
          bool bSchedule = 0;
00238
00239
          // Disable the scheduler while we deal with internal data structures.
00240
          Scheduler::SetScheduler(0);
00241
00242
          // This thread had better be the one that owns the mutex currently...
          KERNEL_ASSERT( (g_pclCurrent == m_pclOwner) );
00243
00244
00245
          // If the owner had claimed the lock multiple times, decrease the lock
00246
          // count and return immediately.
00247
          if (m_u8Recurse)
00248
          {
00249
              m u8Recurse--;
              Scheduler::SetScheduler(1);
00250
00251
              return:
00252
          }
00253
00254
          // Restore the thread's original priority
00255
          if (g_pclCurrent->GetCurPriority() != g_pclCurrent->
     GetPriority())
00256
         {
              g_pclCurrent->SetPriority(g_pclCurrent->
     GetPriority());
00258
              \ensuremath{//} In this case, we want to reschedule
00259
00260
              bSchedule = 1;
00261
          }
00262
00263
          // No threads are waiting on this semaphore?
00264
          if (m_clBlockList.GetHead() == NULL)
00265
              \ensuremath{//} Re-initialize the mutex to its default values
00266
00267
              m_bReady = 1;
```

```
00268
              m_u8MaxPri = 0;
00269
              m_pclOwner = NULL;
00270
00271
          else
00272
00273
              // Wake the highest priority Thread pending on the mutex
00274
              if(WakeNext())
00275
00276
                   // Switch threads if it's higher or equal priority than the current thread
00277
                  bSchedule = 1;
00278
              }
00279
          }
00280
00281
          // Must enable the scheduler again in order to switch threads.
00282
          Scheduler::SetScheduler(1);
00283
          if(bSchedule)
00284
00285
               // Switch threads if a higher-priority thread was woken
00286
              Thread::Yield();
00287
          }
00288 }
00289
00290 #endif //KERNEL_USE_MUTEX
```

15.41 /home/vm/mark3/trunk/embedded/kernel/notify.cpp File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "notify.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

15.41.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.cpp.

15.42 notify.cpp

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00023 #include "mark3cfg.h"
00024 #include "notify.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]---
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG FILE)
00031 # error "Debug logging file token already defined! Bailing."
00032 #else
00033 # define DBG_FILE _DBG___KERNEL_NOTIFY_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL USE NOTIFY
00038 //-
00039 void TimedNotify_Callback(Thread *pclOwner_, void *pvData_)
```

```
00041
          Notify *pclNotify = static_cast<Notify*>(pvData_);
00042
00043
          // Indicate that the semaphore has expired on the thread
00044
          pclOwner_->SetExpired(true);
00045
00046
          // Wake up the thread that was blocked on this semaphore.
00047
          pclNotify->WakeMe(pclOwner_);
00048
00049
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread
      () ->GetCurPriority())
00050
          {
00051
              Thread::Yield();
00052
          }
00053 }
00054
00055 //---
00056 void Notify::Init(void)
00057 {
00058
          m_clBlockList.Init();
00059 }
00060
00061 //---
00062 void Notify::Signal(void)
00063 {
00064
          bool bReschedule = false;
00065
00066
          CS_ENTER();
          Thread *pclCurrent = (Thread*)m_clBlockList.GetHead();
while (pclCurrent != NULL)
00067
00068
00069
00070
              UnBlock (pclCurrent);
00071
              if (!bReschedule &&
00072
                  ( pclCurrent->GetCurPriority() >=
      Scheduler::GetCurrentThread() ->GetCurPriority() ) )
00073
             {
00074
                  bReschedule = true;
00075
00076
              pclCurrent = (Thread*)m_clBlockList.GetHead();
00077
00078
          CS_EXIT();
00079
08000
          if (bReschedule)
00081
          {
00082
              Thread::Yield();
00083
          }
00084 }
00085
00086 //---
00087 void Notify::Wait( bool *pbFlag_ )
00088 {
00089
           CS_ENTER();
00090
          Block(g_pclCurrent);
00091
          if (pbFlag_)
00092
00093
              *pbFlag_ = false;
00094
00095
          CS_EXIT();
00096
00097
          Thread::Yield();
00098
          if (pbFlag_)
00099
          {
00100
              *pbFlag_ = true;
00101
          }
00102 }
00103
00104 //----
00105 #if KERNEL USE TIMEOUTS
00106 bool Notify::Wait( uint32_t u32WaitTimeMS_, bool *pbFlag_ )
00107 {
00108
          bool bUseTimer = false;
00109
          Timer clNotifyTimer;
00110
00111
          CS ENTER();
00112
          if (u32WaitTimeMS_)
00113
          {
              bUseTimer = true;
00114
00115
              g_pclCurrent->SetExpired(false);
00116
00117
              clNotifyTimer.Init();
              clNotifyTimer.Start(0, u32WaitTimeMS_, TimedNotify_Callback, (void*)this);
00118
00119
          }
00120
00121
          Block(g_pclCurrent);
00122
00123
          if (pbFlag_)
00124
00125
              *pbFlag = false;
```

```
00126
00127
          CS_EXIT();
00128
          Thread::Yield();
00129
00130
          if (bUseTimer)
00131
00132
          {
00133
              clNotifyTimer.Stop();
00134
              return (g_pclCurrent->GetExpired() == 0);
00135
          }
00136
00137
          if (pbFlag_)
00138
          {
00139
              *pbFlag_ = true;
00140
00141
00142
          return true;
00143 }
00144 #endif
00146 void Notify::WakeMe(Thread *pclChosenOne_)
00147 {
00148
          UnBlock (pclChosenOne_);
00149 }
00150
00151 #endif
```

15.43 /home/vm/mark3/trunk/embedded/kernel/profile.cpp File Reference

Code profiling utilities.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.43.1 Detailed Description

Code profiling utilities.

Definition in file profile.cpp.

15.44 profile.cpp

```
00001 /*======
00002
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h'
00023 #include "profile.h"
00024 #include "kernelprofile.h"
00025 #include "threadport.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]--
00029 #include "dbg_file_list.h"
```

```
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 # error "Debug logging file token already defined! Bailing."
00033 #else
00034 # define DBG FILE DBG KERNEL PROFILE CPP
00035 #endif
00036 //--[End Autogenerated content]------
00037
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL USE PROFILER
00041
00042 //----
00043 void ProfileTimer::Init()
00044 {
          m_u32Cumulative = 0;
00045
00046
          m_u32CurrentIteration = 0;
00047
         m_u16Iterations = 0;
00048
         m_bActive = 0;
00049 }
00050
00051 //---
00052 void ProfileTimer::Start()
00053 {
00054
          if (!m_bActive)
00055
         {
00056
              CS_ENTER();
00057
             m_u32CurrentIteration = 0;
00058
              m_u32InitialEpoch = Profiler::GetEpoch();
              m_u16Initial = Profiler::Read();
00059
00060
              CS_EXIT();
00061
             m_bActive = 1;
00062
         }
00063 }
00064
00065 //---
00066 void ProfileTimer::Stop()
00067 {
00068
          if (m_bActive)
00069
         {
00070
             uint16_t u16Final;
             uint32_t u32Epoch;
CS_ENTER();
u16Final = Profiler::Read();
u32Epoch = Profiler::GetEpoch();
00071
00072
00073
00074
00075
             // Compute total for current iteration...
00076
             m_u32CurrentIteration = ComputeCurrentTicks(u16Final,
     u32Epoch);
00077
             m_u32Cumulative += m_u32CurrentIteration;
00078
              m_u16Iterations++;
              CS_EXIT();
08000
             m_bActive = 0;
00081
         }
00082 }
00083
00084 //-
00085 uint32_t ProfileTimer::GetAverage()
00086 {
00087
          if (m_u16Iterations)
00088
             return m_u32Cumulative / (uint32_t)m_u16Iterations;
00089
00090
00091
          return 0;
00092 }
00093
00094 //----
00095 uint32_t ProfileTimer::GetCurrent()
00096 {
00097
00098
          if (m_bActive)
00099
00100
              uint16_t u16Current;
00101
              uint32_t u32Epoch;
             CS_ENTER();
u16Current = Profiler::Read();
00102
00103
00104
             u32Epoch = Profiler::GetEpoch();
00105
              CS_EXIT();
00106
              return ComputeCurrentTicks(u16Current, u32Epoch);
00107
00108
          return m u32CurrentIteration;
00109 }
00110
00111 //--
00112 uint32_t ProfileTimer::ComputeCurrentTicks(uint16_t u16Current_, uint32_t
     u32Epoch_)
00113 {
00114
          uint32_t u32Total;
```

```
uint32_t u320verflows;
00116
00117
          u32Overflows = u32Epoch_ - m_u32InitialEpoch;
00118
00119
          // More than one overflow...
          if (u320verflows > 1)
00120
00121
00122
              u32Total = ((uint32_t)(u32Overflows-1) * TICKS_PER_OVERFLOW)
00123
                     + (uint32_t)(TICKS_PER_OVERFLOW - m_u16Initial) +
00124
                      (uint32_t)u16Current_;
00125
         // Only one overflow, or one overflow that has yet to be processed
00126
         else if (u320verflows || (u16Current_ < m_u16Initial))
00127
00128
00129
              u32Total = (uint32_t) (TICKS_PER_OVERFLOW - m_u16Initial) +
00130
                      (uint32_t)u16Current_;
00131
         // No overflows, none pending.
00132
00133
         else
00134
         {
00135
              u32Total = (uint32_t) (u16Current_ - m_u16Initial);
00136
00137
00138
          return u32Total:
00139 }
00140
00141 #endif
```

15.45 /home/vm/mark3/trunk/embedded/kernel/public/atomic.h File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "threadport.h"
```

15.45.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.h.

15.46 atomic.h

```
00001 /
00002
00003
00004
00005
00006 |
00007
80000
      -[Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00021 #ifndef __ATOMIC_H_
00022 #define __ATOMIC_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026 #include "threadport.h"
00027
00028 #if KERNEL_USE_ATOMIC
00029
00039 class Atomic
00040 {
00041 public:
00048
         static uint8_t Set( uint8_t *pu8Source_, uint8_t u8Val_ );
         static uint16_t Set( uint16_t *pu16Source_, uint16_t u16Val_ );
00049
         static uint32_t Set(uint32_t *pu32Source_, uint32_t u32Val_);
```

```
00058
             static uint8_t Add( uint8_t *pu8Source_, uint8_t u8Val_ );
00059
             static uint16_t Add( uint16_t *pu16Source_, uint16_t u16Val_ );
            static uint32_t Add( uint32_t *pu32Source_, uint32_t u32Val_ );
00060
00061
            static uint8_t Sub( uint8_t *pu8Source_, uint8_t u8Val_ );
static uint16_t Sub( uint16_t *pu16Source_, uint16_t u16Val_ );
static uint32_t Sub( uint32_t *pu32Source_, uint32_t u32Val_ );
00068
00069
00070
00071
00086
             static bool TestAndSet( bool *pbLock );
00087 };
00088
00089 #endif // KERNEL_USE_ATOMIC
00090
00091 #endif //__ATOMIC_H__
```

15.47 /home/vm/mark3/trunk/embedded/kernel/public/autoalloc.h File Reference

Automatic memory allocation for kernel objects.

```
#include <stdint.h>
#include <stdbool.h>
#include "mark3cfg.h"
```

15.47.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.h.

15.48 autoalloc.h

```
00001 /*==
                                                  _____
00002
00004 |
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===========
00020 #ifndef __AUTO_ALLOC_H_
00021 #define __AUTO_ALLOC_H_
00022
00023 #include <stdint.h>
00024 #include <stdbool.h>
00025 #include "mark3cfg.h"
00026
00027 #if KERNEL_USE_AUTO_ALLOC
00028 class AutoAlloc
00029 {
00030 public:
00037
         static void Init (void);
00038
00049
         static void *Allocate( uint16_t u16Size_ );
00051 private:
00052
         static uint8_t m_au8AutoHeap[ AUTO_ALLOC_SIZE ];
                                                             // Heap memory
00053
          static K_ADDR m_aHeapTop;
                                                             // Top of the heap
00054 }:
00055 #endif
00056
00057 #endif
```

15.49 /home/vm/mark3/trunk/embedded/kernel/public/blocking.h File Reference

Blocking object base class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
#include "thread.h"
```

Classes

class BlockingObject

Class implementing thread-blocking primatives.

15.49.1 Detailed Description

Blocking object base class declarations.

A Blocking object in Mark3 is essentially a thread list. Any blocking object implementation (being a semaphore, mutex, event flag, etc.) can be built on top of this class, utilizing the provided functions to manipu32ate thread location within the Kernel.

Blocking a thread results in that thread becoming de-scheduled, placed in the blocking object's own private list of threads which are waiting on the object.

Unblocking a thread results in the reverse: The thread is moved back to its original location from the blocking list.

The only difference between a blocking object based on this class is the logic used to determine what consitutes a Block or Unblock condition.

For instance, a semaphore Pend operation may result in a call to the Block() method with the currently-executing thread in order to make that thread wait for a semaphore Post. That operation would then invoke the UnBlock() method, removing the blocking thread from the semaphore's list, and back into the the appropriate thread inside the scheduler.

Care must be taken when implementing blocking objects to ensure that critical sections are used judiciously, otherwise asynchronous events like timers and interrupts could result in non-deterministic and often catastrophic behavior

Definition in file blocking.h.

15.50 blocking.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00047 #ifndef ___BLOCKING_H__
00048 #define __BLOCKING_H_
00049
00050 #include "kerneltypes.h"
00051 #include "mark3cfg.h"
00052
00053 #include "11.h"
```

```
00054 #include "threadlist.h"
00055 #include "thread.h"
00056
00057 #if KERNEL_USE_MUTEX || KERNEL_USE_SEMAPHORE || KERNEL_USE_EVENTFLAG
00058
00059 //--
00065 class BlockingObject
00066 {
00067 protected:
00088
          void Block(Thread *pclThread_ );
00089
00098
          void BlockPriority(Thread *pclThread_ );
00099
00111
          void UnBlock(Thread *pclThread_);
00112
00117
          ThreadList m_clBlockList;
00118 };
00119
00120 #endif
00121
00122 #endif
```

15.51 /home/vm/mark3/trunk/embedded/kernel/public/buffalogger.h File Reference

Super-efficient, super-secure logging routines.

```
#include <stdint.h>
```

15.51.1 Detailed Description

Super-efficient, super-secure logging routines.

Uses offline processing to ensure performance.

Definition in file buffalogger.h.

15.52 buffalogger.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ------ */
00020 #pragma once
00021 #include <stdint.h>
00022
00023 //----
00024 #define STR1(s) #s
00025 #define STR(s) STR1(s)
00026
00027 //--
00028 #define EMIT_DBG_STRING(str) \setminus
00029 do {
         const static volatile char log_str[] __attribute__((section (".logger"))) __attribute__((unused)) =
00030
00031
         const static volatile uint16_t line_id __attribute__((section (".logger"))) __attribute__((unused)) =
00032
         const static volatile uint16_t file_id __attribute__((section (".logger"))) __attribute__((unused)) =
      DBG_FILE; \
         const static volatile uint16_t sync __attribute__((section (".logger"))) __attribute__((unused)) =
00033
      0xCAFE;
00034 } while(0);
00035
```

15.53 /home/vm/mark3/trunk/embedded/kernel/public/driver.h File Reference

Driver abstraction framework.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

Classes

class Driver

Base device-driver class used in hardware abstraction.

· class DriverList

List of Driver objects used to keep track of all device drivers in the system.

15.53.1 Detailed Description

Driver abstraction framework.

15.53.2 Intro

This is the basis of the driver framework. In the context of Mark3, drivers don't necessarily have to be based on physical hardware peripherals. They can be used to represent algorithms (such as random number generators), files, or protocol stacks. Unlike FunkOS, where driver IO is protected automatically by a mutex, we do not use this kind of protection - we leave it up to the driver implementor to do what's right in its own context. This also frees up the driver to implement all sorts of other neat stuff, like sending messages to threads associated with the driver. Drivers are implemented as character devices, with the standard array of posix-style accessor methods for reading, writing, and general driver control.

A global driver list is provided as a convenient and minimal "filesystem" structure, in which devices can be accessed by name.

15.53.3 Driver Design

A device driver needs to be able to perform the following operations: -Initialize a peripheral -Start/stop a peripheral -Handle I/O control operations -Perform various read/write operations

At the end of the day, that's pretty much all a device driver has to do, and all of the functionality that needs to be presented to the developer.

We abstract all device drivers using a base-class which implements the following methods: -Start/Open -Stop/Close -Control -Read -Write

A basic driver framework and API can thus be implemented in five function calls - that's it! You could even reduce that further by handling the initialize, start, and stop operations inside the "control" operation.

15.53.4 Driver API

In C_{++} , we can implement this as a class to abstract these event handlers, with virtual void functions in the base class overridden by the inherited objects.

To add and remove device drivers from the global table, we use the following methods:

```
void DriverList::Add( Driver *pclDriver_);
void DriverList::Remove( Driver *pclDriver_);
```

DriverList::Add()/Remove() takes a single arguments the pointer to he object to operate on.

Once a driver has been added to the table, drivers are opened by NAME using DriverList::FindBy Name("/dev/name"). This function returns a pointer to the specified driver if successful, or to a built in /dev/null device if the path name is invalid. After a driver is open, that pointer is used for all other driver access functions.

This abstraction is incredibly useful any peripheral or service can be accessed through a consistent set of APIs, that make it easy to substitute implementations from one platform to another. Portability is ensured, the overhead is negligible, and it emphasizes the reuse of both driver and application code as separate entities.

Consider a system with drivers for I2C, SPI, and UART peripherals - under our driver framework, an application can initialize these peripherals and write a greeting to each using the same simple API functions for all drivers:

```
pclI2C = DriverList::FindByName("/dev/i2c");
pclUART = DriverList::FindByName("/dev/tty0");
pclSPI = DriverList::FindByName("/dev/spi");
pclI2C->Write(12, "Hello World!");
pclUART->Write(12, "Hello World!");
pclSPI->Write(12, "Hello World!");
```

Definition in file driver.h.

15.54 driver.h

```
00001 /*=
00002
00003
00004
00005
00006
00007
80000
00009
      --[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =====
00105 #include "kerneltypes.h"
00106 #include "mark3cfg.h'
00107
00108 #include "11.h"
00109
00110 #ifndef ___DRIVER_H_
00111 #define __DRIVER_H_
00112
00113 #if KERNEL_USE_DRIVER
00114
00115 class DriverList:
00116 //---
00121 class Driver : public LinkListNode
00122 {
00123 public:
00129
          virtual void Init() = 0;
00130
00138
          virtual uint8 t Open() = 0;
00139
00147
          virtual uint8_t Close() = 0;
00148
00163
          virtual uint16_t Read( uint16_t u16Bytes_,
00164
                                        uint8_t *pu8Data_) = 0;
00165
00181
          virtual uint16_t Write( uint16_t u16Bytes_
00182
                                         uint8_t *pu8Data_) = 0;
00183
00202
          virtual uint16_t Control( uint16_t u16Event_,
00203
                                            void *pvDataIn_,
                                           uint16_t u16SizeIn_,
00204
00205
                                           void *pvDataOut_
00206
                                           uint16_t u16SizeOut_) = 0;
00207
00216
          void SetName( const char *pcName_ ) { m_pcPath = pcName_; }
00217
00225
          const char *GetPath() { return m_pcPath; }
00226
00227 private:
00228
00230
          const char *m_pcPath;
```

```
00231 };
00232
00233 //-
00238 class DriverList
00239 {
00240 public:
         static void Init();
00249
00258
          static void Add( Driver *pclDriver_ ) { m_clDriverList.
     Add(pclDriver_); }
00259
          static void Remove( Driver *pclDriver_ ) { m_clDriverList.
00268
     Remove(pclDriver_); }
00269
00278
          static Driver *FindByPath( const char *m_pcPath );
00279
00280 private:
00281
          static DoubleLinkList m_clDriverList;
00284 };
00285
00286 #endif //KERNEL_USE_DRIVER
00287
00288 #endif
```

15.55 /home/vm/mark3/trunk/embedded/kernel/public/eventflag.h File Reference

Event Flag Blocking Object/IPC-Object definition.

```
#include "mark3cfg.h"
#include "kernel.h"
#include "kerneltypes.h"
#include "blocking.h"
#include "thread.h"
```

Classes

· class EventFlag

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

15.55.1 Detailed Description

Event Flag Blocking Object/IPC-Object definition.

Definition in file eventflag.h.

15.56 eventflag.h

```
00001
00002
00003
00004 |
                   11
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00019 #ifndef ___EVENTFLAG_H_
00020 #define ___EVENTFLAG_H_
00021
00022 #include "mark3cfg.h"
00023 #include "kernel.h
```

```
00024 #include "kerneltypes.h"
00025 #include "blocking.h"
00026 #include "thread.h"
00027
00028 #if KERNEL USE EVENTFLAG
00029
00046 class EventFlag : public BlockingObject
00047
00048 public:
         void Init() { m_u16SetMask = 0; m_clBlockList.
00052
     Init(); }
00053
00061
          uint16_t Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_);
00062
00063 #if KERNEL_USE_TIMEOUTS
00064
00072
          uint16_t Wait(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t
     u32TimeMS_);
00073
00081
          void WakeMe(Thread *pclOwner_);
00082
00083 #endif
00084
00090
         void Set(uint16_t u16Mask_);
00096
          void Clear(uint16_t u16Mask_);
00097
00102
         uint16_t GetMask();
00103
00104 private:
00105
00106 #if KERNEL_USE_TIMEOUTS
00107
00119
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation_t eMode_, uint32_t
     u32TimeMS_);
00120 #else
00131
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation_t eMode_);
00132 #endif
00133
00134
         uint16_t m_u16SetMask;
00135 };
00136
00137 #endif //KERNEL_USE_EVENTFLAG
00138 #endif //__EVENTFLAG_H_
00139
```

15.57 /home/vm/mark3/trunk/embedded/kernel/public/kernel.h File Reference

Kernel initialization and startup class.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "paniccodes.h"
#include "thread.h"
```

Classes

class Kernel

Class that encapsulates all of the kernel startup functions.

15.57.1 Detailed Description

Kernel initialization and startup class.

The Kernel namespace provides functions related to initializing and starting up the kernel.

The Kernel::Init() function must be called before any of the other functions in the kernel can be used.

15.58 kernel.h 175

Once the initial kernel configuration has been completed (i.e. first threads have been added to the scheduler), the Kernel::Start() function can then be called, which will transition code execution from the "main()" context to the threads in the scheduler.

Definition in file kernel.h.

15.58 kernel.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00032 #ifndef __KERNEL_H_
00033 #define __KERNEL_H_
00034
00035 #include "mark3cfg.h"
00036 #include "kerneltypes.h"
00037 #include "paniccodes.h"
00038 #include "thread.h"
00040 #if KERNEL_USE_IDLE_FUNC
00041 typedef void (*idle_func_t)(void);
00042 #endif
00043
00044 //
00048 class Kernel
00049 {
00050 public:
00059
          static void Init (void);
00060
00073
          static void Start (void);
00074
00081
          static bool IsStarted()
00082
00090
          static void SetPanic( panic_func_t pfPanic_ ) {
      m_pfPanic = pfPanic_; }
00091
00096
          static bool IsPanic()
                                      { return m bIsPanic;
00097
00102
          static void Panic (uint16_t u16Cause_);
00103
00104 #if KERNEL_USE_IDLE_FUNC
00105
00110
          static void SetIdleFunc( idle_func_t pfIdle_ ) {    m_pfIdle = pfIdle_; }
00111
00116
          static void IdleFunc(void) { if (m_pfIdle != 0 ) { m_pfIdle(); } }
00117
00125
          static Thread *GetIdleThread(void) { return (Thread*)&
      m clIdle: }
00126 #endif
00127
00128 private:
00129
         static bool m_bIsStarted;
00130
          static bool m_bIsPanic;
          static panic_func_t m_pfPanic;
00131
00132 #if KERNEL_USE_IDLE_FUNC
          static idle_func_t m_pfIdle;
00133
00134
          static FakeThread_t m_clIdle;
00135 #endif
00136 };
00137
00138 #endif
00139
```

15.59 /home/vm/mark3/trunk/embedded/kernel/public/kernelaware.h File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

Classes

· class KernelAware

The KernelAware class.

Enumerations

enum KernelAwareCommand_t {
 KA_COMMAND_IDLE = 0, KA_COMMAND_PROFILE_INIT, KA_COMMAND_PROFILE_START, KA_CO
 MMAND_PROFILE_STOP,
 KA_COMMAND_PROFILE_REPORT, KA_COMMAND_EXIT_SIMULATOR, KA_COMMAND_TRACE_0,
 KA_COMMAND_TRACE_1,
 KA_COMMAND_TRACE 2, KA_COMMAND_PRINT }

This enumeration contains a list of supported commands that can be executed to invoke a response from a kernel aware host.

15.59.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.h.

15.59.2 Enumeration Type Documentation

15.59.2.1 enum KernelAwareCommand_t

This enumeration contains a list of supported commands that can be executed to invoke a response from a kernel aware host.

Enumerator

KA_COMMAND_IDLE Null command, does nothing.

KA_COMMAND_PROFILE_INIT Initialize a new profiling session.

KA_COMMAND_PROFILE_START Begin a profiling sample.

KA_COMMAND_PROFILE_STOP End a profiling sample.

KA_COMMAND_PROFILE_REPORT Report current profiling session.

KA_COMMAND_EXIT_SIMULATOR Terminate the host simulator.

KA_COMMAND_TRACE_0 0-argument kernel trace

KA_COMMAND_TRACE_1 1-argument kernel trace

KA_COMMAND_TRACE_2 2-argument kernel trace

KA_COMMAND_PRINT Print an arbitrary string of data.

Definition at line 33 of file kernelaware.h.

15.60 kernelaware.h

15.60 kernelaware.h

```
00001 /*=========
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #ifndef ___KERNEL_AWARE_H__
00022 #define __KERNEL_AWARE_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #if KERNEL_AWARE_SIMULATION
00028 //--
00033 typedef enum
00034 {
          KA_COMMAND_IDLE = 0,
00035
00036
          KA_COMMAND_PROFILE_INIT,
          KA_COMMAND_PROFILE_START,
00037
00038
          KA_COMMAND_PROFILE_STOP,
00039
          KA_COMMAND_PROFILE_REPORT,
00040
          KA_COMMAND_EXIT_SIMULATOR,
00041
          KA_COMMAND_TRACE_0,
          KA COMMAND_TRACE_1,
00042
00043
          KA_COMMAND_TRACE_2,
00044
          KA_COMMAND_PRINT
00045 } KernelAwareCommand_t;
00046
00047 //---
00065 class KernelAware
00066 1
00067 public:
00068
00079
          static void ProfileInit( const char *szStr_ );
08000
00081
00089
          static void ProfileStart ( void );
00090
00091
00098
          static void ProfileStop( void );
00099
00100
          //----
          static void ProfileReport( void );
00108
00109
00110
00118
          static void ExitSimulator( void );
00119
00120
00128
          static void Print( const char *szStr_ );
00129
00130
00140
          static void Trace( uint16_t u16File_,
00141
                        uint16_t u16Line_);
00142
00143
          static void Trace ( uint16_t u16File_,
00154
00155
                        uint16_t u16Line_,
00156
                        uint16_t u16Arg1_);
00157
00158
          static void Trace( uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_,
00170
00171
00172
00173
                        uint16_t u16Arg2_);
00174
00175
          static bool IsSimulatorAware(void);
00185
00186
00187 private:
00188
00189
00202
          static void Trace_i( uint16_t u16File_,
00203
                                uint16_t u16Line_,
00204
                                uint16_t u16Arg1_,
00205
                                uint16_t u16Arg2_,
00206
                                KernelAwareCommand_t eCmd_);
00207 };
```

```
00208
00209 #endif
00210
00211 #endif
```

15.61 /home/vm/mark3/trunk/embedded/kernel/public/kerneldebug.h File Reference

Macros and functions used for assertions, kernel traces, etc.

```
#include "mark3cfg.h"
#include "tracebuffer.h"
#include "kernelaware.h"
#include "paniccodes.h"
#include "kernel.h"
#include "buffalogger.h"
#include "dbg_file_list.h"
```

Macros

• #define KERNEL_TRACE(x)

Null Kernel Trace Macro.

• #define KERNEL TRACE 1(x, arg1)

Null Kernel Trace Macro.

#define KERNEL_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.

#define KERNEL_ASSERT(x)

Null Kernel Assert Macro.

15.61.1 Detailed Description

Macros and functions used for assertions, kernel traces, etc.

Definition in file kerneldebug.h.

15.62 kerneldebug.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00020 #ifndef __KERNEL_DEBUG_H_
00021 #define ___KERNEL_DEBUG_H__
00022
00023 #include "mark3cfg.h"
00024 #include "tracebuffer.h"
00025 #include "kernelaware.h"
00026 #include "paniccodes.h"
00027 #include "kernel.h"
00028 #include "buffalogger.h"
00029 #include "dbg_file_list.h"
00030
00031 //-
00032 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
```

15.62 kerneldebug.h

```
00033
00034 //--
00035 #define KERNEL_TRACE( x ) \
00036 {
          EMIT_DBG_STRING( x );
00037
00038
          uint16_t au16Msg__[4];
          au16Msg_{[0]} = 0xACDC;
00040
          au16Msg__[1] = DBG_FILE;
          au16Msg_[2] = _LINE_; \
au16Msg_[3] = TraceBuffer::Increment(); \
00041
00042
          TraceBuffer::Write(au16Msg__, 4); \
00043
00044 };
00045
00046 //----
00047 #define KERNEL_TRACE_1( x, arg1 ) \setminus
00048 {
          EMIT_DBG_STRING( x );
00049
00050
          uint16_t au16Msg__[5];
          au16Msg__[0] = 0xACDC;
00051
00052
          au16Msg__[1] = DBG_FILE;
          aul6Msg_[2] = __LINE__; \
aul6Msg_[3] = TraceBuffer::Increment(); \
00053
00054
00055
          au16Msg_{_{_{_{_{}}}}}[4] = arg1;
00056
          TraceBuffer::Write(au16Msg___, 5); \
00057 }
00058
00059 //---
00060 #define KERNEL_TRACE_2( x, arg1, arg2 ) \
00061 {
00062
          EMIT_DBG_STRING( x ); \
00063
          uint16_t au16Msg__[6];
00064
          au16Msg_{[0]} = 0xACDC;
00065
          au16Msg__[1] = DBG_FILE;
00066
          au16Msg_{[2]} = _{LINE}_{;}
          au16Msg__[3] = TraceBuffer::Increment(); \
00067
          au16Msg__[4] = arg1;
00068
00069
          au16Msg_{[5]} = arg2;
00070
          TraceBuffer::Write(au16Msg__, 6); \
00071 }
00072
00073 //----
00074 #define KERNEL_ASSERT( x ) \
00075 {
00076
          if( (x) == false) \
00077
00078
              EMIT_DBG_STRING( "ASSERT FAILED" ); \
00079
              uint16_t au16Msg__[4];
00080
              au16Msg_{[0]} = 0xACDC;
              au16Msg__[1] = DBG_FILE;
00081
              au16Msg_[2] = __LINE__; \
au16Msg_[3] = TraceBuffer::Increment(); \
00082
00083
00084
              TraceBuffer::Write(au16Msg__, 4);
00085
              Kernel::Panic(PANIC_ASSERT_FAILED); \
00086
          }
00087
00088 #elif (KERNEL_USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
00090 //----
00091 #define KERNEL_TRACE( x )
00092 {
          EMIT DBG STRING( x ): \
00093
00094
          KernelAware::Trace( DBG_FILE, __LINE__ ); \
00095 };
00096
00097 //---
00098 #define KERNEL_TRACE_1( x, arg1 ) \setminus
00099 {
00100
          EMIT DBG STRING( x ); \
00101
          KernelAware::Trace( DBG_FILE, __LINE__, arg1 ); \
00102 }
00103
00104 //----
00105 #define KERNEL_TRACE_2( x, arg1, arg2 ) \
00106 {
          EMIT_DBG_STRING( x ); \
00107
00108
          KernelAware::Trace( DBG_FILE, __LINE__, arg1, arg2 ); \
00109 }
00110
00111 //---
00112 #define KERNEL_ASSERT( x ) \
00113 {
00114
          if((x) == false) \setminus
00115
00116
              EMIT_DBG_STRING( "ASSERT FAILED" ); \
00117
              KernelAware::Trace( DBG_FILE, __LINE___); \
              Kernel::Panic( PANIC_ASSERT_FAILED );
00118
00119
          }
```

```
00120 }
00121
00122 #else
00123 //---
00124 // Note -- when kernel-debugging is disabled, we still have to define the
00125 // macros to ensure that the expressions compile (albeit, by elimination
00126 // during pre-processing).
00127 //--
00128 #define KERNEL_TRACE( x )
00129 //-
00130 #define KERNEL_TRACE_1( x, arg1 )
00131 //---
00132 #define KERNEL_TRACE_2( x, arg1, arg2 )
00133 //-
00134 #define KERNEL_ASSERT( x )
00135
00136 #endif // KERNEL_USE_DEBUG
00137
00139 //--
00140 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
00141
00142 //----
00143 #define USER TRACE(x)
00144 {
          EMIT_DBG_STRING( x );
00146
          uint16_t au16Msg__[4];
00147
          au16Msg_{[0]} = 0xACDC;
00148
          au16Msg__[1] = DBG_FILE;
          aul6Msg_[2] = _LINE_; \
aul6Msg_[3] = TraceBuffer::Increment(); \
00149
00150
00151
          TraceBuffer::Write(au16Msg___, 4); \
00152 };
00153
00154 //----
00155 #define USER_TRACE_1( x, arg1 ) \
00156 {
          EMIT_DBG_STRING( x );
00158
          uint16_t au16Msg__[5];
00159
          au16Msg_{[0]} = 0xACDC;
          au16Msg__[1] = DBG_FILE;
00160
          aul6Msg_[2] = __LINE__; \
aul6Msg_[3] = TraceBuffer::Increment(); \
aul6Msg_[4] = arg1; \
00161
00162
00163
          TraceBuffer::Write(au16Msg__, 5); \
00164
00165 }
00166
00167 //----
00168 #define USER_TRACE_2( x, arg1, arg2 ) \
00169 {
00170
          EMIT_DBG_STRING( x );
00171
          uint16_t au16Msg__[6];
00172
          au16Msg_{[0]} = 0xACDC;
00173
          au16Msg_[2] = __LINE__; \
au16Msg_[3] = TraceBuffer::Increment(); \
00174
00175
          au16Msg__[5] = arg1;
au16Msg__[5] = arg2;
00176
00177
00178
          TraceBuffer::Write(au16Msg__, 6); \
00179 }
00180
00181 //-
00182 #define USER_ASSERT( x ) \
00183 {
00184
          if((x) == false) \
00185
              EMIT_DBG_STRING( "ASSERT FAILED" ); \
00186
00187
              uint16_t au16Msg__[4];
              au16Msg__[0] = 0xACDC;
00188
              au16Msg__[1] = DBG_FILE;
00189
              au16Msg_[2] = __LINE__; \
au16Msg_[3] = TraceBuffer::Increment(); \
00190
00191
              TraceBuffer::Write(au16Msg__, 4); \
Kernel::Panic(PANIC_ASSERT_FAILED); \
00192
00193
00194
          }
00195 }
00196 #elif (KERNEL_USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
00197
00198 //---
00199 #define USER TRACE(x)
00200 {
00201
          EMIT_DBG_STRING( x ); \
00202
          KernelAware::Trace( DBG_FILE, __LINE__ ); \
00203 };
00204
00205 //----
00206 #define USER_TRACE_1( x, arg1 ) \
```

```
00208
          EMIT_DBG_STRING( x ); \
         KernelAware::Trace( DBG_FILE, __LINE__, arg1 ); \
00209
00210 }
00211
00212 //--
00213 #define USER_TRACE_2( x, arg1, arg2 ) \
00214 {
00215
         EMIT_DBG_STRING( x ); \
00216
         KernelAware::Trace( DBG_FILE, __LINE__, arg1, arg2 ); \
00217 }
00218
00219 //--
00220 #define USER_ASSERT( x ) \
00221 {
00222
00223
          if((x)) == false) \setminus
             EMIT_DBG_STRING( "ASSERT FAILED" ); \
00224
             KernelAware::Trace( DBG_FILE, __LINE__ ); \
              Kernel::Panic( PANIC_ASSERT_FAILED ); \
00227
00228 }
00229
00230 #else
00231 //-
00232 // Note -- when kernel-debugging is disabled, we still have to define the
00233 // macros to ensure that the expressions compile (albeit, by elimination
00234 // during pre-processing).
00235 //--
00236 #define USER TRACE(x)
00237 //-
00238 #define USER_TRACE_1( x, arg1 )
00239 /
00240 #define USER_TRACE_2( x, arg1, arg2 )
00241 /
00242 #define USER_ASSERT( x )
00243
00244 #endif // KERNEL_USE_DEBUG
00245
00246 #endif
```

15.63 /home/vm/mark3/trunk/embedded/kernel/public/kerneltypes.h File Reference

Basic data type primatives used throughout the OS.

```
#include <stdint.h>
```

Macros

• #define K_ADDR uint32_t

Primative datatype representing address-size.

• #define K_WORD uint32_t

Primative datatype representing a data word.

Typedefs

typedef void(* panic_func_t)(uint16_t u16PanicCode_)

Function pointer type used to implement kernel-panic handlers.

Enumerations

enum EventFlagOperation_t {
 EVENT_FLAG_ALL, EVENT_FLAG_ANY, EVENT_FLAG_ALL_CLEAR, EVENT_FLAG_ANY_CLEAR,
 EVENT_FLAG_MODES, EVENT_FLAG_PENDING_UNBLOCK }

This enumeration describes the different operations supported by the event flag blocking object.

15.63.1 Detailed Description

Basic data type primatives used throughout the OS.

Definition in file kerneltypes.h.

15.63.2 Enumeration Type Documentation

15.63.2.1 enum EventFlagOperation_t

This enumeration describes the different operations supported by the event flag blocking object.

Enumerator

EVENT_FLAG_ALL Block until all bits in the specified bitmask are set.

EVENT_FLAG_ANY Block until any bits in the specified bitmask are set.

EVENT_FLAG_ALL_CLEAR Block until all bits in the specified bitmask are cleared.

EVENT_FLAG_ANY_CLEAR Block until any bits in the specified bitmask are cleared.

EVENT_FLAG_MODES Count of event-flag modes. Not used by user

EVENT_FLAG_PENDING_UNBLOCK Special code. Not used by user

Definition at line 43 of file kerneltypes.h.

15.64 kerneltypes.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00019 #include <stdint.h>
00020
00021 #ifndef __KERNELTYPES_H_
00022 #define __KERNELTYPES_H_
00023
00024 //----
00025 #if !defined(K_ADDR)
00026 #define K_ADDR
                                 uint32 t
00027 #endif
00028 #if !defined(K_WORD)
00029
           #define K_WORD
                                 uint32_t
00030 #endif
00031
00032 //
00036 typedef void (*panic_func_t) ( uint16_t u16PanicCode_ );
00037
00038 //---
00043 typedef enum
00044 {
00045
          EVENT FLAG ALL.
          EVENT_FLAG_ANY,
EVENT_FLAG_ALL_CLEAR,
00046
00047
00048
          EVENT_FLAG_ANY_CLEAR,
00049 //---
00050
          EVENT_FLAG_MODES,
00051
          EVENT FLAG PENDING UNBLOCK
00052 } EventFlagOperation_t;
00053
00054 #endif
```

15.65 /home/vm/mark3/trunk/embedded/kernel/public/ksemaphore.h File Reference

Semaphore Blocking Object class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "threadlist.h"
```

Classes

· class Semaphore

Counting semaphore, based on BlockingObject base class.

15.65.1 Detailed Description

Semaphore Blocking Object class declarations.

Definition in file ksemaphore.h.

15.66 ksemaphore.h

```
00001 /*======
00002
00003
00004
                 1 - 11
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00022 #ifndef ___KSEMAPHORE_H_
00023 #define ___KSEMAPHORE_H_
00024
00025 #include "kerneltypes.h"
00026 #include "mark3cfg.h"
00027
00028 #include "blocking.h"
00029 #include "threadlist.h"
00030
00031 #if KERNEL_USE_SEMAPHORE
00032
00033 //---
00037 class Semaphore : public BlockingObject
00038 {
00039 public:
00049
         void Init(uint16_t u16InitVal_, uint16_t u16MaxVal_);
00059
         bool Post();
00060
00067
         void Pend();
00068
08000
         uint16 t GetCount();
00081
00082 #if KERNEL_USE_TIMEOUTS
00083
00094
         bool Pend( uint32_t u32WaitTimeMS_);
00095
00106
          void WakeMe(Thread *pclChosenOne_);
00107 #endif
00108
00109 private:
00110
00116
          uint8_t WakeNext();
00117
00118 #if KERNEL_USE_TIMEOUTS
00119
```

```
bool Pend_i( uint32_t u32WaitTimeMS_ );
00128 #else
00129
00135
         void Pend_i( void );
00136 #endif
00137
00138
          uint16_t m_u16Value;
00139
          uint16_t m_u16MaxValue;
00140
00141
00142 };
00143
00144 #endif //KERNEL_USE_SEMAPHORE
00145
00146 #endif
```

15.67 /home/vm/mark3/trunk/embedded/kernel/public/II.h File Reference

Core linked-list declarations, used by all kernel list types.

```
#include "kerneltypes.h"
```

Classes

· class LinkListNode

Basic linked-list node data structure.

class LinkList

Abstract-data-type from which all other linked-lists are derived.

class DoubleLinkList

Doubly-linked-list data type, inherited from the base LinkList type.

class CircularLinkList

Circular-linked-list data type, inherited from the base LinkList type.

15.67.1 Detailed Description

Core linked-list declarations, used by all kernel list types.

At the heart of RTOS data structures are linked lists. Having a robust and efficient set of linked-list types that we can use as a foundation for building the rest of our kernel types allows u16 to keep our RTOS code efficient and logically-separated.

So what data types rely on these linked-list classes?

-Threads -ThreadLists -The Scheduler -Timers, -The Timer Scheduler -Blocking objects (Semaphores, Mutexes, etc...)

Pretty much everything in the kernel uses these linked lists. By having objects inherit from the base linked-list node type, we're able to leverage the double and circular linked-list classes to manager virtually every object type in the system without duplicating code. These functions are very efficient as well, allowing for very deterministic behavior in our code.

Definition in file II.h.

15.68 II.h



15.68 II.h 185

```
____
              ___
                     ___
                                                1__
00008
00009 -- [Mark3 Realtime Platform] ------
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00043 #ifndef __LL_H__
00044 #define __LL_H_
00045
00046 #include "kerneltypes.h"
00047
00048 //--
00049 #ifndef NULL
00050 #define NULL
                          (0)
00051 #endif
00052
00053 //---
00059 class LinkList;
00060 class DoubleLinkList;
00061 class CircularLinkList;
00062
00063 //----
00068 class LinkListNode
00069 {
00070 protected:
00071
00072
          LinkListNode *next;
00073
         LinkListNode *prev;
00074
00075
         LinkListNode() { }
00076
00082
         void ClearNode();
00083
00084 public:
         LinkListNode *GetNext(void) { return next; }
00092
00093
00101
          LinkListNode *GetPrev(void) { return prev; }
00102
00103
          friend class LinkList;
00104
          friend class DoubleLinkList;
          friend class CircularLinkList;
00105
00106
          friend class ThreadList;
00107 };
00108
00109 //--
00113 class LinkList
00114 {
00115 protected:
         LinkListNode *m_pstHead;
00116
00117
         LinkListNode *m_pstTail;
00118
00119 public:
00125
         void Init() { m_pstHead = NULL; m_pstTail = NULL; }
00126
00134
         virtual void Add(LinkListNode *node ) = 0;
00135
00143
         virtual void Remove(LinkListNode *node_) = 0;
00144
00152
         LinkListNode *GetHead() { return m_pstHead; }
00153
          LinkListNode *GetTail() { return m_pstTail; }
00161
00162 };
00163
00164 //-
00168 class DoubleLinkList : public LinkList
00169 {
00170 public:
00176
         DoubleLinkList() { m_pstHead = NULL; m_pstTail = NULL; }
00177
00185
         virtual void Add(LinkListNode *node_);
00186
00194
         virtual void Remove(LinkListNode *node_);
00195 };
00196
00197 //
00201 class CircularLinkList : public LinkList
00202 {
00203 public:
00204
         CircularLinkList() { m_pstHead = NULL; m_pstTail = NULL; }
00205
00213
          virtual void Add(LinkListNode *node_);
00214
00222
         virtual void Remove(LinkListNode *node_);
00223
          void PivotForward();
00230
00231
```

15.69 /home/vm/mark3/trunk/embedded/kernel/public/mailbox.h File Reference

Mailbox + Envelope IPC Mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "ksemaphore.h"
```

15.69.1 Detailed Description

Mailbox + Envelope IPC Mechanism.

Definition in file mailbox.h.

15.70 mailbox.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00021 #ifndef ___MAILBOX_H_
00022 #define __MAILBOX_H_
00023
00024 #include "mark3cfg.h"
00025 #include "kerneltypes.h"
00026 #include "ksemaphore.h"
00027
00028 #if KERNEL USE MAILBOX
00029
00030 class Mailbox
00031 {
00032 public:
00033
00044
          void Init( void *pvBuffer_, uint16_t ul6BufferSize_, uint16_t ul6ElementSize_ );
00045
00046 #if KERNEL_USE_AUTO_ALLOC
00047
00060
          static Mailbox* Init( uint16_t u16BufferSize_, uint16_t u16ElementSize_ );
00061
00062 #endif
00063
00077
          bool Send( void *pvData_ );
00078
00092
          bool SendTail( void *pvData_ );
00093
00094 #if KERNEL USE TIMEOUTS
00095
00109
          bool Send( void *pvData_, uint32_t u32TimeoutMS_ );
00110
00125
          bool SendTail( void *pvData_, uint32_t u32TimeoutMS_ );
00126 #endif
00127
00137
          void Receive( void *pvData );
00138
00148
          void ReceiveTail( void *pvData_ );
```

15.70 mailbox.h 187

```
00149
00150 #if KERNEL_USE_TIMEOUTS
00151
00163
          bool Receive( void *pvData_, uint32_t u32TimeoutMS_ );
00164
          bool ReceiveTail( void *pvData_, uint32_t u32TimeoutMS_ );
00177
00178 #endif
00179
00180
          uint16_t GetFreeSlots( void )
00181
              uint16 t rc;
00182
00183
             CS_ENTER();
00184
              rc = m_u16Free;
00185
              CS_EXIT();
00186
              return rc;
00187
          }
00188
00189
          bool IsFull ( void )
00190
00191
              return (GetFreeSlots() == 0);
00192
00193
00194
          bool IsEmpty ( void )
00195
00196
              return (GetFreeSlots() == m_u16Count);
00197
00198
00199 private:
00200
00209
          void *GetHeadPointer(void)
00210
          {
00211
              K_ADDR uAddr = (K_ADDR)m_pvBuffer;
00212
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (m_u16Head);
00213
              return (void*)uAddr;
00214
          }
00215
00224
          void *GetTailPointer(void)
00225
00226
              K_ADDR uAddr = (K_ADDR)m_pvBuffer;
00227
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (m_u16Tail);
00228
              return (void*)uAddr;
00229
          }
00230
00240
          void CopyData( const void *src_, const void *dst_, uint16_t len_ )
00241
00242
              uint8_t *u8Src = (uint8_t*)src_;
00243
              uint8_t *u8Dst = (uint8_t*)dst_;
00244
              while (len_--)
00245
              {
00246
                  *u8Dst++ = *u8Src++;
00247
              }
00248
          }
00249
00255
          void MoveTailForward(void)
00256
00257
              m_u16Tail++;
00258
              if (m_u16Tail == m_u16Count)
00259
00260
                  m_u16Tail = 0;
00261
              }
00262
          }
00263
00269
          void MoveHeadForward(void)
00270
00271
              m_u16Head++;
00272
              if (m_u16Head == m_u16Count)
00273
              {
00274
                  m u16Head = 0:
00275
00276
          }
00277
00283
          void MoveTailBackward(void)
00284
              if (m_u16Tail == 0)
00285
00286
              {
00287
                  m_u16Tail = m_u16Count;
00288
              m_u16Tail--;
00289
00290
          }
00291
00297
          void MoveHeadBackward(void)
00298
00299
              if (m_u16Head == 0)
00300
00301
                  m_u16Head = m_u16Count;
00302
00303
              m_u16Head--;
```

```
00304
00305
00306 #if KERNEL_USE_TIMEOUTS
00307
00317
          bool Send_i( const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_ );
00318 #else
00319
00328
          bool Send_i( const void *pvData_, bool bTail_ );
00329 #endif
00330
00331 #if KERNEL USE TIMEOUTS
00332
00342
         bool Receive_i( const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_ );
00343 #else
00344
00352
          void Receive_i( const void *pvData_, bool bTail_ );
00353 #endif
00354
00355
         uint16_t m_u16Head;
00356
         uint16_t m_u16Tail;
00357
00358
         uint16_t m_u16Count;
00359
         volatile uint16_t m_u16Free;
00360
00361
         uint16_t m_u16ElementSize;
00362
         const void *m_pvBuffer;
00363
00364
         Semaphore m_clRecvSem;
00365
00366 #if KERNEL USE TIMEOUTS
00367
        Semaphore m_clSendSem;
00368 #endif
00369
00370 };
00371
00372 #endif
00373
00374 #endif
00375
```

15.71 /home/vm/mark3/trunk/embedded/kernel/public/manual.h File Reference

Ascii-format documentation, used by doxygen to create various printable and viewable forms.

15.71.1 Detailed Description

Ascii-format documentation, used by doxygen to create various printable and viewable forms. Definition in file manual.h.

15.72 manual.h



15.73 /home/vm/mark3/trunk/embedded/kernel/public/mark3.h File Reference

Single include file given to users of the Mark3 Kernel API.

15.74 mark3.h 189

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "threadport.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "kernelprofile.h"
#include "kernel.h"
#include "thread.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "mutex.h"
#include "eventflag.h"
#include "message.h"
#include "notify.h"
#include "mailbox.h"
#include "atomic.h"
#include "driver.h"
#include "kernelaware.h"
#include "profile.h"
#include "autoalloc.h"
```

15.73.1 Detailed Description

Single include file given to users of the Mark3 Kernel API.

Definition in file mark3.h.

15.74 mark3.h

```
00001 /*
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 -----*/
00021 #ifndef ___MARK3_H__
00022 #define ___MARK3_H__
00023
00024 #include "mark3cfg.h"
00025 #include "kerneltypes.h"
00026
00027 #include "threadport.h"
00028 #include "kernelswi.h"
00029 #include "kerneltimer.h"
00030 #include "kernelprofile.h"
00031
00032 #include "kernel.h"
00033 #include "thread.h"
00034 #include "timerlist.h"
00035
00036 #include "ksemaphore.h"
00037 #include "mutex.h"
00038 #include "eventflag.h"
00039 #include "message.h
00040 #include "notify.h"
00041 #include "mailbox.h"
00042
00043 #include "atomic.h'
00044 #include "driver.h"
00045
00046 #include "kernelaware.h"
```

```
00047
00048 #include "profile.h"
00049 #include "autoalloc.h"
00050
00051 #endif
```

15.75 /home/vm/mark3/trunk/embedded/kernel/public/mark3cfg.h File Reference

Mark3 Kernel Configuration.

Macros

• #define KERNEL USE TIMERS (1)

The following options is related to all kernel time-tracking.

#define KERNEL_TIMERS_TICKLESS (1)

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

• #define KERNEL USE TIMEOUTS (1)

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it

• #define KERNEL_USE_QUANTUM (1)

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

#define THREAD QUANTUM DEFAULT (4)

This value defines the default thread quantum when KERNEL_USE_QUANTUM is enabled.

• #define KERNEL USE NOTIFY (1)

This is a simple blocking object, where a thread (or threads) are guaranteed to block until an asynchronous event signals the object.

• #define KERNEL USE SEMAPHORE (1)

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

• #define KERNEL USE MUTEX (1)

Do you want the ability to use mutual exclusion semaphores (mutex) for resource/block protection? Enabling this feature provides mutexes, with priority inheritence, as declared in mutex.h.

• #define KERNEL USE EVENTFLAG (1)

Provides additional event-flag based blocking.

#define KERNEL_USE_MESSAGE (1)

Enable inter-thread messaging using message queues.

• #define GLOBAL_MESSAGE_POOL_SIZE (8)

If Messages are enabled, define the size of the default kernel message pool.

#define KERNEL_USE_MAILBOX (1)

Enable inter-thread messaging using mailboxes.

• #define KERNEL_USE_SLEEP (1)

Do you want to be able to set threads to sleep for a specified time? This enables the Thread::Sleep() API.

#define KERNEL_USE_DRIVER (1)

Enabling device drivers provides a posix-like filesystem interface for peripheral device drivers.

• #define KERNEL_USE_THREADNAME (0)

Provide Thread method to allow the user to set a name for each thread in the system.

• #define KERNEL_USE_DYNAMIC_THREADS (1)

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime.

• #define KERNEL USE PROFILER (1)

Provides extra classes for profiling the performance of code.

#define KERNEL_USE_DEBUG (1)

Provides extra logic for kernel debugging, and instruments the kernel with extra asserts, and kernel trace functionality.

#define KERNEL ENABLE LOGGING (0)

Set this to 1 to enable very chatty kernel logging.

#define KERNEL ENABLE USER LOGGING (1)

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently.

#define KERNEL USE ATOMIC (0)

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

• #define SAFE UNLINK (0)

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

#define KERNEL AWARE SIMULATION (1)

Include support for kernel-aware simulation.

• #define KERNEL USE IDLE FUNC (1)

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

#define KERNEL USE AUTO ALLOC (0)

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

15.75.1 Detailed Description

Mark3 Kernel Configuration.

This file is used to configure the kernel for your specific application in order to provide the optimal set of features for a given use case.

Since you only pay the price (code space/RAM) for the features you use, you can usually find a sweet spot between features and resource usage by picking and choosing features a-la-carte. This config file is written in an "interactive" way, in order to minimize confusion about what each option provides, and to make dependencies obvious.

Definition in file mark3cfg.h.

15.75.2 Macro Definition Documentation

15.75.2.1 #define GLOBAL_MESSAGE_POOL_SIZE (8)

If Messages are enabled, define the size of the default kernel message pool.

Messages can be manually added to the message pool, but this mechansims is more convenient and automatic. All message queues share their message objects from this global pool to maximize efficiency and simplify data management.

Definition at line 150 of file mark3cfg.h.

15.75.2.2 #define KERNEL_AWARE_SIMULATION (1)

Include support for kernel-aware simulation.

Enabling this feature adds advanced profiling, trace, and environment-aware debugging and diagnostic functionality when Mark3-based applications are run on the flavr AVR simulator.

Definition at line 254 of file mark3cfg.h.

15.75.2.3 #define KERNEL_ENABLE_LOGGING (0)

Set this to 1 to enable very chatty kernel logging.

Since most important things in the kernel emit logs, a large log-buffer and fast output are required in order to keep up. This is a pretty advanced power-user type feature, so it's disabled by default.

Definition at line 218 of file mark3cfg.h.

15.75.2.4 #define KERNEL_ENABLE_USER_LOGGING (1)

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently.

This allows for user-code to benefit from the built-in kernel logging macros without having to account for the superhigh-volume of logs generated by kernel code.1 to enable logging outside of kernel code

Definition at line 227 of file mark3cfg.h.

15.75.2.5 #define KERNEL_TIMERS_TICKLESS (1)

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

Tick-based timers provide a "traditional" RTOS timer implementation based on a fixed-frequency timer interrupt. While this provides very accurate, reliable timing, it also means that the CPU is being interrupted far more often than may be necessary (as not all timer ticks result in "real work" being done).

Tick-less timers still rely on a hardware timer interrupt, but uses a dynamic expiry interval to ensure that the interrupt is only called when the next timer expires. This increases the complexity of the timer interrupt handler, but reduces the number and frequency.

Note that the CPU port (kerneltimer.cpp) must be implemented for the particular timer variant desired.

Definition at line 62 of file mark3cfg.h.

15.75.2.6 #define KERNEL_USE_ATOMIC (0)

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

Add/Sub/Set contain 8, 16, and 32-bit variants.

Definition at line 238 of file mark3cfg.h.

15.75.2.7 #define KERNEL_USE_AUTO_ALLOC (0)

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

Note that auto-alloc memory cannot be reclaimed.

Definition at line 271 of file mark3cfg.h.

15.75.2.8 #define KERNEL_USE_DYNAMIC_THREADS (1)

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime. useful for designs implementing worker threads, or threads that can be restarted after encountering error conditions. Definition at line 197 of file mark3cfg.h.

15.75.2.9 #define KERNEL_USE_EVENTFLAG (1)

Provides additional event-flag based blocking.

This relies on an additional per-thread flag-mask to be allocated, which adds 2 bytes to the size of each thread object.

Definition at line 129 of file mark3cfg.h.

15.75.2.10 #define KERNEL_USE_IDLE_FUNC (1)

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

This saves a full thread stack, but also requires a bit extra static data. This also adds a slight overhead to the context switch and scheduler, as a special case has to be taken into account.

Definition at line 263 of file mark3cfg.h.

15.75.2.11 #define KERNEL_USE_MAILBOX (1)

Enable inter-thread messaging using mailboxes.

A mailbox manages a blob of data provided by the user, that is partitioned into fixed-size blocks called envelopes. The size of an envelope is set by the user when the mailbox is initialized. Any number of threads can read-from and write-to the mailbox. Envelopes can be sent-to or received-from the mailbox at the head or tail. In this way, mailboxes essentially act as a circular buffer that can be used as a blocking FIFO or LIFO queue.

Definition at line 163 of file mark3cfg.h.

15.75.2.12 #define KERNEL_USE_MESSAGE (1)

Enable inter-thread messaging using message queues.

This is the preferred mechanism for IPC for serious multi-threaded communications; generally anywhere a semaphore or event-flag is insufficient.

Definition at line 137 of file mark3cfg.h.

15.75.2.13 #define KERNEL_USE_PROFILER (1)

Provides extra classes for profiling the performance of code.

useful for debugging and development, but uses an additional hardware timer.

Definition at line 203 of file mark3cfg.h.

15.75.2.14 #define KERNEL_USE_QUANTUM (1)

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

This allows equal tasks to use unequal amounts of the CPU, which is a great way to set up CPU budgets per thread in a round-robin scheduling system. If enabled, you can specify a number of ticks that serves as the default time period (quantum). Unless otherwise specified, every thread in a priority will get the default quantum.

Definition at line 92 of file mark3cfg.h.

15.75.2.15 #define KERNEL_USE_SEMAPHORE (1)

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

If you have to pick one blocking mechanism, this is the one to choose.

Definition at line 115 of file mark3cfg.h.

15.75.2.16 #define KERNEL_USE_THREADNAME (0)

Provide Thread method to allow the user to set a name for each thread in the system.

Adds a const char* pointer to the size of the thread object.

Definition at line 189 of file mark3cfg.h.

15.75.2.17 #define KERNEL_USE_TIMEOUTS (1)

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it.

This support comes at a small cost to code size, but a slightly larger cost to realtime performance - as checking for the use of timers in the underlying internal code costs some cycles.

As a result, the option is given to the user here to manually disable these timeout-based APIs if desired by the user for performance and code-size reasons.

Definition at line 77 of file mark3cfg.h.

15.75.2.18 #define KERNEL_USE_TIMERS (1)

The following options is related to all kernel time-tracking.

-timers provide a way for events to be periodically triggered in a lightweight manner. These can be periodic, or one-shot.

-Thread Quantum (usedd for round-robin scheduling) is dependent on this module, as is Thread Sleep functionality. Definition at line 41 of file mark3cfg.h.

15.75.2.19 #define SAFE_UNLINK (0)

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

This goes beyond pointer checks, adding a layer of structural and metadata validation to help detect system corruption early.

Definition at line 246 of file mark3cfg.h.

15.75.2.20 #define THREAD QUANTUM DEFAULT (4)

This value defines the default thread quantum when KERNEL_USE_QUANTUM is enabled.

The thread quantum value is in milliseconds

Definition at line 101 of file mark3cfg.h.

15.76 mark3cfg.h 195

15.76 mark3cfg.h

```
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 -----
00029 #ifndef ___MARK3CFG_H__
00030 #define __MARK3CFG_H_
00031
00041 #define KERNEL_USE_TIMERS
                                             (1)
00042
00061 #if KERNEL_USE_TIMERS
00062
        #define KERNEL_TIMERS_TICKLESS
                                             (1)
00063 #endif
00064
00076 #if KERNEL_USE_TIMERS
00077
        #define KERNEL_USE_TIMEOUTS
                                             (1)
00078 #else
00079
       #define KERNEL_USE_TIMEOUTS
00080 #endif
00081
00091 #if KERNEL_USE_TIMERS
00092
         #define KERNEL_USE_QUANTUM
                                             (1)
00093 #else
        #define KERNEL_USE_QUANTUM
00094
00095 #endif
00096
00101 #define THREAD_QUANTUM_DEFAULT
                                             (4)
00102
00107 #define KERNEL_USE_NOTIFY
                                             (1)
00108
00115 #define KERNEL_USE_SEMAPHORE
                                             (1)
00116
00122 #define KERNEL_USE_MUTEX
                                             (1)
00123
00129 #define KERNEL_USE_EVENTFLAG
00130
00136 #if KERNEL_USE_SEMAPHORE
         #define KERNEL_USE_MESSAGE
                                             (1)
00138 #else
00139
        #define KERNEL_USE_MESSAGE
                                             (0)
00140 #endif
00141
00149 #if KERNEL_USE_MESSAGE
         #define GLOBAL_MESSAGE_POOL_SIZE
00150
                                             (8)
00151 #endif
00152
00162 #if KERNEL USE SEMAPHORE
00163
        #define KERNEL_USE_MAILBOX
00164 #else
00165
        #define KERNEL_USE_MAILBOX
                                             (0)
00166 #endif
00167
00172 #if KERNEL_USE_TIMERS && KERNEL_USE_SEMAPHORE
00173
        #define KERNEL_USE_SLEEP
00174 #else
00175
       #define KERNEL_USE_SLEEP
00176 #endif
00177
00182 #define KERNEL_USE_DRIVER
                                             (1)
00183
00189 #define KERNEL USE THREADNAME
00190
00197 #define KERNEL_USE_DYNAMIC_THREADS
                                             (1)
00198
00203 #define KERNEL_USE_PROFILER
                                             (1)
00204
00209 #define KERNEL USE DEBUG
00210
00211 #if KERNEL_USE_DEBUG
00212
00218
         #define KERNEL_ENABLE_LOGGING
                                             (0)
00219
         #define KERNEL ENABLE USER LOGGING
                                             (1)
00228 #else
00229
       #define KERNEL_ENABLE_LOGGING
00230
         #define KERNEL_ENABLE_USER_LOGGING
```

```
00231 #endif
00233
00238 #define KERNEL_USE_ATOMIC
00239
00246 #define SAFE_UNLINK
00254 #define KERNEL_AWARE_SIMULATION
00255
00263 #define KERNEL USE IDLE FUNC
                                                (1)
00264
00271 #define KERNEL USE AUTO ALLOC
00272
00273 #if KERNEL_USE_AUTO_ALLOC
00274
         #define AUTO_ALLOC_SIZE
                                                (512)
00275 #endif
00276
00277 #endif
```

15.77 /home/vm/mark3/trunk/embedded/kernel/public/message.h File Reference

Inter-thread communication via message-passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "ksemaphore.h"
#include "timerlist.h"
```

Classes

· class Message

Class to provide message-based IPC services in the kernel.

class GlobalMessagePool

Implements a list of message objects shared between all threads.

· class MessageQueue

List of messages, used as the channel for sending and receiving messages between threads.

15.77.1 Detailed Description

Inter-thread communication via message-passing.

Embedded systems guru Jack Ganssle once said that without a robust form of interprocess communications (IPC), an RTOS is just a toy. Mark3 implements a form of IPC to provide safe and flexible messaging between threads.

using kernel-managed IPC offers significant benefits over other forms of data sharing (i.e. Global variables) in that it avoids synchronization issues and race conditions common to the practice. using IPC also enforces a more disciplined coding style that keeps threads decoupled from one another and minimizes global data, preventing careless and hard-to-debug errors.

15.77.2 using Messages, Queues, and the Global Message Pool

15.78 message.h 197

```
void Thread1()
   // Example TX thread - sends a message every 10ms
   while(1)
       // Grab a message from the global message pool
       Message *tx_message = GlobalMessagePool::Pop();
       // Set the message data/parameters
       tx_message->SetCode( 1234 );
       tx_message->SetData( NULL );
       // Send the message on the queue.
       my_queue.Send( tx_message );
       Thread::Sleep(10);
void Thread2()
   while()
       // Do something with the message data...
       // Return back into the pool when done
       GlobalMessagePool::Push(rx_message);
}
```

Definition in file message.h.

15.78 message.h

```
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -----
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00080 #ifndef __MESSAGE_H_
00081 #define __MESSAGE_H_
00082
00083 #include "kerneltypes.h"
00084 #include "mark3cfg.h"
00085
00086 #include "11.h"
00087 #include "ksemaphore.h"
00088
00089 #if KERNEL_USE_MESSAGE
00090
00091 #if KERNEL_USE_TIMEOUTS
        #include "timerlist.h"
00092
00093 #endif
00094
00095 //--
00099 class Message : public LinkListNode
00100 {
00101 public:
00107
         void Init() { ClearNode(); m_pvData = NULL; m_u16Code = 0; }
00108
00116
         void SetData( void *pvData_ ) { m_pvData = pvData_; }
00117
00125
         void *GetData() { return m_pvData; }
00126
00134
         void SetCode( uint16_t u16Code_ ) { m_u16Code = u16Code_; }
00135
00143
         uint16_t GetCode() { return m_u16Code; }
00144 private:
00145
00147
         void *m pvData;
00148
00150
         uint16_t m_u16Code;
```

```
00151 };
00153 //--
00157 class GlobalMessagePool
00158 {
00159 public:
00165
         static void Init();
00166
00176
         static void Push( Message *pclMessage_ );
00177
00186
         static Message *Pop();
00187
00188 private:
         static Message m_aclMessagePool[
     GLOBAL_MESSAGE_POOL_SIZE];
00191
         static DoubleLinkList m clList:
00193
00194 };
00195
00196 //--
00201 class MessageQueue
00202 {
00203 public:
00209
         void Init();
00210
00219
        Message *Receive();
00220
00221 #if KERNEL_USE_TIMEOUTS
00222
         Message *Receive( uint32_t u32TimeWaitMS_ );
00236
00237 #endif
00238
00247
         void Send( Message *pclSrc_ );
00248
00256
         uint16_t GetCount();
00257 private:
00258
00259 #if KERNEL_USE_TIMEOUTS
00260
00269
         Message *Receive_i( uint32_t u32TimeWaitMS_ );
00270 #else
00271
00278
          Message *Receive_i( void );
00279 #endif
00280
00282
          Semaphore m_clSemaphore;
00283
00285
         DoubleLinkList m_clLinkList;
00286 };
00287
00288 #endif //KERNEL_USE_MESSAGE
00289
00290 #endif
```

15.79 /home/vm/mark3/trunk/embedded/kernel/public/mutex.h File Reference

Mutual exclusion class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "timerlist.h"
```

Classes

class Mutex

Mutual-exclusion locks, based on BlockingObject.

15.79.1 Detailed Description

Mutual exclusion class declaration.

15.80 mutex.h 199

Resource locks are implemented using mutual exclusion semaphores (Mutex_t). Protected blocks can be placed around any resource that may only be accessed by one thread at a time. If additional threads attempt to access the protected resource, they will be placed in a wait queue until the resource becomes available. When the resource becomes available, the thread with the highest original priority claims the resource and is activated. Priority inheritance is included in the implementation to prevent priority inversion. Always ensure that you claim and release your mutex objects consistently, otherwise you may end up with a deadlock scenario that's hard to debug.

15.79.2 Initializing

Initializing a mutex object by calling:

```
clMutex.Init();
```

15.79.3 Resource protection example

```
clMutex.Claim();
...
<resource protected block>
...
clMutex.Release();
```

Definition in file mutex.h.

15.80 mutex.h

```
00001 /
00002
00004
00005
00006
00007
00008
00009 -
        -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===
00050 #ifndef __MUTEX_H_
00051 #define __MUTEX_H_
00052
00053 #include "kerneltypes.h"
00054 #include "mark3cfg.h"
00055
00056 #include "blocking.h"
00057
00058 #if KERNEL_USE_MUTEX
00059
00060 #if KERNEL_USE_TIMEOUTS
00061 #include "timerlist.h"
00062 #endif
00063
00064 //
00068 class Mutex : public BlockingObject
00069 (
00070 public:
00077
           void Init();
00078
00085
           void Claim();
00086
00087 #if KERNEL_USE_TIMEOUTS
00088
00097
           bool Claim (uint32 t u32WaitTimeMS );
00098
00111
           void WakeMe( Thread *pclOwner_ );
00112
00113 #endif
00114
00121
           void Release();
00122
00123 private:
00124
```

```
00130
          uint8_t WakeNext();
00132
00133 #if KERNEL USE TIMEOUTS
00134
00142
          bool Claim_i( uint32_t u32WaitTimeMS_ );
00144
00150
          void Claim_i(void);
00151 #endif
00152
          uint8_t m_u8Recurse;
00153
00154
          bool m_bReady;
00155
          uint8_t m_u8MaxPri;
00156
          Thread *m_pclOwner;
00157
00158 };
00159
00160 #endif //KERNEL_USE_MUTEX
00162 #endif //__MUTEX_H_
00163
```

15.81 /home/vm/mark3/trunk/embedded/kernel/public/notify.h File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "blocking.h"
```

15.81.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.h.

15.82 notify.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ========
00022 #ifndef __NOTIFY_H_
00023 #define __NOTIFY_H_
00024
00025 #include "mark3cfg.h"
00026 #include "blocking.h"
00027
00028 #if KERNEL USE NOTIFY
00029
00030 class Notify : public BlockingObject
00031 {
00032 public:
00038
          void Init (void);
00039
00049
          void Signal(void);
00050
00060
          void Wait( bool *pbFlag_ );
00061
00062 #if KERNEL_USE_TIMEOUTS
00063
00075
          bool Wait( uint32_t u32WaitTimeMS_, bool *pbFlaq_ );
00076 #endif
00077
```

15.83 /home/vm/mark3/trunk/embedded/kernel/public/paniccodes.h File Reference

Defines the reason codes thrown when a kernel panic occurs.

15.83.1 Detailed Description

Defines the reason codes thrown when a kernel panic occurs.

Definition in file paniccodes.h.

15.84 paniccodes.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00020 #ifndef ___PANIC_CODES_H
00021 #define ___PANIC_CODES_H
00022
00023 #define PANIC_ASSERT_FAILED
                                               (1)
00024 #define PANIC_LIST_UNLINK_FAILED 00025 #define PANIC_STACK_SLACK_VIOLATED
                                               (2)
00026 #define PANIC_AUTO_HEAP_EXHUSTED
00027
00028 #endif // ___PANIC_CODES_H
00029
```

15.85 /home/vm/mark3/trunk/embedded/kernel/public/profile.h File Reference

High-precision profiling timers.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

Classes

class ProfileTimer

Profiling timer.

15.85.1 Detailed Description

High-precision profiling timers.

Enables the profiling and instrumentation of performance-critical code. Multiple timers can be used simultaneously to enable system-wide performance metrics to be computed in a lightweight manner.

Usage:

```
ProfileTimer clMyTimer;
int i;

clMyTimer.Init();

// Profile the same block of code ten times
for (i = 0; i < 10; i++)
{
    clMyTimer.Start();
    ...
    //Block of code to profile
    ...
    clMyTimer.Stop();
}

// Get the average execution time of all iterations
u32AverageTimer = clMyTimer.GetAverage();

// Get the execution time from the last iteration
u32LastTimer = clMyTimer.GetCurrent();</pre>
```

Definition in file profile.h.

15.86 profile.h

```
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00053 #ifndef __PROFILE_H__
00054 #define ___PROFILE_H__
00055
00056 #include "kerneltypes.h"
00057 #include "mark3cfg.h"
00058 #include "ll.h"
00059
00060 #if KERNEL_USE_PROFILER
00061
00070 class ProfileTimer
00071 {
00072
00073 public:
08000
          void Init();
00081
00088
          void Start();
00089
00096
          void Stop();
00097
00105
          uint32_t GetAverage();
00106
00115
          uint32_t GetCurrent();
00116
00117 private:
00118
00129
          uint32_t ComputeCurrentTicks(uint16_t u16Count_, uint32_t u32Epoch_);
00130
          uint32_t m_u32Cumulative;
00131
          uint32_t m_u32CurrentIteration;
uint16_t m_u16Initial;
00132
00133
00134
          uint32_t m_u32InitialEpoch;
00135
          uint16_t m_u16Iterations;
00136
          bool m_bActive;
00137 };
00138
00139 #endif // KERNEL_USE_PROFILE
00140
00141 #endif
```

15.87 /home/vm/mark3/trunk/embedded/kernel/public/quantum.h File Reference

Thread Quantum declarations for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
```

Classes

class Quantum

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

15.87.1 Detailed Description

Thread Quantum declarations for Round-Robin Scheduling.

Definition in file quantum.h.

15.88 quantum.h

```
00001 /*----
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #ifndef __KQUANTUM_H_
00023 #define __KQUANTUM_H_
00024
00025 #include "kerneltypes.h"
00026 #include "mark3cfg.h"
00027
00028 #include "thread.h"
00029 #include "timer.h"
00030 #include "timerlist.h"
00031 #include "timerscheduler.h"
00032
00033 #if KERNEL_USE_QUANTUM
00034 class Timer;
00035
00041 class Quantum
00042 {
00043 public:
00052
         static void UpdateTimer();
00053
00060
         static void AddThread( Thread *pclThread_ );
00061
00067
         static void RemoveThread();
00068
         static void SetInTimer(void) { m bInTimer = true; }
00077
00078
         static void ClearInTimer(void) { m_bInTimer = false; }
00085
00086 private:
00098
         static void SetTimer( Thread *pclThread_ );
00099
00100
         static Timer m clOuantumTimer:
00101
         static bool m_bActive;
00102
         static bool m_bInTimer;
```

```
00103 };
00104
00105 #endif //KERNEL_USE_QUANTUM
00106
00107 #endif
```

15.89 /home/vm/mark3/trunk/embedded/kernel/public/scheduler.h File Reference

Thread scheduler function declarations.

```
#include "kerneltypes.h"
#include "thread.h"
#include "threadport.h"
```

Classes

· class Scheduler

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

Macros

• #define NUM_PRIORITIES (8)

Defines the maximum number of thread priorities supported in the scheduler.

Variables

volatile Thread * g_pclNext

Pointer to the currently-chosen next-running thread.

• Thread * g pclCurrent

Pointer to the currently-running thread.

15.89.1 Detailed Description

Thread scheduler function declarations.

This scheduler implements a very flexible type of scheduling, which has become the defacto industry standard when it comes to real-time operating systems. This scheduling mechanism is referred to as priority round- robin.

From the name, there are two concepts involved here:

1) Priority scheduling:

Threads are each assigned a priority, and the thread with the highest priority which is ready to run gets to execute.

2) Round-robin scheduling:

Where there are multiple ready threads at the highest-priority level, each thread in that group gets to share time, ensuring that progress is made.

The scheduler uses an array of ThreadList objects to provide the necessary housekeeping required to keep track of threads at the various priorities. As s result, the scheduler contains one ThreadList per priority, with an additional list to manage the storage of threads which are in the "stopped" state (either have been stopped, or have not been started yet).

Definition in file scheduler.h.

15.90 scheduler.h 205

15.90 scheduler.h

```
00003
00004
00005
00006
00007
00008
00009
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =========
00046 #ifndef __SCHEDULER_H_
00047 #define ___SCHEDULER_H_
00048
00049 #include "kerneltypes.h"
00050 #include "thread.h'
00051 #include "threadport.h"
00052
00053 extern volatile Thread *g_pclNext;
00054 extern Thread *g_pclCurrent;
00055
00056 #define NUM_PRIORITIES
                                           (8)
00057 //--
00058
00062 class Scheduler
00063 {
00064 public:
00070
          static void Init();
00071
00079
         static void Schedule();
00080
00088
         static void Add(Thread *pclThread_);
00089
00098
          static void Remove(Thread *pclThread_);
00099
00112
          static bool SetScheduler (bool bEnable );
00113
00121
          static Thread *GetCurrentThread() { return g_pclCurrent; }
00122
00131
          static volatile Thread *GetNextThread() { return g_pclNext; }
00132
          static ThreadList *GetThreadList(uint8_t u8Priority_) {    return &
00143
      m_aclPriorities[u8Priority_]; }
00144
00153
          static ThreadList *GetStopList() { return &m_clStopList; }
00154
00163
          static uint8_t IsEnabled() { return m_bEnabled; }
00164
00171
          static void QueueScheduler() { m_bQueuedSchedule = true; }
00172
00173 private:
00175
          static bool m_bEnabled;
00176
00178
          static bool m bQueuedSchedule;
00179
          static ThreadList m_clStopList;
00182
00184
          static ThreadList m_aclPriorities[NUM_PRIORITIES];
00185
00187
          static uint8_t m_u8PriFlag;
00188 };
00189 #endif
00190
```

15.91 /home/vm/mark3/trunk/embedded/kernel/public/thread.h File Reference

Platform independent thread class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
#include "scheduler.h"
#include "threadport.h"
#include "quantum.h"
#include "autoalloc.h"
```

Classes

· class Thread

Object providing fundamental multitasking support in the kernel.

struct FakeThread t

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

Typedefs

typedef void(* ThreadEntry_t)(void *pvArg_)
 Function pointer type used for thread entrypoint functions.

Enumerations

· enum ThreadState t

Enumeration representing the different states a thread can exist in.

15.91.1 Detailed Description

Platform independent thread class declarations.

Threads are an atomic unit of execution, and each instance of the thread class represents an instance of a program running of the processor. The Thread is the fundmanetal user-facing object in the kernel - it is what makes multiprocessing possible from application code.

In Mark3, threads each have their own context - consisting of a stack, and all of the registers required to multiplex a processor between multiple threads.

The Thread class inherits directly from the LinkListNode class to facilitate efficient thread management using Double, or Double-Circular linked lists.

Definition in file thread.h.

15.92 thread.h

15.92 thread.h 207

```
00035 #ifndef __THREAD_H_
00036 #define __THREAD_H_
00037
00038 #include "kerneltypes.h"
00039 #include "mark3cfg.h"
00040
00041 #include "11.h"
00042 #include "threadlist.h"
00043 #include "scheduler.h"
00044 #include "threadport.h"
00045 #include "quantum.h"
00046 #include "autoalloc.h"
00047
00048 //----
00052 typedef void (*ThreadEntry_t)(void *pvArg_);
00053
00054 //----
00058 typedef enum
00059 {
00060
          THREAD_STATE_EXIT = 0,
00061
          THREAD_STATE_READY,
00062
          THREAD_STATE_BLOCKED,
00063
          THREAD_STATE_STOP,
00064 //--
00065
          THREAD_STATES
00066 } ThreadState_t;
00067
00068 //---
00072 class Thread : public LinkListNode
00073 {
00074 public:
00090
          void Init(K_WORD *pwStack_
00091
                     uint16_t u16StackSize_,
00092
                     uint8_t u8Priority_,
00093
                     ThreadEntry_t pfEntryPoint_,
00094
                     void *pvArg_ );
00095
00096 #if KERNEL_USE_AUTO_ALLOC
00097
00115
          static Thread* Init(uint16_t u16StackSize_,
00116
                                        uint8_t u8Priority_
                                        ThreadEntry_t pfEntryPoint_,
00117
00118
                                        void *pvArg_);
00119 #endif
00120
00128
          void Start();
00129
00130
00137
          void Stop();
00138
00139 #if KERNEL_USE_THREADNAME
00140
00149
          void SetName(const char *szName_) { m_szName = szName_; }
00150
00157
          const char* GetName() { return m_szName; }
00158 #endif
00159
00168
          ThreadList *GetOwner(void) { return m_pclOwner; }
00169
00177
          ThreadList *GetCurrent(void) { return m_pclCurrent; }
00178
00187
          uint8_t GetPriority(void) { return m_u8Priority; }
00188
00196
          uint8_t GetCurPriority(void) { return m_u8CurPriority; }
00197
00198 #if KERNEL_USE_QUANTUM
00199
00206
          void SetQuantum( uint16_t u16Quantum_ ) { m_u16Quantum = u16Quantum_; }
00207
          uint16_t GetQuantum(void) { return m_u16Quantum; }
00216 #endif
00217
00225
          void SetCurrent( ThreadList *pclNewList_ ) {
     m_pclCurrent = pclNewList_; }
00226
00234
          void SetOwner( ThreadList *pclNewList_ ) { m_pclOwner = pclNewList_; }
00235
00248
          void SetPriority(uint8_t u8Priority_);
00249
00259
          void InheritPriority(uint8 t u8Priority);
00260
00261 #if KERNEL_USE_DYNAMIC_THREADS
00262
          void Exit();
00273
00274 #endif
00275
00276 #if KERNEL_USE_SLEEP
```

```
00277
00285
          static void Sleep(uint32_t u32TimeMs_);
00286
00295
          static void USleep (uint32_t u32TimeUs_);
00296 #endif
00297
00305
          static void Yield(void);
00306
00314
          void SetID( uint8_t u8ID_ ) { m_u8ThreadID = u8ID_; }
00315
          uint8_t GetID() { return m_u8ThreadID; }
00323
00324
00325
00338
          uint16_t GetStackSlack();
00339
00340 #if KERNEL_USE_EVENTFLAG
00341
00348
          uint16_t GetEventFlagMask() { return m_u16FlagMask; }
00349
00354
          void SetEventFlagMask(uint16_t u16Mask_) { m_u16FlagMask = u16Mask_; }
00355
00361
          void SetEventFlagMode(EventFlagOperation_t eMode_ ) {
      m_eFlagMode = eMode_; }
00362
00367
          EventFlagOperation_t GetEventFlagMode() { return
      m_eFlagMode; }
00368 #endif
00369
00370 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00371
00374
          Timer *GetTimer();
00375 #endif
00376 #if KERNEL_USE_TIMEOUTS
00377
00385
          void SetExpired( bool bExpired_ );
00386
00393
         bool GetExpired();
00394 #endif
00395
00396 #if KERNEL_USE_IDLE_FUNC
00397
00402
         void InitIdle();
00403 #endif
00404
          ThreadState_t GetState()
00411
                                          { return
      m_eState; }
00412
          void SetState( ThreadState_t eState_ ) { m_eState = eState_; }
00420
00421
00422
          friend class ThreadPort:
00423
00424 private:
00432
          static void ContextSwitchSWI (void);
00433
          void SetPriorityBase(uint8_t u8Priority_);
00439
00440
          K_WORD *m_pwStackTop;
00443
00445
          K_WORD *m_pwStack;
00446
00448
          uint8 t m u8ThreadID;
00449
00451
          uint8_t m_u8Priority;
00452
00454
          uint8_t m_u8CurPriority;
00455
00457
          ThreadState_t m_eState;
00458
00459 #if KERNEL_USE_THREADNAME
00460
          const char *m_szName;
00462 #endif
00463
00465
          uint16_t m_u16StackSize;
00466
00468
          ThreadList *m pclCurrent;
00469
00471
          ThreadList *m_pclOwner;
00472
00474
          ThreadEntry_t m_pfEntryPoint;
00475
00477
          void *m pvArg;
00478
00479 #if KERNEL_USE_QUANTUM
00480
          uint16_t m_u16Quantum;
00482 #endif
00483
00484 #if KERNEL_USE_EVENTFLAG
```

```
00485
         uint16_t m_u16FlagMask;
00487
00489
         EventFlagOperation_t m_eFlagMode;
00490 #endif
00491
00492 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00493
          Timer m_clTimer;
00495 #endif
00496 #if KERNEL_USE_TIMEOUTS
00497
         bool
                 m_bExpired;
00499 #endif
00500
00501 };
00502
00503 #if KERNEL_USE_IDLE_FUNC
00504 //--
00516 typedef struct
00517 {
00518
          LinkListNode *next;
00519
         LinkListNode *prev;
00520
00522
         K_WORD *m_pwStackTop;
00523
00525
         K WORD *m pwStack;
00526
         uint8_t m_u8ThreadID;
00529
00531
         uint8_t m_u8Priority;
00532
00534
         uint8_t m_u8CurPriority;
00535
          ThreadState_t m_eState;
00538
00539 #if KERNEL_USE_THREADNAME
00540
         const char *m_szName;
00542 #endif
00543
00544 } FakeThread_t;
00545 #endif
00546
00547 #endif
```

15.93 /home/vm/mark3/trunk/embedded/kernel/public/threadlist.h File Reference

Thread linked-list declarations.

```
#include "kerneltypes.h"
#include "ll.h"
```

Classes

· class ThreadList

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

15.93.1 Detailed Description

Thread linked-list declarations.

Definition in file threadlist.h.

15.94 threadlist.h



```
00009 -- [Mark3 Realtime Platform] -----
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #ifndef __THREADLIST_H_
00023 #define __THREADLIST_H_
00024
00025 #include "kerneltypes.h" 00026 #include "11.h"
00027
00028 class Thread;
00029
00034 class ThreadList : public CircularLinkList
00035 {
00036 public:
          ThreadList() { m_u8Priority = 0; m_pu8Flag = NULL; }
00042
00051
          void SetPriority(uint8_t u8Priority_);
00052
00061
          void SetFlagPointer(uint8_t *pu8Flag_);
00062
00070
          void Add(LinkListNode *node_);
00071
00083
          void Add(LinkListNode *node_, uint8_t *pu8Flag_, uint8_t u8Priority_);
00084
00093
          void AddPriority(LinkListNode *node_);
00094
00102
          void Remove(LinkListNode *node );
00103
00111
          Thread *HighestWaiter();
00112 private:
00113
00115
          uint8_t m_u8Priority;
00116
00118
          uint8_t *m_pu8Flag;
00119 };
00120
00121 #endif
00122
```

15.95 /home/vm/mark3/trunk/embedded/kernel/public/timer.h File Reference

Timer object declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

Classes

· class Timer

Timer - an event-driven execution context based on a specified time interval.

Macros

• #define TIMERLIST_FLAG_ONE_SHOT (0x01)

Timer is one-shot.

• #define TIMERLIST_FLAG_ACTIVE (0x02)

Timer is currently active.

#define TIMERLIST_FLAG_CALLBACK (0x04)

Timer is pending a callback.

• #define TIMERLIST_FLAG_EXPIRED (0x08)

Timer is actually expired.

#define MAX_TIMER_TICKS (0x7FFFFFFF)

15.96 timer.h 211

Maximum value to set.

• #define MIN_TICKS (3)

The minimum tick value to set.

Typedefs

typedef void(* TimerCallback_t)(Thread *pclOwner_, void *pvData_)
 This type defines the callback function type for timer events.

15.95.1 Detailed Description

Timer object declarations.

Definition in file timer.h.

15.95.2 Macro Definition Documentation

15.95.2.1 #define TIMERLIST_FLAG_EXPIRED (0x08)

Timer is actually expired.

Definition at line 36 of file timer.h.

15.95.3 Typedef Documentation

15.95.3.1 typedef void(* TimerCallback_t)(Thread *pclOwner_, void *pvData_)

This type defines the callback function type for timer events.

Since these are called from an interrupt context, they do not operate from within a thread or object context directly – as a result, the context must be manually passed into the calls.

pclOwner_ is a pointer to the thread that owns the timer pvData_ is a pointer to some data or object that needs to know about the timer's expiry from within the timer interrupt context.

Definition at line 91 of file timer.h.

15.96 timer.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00021 #ifndef __TIMER_H_
00022 #define ___TIMER_H_
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #include "11.h"
00028
00029 #if KERNEL_USE_TIMERS
00030 class Thread;
00031
```

```
00033 #define TIMERLIST_FLAG_ONE_SHOT (0x01)
00034 #define TIMERLIST_FLAG_ACTIVE
                                                (0x02)
00035 #define TIMERLIST_FLAG_CALLBACK
                                                (0 \times 0.4)
00036 #define TIMERLIST_FLAG_EXPIRED
                                                (0x08)
00037
00039 #define MAX_TIMER_TICKS
                                                (0x7FFFFFFF)
00040
00041 //----
00042 #if KERNEL_TIMERS_TICKLESS
00043
00044 //-
00045 /*
00046
          Ugly macros to support a wide resolution of delays.
          Given a 16-bit timer @ 16MHz & 256 cycle prescaler, this gives u16...

Max time, SECONDS_TO_TICKS: 68719s

Max time, MSECONDS_TO_TICKS: 6871.9s

Max time, useCONDS_TO_TICKS: 6.8719s
00047
00048
00049
00050
00051
00052
          ...With a 16us tick resolution.
00053
00054
          Depending on the system frequency and timer resolution, you may want to
00055
          customize these values to suit your system more appropriately.
00056 */
00057 //---
00058 #define SECONDS_TO_TICKS(x)
                                                ((((uint32_t)x) * TIMER_FREQ))
                                                ((((((uint32_t)x) * (TIMER_FREQ/100)) + 5) / 10))
((((((uint32_t)x) * TIMER_FREQ) + 50000) / 1000000))
00059 #define MSECONDS_TO_TICKS(x)
00060 #define useCONDS_TO_TICKS(x)
00061
00062 //--
00063 #define MIN_TICKS
00064 //--
00065
00066 #else
00067
00068 //-
00069 // add time because we don't know how far in an epoch we are when a call is made.
                                      (((uint32_t)(x) * 1000) + 1)
00070 #define SECONDS_TO_TICKS(x)
00071 #define MSECONDS_TO_TICKS(x)
                                                 ((uint32_t)(x + 1))
00072 #define useCONDS_TO_TICKS(x)
                                                (((uint32_t)(x + 999)) / 1000)
00073
00074 //--
00075 #define MIN_TICKS
                                                (1)
00076 //--
00077
00078 #endif // KERNEL_TIMERS_TICKLESS
00079
00080 //----
00091 typedef void (*TimerCallback_t)(Thread *pclOwner_, void *pvData_);
00093 //----
00094 class TimerList;
00095 class TimerScheduler;
00096 class Quantum;
00102 class Timer : public LinkListNode
00103 {
00104 public:
00110
         Timer() { }
00111
          void Init() { ClearNode(); m_u32Interval = 0;
00117
      m_u32TimerTolerance = 0; m_u32TimeLeft = 0;
      m_u8Flags = 0;}
00118
00130
          void Start( bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback_t pfCallback_,
      void *pvData_ );
00131
          void Start( bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_,
00145
      TimerCallback_t pfCallback_, void *pvData_ );
00153
           void Stop();
00154
00164
          void SetFlags (uint8_t u8Flags_) { m_u8Flags = u8Flags_; }
00165
          void SetCallback( TimerCallback_t pfCallback_) {
00173
      m_pfCallback = pfCallback_; }
00174
00182
          void SetData( void *pvData_ ) { m_pvData = pvData_; }
00183
          void SetOwner( Thread *pclOwner ) { m pclOwner = pclOwner; }
00192
00193
00201
          void SetIntervalTicks(uint32_t u32Ticks_);
00202
00210
          void SetIntervalSeconds(uint32_t u32Seconds_);
00211
          uint32_t GetInterval() { return m_u32Interval; }
00218
```

```
00226
          void SetIntervalMSeconds(uint32_t u32MSeconds_);
00227
00235
          void SetIntervalUSeconds(uint32_t u32USeconds_);
00236
00245
          void SetTolerance(uint32_t u32Ticks_);
00246
00247 private:
00248
00249
          friend class TimerList;
00250
00252
         uint8_t m_u8Flags;
00253
          TimerCallback_t m_pfCallback;
00256
00258
         uint32_t m_u32Interval;
00259
         uint32_t m_u32TimeLeft;
00261
00262
00264
         uint32_t m_u32TimerTolerance;
00265
          Thread *m_pclOwner;
00268
00270
          void
                *m_pvData;
00271 };
00272
00273 #endif // KERNEL_USE_TIMERS
00274
00275 #endif
```

15.97 /home/vm/mark3/trunk/embedded/kernel/public/timerlist.h File Reference

Timer list declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timer.h"
```

Classes

class TimerList

TimerList class - a doubly-linked-list of timer objects.

15.97.1 Detailed Description

Timer list declarations.

These classes implements a linked list of timer objects attached to the global kernel timer scheduler.

Definition in file timerlist.h.

15.98 timerlist.h

```
00027 #include "kerneltypes.h"
00028 #include "mark3cfg.h"
00029
00030 #include "timer.h"
00031 #if KERNEL_USE_TIMERS
00032
00037 class TimerList : public DoubleLinkList
00038 {
00039 public:
00046
         void Init();
00047
00055
         void Add(Timer *pclListNode_);
00056
00064
         void Remove(Timer *pclListNode_);
00065
00072
         void Process();
00073
00074 private:
00076
         uint32_t m_u32NextWakeup;
00077
00079
         bool m_bTimerActive;
00080 };
00081
00082 #endif // KERNEL_USE_TIMERS
00084 #endif
```

15.99 /home/vm/mark3/trunk/embedded/kernel/public/timerscheduler.h File Reference

Timer scheduler declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "timer.h"
#include "timerlist.h"
```

Classes

· class TimerScheduler

"Static" Class used to interface a global TimerList with the rest of the kernel.

15.99.1 Detailed Description

Timer scheduler declarations.

Definition in file timerscheduler.h.

15.100 timerscheduler.h

```
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #include "11.h"
00028 #include "timer.h"
00029 #include "timerlist.h"
00031 #if KERNEL_USE_TIMERS
00032
00033 //----
00038 class TimerScheduler
00039 {
00040 public:
         static void Init() { m_clTimerList.Init(); }
00048
00057
         static void Add(Timer *pclListNode_)
00058
             {m_clTimerList.Add(pclListNode_); }
00059
00068
         static void Remove(Timer *pclListNode_)
00069
            {m_clTimerList.Remove(pclListNode_);
00070
00079
         static void Process() {m_clTimerList.Process();}
00080 private:
00081
00083
          static TimerList m_clTimerList;
00084 };
00085
00086 #endif //KERNEL_USE_TIMERS
00087
00088 #endif //__TIMERSCHEDULER_H_
00089
```

15.101 /home/vm/mark3/trunk/embedded/kernel/public/tracebuffer.h File Reference

Kernel trace buffer class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

15.101.1 Detailed Description

Kernel trace buffer class declaration.

Global kernel trace-buffer. used to instrument the kernel with lightweight encoded print statements. If something goes wrong, the tracebuffer can be examined for debugging purposes. Also, subsets of kernel trace information can be extracted and analyzed to provide information about runtime performance, thread-scheduling, and other nifty things in real-time.

Definition in file tracebuffer.h.

15.102 tracebuffer.h

```
00001 /*==
00002
00003
00004
00005
                 1 11
00006 |
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00024 #ifndef __TRACEBUFFER_H_
00025 #define __TRACEBUFFER_H_
00026
00027 #include "kerneltypes.h"
00028 #include "mark3cfg.h"
00029
```

```
00030 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00032 #define TRACE_BUFFER_SIZE
00033
00034 typedef void (*TraceBufferCallback_t)(uint16_t *pu16Source_, uint16_t u16Len_, bool bPingPong_);
00035
00039 class TraceBuffer
00040 {
00041 public:
         static void Init();
00047
00048
00053
         static uint16 t Increment (void)
00054
                 { return m_u16SyncNumber++; }
00055
00064
         static void Write( uint16_t *pu16Data_, uint16_t u16Size_ );
00065
         static void SetCallback( TraceBufferCallback_t pfCallback_)
00074
00075
             { m_pfCallback = pfCallback_; }
00076 private:
00077
         static TraceBufferCallback_t m_pfCallback;
00078
         static uint16_t m_u16SyncNumber;
00079
          static uint16_t m_u16Index;
08000
         static uint16_t m_au16Buffer[ (TRACE_BUFFER_SIZE / sizeof( uint16_t )) ];
00081 };
00082
00083 #endif //KERNEL_USE_DEBUG
00084
00085 #endif
```

15.103 /home/vm/mark3/trunk/embedded/kernel/quantum.cpp File Reference

Thread Quantum Implementation for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernelaware.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Functions

static void QuantumCallback (Thread *pclThread_, void *pvData_)
 QuantumCallback.

15.103.1 Detailed Description

Thread Quantum Implementation for Round-Robin Scheduling.

Definition in file quantum.cpp.

15.103.2 Function Documentation

```
15.103.2.1 static void QuantumCallback ( Thread * pclThread_, void * pvData_ ) [static]
```

QuantumCallback.

This is the timer callback that is invoked whenever a thread has exhausted its current execution quantum and a new thread must be chosen from within the same priority level.

15.104 quantum.cpp 217

Parameters

pclThread_	Pointer to the thread currently executing
pvData_	Unused in this context.

Definition at line 62 of file quantum.cpp.

15.104 quantum.cpp

```
00001 /*=====
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00026 #include "timerlist.h"
00027 #include "quantum.h"
00028 #include "kernelaware.h"
00029
00030 #define _CAN_HAS_DEBUG
00031 //--[Autogenerated - Do Not Modify]-----
00032 #include "dbg_file_list.h"
00033 #include "buffalogger.h"
00034 #if defined(DBG_FILE)
00035 # error "Debug logging file token already defined! Bailing."
00036 #else
00037 # define DBG_FILE _DBG___KERNEL_QUANTUM_CPP
00038 #endif
00039 //--[End Autogenerated content]------
00040 #include "kerneldebug.h'
00041
00042 #if KERNEL_USE_QUANTUM
00043
00044 //----
00045 static volatile bool bAddQuantumTimer; // Indicates that a timer add is pending
00046
00047 //----
00048 Timer Quantum::m_clQuantumTimer; // The global timernodelist_t object
00049 bool Quantum::m_bActive;
00050 bool Quantum::m_bInTimer;
00051 //--
00062 static void QuantumCallback(Thread *pclThread_, void *pvData_)
00063 {
00064
          // Validate thread pointer, check that source/destination match (it's
         // in its real priority list). Also check that this thread was part of // the highest-running priority level.
00065
00066
          if (pclThread_->GetPriority() >= Scheduler::GetCurrentThread()->
00067
     GetPriority())
00068
       {
              if (pclThread_->GetCurrent()->GetHead() != pclThread_->
00069
     GetCurrent()->GetTail() )
00070
             {
00071
                  bAddQuantumTimer = true;
00072
                  pclThread_->GetCurrent()->PivotForward();
00073
              }
00074
          }
00075 }
00076
00077 //--
00078 void Quantum::SetTimer(Thread *pclThread_)
00079 {
08000
          m_clQuantumTimer.SetIntervalMSeconds(pclThread_->
     GetQuantum());
00081
          m_clQuantumTimer.SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00082
          m_clQuantumTimer.SetData(NULL);
00083
          m_clQuantumTimer.SetCallback((TimerCallback_t)
     QuantumCallback);
00084
          m_clQuantumTimer.SetOwner(pclThread_);
00085 }
00086
00087 //-
```

```
00088 void Quantum::AddThread(Thread *pclThread_)
          if (m_bActive
00090
00091 #if KERNEL_USE_IDLE_FUNC
                 || (pclThread_ == Kernel::GetIdleThread())
00092
00093 #endif
00095
         {
00096
             return;
00097
         }
00098
         // If this is called from the timer callback, queue a timer add...
00099
00100
          if (m bInTimer)
00101
00102
              bAddQuantumTimer = true;
00103
00104
00105
00106
         // If this isn't the only thread in the list.
         if ( pclThread_->GetCurrent() ->GetHead()
00108
                pclThread_->GetCurrent()->GetTail() )
00109
00110
             Quantum::SetTimer(pclThread_);
00111
             TimerScheduler::Add(&m_clQuantumTimer);
00112
             m_bActive = 1;
00113
00114 }
00115
00116 //---
00117 void Ouantum::RemoveThread(void)
00118 {
00119
          if (!m bActive)
00120
00121
             return;
00122
00123
00124
         // Cancel the current timer
         TimerScheduler::Remove(&m_clQuantumTimer);
00126
         m_bActive = 0;
00127 }
00128
00129 //---
00130 void Quantum::UpdateTimer(void)
00131 {
00132
          // If we have to re-add the quantum timer (more than 2 threads at the
00133
         // high-priority level...)
00134
         if (bAddQuantumTimer)
00135
              // Trigger a thread yield - this will also re-schedule the
00136
00137
              // thread *and* reset the round-robin scheduler.
00138
              Thread::Yield();
00139
              bAddQuantumTimer = false;
00140
         }
00141 }
00142
00143 #endif //KERNEL_USE_QUANTUM
```

15.105 /home/vm/mark3/trunk/embedded/kernel/scheduler.cpp File Reference

Strict-Priority + Round-Robin thread scheduler implementation.

```
#include "kerneltypes.h"
#include "ll.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "kernel.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Variables

volatile Thread * g_pclNext

15.106 scheduler.cpp 219

Pointer to the currently-chosen next-running thread.

Thread * g_pclCurrent

Pointer to the currently-running thread.

This implements a 4-bit "Count-leading-zeros" operation using a RAM-based lookup table.

15.105.1 Detailed Description

Strict-Priority + Round-Robin thread scheduler implementation.

Definition in file scheduler.cpp.

15.105.2 Variable Documentation

This implements a 4-bit "Count-leading-zeros" operation using a RAM-based lookup table.

It is used to efficiently perform a CLZ operation under the assumption that a native CLZ instruction is unavailable. This table is further optimized to provide a 0xFF result in the event that the index value is itself zero, allowing u16 to quickly identify whether or not subsequent 4-bit LUT operations are required to complete the scheduling process.

Definition at line 61 of file scheduler.cpp.

15.106 scheduler.cpp

```
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =
00022 #include "kerneltypes.h"
00023 #include "11.h"
00024 #include "scheduler.h'
00025 #include "thread.h"
00026 #include "threadport.h"
00027 #include "kernel.h"
00028
00029 #define _CAN_HAS_DEBUG
00030 //--[Autogenerated - Do Not Modify]-----
00031 #include "dbg_file_list.h"
00032 #include "buffalogger.h"
00033 #if defined(DBG_FILE)
00034 # error "Debug logging file token already defined! Bailing."
00035 #else
00036 # define DBG_FILE _DBG___KERNEL_SCHEDULER_CPP
00037 #endif
00038 //--[End Autogenerated content]-----
00039
00040 #include "kerneldebug.h"
00041 volatile Thread *g_pclNext;
00042 Thread *g_pclCurrent;
00043
00044 //---
00045 bool Scheduler::m_bEnabled;
00046 bool Scheduler::m_bQueuedSchedule;
00047
00048 ThreadList Scheduler::m_clStopList;
00049 ThreadList Scheduler::m_aclPriorities[
      NUM PRIORITIES];
00050 uint8_t Scheduler::m_u8PriFlag;
00051
00052 /
```

```
00061 static const uint8_t aucCLZ[16] ={255,0,1,1,2,2,2,2,3,3,3,3,3,3,3,3,3};
00062
00063 //----
00064 void Scheduler::Init()
00065 {
00066
          m_u8PriFlag = 0;
          for (int i = 0; i < NUM_PRIORITIES; i++)</pre>
00068
00069
               m_aclPriorities[i].SetPriority(i);
00070
              m_aclPriorities[i].SetFlagPointer(&
     m_u8PriFlag);
00071
         }
00072
          m_bQueuedSchedule = false;
00073 }
00074
00075 //---
00076 void Scheduler::Schedule()
00077 {
          uint8_t u8Pri = 0;
00079
00080
           // Figure out what priority level has ready tasks (8 priorities max)
00081
          // To do this, we apply our current active-thread bitmap (m\_u8PriFlag)
          // and perform a \mathtt{CLZ} on the upper four bits. If no tasks are found
00082
          // in the higher priority bits, search the lower priority bits. This // also assumes that we always have the idle thread ready-to-run in
00083
00084
00085
          // priority level zero.
00086
          u8Pri = aucCLZ[m_u8PriFlag >> 4 ];
00087
          if (u8Pri == 0xFF)
00088
          {
00089
              u8Pri = aucCLZ[m u8PriFlag & 0x0F];
00090
          }
00091
          else
00092
          {
00093
              u8Pri += 4;
00094
          }
00095
00096 #if KERNEL_USE_IDLE_FUNC
          if (u8Pri == 0xFF)
00098
          {
00099
               // There aren't any active threads at all - set g_pclNext to IDLE
00100
               g_pclNext = Kernel::GetIdleThread();
00101
          }
00102
          else
00103 #endif
00104
         {
00105
               \ensuremath{//} Get the thread node at this priority.
00106
              g_pclNext = (Thread*) ( m_aclPriorities[u8Pri].GetHead() );
00107
          KERNEL_TRACE_1( "Next Thread: %d\n", (uint16_t)((Thread*)g_pclNext)->GetID() );
00108
00109
00110 }
00111
00112 //--
00113 void Scheduler::Add(Thread *pclThread_)
00114 {
00115
          m aclPriorities[pclThread ->GetPriority()].Add(pclThread);
00116 }
00117
00118 //--
00119 void Scheduler::Remove(Thread *pclThread_)
00120 {
00121
          m_aclPriorities[pclThread_->GetPriority()].Remove(pclThread_);
00122 }
00123
00124 //--
00125 bool Scheduler::SetScheduler(bool bEnable_)
00126 {
          bool bRet :
00127
00128
          CS_ENTER();
00129
          bRet = m_bEnabled;
00130
          m_bEnabled = bEnable_;
00131
          // If there was a queued scheduler evevent, dequeue and trigger an
          // immediate Yield
00132
00133
          if (m_bEnabled && m_bQueuedSchedule)
00134
          {
00135
              m_bQueuedSchedule = false;
00136
              Thread::Yield();
00137
          CS EXIT();
00138
00139
          return bRet;
00140 }
```

15.107 /home/vm/mark3/trunk/embedded/kernel/thread.cpp File Reference

Platform-Independent thread class Definition.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "scheduler.h"
#include "kernelswi.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "quantum.h"
#include "kernel.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Functions

static void ThreadSleepCallback (Thread *pclOwner_, void *pvData_)
 This callback is used to wake up a thread once the interval has expired.

15.107.1 Detailed Description

Platform-Independent thread class Definition.

Definition in file thread.cpp.

15.108 thread.cpp

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00026 #include "scheduler.h"
00027 #include "kernelswi.h"
00028 #include "timerlist.h"
00029 #include "ksemaphore.h"
00030 #include "quantum.h"
00031 #include "kernel.h"
00032
00033 #define _CAN_HAS_DEBUG
00034 //--[Autogenerated - Do Not Modify]------
00035 #include "dbg_file_list.h"
00036 #include "buffalogger.h"
00037 #if defined (DBG FILE)
00038 # error "Debug logging file token already defined! Bailing."
00039 #else
00040 # define DBG_FILE _DBG___KERNEL_THREAD_CPP
00041 #endif
00042 //--[End Autogenerated content]-----
00043
00044 #include "kerneldebug.h"
00045 //-
```

```
00046 void Thread::Init( K_WORD *pwStack_,
00047
                        uint16_t u16StackSize_,
00048
                         uint8_t u8Priority_,
                         ThreadEntry_t pfEntryPoint_,
00049
00050
                         void *pvArg_ )
00051 {
00052
           static uint8_t u8ThreadID = 0;
00053
00054
           KERNEL_ASSERT( pwStack_ );
00055
           KERNEL_ASSERT( pfEntryPoint_ );
00056
00057
           ClearNode();
00058
00059
           m_u8ThreadID = u8ThreadID++;
00060
           KERNEL_TRACE_1( "Stack Size: %d", u16StackSize_ );
KERNEL_TRACE_1( "Thread Pri: %d", (uint8_t)u8Priority_ );
KERNEL_TRACE_1( "Thread Id: %d", (uint16_t)m_u8ThreadID );
KERNEL_TRACE_1( "Entrypoint: %x", (uint16_t)pfEntryPoint_ );
00061
00062
00063
00064
00065
           // Initialize the thread parameters to their initial values.
00066
00067
           m_pwStack = pwStack_;
           m_pwStackTop = TOP_OF_STACK(pwStack_, u16StackSize_);
00068
00069
00070
           m_u16StackSize = u16StackSize_;
00071
00072 #if KERNEL_USE_QUANTUM
00073
         m_u16Quantum = THREAD_QUANTUM_DEFAULT;
00074 #endif
00075
           m_u8Priority = u8Priority_ ;
00076
          m_u8CurPriority = m_u8Priority;
m_pfEntryPoint = pfEntryPoint_;
00077
00078
          m_pvArg = pvArg_;
m_eState = THREAD_STATE_STOP;
00079
00080
00081
00082 #if KERNEL_USE_THREADNAME
         m_szName = NULL;
00084 #endif
00085 #if KERNEL_USE_TIMERS
00086
          m_clTimer.Init();
00087 #endif
00088
00089
           // Call CPU-specific stack initialization
00090
           ThreadPort::InitStack(this);
00091
00092
           // Add to the global "stop" list.
00093
           CS_ENTER();
           m_pclOwner = Scheduler::GetThreadList(
00094
      m_u8Priority);
00095
          m_pclCurrent = Scheduler::GetStopList();
00096
           m_pclCurrent->Add(this);
00097
           CS_EXIT();
00098 }
00099
00100 #if KERNEL USE AUTO ALLOC
00102 Thread* Thread::Init(uint16_t u16StackSize_,
00103
                                       uint8_t u8Priority_,
00104
                                       ThreadEntry_t pfEntryPoint_,
00105
                                       void *pvArg_)
00106 {
00107
           Thread *pclNew
                               = (Thread*)AutoAlloc::Allocate(sizeof(Thread));
00108
           K_WORD *pwStack = (K_WORD*)AutoAlloc::Allocate(u16StackSize_);
00109
           pclNew->Init(pwStack, u16StackSize_, u8Priority_, pfEntryPoint_, pvArg_ );
00110
           return pclNew;
00111 }
00112 #endif
00113
00114 //--
00115 void Thread::Start(void)
00116 {
00117
            // Remove the thread from the scheduler's "stopped" list, and add it
           // Kennove the thread from the scheduler's scheduler's ready list at the proper priority.

KERNEL_TRACE_1( "Starting Thread %d", (uint16_t)m_u8ThreadID );
00118
00119
00120
00121
           CS_ENTER();
00122
           Scheduler::GetStopList()->Remove(this);
00123
           Scheduler::Add(this);
           m_pclOwner = Scheduler::GetThreadList(
00124
      m_u8Priority);
00125
          m_pclCurrent = m_pclOwner;
00126
           m_eState = THREAD_STATE_READY;
00127
00128 #if KERNEL_USE_QUANTUM
          if (GetCurPriority() >= Scheduler::GetCurrentThread()->
00129
      GetCurPriority())
```

15.108 thread.cpp 223

```
00130
          {
00131
              // Deal with the thread Quantum
00132
              Quantum::RemoveThread();
              Quantum::AddThread(this);
00133
00134
00135 #endif
00136
00137
          if (Kernel::IsStarted())
00138
              if (GetCurPriority() >= Scheduler::GetCurrentThread()->
00139
     GetCurPriority())
00140
           {
00141
                  Thread::Yield();
00142
00143
00144
          CS_EXIT();
00145 }
00146
00147 //-
00148 void Thread::Stop()
00149 {
00150
          bool bReschedule = 0;
00151
00152
          CS ENTER():
00153
00154
          // If a thread is attempting to stop itself, ensure we call the scheduler
00155
          if (this == Scheduler::GetCurrentThread())
00156
00157
              bReschedule = true;
00158
          }
00159
00160
          // Add this thread to the stop-list (removing it from active scheduling)
00161
          // Remove the thread from scheduling
00162
          if (m_eState == THREAD_STATE_READY)
00163
00164
              Scheduler::Remove(this);
00165
          else if (m_eState == THREAD_STATE_BLOCKED)
00166
00167
          {
00168
              m_pclCurrent->Remove(this);
00169
00170
00171
          m_pclOwner = Scheduler::GetStopList();
00172
          m_pclCurrent = m_pclOwner;
00173
          m_pclOwner->Add(this);
00174
          m_eState = THREAD_STATE_STOP;
00175
00176 #if KERNEL_USE_TIMERS
          // Just to be safe - attempt to remove the thread's timer // from the timer-scheduler (does no harm if it isn't
00177
00178
          // in the timer-list)
00179
00180
          TimerScheduler::Remove(&m_clTimer);
00181 #endif
00182
          CS_EXIT();
00183
00184
00185
          if (bReschedule)
00186
          {
00187
              Thread::Yield();
00188
00189 }
00190
00191 #if KERNEL_USE_DYNAMIC_THREADS
00192 //-
00193 void Thread::Exit()
00194 {
00195
          bool bReschedule = 0;
00196
00197
          KERNEL_TRACE_1( "Exit Thread %d", m_u8ThreadID );
00198
00199
          CS_ENTER();
00200
00201
          // If this thread is the actively-running thread, make sure we run the
00202
          // scheduler again.
00203
          if (this == Scheduler::GetCurrentThread())
00204
              bReschedule = 1;
00205
00206
00207
00208
          // Remove the thread from scheduling
00209
          if (m_eState == THREAD_STATE_READY)
00210
00211
              Scheduler::Remove(this);
00212
00213
          else if (m_eState == THREAD_STATE_BLOCKED)
00214
00215
              m pclCurrent->Remove(this);
```

```
00216
00217
00218
          m_pclCurrent = 0;
00219
          m_pclOwner = 0;
          m_eState = THREAD_STATE EXIT:
00220
00221
00222
          // We've removed the thread from scheduling, but interrupts might
00223
          // trigger checks against this thread's currently priority before
00224
          \ensuremath{//} we get around to scheduling new threads. As a result, set the
          \ensuremath{//} priority to idle to ensure that we always wind up scheduling \ensuremath{//} new threads.
00225
00226
          m_u8CurPriority = 0;
00227
00228
          m_u8Priority = 0;
00229
00230 #if KERNEL_USE_TIMERS
         // Just to be safe - attempt to remove the thread's timer
// from the timer-scheduler (does no harm if it isn't
00231
00232
          // in the timer-list)
00233
00234
          TimerScheduler::Remove(&m_clTimer);
00235 #endif
00236
00237
          CS_EXIT();
00238
00239
          if (bReschedule)
00240
          {
               // Choose a new "next" thread if we must
00241
00242
              Thread::Yield();
00243
          }
00244 }
00245 #endif
00246
00247 #if KERNEL_USE_SLEEP
00248 //--
00250 static void ThreadSleepCallback( Thread *pclOwner_, void *pvData_ )
00251 {
00252
          Semaphore *pclSemaphore = static_cast<Semaphore*>(pvData_);
00253
          // Post the semaphore, which will wake the sleeping thread.
00254
          pclSemaphore->Post();
00255 }
00256
00257 //---
00258 void Thread::Sleep(uint32_t u32TimeMs_)
00259 {
00260
          Semaphore clSemaphore;
00261
          Timer *pclTimer = g_pclCurrent->GetTimer();
00262
00263
          // Create a semaphore that this thread will block on
00264
          clSemaphore.Init(0, 1);
00265
00266
          // Create a one-shot timer that will call a callback that posts the
00267
          // semaphore, waking our thread.
00268
          pclTimer->Init();
00269
          pclTimer->SetIntervalMSeconds(u32TimeMs_);
00270
          pclTimer->SetCallback(ThreadSleepCallback);
00271
          pclTimer->SetData((void*)&clSemaphore);
00272
          pclTimer->SetFlags(TIMERLIST FLAG ONE SHOT);
00273
          // Add the new timer to the timer scheduler, and block the thread
00274
00275
          TimerScheduler::Add(pclTimer);
00276
          clSemaphore.Pend();
00277 }
00278
00279 //-
00280 void Thread::USleep(uint32_t u32TimeUs_)
00281 {
00282
          Semaphore clSemaphore;
          Timer *pclTimer = g_pclCurrent->GetTimer();
00283
00284
00285
          // Create a semaphore that this thread will block on
00286
          clSemaphore.Init(0, 1);
00287
00288
          // Create a one-shot timer that will call a callback that posts the
00289
          \ensuremath{//} semaphore, waking our thread.
          pclTimer->Init();
00290
00291
          pclTimer->SetIntervalUSeconds(u32TimeUs_);
00292
          pclTimer->SetCallback(ThreadSleepCallback);
00293
          pclTimer->SetData((void*)&clSemaphore);
00294
          pclTimer->SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00295
00296
          // Add the new timer to the timer scheduler, and block the thread
          TimerScheduler::Add(pclTimer);
00297
00298
          clSemaphore.Pend();
00299 }
00300 #endif // KERNEL_USE_SLEEP
00301
00302 //----
00303 uint16_t Thread::GetStackSlack()
```

15.108 thread.cpp 225

```
00304 {
00305
          uint16_t u16Count = 0;
00306
00307
          CS ENTER();
00308
00310
          for (u16Count = 0; u16Count < m_u16StackSize; u16Count++)</pre>
00311
00312
               if (m_pwStack[u16Count] != 0xFF)
00313
00314
                   break;
              }
00315
00316
          }
00317
00318
          CS_EXIT();
00319
00320
          return u16Count;
00321 }
00322
00323 //--
00324 void Thread::Yield()
00325 {
00326
          CS_ENTER();
00327
          // Run the scheduler
          if (Scheduler::IsEnabled())
00328
00329
          {
00330
               Scheduler::Schedule();
00331
00332
               // Only switch contexts if the new task is different than the old task
               if (Scheduler::GetCurrentThread() !=
00333
      Scheduler::GetNextThread())
00334
00335 #if KERNEL_USE_QUANTUM
                  // new thread scheduled. Stop current quantum timer (if it exists),
// and restart it for the new thread (if required).
00336
00337
00338
                   Quantum::RemoveThread();
00339
                   Quantum::AddThread((Thread*)q_pclNext);
00340 #endif
00341
                   Thread::ContextSwitchSWI();
00342
              }
00343
          }
00344
          else
00345
          {
00346
              Scheduler::OueueScheduler():
00347
00348
00349
          CS_EXIT();
00350 }
00351
00352 //---
00353 void Thread::SetPriorityBase(uint8_t u8Priority_)
00354 {
00355
            GetCurrent() ->Remove(this);
00356
00357
           SetCurrent (Scheduler::GetThreadList(
      m_u8Priority));
00358
00359
            GetCurrent()->Add(this);
00360 }
00361
00362 //---
00363 void Thread::SetPriority(uint8_t u8Priority_)
00364 {
00365
          bool bSchedule = 0;
00366
00367
          CS_ENTER();
00368
          // If this is the currently running thread, it's a good idea to reschedule
          /// Or, if the new priority is a higher priority than the current thread's.
if ((g_pclCurrent == this) || (u8Priority_ > g_pclCurrent->
00369
00370
      GetPriority()))
00371
          {
00372
              bSchedule = 1;
00373
00374
          Scheduler::Remove(this);
00375
          CS_EXIT();
00376
00377
          m_u8CurPriority = u8Priority_;
00378
          m_u8Priority = u8Priority_;
00379
00380
          CS_ENTER();
          Scheduler::Add(this);
00381
00382
          CS EXIT();
00383
00384
           if (bSchedule)
00385
00386
               if (Scheduler::IsEnabled())
00387
               {
00388
                   CS_ENTER();
```

```
Scheduler::Schedule();
00390
         #if KERNEL_USE_QUANTUM
         // new thread scheduled. Stop current quantum timer (if it exists),
00391
                 // and restart it for the new thread (if required).
00392
00393
                  Quantum::RemoveThread();
00394
                  Quantum::AddThread((Thread*)g_pclNext);
00395
       #endif
00396
00397
                  Thread::ContextSwitchSWI();
00398
00399
             else
            {
00400
00401
                  Scheduler::QueueScheduler();
00402
00403
         }
00404 }
00405
00406 //--
00407 void Thread::InheritPriority(uint8_t u8Priority_)
00408 {
00409
          SetOwner(Scheduler::GetThreadList(u8Priority_));
00410
         m_u8CurPriority = u8Priority_;
00411 }
00412
00413 //-
00414 void Thread::ContextSwitchSWI()
00415 {
00416
          // Call the context switch interrupt if the scheduler is enabled.
00417
         if (Scheduler::IsEnabled() == 1)
00418
        {
             KERNEL_TRACE_1( "Context switch to Thread %d", (uint16_t)((
00419
     Thread*)g_pclNext)->GetID() );
00420
            KernelSWI::Trigger();
00421
00422 }
00423
00424 #if KERNEL USE TIMEOUTS
00426 Timer *Thread::GetTimer()
m_clTimer; }
00427
00428 //---
00429 void Thread::SetExpired( bool bExpired_)
                                                  { m_bExpired = bExpired_; }
00432 bool Thread::GetExpired()
                                                   { return
     m_bExpired; }
00433 #endif
00434
00435 #if KERNEL_USE_IDLE_FUNC
00437 void Thread::InitIdle( void )
00438 {
00439
         ClearNode();
00440
00441
00442
       m_u8Priority = 0;
m_u8CurPriority = 0;
00443
         m_pfEntryPoint = 0;
       m_pvArg = 0;
m_u8ThreadID = 255;
00444
00445
         m eState = THREAD STATE READY:
00446
00447 #if KERNEL_USE_THREADNAME
00448
         m_szName = "IDLE";
00449 #endif
00450 }
00451 #endif
```

15.109 /home/vm/mark3/trunk/embedded/kernel/threadlist.cpp File Reference

Thread linked-list definitions.

```
#include "kerneltypes.h"
#include "ll.h"
#include "threadlist.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.110 threadlist.cpp 227

15.109.1 Detailed Description

Thread linked-list definitions.

Definition in file threadlist.cpp.

15.110 threadlist.cpp

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -----
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #include "11.h"
00024 #include "threadlist.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]------
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h'
00031 #if defined(DBG_FILE)
00032 # error "Debug logging file token already defined! Bailing."
00033 #else
00034 # define DBG_FILE _DBG___KERNEL_THREADLIST_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037 #include "kerneldebug.h"
00038
00039 //--
00040 void ThreadList::SetPriority(uint8_t u8Priority_)
00041 {
00042
          m_u8Priority = u8Priority_;
00043 }
00044
00045 //-
00046 void ThreadList::SetFlagPointer( uint8_t *pu8Flag_)
00047 {
00048
          m_pu8Flag = pu8Flag_;
00049 }
00050
00051 //---
00052 void ThreadList::Add(LinkListNode *node_) {
00053
          CircularLinkList::Add(node_);
00054
          CircularLinkList::PivotForward();
00055
00056
          // We've specified a bitmap for this threadlist
00057
          if (m_pu8Flag)
00058
          {
00059
               // Set the flag for this priority level
00060
               *m_pu8Flag \mid = (1 << m_u8Priority);
00061
          }
00062 }
00063
00064 //---
00065 void ThreadList::AddPriority(LinkListNode *node_) {
00066
          Thread *pclCurr = static_cast<Thread*>(GetHead());
          if (!pclCurr) {
00067
00068
               Add (node );
00069
               return;
00070
00071
          uint8_t u8HeadPri = pclCurr->GetCurPriority();
00072
00073
          Thread *pclTail = static_cast<Thread*>(GetTail());
Thread *pclNode = static_cast<Thread*>(node_);
00074
00075
00076
           // Set the threadlist's priority level, flag pointer, and then add the
00077
           // thread to the threadlist
00078
          uint8_t u8Priority = pclNode->GetCurPriority();
00079
00080
00081
               if (u8Priority > pclCurr->GetCurPriority())
00082
```

```
break;
00084
              pclCurr = static_cast<Thread*>(pclCurr->GetNext());
00085
00086
          } while (pclCurr != pclTail);
00087
00088
          // Insert pclNode before pclCurr in the linked list.
          InsertNodeBefore(pclNode, pclCurr);
00090
00091
          // If the priority is greater than current head, reset
00092
          // the head pointer.
          if (u8Priority > u8HeadPri) {
   m_pstHead = pclNode;
00093
00094
              m_pstTail = m_pstHead->prev;
00095
00096
00097
          else if (pclNode->GetNext() == m_pstHead)
00098
              m_pstTail = pclNode;
00099
00100
00101 }
00102
00103 //---
00104 void ThreadList::Add(LinkListNode *node_, uint8_t *pu8Flag_, uint8_t u8Priority_
00105
          \ensuremath{//} Set the threadlist's priority level, flag pointer, and then add the
00106
          // thread to the threadlist
          SetPriority(u8Priority_);
00108
          SetFlagPointer(pu8Flag_);
00109
          Add (node_);
00110 }
00111
00112 //---
00113 void ThreadList::Remove(LinkListNode *node_) {
00114
       // Remove the thread from the list
00115
          CircularLinkList::Remove(node_);
00116
         // If the list is empty...
00117
00118
          if (!m_pstHead)
00119
00120
              // Clear the bit in the bitmap at this priority level
00121
              if (m_pu8Flag)
00122
              {
                  *m_pu8Flag &= ~(1 << m_u8Priority);
00123
00124
00125
          }
00126 }
00127
00128 //---
00129 Thread *ThreadList::HighestWaiter()
00130 {
00131
          return static cast<Thread*>(GetHead());
00132 }
```

15.111 /home/vm/mark3/trunk/embedded/kernel/timer.cpp File Reference

Timer implementations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.111.1 Detailed Description

Timer implementations.

15.112 timer.cpp 229

Definition in file timer.cpp.

15.112 timer.cpp

```
00001 /*----
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] --
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00025 #include "timer.h"
00026 #include "timerlist.h"
00027 #include "timerscheduler.h"
00028 #include "kerneltimer.h"
00029 #include "threadport.h"
00030 #include "quantum.h"
00031
00032 #define _CAN_HAS_DEBUG
00033 //--[Autogenerated - Do Not Modify]------
00034 #include "dbg_file_list.h"
00035 #include "buffalogger.h"
00036 #if defined(DBG_FILE)
00037 # error "Debug logging file token already defined! Bailing."
00038 #else
00039 # define DBG_FILE _DBG___KERNEL_TIMER_CPP
00040 #endif
00041 //--[End Autogenerated content]-----
00042
00043 #include "kerneldebug.h"
00044
00045 #if KERNEL_USE_TIMERS
00046
00047 //---
00048 void Timer::Start (bool bRepeat_, uint32_t u32IntervalMs_,
      TimerCallback_t pfCallback_, void *pvData_ )
00049 {
00050
          SetIntervalMSeconds(u32IntervalMs_);
         m_u32TimerTolerance = 0;
m_pfCallback = pfCallback_;
00051
00052
00053
         m_pvData = pvData_;
00054
         if (!bRepeat )
00055
00056
             m_u8Flags = TIMERLIST_FLAG_ONE_SHOT;
00057
         }
00058
         else
00059
         {
00060
             m_u8Flags = 0;
00061
00062
         m_pclOwner = Scheduler::GetCurrentThread();
00063
         TimerScheduler::Add(this);
00064 }
00065
00066 //
00067 void Timer::Start( bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_,
     TimerCallback_t pfCallback_, void *pvData_ )
00068 {
00069
         m_u32TimerTolerance = MSECONDS_TO_TICKS(u32ToleranceMs_);
00070
         Start(bRepeat_, u32IntervalMs_, pfCallback_, pvData_);
00071 }
00072
00073 //--
00074 void Timer::Stop()
00075 {
00076
         TimerScheduler::Remove(this);
00077 }
00079 //-
00080 void Timer::SetIntervalTicks( uint32_t u32Ticks_ )
00081 {
00082
         m u32Interval = u32Ticks ;
00083 }
00084
00085 //--
```

```
00088 void Timer::SetIntervalSeconds( uint32_t u32Seconds_)
00089 {
          m_u32Interval = SECONDS_TO_TICKS(u32Seconds_);
00090
00091 }
00092
00093 //--
00094 void Timer::SetIntervalMSeconds( uint32_t u32MSeconds_)
00095 {
00096
          m_u32Interval = MSECONDS_TO_TICKS(u32MSeconds_);
00097 }
00098
00099 //--
00100 void Timer::SetIntervalUSeconds( uint32_t u32USeconds_)
00101 {
00102
          m_u32Interval = useCONDS_TO_TICKS(u32USeconds_);
00103 }
00104
00105 //--
00106 void Timer::SetTolerance(uint32_t u32Ticks_)
00107 {
00108
          m_u32TimerTolerance = u32Ticks_;
00109 }
00110
00111 #endif
```

15.113 /home/vm/mark3/trunk/embedded/kernel/timerlist.cpp File Reference

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timerlist.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.113.1 Detailed Description

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

Definition in file timerlist.cpp.

15.114 timerlist.cpp

```
00001 /
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 =======
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025
00026 #include "timerlist.h"
00027 #include "kerneltimer.h"
00028 #include "threadport.h"
00029 #include "quantum.h"
00030
```

15.114 timerlist.cpp 231

```
00031 #define _CAN_HAS_DEBUG
00032 //--[Autogenerated - Do Not Modify]-----
00033 #include "dbg_file_list.h"
00034 #include "buffalogger.h"
00035 #if defined(DBG FILE)
00036 # error "Debug logging file token already defined! Bailing."
00037 #else
00038 # define DBG_FILE _DBG___KERNEL_TIMERLIST_CPP
00039 #endif
00040 //--[End Autogenerated content]------
00041
00042 #include "kerneldebug.h"
00043
00044 #if KERNEL_USE_TIMERS
00045 //---
00046 TimerList TimerScheduler::m_clTimerList;
00047
00048 //-
00049 void TimerList::Init(void)
00050 {
00051
         m_bTimerActive = 0;
00052
         m_u32NextWakeup = 0;
00053 }
00054
00055 //-
00056 void TimerList::Add(Timer *pclListNode_)
00057 {
00058 #if KERNEL_TIMERS_TICKLESS
       bool bStart = 0;
00059
00060
         int32_t lDelta;
00061 #endif
00062
00063
         CS_ENTER();
00064
00065 #if KERNEL_TIMERS_TICKLESS
00066
         if (GetHead() == NULL)
00067
             bStart = 1;
00069
00070 #endif
00071
         pclListNode_->ClearNode();
00072
00073
         DoubleLinkList::Add(pclListNode);
00074
00075
         // Set the initial timer value
00076
         pclListNode_->m_u32TimeLeft = pclListNode_->m_u32Interval;
00077
00078 #if KERNEL_TIMERS_TICKLESS
00079
       if (!bStart)
08000
         {
00081
              // If the new interval is less than the amount of time remaining...
             1Delta = KernelTimer::TimeToExpiry() - pclListNode_->
00082
     m_u32Interval;
00083
00084
             if (lDelta > 0)
00085
             {
00086
                 // Set the new expiry time on the timer.
00087
                 m_u32NextWakeup = KernelTimer::SubtractExpiry((
     uint32_t)1Delta);
00088
00089
         }
00090
         else
00091
         {
00092
             m_u32NextWakeup = pclListNode_->m_u32Interval;
00093
             KernelTimer::SetExpiry(m_u32NextWakeup);
00094
             KernelTimer::Start();
00095
00096 #endif
00097
00098
         // Set the timer as active.
00099
         pclListNode_->m_u8Flags |= TIMERLIST_FLAG_ACTIVE;
00100
         CS EXIT();
00101 }
00102
00103 //--
00104 void TimerList::Remove(Timer *pclLinkListNode_)
00105 {
00106
         CS_ENTER();
00107
00108
         DoubleLinkList::Remove(pclLinkListNode);
00109
00110 #if KERNEL_TIMERS_TICKLESS
00111
         if (this->GetHead() == NULL)
00112
00113
             KernelTimer::Stop();
00114
00115 #endif
```

```
00117
          CS_EXIT();
00118 }
00119
00120 //---
00121 void TimerList::Process(void)
00122 {
00123 #if KERNEL_TIMERS_TICKLESS
00124
        uint32_t u32NewExpiry;
00125
          uint32 t u320vertime;
00126
          bool bContinue:
00127 #endif
00128
00129
          Timer *pclNode;
00130
          Timer *pclPrev;
00131
00132 #if KERNEL_USE_QUANTUM
         Quantum::SetInTimer();
00133
00134 #endif
00135 #if KERNEL_TIMERS_TICKLESS
00136
           // Clear the timer and its expiry time - keep it running though
00137
          KernelTimer::ClearExpiry();
00138
          do
00139
00140 #endif
               pclNode = static_cast<Timer*>(GetHead());
00141
               pclPrev = NULL;
00142
00143
00144 #if KERNEL_TIMERS_TICKLESS
00145
               bContinue = 0;
               u32NewExpiry = MAX_TIMER_TICKS;
00146
00147 #endif
00148
00149
               \ensuremath{//} Subtract the elapsed time interval from each active timer.
00150
               while (pclNode)
00151
               {
                    // Active timers only...
00152
                    if (pclNode->m_u8Flags & TIMERLIST_FLAG_ACTIVE)
00153
00154
                   {
00155
                        // Did the timer expire?
00156 #if KERNEL_TIMERS_TICKLESS
00157
                        if (pclNode->m_u32TimeLeft <= m_u32NextWakeup)</pre>
00158 #else
00159
                        pclNode->m_u32TimeLeft--;
                        if (0 == pclNode->m_u32TimeLeft)
00160
00161 #endif
00162
                            // Yes - set the "callback" flag - we'll execute the callbacks later pclNode->m_u8Flags \mid = TIMERLIST_FLAG_CALLBACK;
00163
00164
00165
00166
                             if (pclNode->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT)
00167
00168
                                 \ensuremath{//} If this was a one-shot timer, deactivate the timer.
                                 pclNode->m_u8Flags |= TIMERLIST_FLAG_EXPIRED;
pclNode->m_u8Flags &= ~TIMERLIST_FLAG_ACTIVE;
00169
00170
00171
                             }
00172
00173
00174
                                 // Reset the interval timer.
                                 // I think we're good though...
00176
                                 pclNode->m_u32TimeLeft = pclNode->
00177
      m_u32Interval;
00178
00179 #if KERNEL_TIMERS_TICKLESS
00180
                                 // If the time remaining (plus the length of the tolerance interval)
                                 // is less than the next expiry interval, set the next expiry interval.
uint32_t u32Tmp = pclNode->m_u32TimeLeft + pclNode->
00181
00182
      m_u32TimerTolerance;
00183
00184
                                 if (u32Tmp < u32NewExpiry)</pre>
00185
00186
                                     u32NewExpiry = u32Tmp;
00187
00188 #endif
00189
00190
00191 #if KERNEL_TIMERS_TICKLESS
00192
                        else
00193
                             // Not expiring, but determine how int32_t to run the next timer interval for.
00194
00195
                            pclNode->m_u32TimeLeft -= m_u32NextWakeup;
                             if (pclNode->m_u32TimeLeft < u32NewExpiry)</pre>
00196
00197
00198
                                 u32NewExpiry = pclNode->m_u32TimeLeft;
00199
                        }
00200
```

```
00201 #endif
00202
00203
                 pclNode = static_cast<Timer*>(pclNode->GetNext());
00204
00205
             // Process the expired timers callbacks.
00206
             pclNode = static_cast<Timer*>(GetHead());
00208
              while (pclNode)
00209
00210
                  pclPrev = NULL;
00211
00212
                  // If the timer expired, run the callbacks now.
00213
                  if (pclNode->m_u8Flags & TIMERLIST_FLAG_CALLBACK)
00214
00215
                      // Run the callback. these callbacks must be very fast...
00216
                     pclNode->m_pfCallback( pclNode->m_pclOwner, pclNode->
     m_pvData );
00217
                     pclNode->m u8Flags &= ~TIMERLIST FLAG CALLBACK;
00218
00219
                      // If this was a one-shot timer, let's remove it.
00220
                      if (pclNode->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT)
00221
00222
                          pclPrev = pclNode;
00223
00224
                 pclNode = static_cast<Timer*>(pclNode->GetNext());
00226
00227
                  // Remove one-shot-timers
00228
                  if (pclPrev)
00229
00230
                      Remove (pclPrev);
00231
                  }
00232
00233
00234 #if KERNEL_TIMERS_TICKLESS
       // Check to see how much time has elapsed since the time we
00235
              // acknowledged the interrupt...
00236
             u32Overtime = KernelTimer::GetOvertime();
00238
00239
            if( u320vertime >= u32NewExpiry ) {
00240
                  m_u32NextWakeup = u32Overtime;
00241
                 bContinue = 1;
00242
00243
00244
          // If it's taken longer to go through this loop than would take u16 to
00245
         // the next expiry, re-run the timing loop
00246
00247
         } while (bContinue);
00248
         // This timer elapsed, but there's nothing more to do...
00249
00250
         // Turn the timer off.
00251
         if (u32NewExpiry >= MAX_TIMER_TICKS)
00252
         {
00253
              KernelTimer::Stop();
00254
00255
         else
00257
              // Update the timer with the new "Next Wakeup" value, plus whatever
00258
             // overtime has accumulated since the last time we called this handler
00259
00260
             m_u32NextWakeup = KernelTimer::SetExpiry(u32NewExpiry +
m_u32
u32Overtime);
00261 }
00262 #endif
00263 #if KERNEL_USE_QUANTUM
00264
        Quantum::ClearInTimer();
00265 #endif
00266 }
00267
00269 #endif //KERNEL_USE_TIMERS
```

15.115 /home/vm/mark3/trunk/embedded/kernel/tracebuffer.cpp File Reference

Kernel trace buffer class definition.

```
#include "kerneltypes.h"
#include "tracebuffer.h"
#include "mark3cfg.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

15.115.1 Detailed Description

Kernel trace buffer class definition.

Definition in file tracebuffer.cpp.

15.116 tracebuffer.cpp

```
00001 /*========
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012-2015 Funkenstein Software Consulting, all rights reserved.
00012 See license.txt for more information
00013 ===========
00019 #include "kerneltypes.h"
00020 #include "tracebuffer.h"
00021 #include "mark3cfg.h"
00022
00023 #define _CAN_HAS_DEBUG
00024 //--[Autogenerated - Do Not Modify]------
00025 #include "dbg_file_list.h"
00026 #include "buffalogger.h"
00027 #if defined(DBG_FILE)
00028 # error "Debug logging file token already defined! Bailing."
00029 #else
00030 # define DBG_FILE _DBG____KERNEL_TRACEBUFFER_CPP
00031 #endif
00032
00033 #include "kerneldebug.h"
00034
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL USE DEBUG && !KERNEL AWARE SIMULATION
00038 //--
00039 TraceBufferCallback_t TraceBuffer::m_pfCallback;
00040 uint16_t TraceBuffer::m_u16Index;
00041 uint16_t TraceBuffer::m_u16SyncNumber;
00042 uint16_t TraceBuffer::m_aul6Buffer[ (TRACE_BUFFER_SIZE/sizeof(uint16_t)) ];
00043
00044 //----
00045 void TraceBuffer::Init()
00046 {
00047
          m_u16Index = 0;
00048
          m_u16SyncNumber = 0;
00049
          m_pfCallback = 0;
00050 }
00051
00052 //-
00053 void TraceBuffer::Write( uint16_t *pu16Data_, uint16_t u16Size_ )
00054 {
00055
          // Pipe the data directly to the circular buffer
00056
          uint16_t u16Start;
00057
00058
          // Update the circular buffer index in a critical section. The
00059
          // rest of the operations can take place in any context.
00060
          CS_ENTER();
          uint16_t u16NextIndex;
00061
00062
          u16Start = m_u16Index;
00063
          u16NextIndex = m_u16Index + u16Size_;
00064
          if (u16NextIndex >= (sizeof(m_au16Buffer) / sizeof(uint16_t)) )
00065
```

```
00066
               u16NextIndex -= (sizeof(m_au16Buffer) / sizeof(uint16_t));
00067
           m_u16Index = u16NextIndex;
00068
00069
          CS_EXIT();
00070
00071
           // Write the data into the circular buffer.
00072
          uint16_t i;
00073
           bool bCallback = false;
          bool bPingPong = false;
for (i = 0; i < u16Size_; i++)</pre>
00074
00075
00076
               m_au16Buffer[u16Start++] = pu16Data_[i];
if (u16Start >= (sizeof(m_au16Buffer) / sizeof(uint16_t)) )
00077
00078
00079
08000
                    u16Start = 0;
00081
                   bCallback = true;
00082
00083
               else if (ul6Start == ((sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2))
00084
                   bPingPong = true;
bCallback = true;
00085
00086
00087
               }
00088
          }
00089
00090
          // Done writing - see if there's a 50% or rollover callback
00091
          if (bCallback && m_pfCallback) {
00092
               uint16_t u16Size = (sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2;
00093
               if (bPingPong) {
               m_pfCallback(m_aul6Buffer, ul6Size, bPingPong);
} else {
00094
00095
                   m_pfCallback(m_au16Buffer + u16Size, u16Size, bPingPong);
00096
00097
00098
00099 }
00100
00101 #endif
00102
```

Index

Add	kernelaware.h, 176
Scheduler, 90	KA COMMAND PROFILE REPORT
,	kernelaware.h, 176
Claim	KA COMMAND PROFILE START
Mutex, 83	kernelaware.h, 176
Close	KA COMMAND PROFILE STOP
Driver, 53	kernelaware.h, 176
Control	KA_COMMAND_TRACE_0
Driver, 53	kernelaware.h, 176
Driver FO	KA_COMMAND_TRACE_1
Driver, 52	kernelaware.h, 176
Close, 53	KA_COMMAND_TRACE_2
Control, 53	kernelaware.h, 176
Init, 55 Open, 55	Kernel, 63
Read, 55	Init, 64
Write, 56	Panic, 64
write, 50	Start, 65
EVENT FLAG ALL	kernelaware.h
kerneltypes.h, 182	KA_COMMAND_EXIT_SIMULATOR, 176
EVENT FLAG ALL CLEAR	KA_COMMAND_IDLE, 176
kerneltypes.h, 182	KA_COMMAND_PRINT, 176
EVENT_FLAG_ANY	KA_COMMAND_PROFILE_INIT, 176
kerneltypes.h, 182	KA_COMMAND_PROFILE_REPORT, 176
EVENT_FLAG_ANY_CLEAR	KA_COMMAND_PROFILE_START, 176
kerneltypes.h, 182	KA_COMMAND_PROFILE_STOP, 176
EVENT_FLAG_MODES	KA_COMMAND_TRACE_0, 176
kerneltypes.h, 182	KA_COMMAND_TRACE_1, 176
EVENT_FLAG_PENDING_UNBLOCK	KA_COMMAND_TRACE_2, 176
kerneltypes.h, 182	kerneltypes.h
Exit	EVENT_FLAG_ALL, 182
Thread, 98	EVENT_FLAG_ALL_CLEAR, 182
1.9	EVENT_FLAG_ANY, 182
Init	EVENT_FLAG_ANY_CLEAR, 182
Driver, 55	EVENT_FLAG_MODES, 182
Kernel, 64	EVENT_FLAG_PENDING_UNBLOCK, 182
Message, 79	Message, 78
Mutex, 83 Profiler, 85	Init, 79
Scheduler, 91	Mutex, 82
Semaphore, 94	Claim, 83
Thread, 101	Init, 83
Timer, 111	Release, 83
KA_COMMAND_EXIT_SIMULATOR	Open
kernelaware.h, 176	Driver, 55
KA_COMMAND_IDLE	
kernelaware.h, 176	Panic
KA_COMMAND_PRINT	Kernel, 64
kernelaware.h, 176	Pend
KA_COMMAND_PROFILE_INIT	Semaphore, 94

Post Yield Semaphore, 95 Thread, 104 Process Profiler, 85 Profiler, 84 Init, 85 Process, 85 Read, 85 Start, 85 Stop, 85 Quantum, 88 Read Driver, 55 Profiler, 85 Release Mutex, 83 Remove Scheduler, 92 Schedule Scheduler, 92 Scheduler, 89 Add, 90 Init, 91 Remove, 92 Schedule, 92 Semaphore, 93 Init, 94 Pend, 94 Post, 95 Sleep Thread, 103 Start Kernel, 65 Profiler, 85 Thread, 103 Timer, 113 Stop Profiler, 85 Thread, 103 Timer, 113 Thread, 95 Exit, 98 Init, 101 Sleep, 103 Start, 103 Stop, 103 Yield, 104 Timer, 109 Init, 111 Start, 113 Stop, 113 Timer, 110 Write

Driver, 56