Lab 4. Arithmetic and Logical Instructions

Goals

After this laboratory exercise, you should know how to use arithmetic, logical and shift instructions. In addition, you should also understand overflow in arithmetic operation and how to detect it.

References

- RISC-V documents, textbook.
- The RISC-V Instruction Set Manual: <u>risev-spec-20191213.pdf</u>

Preparation

Assignments at Home and at Lab

Home Assignment 1

The arithmatic was introduced in Laboratory Exercises 02, this assignment describes a special situation when adding two integers – the overflow.

Support: The sum of two 32-bit integers may not be representable in 32 bits. In this case, we say that an overflow has occurred. Overflow is possible only with operands of the same sign.

For two nonnegative (negative) operands, if the sum obtained is less (greater) than eitheir operand, overflow has occurred

The following program dectects overflow based on this rule. Two operands are stored in register s1 and s2, the sum is stored in register s3. If overflow occur, t0 register is set to 1 and clear to 0 in otherwise.

```
# Laboratory Exercise 4, Home Assignment 1
  # TODO: Initialize s1 and s2 in different cases
  # Algorithm for determing orverflow condition
  li
       t0, 0 # No overflow is default status
  add s3, s1, s2  # s3 = s1 + s2
xor t1, s1, s2  # Test if s1 and s2 have the same sign
  blt t1, zero, EXIT # If not, exit
  slt
        t2, s3, s1
        s1, zero, NEGATIVE # Test if s1 and s2 is negative?
  beg t2, zero, EXIT # s1 and s2 are positive
  # if s3 > s1 then the result is not overflow
        OVERFLOW
NEGATIVE:
  bne t2, zero, EXIT # s1 and s2 are negative
  # if s3 < s1 then the result is not overflow
```

```
OVERFLOW:
li t0, 1 # The result is overflow
EXIT:
```

Home Assignment 2

The basic logical operation includes and, or, xor, not.

These instructions operates with bits of source operands and write the result to destination operand.

					Source registers						
				s1	0100 0110	1010 0001	1111 0001	1011 0111			
				s2	1111 1111	1111 1111	0000 0000	0000 0000			
Assembly code				Result							
As	semb	ly co	de			Res	sult				
	semb			s3	0100 0110	81,300	0000 0000	0000 0000			
		s1,	s2	s3	0100 0110	81,300		0000 0000			

There are versions of immediate format of **and**, **or**, **xor** using with a source register and a 12-bit immediate value.

Some useful ways with logical operations:

- i. and is used to extract some bits from a register or value
- ii. and is used to clear some bits of a register or value
- iii. **or** is used to set some bits for a register.

The following program demonstrates how to use logical instructions to extract information from one register. We can extract one bit or more according to the mask we use. Read this example carefully and explain each lines of:

```
# Laboratory Exercise 4, Home Assignment 2
.text
    li    s0, 0x12345678 # Test value
    andi    t0, s0, 0xff  # Extract LSB of s0
    andi    t1, s0, 0x0400 # Extract bit 10 of s0
```

Home Assignment 3

The next logical instructions in this assignment are shift instructions including sll (shift left logical), srl (shift right logical), and sra (shift right arithmetic).

				Source register					
			s5	1111 1111	0001 1100	0001 0000	1110 0111		
Assembly code				Result					
slli t0,	s5,	7	t0	1000 1110	0000 1000	0111 0011	1000 0000		
srli s1,	s5,	17	s1	0000 0000	0000 0000	0111 1111	1000 1110		
srai t2,	s5,	3	t2	1111 1111	1110 0011	1000 0010	0001 1100		

RISC-V supports the immediate format of the shift instructions (slli, srli, and srai), with 5-bit constant.

Note that, shifting left (right) n-bit is equivalent to multiply (divide) by 2ⁿ.

This example show how the shift operations used to implement other instructions, such as multiply by a small power of 2

Assignment 1

Create a new project to implement the Home Assignment 1. Compile and upload to simulator. Initialize two operands (register s1 and s2), run this program step by step, observe memory and registers value.

Assignment 2

Write a program to do the following tasks:

- Extract MSB of s0
- Clear LSB of s0
- Set LSB of s0 (bits 7 to 0 are set to 1)
- Clear s0 (s0=0, must use logical instructions)

MSB: Most Significant Byte LSB: Least Significant Byte

$$s0 = 0 \times \frac{1}{\sqrt{2}} \times 3 \times 4 \times 5 \times 6 \times \frac{7}{\sqrt{8}}$$

$$MSB \qquad LSB$$

Assignment 3

Pseudo instructions in RISC-V are not-directly-run-on-RISC-V-processor instructions which need to be converted to real-instructions of RISC-V. Re-write the following pseudo instructions using real-instructions understood by RISC-V processors:

a. abs
$$s0$$
, $s1$
 $s0 = abs($s1)$

Assignment 4

To dectect overflow in additional operation, we also use other rule than the one in Assignment 1. This rule is: when add two operands that have the same sign, overflow will occur if the sum doesn't have the same sign with either operands. You need to use this rule to write another overflow detection program.

Assignment 5

Write a program that implement multiply by a small power of 2. (2, 4, 8, 16, etc for example).

Conclusions

What is benefit of using shift instructions for implementing multiplication comparing with multiply instructions (RV32M: RISC-V 32-bit Multiplier/Divider)?