1. Description

1.1. Project

Project Name	IUS
Board Name	NUCLEO-F429ZI
Generated with:	STM32CubeMX 4.27.0
Date	12/09/2018


1.2. MCU

MCU Series	STM32F4
MCU Line	STM32F429/439
MCU name	STM32F429ZITx
MCU Package	LQFP144
MCU Pin number	144

1.3. Caution

The report was generated although the configuration was in a modified state. It may be not accurate

2. Pinout Configuration




3. Pins Configuration

Pin Number	Pin Name	Pin Type	Alternate	Label
LQFP144	(function after		Function(s)	
	reset)		(1)	
6	VBAT	Power		
7	PC13	I/O	GPIO_EXTI13	USER_Btn [B1]
8	PC14/OSC32_IN	I/O	RCC_OSC32_IN	
9	PC15/OSC32_OUT	I/O	RCC_OSC32_OUT	
16	VSS	Power		
17	VDD	Power		
23	PH0/OSC_IN	I/O	RCC_OSC_IN	MCO [STM32F103CBT6_PA8]
24	PH1/OSC_OUT	I/O	RCC_OSC_OUT	
25	NRST	Reset		
27	PC1	I/O	ETH_MDC	
30	VDD	Power		
31	VSSA	Power		
32	VREF+	Power		
33	VDDA	Power		
35	PA1	I/O	ETH_REF_CLK	
36	PA2	I/O	ETH_MDIO	
38	VSS	Power		
39	VDD	Power		
43	PA7	I/O	ETH_CRS_DV	
44	PC4	I/O	ETH_RXD0	
45	PC5	I/O	ETH_RXD1	
51	VSS	Power		
52	VDD	Power		
61	VSS	Power		
62	VDD	Power		
70	PB11	I/O	ETH_TX_EN	
71	VCAP_1	Power		
72	VDD	Power		
73	PB12	I/O	ETH_TXD0	
74	PB13	I/O	ETH_TXD1	
75	PB14 *	I/O	GPIO_Output	LD3 [Red]
83	VSS	Power		
84	VDD	Power		
91	PG6 *	I/O	GPIO_Output	USB_PowerSwitchOn [STMPS2151STR_EN]

Pin Number LQFP144	Pin Name (function after reset)	Pin Type	Alternate Function(s)	Label
92	PG7 *	I/O	GPIO_Input	USB_OverCurrent [STMPS2151STR_FAULT]
94	VSS	Power		
95	VDD	Power		
105	PA13	I/O	SYS_JTMS-SWDIO	TMS
106	VCAP_2	Power		
107	VSS	Power		
108	VDD	Power		
109	PA14	I/O	SYS_JTCK-SWCLK	TCK
120	VSS	Power		
121	VDD	Power		
130	VSS	Power		
131	VDD	Power		
137	PB7 *	I/O	GPIO_Output	LD2 [Blue]
138	воото	Boot		
143	PDR_ON	Reset		
144	VDD	Power		

^{*} The pin is affected with an I/O function

4. Clock Tree Configuration



Page 5

5. *IPs and Middleware Configuration* **5.1.** *ETH*

Mode: RMII

5.1.1. Parameter Settings:

Advanced : Ethernet Media Configuration:

Auto Negotiation Enabled

General: Ethernet Configuration:

Ethernet MAC Address 12:80:E1:00:13:77 *

PHY Address 1

Ethernet Basic Configuration:

Rx Mode Polling Mode
TX IP Header Checksum Computation By hardware

5.1.2. Advanced Parameters:

External PHY Configuration:

PHY LAN8742A_PHY_ADDRESS

PHY Address Value 1

PHY Reset delay these values are based on a 1 ms

Systick interrupt

0x00000FF *

PHY Configuration delay

PHY Read TimeOut

Ox0000FFF *

PHY Write TimeOut

Ox0000FFF *

Common: External PHY Configuration:

Transceiver Basic Control Register 0x00 * Transceiver Basic Status Register 0x01 * **PHY Reset** 0x8000 * Select loop-back mode 0x4000 * Set the full-duplex mode at 100 Mb/s 0x2100 * Set the half-duplex mode at 100 Mb/s 0x2000 * Set the full-duplex mode at 10 Mb/s 0x0100 * Set the half-duplex mode at 10 Mb/s 0x0000 * Enable auto-negotiation function 0x1000 * Restart auto-negotiation function 0x0200 * Select the power down mode 0x0800 * Isolate PHY from MII 0x0400 *

Extended: External PHY Configuration:

PHY special control/status register Offset

Ox10 *

PHY Speed mask

Ox0002 *

PHY Duplex mask

Ox0004 *

PHY Interrupt Source Flag register Offset

Ox000B *

PHY Link down inturrupt

Ox000B *

5.2. RCC

High Speed Clock (HSE): BYPASS Clock Source Low Speed Clock (LSE): Crystal/Ceramic Resonator

5.2.1. Parameter Settings:

System Parameters:

VDD voltage (V) 3.3
Instruction Cache Enabled
Prefetch Buffer Enabled
Data Cache Enabled

Flash Latency(WS) 5 WS (6 CPU cycle)

RCC Parameters:

HSI Calibration Value 16

TIM Prescaler Selection Disabled

HSE Startup Timout Value (ms) 100

LSE Startup Timout Value (ms) 5000

Power Parameters:

Power Regulator Voltage Scale Power Regulator Voltage Scale 1

Power Over Drive Disabled

5.3. SYS

Debug: Serial Wire

Timebase Source: SysTick

5.4. LWIP

mode: Enabled

Advanced parameters are not listed except if modified by user.

5.4.1. General Settings:

LwIP Version:

LwIP Version (Version of LwIP supported by CubeMX ** CubeMX specific **) 2.0.3

IPv4 - DHCP Options:

LWIP_DHCP (DHCP Module) Enabled

RTOS Dependency:

WITH_RTOS (Use FREERTOS ** CubeMX specific **)

Disabled

Protocols Options:

 LWIP_ICMP (ICMP Module Activation)
 Enabled

 LWIP_IGMP (IGMP Module)
 Disabled

 LWIP_DNS (DNS Module)
 Enabled *

 LWIP_UDP (UDP Module)
 Enabled

 MEMP_NUM_UDP_PCB (Number of UDP Connections)
 4

 LWIP_TCP (TCP Module)
 Enabled

MEMP_NUM_TCP_PCB (Number of TCP Connections) 5

5.4.2. Key Options:

Infrastructure - OS Awarness Option:

NO_SYS (OS Awarness)

OS Not Used

Infrastructure - Timers Options:

LWIP_TIMERS (Use Support For sys_timeout) Enabled

Infrastructure - Core Locking and MPU Options:

SYS_LIGHTWEIGHT_PROT (Memory Functions Protection)

Disabled

Infrastructure - Heap and Memory Pools Options:

MEMP_NUM_LOCALHOSTLIST (Number of Host Entries in the Local Host List)

MEM_SIZE (Heap Memory Size) 1600

Infrastructure - Internal Memory Pool Sizes: MEMP_NUM_PBUF (Number of Memory Pool struct Pbufs)

MEMP_NUM_RAW_PCB (Number of Raw Protocol Control Blocks) 4

MEMP_NUM_TCP_PCB_LISTEN (Number of Listening TCP Connections) 8

MEMP_NUM_TCP_SEG (Number of TCP Segments simultaneously queued) 16

Pbuf Options:

PBUF_POOL_SIZE (Number of Buffers in the Pbuf Pool)

16
PBUF_POOL_BUFSIZE (Size of each pbuf in the pbuf pool)

592

16

1

IPv4 - ARP Options:

LWIP_ARP (ARP Functionality) Enabled

Callback - TCP Options:

TCP_TTL (Number of Time-To-Live Used by TCP Packets)

255

TCP_WND (TCP Receive Window Maximum Size)

2144

TCP_QUEUE_OOSEQ (Allow Out-Of-Order Incoming Packets)

Enabled

TCP_MSS (Maximum Segment Size)

536

TCP_SND_BUF (TCP Sender Buffer Space)

1072

TCP_SND_QUEUELEN (Number of Packet Buffers Allowed for TCP Sender)

9

Network Interfaces Options:

LWIP_NETIF_STATUS_CALLBACK (Callback Function on Interface Status Changes)

Enabled *

LWIP_NETIF_LINK_CALLBACK (Callback Function on Interface Link Changes)

Enabled *

NETIF - Loopback Interface Options:

LWIP_NETIF_LOOPBACK (NETIF Loopback)

Enabled *

Thread Safe APIs - Socket Options:

LWIP_SOCKET (Socket API) Disabled

5.4.3. PPP:

PPP Options:

PPP_SUPPORT (PPP Module) Disabled

5.4.4. IPv6:

IPv6 Options:

LWIP_IPV6 (IPv6 Protocol) Disabled

5.4.5. HTTPD:

HTTPD Options:

LWIP_HTTPD (LwIP HTTPD Support ** CubeMX specific **) Disabled

5.4.6. SNMP:

SNMP Options:

LWIP_SNMP (LwIP SNMP Agent) Disabled

5.4.7. SNTP:

SNTP Options:

LWIP_SNTP (LWIP SNTP Support ** CubeMX specific **)

Disabled

5.4.8. MDNS/TFTP:

MDNS Options:

LWIP_MDNS (Multicast DNS Support ** CubeMX specific **)

Disabled

TFTP Options:

LWIP_TFTP (TFTP Support ** CubeMX specific **)

Disabled

5.4.9. Perf/Checks:

Sanity Checks:

LWIP_DISABLE_TCP_SANITY_CHECKS (TCP Sanity Checks)

LWIP_DISABLE_MEMP_SANITY_CHECKS (MEMP Sanity Checks)

Disabled

Disabled

Performance Options:

LWIP_PERF (Performace Testing for LwIP)

Disabled

5.4.10. Statistics:

Debug - Statistics Options:

LWIP_STATS (Statictics Collection)

Enabled *

5.4.11. Checksum:

Infrastructure - Checksum Options:

Disabled CHECKSUM_BY_HARDWARE (Hardware Checksum ** CubeMX specific **) LWIP_CHECKSUM_CTRL_PER_NETIF (Generate/Check Checksum per Netif) Disabled Disabled CHECKSUM_GEN_IP (Generate Software Checksum for Outgoing IP Packets) Disabled CHECKSUM_GEN_UDP (Generate Software Checksum for Outgoing UDP Packets) Disabled CHECKSUM_GEN_TCP (Generate Software Checksum for Outgoing TCP Packets) CHECKSUM_GEN_ICMP (Generate Software Checksum for Outgoing ICMP Packets) Disabled Disabled CHECKSUM_GEN_ICMP6 (Generate Software Checksum for Outgoing ICMP6 Packets) Disabled CHECKSUM_CHECK_IP (Generate Software Checksum for Incoming IP Packets) Disabled CHECKSUM_CHECK_UDP (Generate Software Checksum for Incoming UDP Packets) CHECKSUM_CHECK_TCP (Generate Software Checksum for Incoming TCP Packets) Disabled CHECKSUM_CHECK_ICMP (Generate Software Checksum for Incoming ICMP Packets) Disabled

Disabled

CHECKSUM_CHECK_ICMP6 (Generate Software Checksum for Incoming ICMP6 Packets)

5.4.12. Debug:

LwIP Main Debugging Options:

LWIP_DBG_MIN_LEVEL (Minimum Level)	All
NETIF_DEBUG (Debug in NETIF)	Enabled *
PBUF_DEBUG (Debug in Pbuf)	Enabled *
INET_DEBUG (Debug in INET)	Enabled *
IP_DEBUG (Debug in IP)	Enabled *
TCPIP_DEBUG (Debug in TCPIP)	Enabled *
DHCP_DEBUG (Debug in DHCP)	Enabled *
AUTOIP_DEBUG (Debug in AUTOIP)	Enabled *
DNS_DEBUG (Debug for DNS)	Enabled *

^{*} User modified value

6. System Configuration

6.1. GPIO configuration

IP	Pin	Signal	GPIO mode	GPIO pull/up pull down	Max Speed	User Label
ETH	PC1	ETH_MDC	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PA1	ETH_REF_CLK	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PA2	ETH_MDIO	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PA7	ETH_CRS_DV	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PC4	ETH_RXD0	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PC5	ETH_RXD1	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PB11	ETH_TX_EN	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PB12	ETH_TXD0	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
	PB13	ETH_TXD1	Alternate Function Push Pull	No pull-up and no pull-down	Very High	
RCC	PC14/OSC3 2_IN	RCC_OSC32_IN	n/a	n/a	n/a	
	PC15/OSC3 2_OUT	RCC_OSC32_O UT	n/a	n/a	n/a	
	PH0/OSC_I N	RCC_OSC_IN	n/a	n/a	n/a	MCO [STM32F103CBT6_PA8]
	PH1/OSC_O UT	RCC_OSC_OUT	n/a	n/a	n/a	
SYS	PA13	SYS_JTMS- SWDIO	n/a	n/a	n/a	TMS
	PA14	SYS_JTCK- SWCLK	n/a	n/a	n/a	TCK
GPIO	PC13	GPIO_EXTI13	External Interrupt Mode with Rising edge trigger detection	No pull-up and no pull-down	n/a	USER_Btn [B1]
	PB14	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	LD3 [Red]
	PG6	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	USB_PowerSwitchOn [STMPS2151STR_EN]
	PG7	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	USB_OverCurrent

IP	Pin	Signal	GPIO mode	GPIO pull/up pull	Max	User Label
				down	Speed	[STMPS2151STR_FAULT]
	PB7	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	LD2 [Blue]

6.2. DMA configuration

nothing configured in DMA service

6.3. NVIC configuration

Interrupt Table	Enable	Preenmption Priority	SubPriority
Non maskable interrupt	true	0	0
Hard fault interrupt	true	0	0
Memory management fault	true	0	0
Pre-fetch fault, memory access fault	true	0	0
Undefined instruction or illegal state	true	0	0
System service call via SWI instruction	true	0	0
Debug monitor	true	0	0
Pendable request for system service	true	0	0
System tick timer	true	0	0
Ethernet global interrupt	true	0	0
PVD interrupt through EXTI line 16		unused	
Flash global interrupt		unused	
RCC global interrupt	unused		
EXTI line[15:10] interrupts	unused		
Ethernet wake-up interrupt through EXTI line 19	9 unused		
FPU global interrupt		unused	

^{*} User modified value

7. Power Consumption Calculator report

7.1. Microcontroller Selection

Series	STM32F4
Line	STM32F429/439
MCU	STM32F429ZITx
Datasheet	024030_Rev9

7.2. Parameter Selection

Temperature	25
11/100	3.6

8. Software Project

8.1. Project Settings

Name	Value
Project Name	IUS
Project Folder	D:\STM32\IUS\IUS
Toolchain / IDE	EWARM V8
Firmware Package Name and Version	STM32Cube FW_F4 V1.21.0

8.2. Code Generation Settings

Name	Value
STM32Cube Firmware Library Package	Copy all used libraries into the project folder
Generate peripheral initialization as a pair of '.c/.h' files	No
Backup previously generated files when re-generating	No
Delete previously generated files when not re-generated	Yes
Set all free pins as analog (to optimize the power	No
consumption)	

9. Software Pack Report